

"XX" indicates one specific E2E profile.

E2E_PXXForward(Config, State, Data,
Length, ForwardStatus)

Tyhe type of CheckState is
described in [PRS_E2E_
0059 7]

