

Document Title	Specification of FlexRay Interface
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	027
Document Classification	Standard

Document Version	3.1.0
Document Status	Final
Part of Release	3.0
Revision	7

Document Change History

Date	Version	Changed by	Change Description
20.09.2010	3.1.0	AUTOSAR Administration	<ul style="list-style-type: none"> Update sequence chart 9-6 Extension of FrIf05063 (behavior in case of return value E_NOT_OK for API TriggerTransmit())
22.01.2008	3.0.1	AUTOSAR Administration	Correction of Figure 5.1
18.12.2007	3.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> Simplification of the FlexRay Interface State Machine due to the introduction of the new AUTOSAR SWS FlexRay State Manager Cluster-based APIs were removed due to the introduced AUTOSAR SWS FlexRay State Manager The FlexRay Interface does not initialize any other modules any more due to the introduction of the "flat initialization" for AUTOSAR release 3.0 Document meta information extended Small layout adaptations made
06.02.2007	2.0.1	AUTOSAR Administration	<ul style="list-style-type: none"> "Advice for users" revised Legal disclaimer added "Revision Information" added Release Notes added
30.06.2006	2.0.0	AUTOSAR Administration	Second Release
19.09.2005	1.0.0	AUTOSAR Administration	Initial Release

Disclaimer

This specification and the material contained in it, as released by AUTOSAR is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.

For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR Specification Documents may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the Specification Documents for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such Specification Documents, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

1	Introduction and Functional Overview	7
2	Information about this Document.....	9
2.1	General Hints	9
2.2	Acronyms and Abbreviations.....	10
3	Related Documentation.....	11
3.1	Input Documents	11
3.2	Related Standards and Norms	12
4	Constraints and Assumptions.....	13
4.1	Limitations	13
4.2	Applicability to Car Domains	13
5	Dependencies to Other Modules	14
5.1	AUTOSAR Operating System	14
5.2	AUTOSAR BSW Scheduler.....	14
5.3	All Upper Layer AUTOSAR BSW Modules.....	14
5.4	AUTOSAR PDU-Router	14
5.5	AUTOSAR FlexRay Network Management.....	15
5.6	AUTOSAR FlexRay Transport Protocol	15
5.7	AUTOSAR FlexRay Driver	15
5.8	AUTOSAR FlexRay Transceiver Driver.....	15
5.9	AUTOSAR Development Error Tracer.....	15
5.10	AUTOSAR Diagnostic Event Manager	15
5.11	File Structure	16
5.11.1	Code File Structure	16
5.11.2	Header File Structure	16
6	Requirements Traceability.....	19
6.1	General Requirements on Basic Software Modules	19
6.2	Requirements on FlexRay	21
6.3	Specification Items	22
7	Functional Specification.....	24
7.1	FlexRay BSW Stack	24
7.2	Indexing Scheme.....	24
7.2.1	Principle	24
7.2.2	Supported Indexed Resources.....	27
7.3	FlexRay Interface State Machine	27
7.3.1	FlexRay Interface Main Function.....	29
7.4	Implementation Requirements	31
7.5	Configuration description.....	32
7.6	Data Communication via FlexRay	33
7.6.1	PDU Packing, PDU Update-Bits, and Frame Construction Plans	33
7.6.1.1	AlwaysTransmit	35
7.6.2	Realization of the Time-Driven FlexRay Schedule	35
7.6.2.1	FlexRay Job List	36

7.6.2.2	FlexRay Job List Execution Function.....	37
7.6.3	Communication Operations.....	39
7.6.3.1	TransmitWithDecoupledBufferAccess	39
7.6.3.2	ProvideTxConfirmation	40
7.6.3.3	ReceiveAndStore.....	40
7.6.3.4	ProvideRxIndication.....	41
7.6.3.5	ReceiveAndIndicate.....	41
7.6.3.6	PREPARE_LPDU.....	42
7.6.4	Transmission with Immediate Buffer Access.....	42
7.7	Error Classification	43
7.8	Error Detection	44
7.9	Error Notification.....	44
8	API Service Specification	45
8.1	Imported types.....	45
8.2	Type Definitions.....	45
8.2.1	Frlf_ConfigType	45
8.2.2	Frlf_StateType	46
8.2.3	Frlf_StateTransitionType.....	46
8.3	Function Definitions.....	46
8.3.1	Frlf_GetVersionInfo.....	47
8.3.2	Frlf_Init.....	48
8.3.3	Frlf_ControllerInit	49
8.3.4	Frlf_StartCommunication	49
8.3.5	Frlf_HaltCommunication	50
8.3.6	Frlf_AbortCommunication	51
8.3.7	Frlf_GetState.....	52
8.3.8	Frlf_SetState	52
8.3.9	Frlf_SetWakeupChannel	53
8.3.10	Frlf_SendWUP	54
8.3.11	Frlf_GetSyncState.....	55
8.3.12	Frlf_SetExtSync	56
8.3.13	Frlf_GetPOCStatus	57
8.3.14	Frlf_GetGlobalTime.....	57
8.3.15	Frlf_AllowColdstart.....	58
8.3.16	Frlf_GetMacroticksDuration	59
8.3.17	Frlf_Transmit.....	60
8.3.18	Frlf_SetTransceiverMode.....	61
8.3.19	Frlf_GetTransceiverMode	62
8.3.20	Frlf_GetTransceiverWUReason	63
8.3.21	Frlf_EnableTransceiverWakeups.....	64
8.3.22	Frlf_DisableTransceiverWakeups.....	65
8.3.23	Frlf_ClearTransceiverWakeups	66
8.3.24	Frlf_GetCycleLength	67
8.4	Optional Function Definitions	68
8.4.1	Frlf_SetAbsoluteTimer	68
8.4.2	Frlf_SetRelativeTimer	69
8.4.3	Frlf_CancelAbsoluteTimer.....	69
8.4.4	Frlf_CancelRelativeTimer	70
8.4.5	Frlf_EnableAbsoluteTimerIRQ	71

8.4.6	Frlf_EnableRelativeTimerIRQ	72
8.4.7	Frlf_GetAbsoluteTimerIRQStatus	73
8.4.8	Frlf_GetRelativeTimerIRQStatus	74
8.4.9	Frlf_AckAbsoluteTimerIRQ	75
8.4.10	Frlf_AckRelativeTimerIRQ	76
8.4.11	Frlf_DisableAbsoluteTimerIRQ	77
8.4.12	Frlf_DisableRelativeTimerIRQ	77
8.4.13	Frlf_GetNmVector	78
8.5	Interrupt Service Routines	80
8.5.1	Frlf_JobListExec_<ClstIdx>	80
8.6	Call-back Notifications	81
8.6.1	Frlf_Cbk_WakeupByTransceiver	81
8.7	Scheduled Functions	82
8.7.1	Frlf_MainFunction_<ClstIdx>	82
8.8	Expected Interfaces	83
8.8.1	Mandatory Interfaces	83
8.8.2	Optional Interfaces	84
8.8.3	Configurable Interfaces	84
8.8.3.1	<UL_RxIndication>	84
8.8.3.2	<UL_TxConfirmation>	85
8.8.3.3	<UL_TriggerTransmit>	85
9	Sequence Diagrams	87
9.1	Data Transmission	87
9.1.1	TransmitWithImmediateBufferAccess	87
9.1.2	TransmitWithDecoupledBufferAccess	88
9.1.3	ProvideTxConfirmation	89
9.2	Data Reception	90
9.2.1	ReceiveAndIndicate	90
9.2.2	ReceiveAndStore	91
9.2.3	ProvideRxIndication	92
10	Configuration Specification	93
10.1	How to Read this Chapter	93
10.1.1	Configuration and Configuration Parameters	93
10.1.2	Variants	93
10.1.3	Containers	94
10.1.4	Specification Template for Configuration Parameters	94
10.2	Containers and Configuration Parameters	95
10.2.1	Variants	95
10.2.2	Frlf	95
10.2.3	FrlfGeneral	96
10.2.4	FrlfCluster	97
10.2.5	FrlfController	107
10.2.6	FrlfAbsTimer	108
10.2.7	FrlfRelTimer	108
10.2.8	FrlfFrameTriggering	109
10.2.9	FrlfJobList	111
10.2.10	FrlfJob	112
10.2.11	FrlfCommunicationOperation	113
10.2.12	FrlfFrameStructure	114

10.2.13	FrlfPdusInFrame.....	114
10.2.14	FrlfLPdu.....	115
10.2.15	FrlfPdu.....	116
10.2.16	FrlfTxPdu.....	116
10.2.17	FrlfRxPdu	117
10.2.18	FrlfPduDirection.....	117
10.2.19	FrlfTransceiver	118
10.2.20	FrlfConfig.....	118
10.3	Published Information.....	120
11	Changes during SWS Improvements by Technical Office	121
11.1	Deleted SWS Items	121
11.2	Replaced SWS Items	121
11.3	Changed SWS Items.....	121
11.4	Added SWS Items	121

1 Introduction and Functional Overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module "FlexRay Interface".

In the AUTOSAR Layered Software Architecture [2], the FlexRay Interface belongs to the *ECU Abstraction Layer*, or more precisely, to the *Communication Hardware Abstraction*. This indicates the main task of the FlexRay Interface:

Provide to upper layers an abstract interface to the FlexRay Communication System. At least as far as data transmission (i.e. data sending and reception) is concerned, this interface shall be uniform for all bus systems in Autosar (FlexRay, CAN, LIN). Thus, the upper layer (Communication Services like PDU Router, Transport Protocol, and Network Management and others) may access all underlying bus systems for data transmission in a uniform manner. The configuration of the FlexRay Interface however is bus-specific, since it takes into account the specific features of the communication system.

The FlexRay Interface does not directly access the FlexRay hardware (FlexRay Communication Controller and FlexRay Transceiver), but by means of one or more hardware-specific Driver modules.

In order to access the FlexRay Communication Controller(s), the FlexRay Interface uses one or multiple FlexRay Driver modules, which abstract the specific features and interfaces ([CHI](#)) of the respective FlexRay Communication Controller(s).

Frlf05095:

Likewise, in order to access the FlexRay Transceiver(s), the FlexRay Interface shall use one or multiple FlexRay Transceiver Driver module(s), which abstract the specific features and interfaces of the respective FlexRay Transceiver(s)

Frlf05096:

Therefore, the FlexRay Interface executable code (however, not the configuration used during runtime) shall be completely independent of the FlexRay Communication Controller(s) and the FlexRay Transceiver(s).

Note:

The FlexRay Interface is specified in a way that allows for object code delivery of the code module, following the "one-fits-all" principle, i.e. the entire configuration of the FlexRay Interface can be carried out without modifying any source code. Thus, the configuration of the FlexRay Interface can be carried out largely without detailed knowledge of the underlying hardware.

FrIf05097:

The FlexRay Interface provides to upper layer AUTOSAR [BSW](#) modules the following groups of functions:

- initialization
- data transmission (sending and reception)
- start/halt/abort communication
- FlexRay specific functions (e.g. send wake-up pattern)
- set operation mode
- get status information
- various timer functions

2 Information about this Document

2.1 General Hints

In general, the FlexRay Interface has no knowledge of the origin of a PDU passed to it in an API service call.

Therefore, throughout this document, unless stated otherwise, the term "PDU" is being used for PDUs originating from or sent to:

- AUTOSAR Com (I-PDU) via the PDU-Router, or
- AUTOSAR FlexRay TP (N-PDU), or
- AUTOSAR FlexRay NM

Frlf05098:

In addition to the above-mentioned AUTOSAR BSW modules, the Frlf shall, with the functionality described within the specification in hand, also support other non-AUTOSAR upper layer software modules, provided that these modules interact with the Frlf in the same manner as the upper layer AUTOSAR BSW modules.

One example for such a non-AUTOSAR software module is a proprietary XCPonFlexRay module that users may add to their AUTOSAR BSW stack.

Throughout this document, several scenarios for changing configuration data are mentioned. They are being used as follows:

- "**pre compile time**" = carried out *before* compiling the code of the FlexRay Interface, since the code generation depends on this setting.
- "**at system configuration time**" = static configuration parameters stored in the FlexRay Interface; may be defined *after* compilation of the code of the FlexRay Interface ("**link time**" or "**post build time**"), but have to be defined *before* the first execution of the FlexRay Interface code.
- "**by a flashing process**" = data (not code!) manipulation carried out in a *flashing* process of a flashable memory (in general a Flash-EEPROM) e.g. in a garage, but **not** while the car is being driven. Usually used to **replace** a static configuration *already stored* in the ECU, or a part thereof. Therefore, the respective data are of configuration class "link time" or "post build time".
- "**during runtime**" = dynamically switching (in **POC**:*normal active state* of the FlexRay **CC**, if supported) between different configuration parameter sets stored in the static configuration of the FlexRay Interface, or the FlexRay Driver, respectively.

Everything not explicitly mentioned in this document, should be considered as implementation-specific.

2.2 Acronyms and Abbreviations

The following acronyms and abbreviations are used throughout this document:

Acronym:	Description:
FrIf	FlexRay Interface (AUTOSAR BSW module)
CC	(FlexRay) Communication Controller
WUP	Wake-Up Pattern
WUS	Wake-Up Symbol
CAS	Collision Avoidance Symbol
MTS	Media Access Test Symbol
POC	Protocol Operation Control
CHI	Controller Host Interface of a FlexRay CC
BSW	(AUTOSAR) Basic Software
ISR	Interrupt Service Routine
COM	Communication (AUTOSAR BSW module)
PduR	PDU Router (AUTOSAR BSW module)
FrTp	FlexRay Transport Layer (AUTOSAR BSW module)
FrNm	FlexRay Network Management (AUTOSAR BSW module)
DEM	Diagnostic Event Manager (AUTOSAR BSW module)
DET	Development Error Tracer (AUTOSAR BSW module)
ComM	Communication Manager (AUTOSAR BSW module)
System Designer	The person responsible for the configuration of all system parameters that do not influence the executable code itself (i.e. the sequence of instructions executed during runtime), but the data used to configure which operations this executable code performs on which data and at which points in time.

Abbreviation:	Description:
i.e.	[lat.] id est = [eng.] that is
e.g.	[lat.] exempli gratia = [eng.] for example
N/A	not applicable

3 Related Documentation

3.1 Input Documents

- [1] List of Basic Software Modules
AUTOSAR_BasicSoftwareModules.pdf
- [2] AUTOSAR Layered Software Architecture
AUTOSAR_LayeredSoftwareArchitecture.pdf
- [3] AUTOSAR General Requirements on Basic Software Modules
AUTOSAR_SRS_General.pdf
- [4] Specification of AUTOSAR COM
AUTOSAR_SWS_COM.pdf
- [5] AUTOSAR Requirements on FlexRay
AUTOSAR_SRS_FlexRay.pdf
- [6] Specification of FlexRay Driver
AUTOSAR_SWS_FlexRay_Driver.pdf
- [7] FlexRay State Manager
AUTOSAR_SWS_FlexRayStateManager.pdf
- [8] Specification of FlexRay Transceiver Driver
AUTOSAR_SWS_FlexRayTransceiver.pdf
- [9] Specification of FlexRay Transport Layer
AUTOSAR_SWS_FlexRay_TP.pdf
- [10] Specification of FlexRay Network Management
AUTOSAR_SWS_FlexRay_NM.pdf
- [11] Specification of PDU Router
AUTOSAR_SWS_PDU_Router.pdf
- [12] Specification of BSW Scheduler
AUTOSAR_SWS_Scheduler.pdf
- [13] ECU Configuration Specification
AUTOSAR_SWS_ECU_StateManager.pdf
- [14] Specification of Memory Mapping
AUTOSAR_SWS_MemoryMapping.pdf
- [15] AUTOSAR Basic Software Module Description Template,
AUTOSAR_BSW_Module_Description.pdf

3.2 Related Standards and Norms

- [16] FlexRay Communications System Protocol Specification Version 2.1 Revision A
- [17] FlexRay Communications System Electrical Physical Layer Specification Version 2.1 Revision A

4 Constraints and Assumptions

4.1 Limitations

The FlexRay [BSW](#) modules are only able to handle a single thread of execution per Cluster. The execution for a particular Cluster must not be pre-empted by itself for the same Cluster. The same applies to the execution of the FlexRay Job List Execution Function.

It is not possible to transmit signals, PDUs, and/or L-SDUs, which exceed the available buffer size of the used FlexRay [CC](#) during normal operation. Longer signals, PDUs, and/or L-SDUs have to be transmitted using the FlexRay Transport Protocol.

Note:

The FlexRay Interface does not make any PDU payload-dependent routing decisions.

Frlf05008:

In order for the AUTOSAR FlexRay [BSW](#) ([Frlf](#) and FlexRay Driver) modules to be able to control a FlexRay [CC](#), this [CC](#) must allow for configuring its transmit/receive buffers to support the Cycle Counter Filter Criterion / (Support of Slot/Cycle Multiplexing)

$$\text{Cycle Number} = (B + n * 2^R)_{\text{mod}64}$$

with **exactly one tuple** of values for **B** and **2^R** , where:

- Base Cycle **B** $\in [0 \dots 63]$
- Cycle Repetition **2^R** ; **R** $\in [0 \dots 6]$
- Variable **n** = 0 ... 63
- **B < 2^R**

4.2 Applicability to Car Domains

The FlexRay BSW Stack can be used wherever high data rates and fault tolerant communication (in conjunction with AUTOSAR [COM](#)) are required. Of course, it can also be used for less-demanding use cases, i.e. for low data rates or non-fault-tolerant communication. Furthermore, it enables the synchronized operation of several ECUs within a car.

5 Dependencies to Other Modules

Frlf05074:

5.1 AUTOSAR Operating System

Frlf05099:

There is one dedicated FlexRay Job List Execution Function for each FlexRay Cluster.

Frlf05100:

The FlexRay Interface executes the Flexray Job List Execution Function.

Note:

It is up to the implementer whether the FlexRay Job List Execution Functions runs in a task context or in an ISR.

5.2 AUTOSAR BSW Scheduler

Frlf05101:

There is one dedicated FlexRay Interface Main Function for each FlexRay Cluster

Frlf05102:

Each of these FlexRay Interface Main Functions must be called cyclically from a task body provided by the [BSW](#) Scheduler. The calling period must be configurable.

5.3 All Upper Layer AUTOSAR BSW Modules

Frlf05050:

The calling of the FlexRay Job List Execution Function synchronously to the FlexRay Global Time shall ensure that both the indication (to an upper layer [BSW](#) module) of received data and the request (to an upper layer [BSW](#) module) for data to be sent occur synchronously to the FlexRay Global Time.

Frlf05049:

If the respective upper layer [BSW](#) module does not operate synchronously to the FlexRay Global Time, these occurrences are asynchronous to the code execution of this [BSW](#) module. Therefore, this [BSW](#) module shall allow access to its PDU buffers at all times and it also has to ensure data consistency in its buffers.

5.4 AUTOSAR PDU-Router

The [Frlf](#) declares and calls some callback functions of the PDU-Router in order to confirm transmission and notify reception of PDUs.

5.5 AUTOSAR FlexRay Network Management

The [Frlf](#) declares and calls some callback functions of the FlexRay Network Management in order to confirm transmission and notify reception of PDUs.

5.6 AUTOSAR FlexRay Transport Protocol

The [Frlf](#) declares and calls some callback functions of the FlexRay Transport Protocol in order to confirm transmission and notify reception of PDUs.

5.7 AUTOSAR FlexRay Driver

The [Frlf](#) has a tight relation to the FlexRay Driver since many of the FlexRay-related services offered by the [Frlf](#) to upper layer [BSW](#) modules are actually carried out by the FlexRay Driver [BSW](#) module. For those services, the [Frlf](#) mainly performs only an abstraction of the communication hardware specific information (e.g. the topology of the FlexRay Communication System) and then calls the respective FlexRay Driver with the appropriate parameters.

Frlf05051:

The FlexRay Driver shall be the only BSW Modules which has to run necessarily synchronous to the FlexRay Interface.

5.8 AUTOSAR FlexRay Transceiver Driver

The [Frlf](#) has a tight relation to the FlexRay Transceiver Driver since calls of API services of the FlexRay Transceiver Driver are also routed through the [Frlf](#) in order to abstract the communication hardware specific information (e.g. the topology of the FlexRay Communication System).

5.9 AUTOSAR Development Error Tracer

Frlf05065:

In order to be able to report development errors, the [Frlf](#) has to have access to the error hook of the Development Error Tracer.

5.10 AUTOSAR Diagnostic Event Manager

Frlf05066:

In order to be able to report production errors, the [Frlf](#) has to have access to the Diagnostic Event Manager.

5.11 File Structure

5.11.1 Code File Structure

The code file structure shall not completely be defined within this specification.

Frlf05075:

However, the code-file structure shall include the following files:

Frlf.c	general source code file of the FlexRay Interface
Frlf_Cfg.c	contains pre-compile time configurable parameters
Frlf_Lcfg.c	contains link time configurable parameters
Frlf_PBcfg.c	contains post build time configurable parameters

5.11.2 Header File Structure

Frlf05076:

The header file structure shall contain the following header files:

Frlf.h	general header file of the FlexRay Interface
Frlf_Cfg.h	contains the Frlf pre-compile-time configurable parameters (pre processor constants)
Frlf_Cbk.h	contains the declarations of the callback functions provided by the Frlf to other BSW modules
Fr.h	contains the declarations of the API services of the FlexRay Driver used by the FlexRay Interface
FrTrcv.h	contains the declarations of the API services of the FlexRay Transceiver Driver used by the FlexRay Interface.
Fr_Types.h	contains declarations shared by all AUTOSAR FlexRay BSW modules
ComStack_Types.h	contains the communication module abstracted datatypes shared by AUTOSAR communication BSW.
PduR_Frlf.h	contains the declarations of API services the PDU router offers to the FlexRay Interface
FrNm_Cbk.h	contains the declarations of API services the FrNm offers to the FlexRay Interface
FrTp_Cbk.h	contains the declarations of API services the FrTp offers to the FlexRay Interface
Dem.h	contains the declarations of the API services of the Dem used by the FlexRay Interface
Det.h	contains the declarations of the API services of the Det optionally used by the FlexRay Interface
SchM_Frlf.h	Contains the declaration of the API services the SchM offers to the FlexRay Interface
MemMap.h	




Figure 5-1: FlexRay Interface Header File Structure

Besides the FlexRay-specific header files, the FlexRay Interface shall include the file `Dem.h`. By this inclusion, the API services used to report errors as well as the required Event-Id symbols are included. The specification in hand defines the name of the Event-Id symbols, which are provided in XML format to the [DEM](#) configuration tool. The [DEM](#) configuration tool assigns ECU-dependent values to the Event-Id symbols and publishes the symbols in `Dem_IntErrId.h`.

Frlf05081:

All files related to the `Frlf` module shall follow the naming convention `Frlf[_<description>].<extension>`

Frlf05091:

The `Frlf` module shall include the `Dem.h` file. By this inclusion the APIs to report errors as well as the required Event Id symbols are included. This specification defines the name of the Event Id symbols, which are provided by XML to the DEM configuration tool. The DEM configuration tool assigns ECU dependent values to the Event Id symbols and publishes the symbols in `Dem_IntErrId.h`.

Frlf05140:

The implementation of the `Frlf` module shall provide the header file `Frlf.h`, which is the main module interface file. It shall contain all types and function prototypes required by the `Frlf` module's environment.

Frlf05141:

The implementation of the `Frlf` module shall provide the header file `Frlf_Cfg.h` that shall contain the pre-compile-time configuration parameters.

6 Requirements Traceability

6.1 General Requirements on Basic Software Modules

Requirement	Satisfied by
BSW00344 Reference to link-time configuration	Frlf05068
BSW00404 Reference to post build time configuration	Frlf05069
BSW00405 Reference to multiple configuration sets	Frlf05003
BSW00345 Pre-compile-time configuration	Frlf05069
BSW159 Tool-based configuration	Frlf05070
BSW167 Static configuration checking	Frlf05071, Frlf05072, Frlf05073
BSW171 Configurability of optional functionality	Frlf05089
BSW170 Data for reconfiguration of AUTOSAR SW-Components	Frlf05089
BSW00380 Separate C-Files for configuration parameters	Frlf05075
BSW00419 Separate C-Files for pre-compile time configuration parameters	Frlf05075
BSW00381 Separate configuration header file for pre-compile time parameters	Frlf05075
BSW00412 Separate H-File for configuration parameters	Frlf05076
BSW00383 List dependencies of configuration files	Frlf05075
BSW00384 List dependencies to other modules	Frlf05074
BSW00387 Specify the configuration class of callback function	n/a
BSW00388 Introduce containers	Frlf05077
BSW00389 Containers shall have names	Chapter 10.2
BSW00390 Parameter content shall be unique within the module	Chapter 10.2
BSW00391 Parameter shall have unique names	Chapter 10.2
BSW00392 Parameters shall have a type	Chapter 10.2
BSW00393 Parameters shall have a range	Chapter 10.2
BSW00394 Specify the scope of the parameters	Chapter 10.2
BSW00395 List the required parameters (per parameter)	Chapter 10.2
BSW00396 Configuration classes	Chapter 10.2
BSW00397 Pre-compile-time parameters	Chapter 10.2
BSW00398 Link-time parameters	Chapter 10.2
BSW00399 Loadable Post-build time parameters	Chapter 10.2
BSW00400 Selectable Post-build time parameters	Chapter 10.2
BSW00402 Published information	Frlf05086
BSW00375 Notification of wake-up reason	
BSW101 Initialization interface	Frlf05003
BSW00416 Sequence of Initialization	n/a
BSW00406 Check module initialization	Frlf05002
BSW168 Diagnostic Interface of SW components	n/a
BSW00407 Function to read out published parameters	Frlf05002
BSW00423 Usage of SW-C template to describe BSW modules with AUTOSAR Interfaces	
BSW00424 BSW main processing function task allocation	n/a
BSW00425 Trigger conditions for schedulable objects	
BSW00426 Exclusive areas in BSW modules	n/a
BSW00427 ISR description for BSW modules	n/a
BSW00428 Execution order dependencies of main processing functions	n/a
BSW00429 Restricted BSW OS functionality access	n/a
BSW00431 The BSW Scheduler module implements task bodies	n/a
BSW00432 Modules should have separate main processing functions for read/receive and write/transmit data path	n/a
BSW00433 Calling of main processing functions	
BSW00434 The Schedule Module shall provide an API for exclusive areas	n/a

BSW00336	Shutdown interface	Frlf05006
BSW00337	Classification of errors	Frlf05139
BSW00338	Detection and Reporting of development errors	Chapter 8.3
BSW00369	Do not return development error codes via API	Chapter 8.3
BSW00339	Reporting of production relevant error status	Chapter 8.3
BSW00417	Reporting of Error Events by Non-Basic Software	n/a
BSW00323	API parameter checking	Chapter 8.3
BSW004	Version check	Frlf05090
BSW00409	Header files for production code error IDs	Frlf05091
BSW00385	List possible error notifications	Chapter 8.3
BSW00386	Configuration for detecting an error	n/a
BSW161	Microcontroller abstraction	n/a
BSW162	ECU layout abstraction	n/a
BSW005	No hard coded horizontal interfaces within MCAL	n/a
BSW00415	User dependent include files	n/a
BSW164	Implementation of interrupt service routines	n/a
BSW00325	Runtime of interrupt service routines	n/a
BSW00326	Transition from ISRs to OS tasks	n/a
BSW00342	Usage of source code and object code	Frlf05078
BSW00343	Specification and configuration of time	Frlf05141
BSW160	Human-readable configuration data	Frlf05079
BSW007	HIS MISRA C	Frlf05080
BSW00300	Module naming convention	Frlf05081
BSW00413	Accessing instances of BSW modules	n/a
BSW00347	Naming separation of different instances of BSW drivers	n/a
BSW00305	Self-defined data types naming convention	Frlf05082
BSW00307	Global variables naming convention	Frlf05083
BSW00310	API naming convention	Frlf05083
BSW00373	Main processing function naming convention	n/a
BSW00327	Error values naming convention	Frlf05142
BSW00335	Status values naming convention	n/a
BSW00350	Development error detection keyword	Frlf05084
BSW00408	Configuration parameter naming convention	
BSW00410	Compiler switches shall have defined values	n/a
BSW00411	Get version info keyword	Frlf05002
BSW00346	Basic set of module files	Frlf05075
BSW158	Separation of configuration from implementation	Frlf05075
BSW00314	Separation of interrupt frames and service routines	n/a
BSW00370	Separation of callback interface from API	n/a
BSW00348	Standard type header	Frlf05001
BSW00353	Platform specific type header	Frlf05001
BSW00361	Compiler specific language extension header	Frlf05001
BSW00301	Limit imported information	Figure 5-1
BSW00302	Limit exported information	Frlf05141
BSW00328	Avoid duplication of code	n/a
BSW00312	Shared code shall be reentrant	n/a
BSW006	Platform independency	n/a
BSW00357	Standard API return type	Chapter 8.3
BSW00377	Module specific API return types	n/a
BSW00304	AUTOSAR integer data types	Frlf05001
BSW00355	Do not redefine AUTOSAR integer data types	Frlf05001
BSW00378	AUTOSAR boolean type	Frlf05001
BSW00306	Avoid direct use of compiler and platform specific keywords	n/a
BSW00308	Definition of global data	Frlf05143
BSW00309	Global data with read-only constraint	Frlf05068
BSW00371	Do not pass function pointers via API	n/a
BSW00358	Return type of init() functions	Frlf05003
BSW00414	Parameter of init function	Frlf05003

BSW00376	Return type and parameters of main processing functions	n/a
BSW00359	Return type of callback functions	Chapter 8.7.3
BSW00360	Parameters of callback functions	Chapter 8.7.3
BSW00329	Avoidance of generic interfaces	n/a
BSW00330	Usage of macros / inline functions instead of functions	n/a
BSW00331	Separation of error and status values	n/a
BSW009	Module User Documentation	n/a
BSW00401	Documentation of multiple instances of configuration parameters	
BSW172	Compatibility and documentation of scheduling strategy	n/a
BSW010	Memory resource documentation	n/a
BSW00333	Documentation of callback function context	n/a
BSW00374	Module vendor identification	Frlf 05086
BSW00379	Module identification	Frlf 05086
BSW003	Version identification	Frlf 05086
BSW00318	Format of module version numbers	Frlf 05086
BSW00321	Enumeration of module version numbers	Frlf 05086
BSW00341	Microcontroller compatibility documentation	n/a
BSW00334	Provision of XML file	Frlf05089
BSW00435	Header File Structure for the Basic Software Scheduler	Frlf05087
BSW00436	Module Header File Structure for the Memory Mapping	Frlf05088

6.2 Requirements on FlexRay

<i>Requirement</i>	<i>Satisfied by</i>
BSW05000 Support of Synchronous SW Modules	Frlf05050
BSW05001 Support of Asynchronous SW Modules	Frlf05049
BSW05002 FlexRay Interface and FlexRay Driver as Only Necessarily Synchronous SW Modules	Frlf05051
BSW05003 Support of Slot/Cycle Multiplexing	Frlf05008
BSW05169 Avoid Timer Interrupts during Start-up	8.3.2
BSW05055 Avoid Timer Interrupts during Shutdown	8.3.8, 8.3.9
BSW05004 PDU-Based Data API	Frlf05055
BSW05010 Unique PDU-ID	Frlf05052
BSW05126 PDU Update/Valid Information	Frlf05056
BSW05097 Number of FlexRay Drivers per FlexRay Interface	Frlf05057
BSW05007 Number of FlexRay CCs per Interface	Frlf05053
BSW05130 Transmit Request Queuing	Frlf05058
BSW05060 Scheduling of Copy Operation into/from FlexRay CC	Frlf05059
BSW05096 Assignment of Drivers to Controllers	Frlf05060
BSW05013 Initialize Local Memory Space	Frlf05003
BSW05031] Initialization of a FlexRay CC	Frlf05004
BSW05078 Initialization of a FlexRay Cluster	N/A (moved to FrSm)
BSW05034 Configuration Modifiable by a Flashing Process	
BSW05042 Switch Configuration in Normal Active Mode	Frlf05061
BSW05015 Start-up of a FlexRay CC	Frlf05005
BSW05101 Start-up of a FlexRay Cluster	N/A (moved to FrSm)
BSW05018 Sending of a Wake-Up Pattern	Frlf05011
BSW05158 Get FlexRay Transceiver Wake-up Reason	Frlf05036
BSW05159 Enable FlexRay Transceiver Wake-up Indication	Frlf05037
BSW05163 Cluster-wide Enable FlexRay Transceiver Wake-up Indication	N/A (moved to FrSm)
BSW05160 Disable FlexRay Transceiver Wake-up	Frlf05038
BSW05164 Cluster-wide Disable FlexRay Transceiver Wake-up Indication	N/A (moved to FrSm)
BSW05161 Clear FlexRay Transceiver Wake-up Events	Frlf05039
BSW05165 Cluster-wide Clear FlexRay Transceiver Wake-up Events	N/A (moved to FrSm)
BSW05067 Set FlexRay Cluster Offline Mode	N/A
BSW05068 Set FlexRay Cluster Online Mode	N/A (moved to FrSm)
BSW05155 Set FöexRay Cpmtrpööer Pmöome ;pde	Frlf05005

BSW05069	Get FlexRay Cluster Mode	N/A (moved to FrSm)
BSW05153	Get FlexRay Controller Mode	N/A (moved to FrSm)
BSW05022	Get FlexRay CC POC Status	FrIfo5014
BSW05023	Get FlexRay CC Sync State	FrIfo5012
BSW05035	MTS Sending	N/A (no use without BG)
BSW05038	Get MTS Reception Status	N/A (no use without BG)
BSW05039	Set FlexRay Transceiver Operation Mode	FrIfo5034
BSW05162	Set Cluster-wide FlexRay Transceiver Operation Mode	N/A (moved to FrSm)
BSW05157	Get FlexRay Transceiver Operation Mode	FrIfo5035
BSW05174	Interrupt Handling	
BSW05170	Receive PDU	FrIfo5062
BSW05027	Transmit PDU	FrIfo5063
BSW05016	Abortion of a FlexRay CC Communication	FrIfo5007
BSW05113	Abortion of a FlexRay Cluster Communication	N/A (moved to FrSm)
BSW05063	Halt of a FlexRay CC Communication	FrIfo5006
BSW05102	Halt of a FlexRay Cluster Communication	N/A (moved to FrSm)
BSW05102	Provide Error Information	FrIfo5065, FrIfo5066
BSW05006	Abstraction of FlexRay-Specific Features	
BSW05009	Local Memory Space Usage	
BSW05056	Configuration of the FlexRay Interface at System Configuration Time	FrIfo5067, FrIfo5054

6.3 Specification Items

The following Items shall be seen as implementation hints only!

Functional Specification

Usage of abstract index	FrIfo5103
Passing of translated index	FrIfo5104
Abstraction of FlexRay Transceivers	FrIfo5105
Usage of Controller and Channel Index	FrIfo5106
Usage of zero-based index	FrIfo5107
Usage of FR Cluster Index	FrIfo5108
Configuration Data	FrIfo5109
Usage of PDU index	FrIfo5110
Support one of both or both FlexRay Channels	FrIfo5111
Support of at least four FlexRay Clusters	FrIfo5112
Support of at least one absolute timer per FlexRay CCs	FrIfo5113
Support of at least one relative timer per FlexRay CC	FrIfo5114

FlexRay Interface State Machine

One State Machine per Cluster	FrIfo5115
FrIfo_State offline during initialization	FrIfo5116
FrIfo_State offline during initialization	FrIfo5117

FlexRay Interface Main Function

One Main Function for each FlexRay Cluster	FrIfo5119
Main Function tasks	FrIfo5120

Data Communication via FlexRay

Packaging of multiple PDUs in one FR Frame	Frlf05121
Frame construction plan (layout)	Frlf05122
Frame construction plan (config)	Frlf05123
Transmission rule	Frlf05124
Update Information per PDU	Frlf05125
Location of Update Information	Frlf05126
Configuration of Update Information	Frlf05127
Indication in case of no update information	Frlf05128
Transmission with Immediate Buffer Access	Frlf05129
Ensure synchronous buffer access	Frlf05130
Sortation of Communication Job	Frlf05131
Communication Job properties	Frlf05132
Communication Job execution start time	Frlf05133
Actions specified by Communication Operation	Frlf05134
Communication Operation properties	Frlf05135
Job List Execution Function naming	Frlf05136
Job List synchronously to global time	Frlf05137
Job List Execution Function actions	Frlf05138

7 Functional Specification

7.1 FlexRay BSW Stack

As part of the AUTOSAR Layered Software Architecture according to [2], the FlexRay [BSW](#) modules also form a layered software stack.

Figure 7-1 depicts the basic structure of this FlexRay [BSW](#) stack. The [FrIf](#) accesses several [CCs](#) using the FlexRay Driver layer, which can be made up of several FlexRay Drivers modules. The FlexRay Transceivers are not shown in this figure; however, the structure that applies to the FlexRay Drivers and the FlexRay [CCs](#) analogously applies to the FlexRay Transceiver Drivers and the FlexRay Transceivers.




Figure 7-1: Basic Structure of the FlexRay BSW Stack

7.2 Indexing Scheme

7.2.1 Principle

Most of the [FrIf](#)'s API services used for accessing the numerous (hardware and software) resources¹ map to corresponding API services of the underlying FlexRay Driver(s), or FlexRay Transceiver Driver(s), respectively.

¹ E.g. timers, configuration data sets, etc.

In order to select those resources spread over the various entities² accessed via the [FrIf](#), the FlexRay-related AUTOSAR [BSW](#) modules use an indexing scheme that exemplarily described in

Figure 7-2 and Figure 7-3.

FrIf05052:

The [FrIf](#) achieves the abstraction (of the CCs and Drivers) by providing to the upper layer [BSW](#) modules an abstract, unique, zero-based consecutive index³ for each sort of resource, independent of their type, location, and access method.


FrIf05103:

In general, the [FrIf](#) API service then uses the abstract index passed to it by the upper layer [BSW](#) module to retrieve:

1. **the function pointer to a corresponding lower layer BSW module's API service** from a static configuration data table containing function pointers to all API services of all lower layer [BSW](#) modules called by the [FrIf](#)⁴, and
2. **the translated index used in the call to the lower layer BSW module's API service** from a static configuration data table.

FrIf05104:

The [FrIf](#) then calls the corresponding lower layer [BSW](#) module's API service via the function pointer and passes the translated index in the API call.



² FlexRay Drivers, FlexRay Communication Controllers, FlexRay Transceiver Drivers, and FlexRay Transceivers

³ Like ControllerIndex, ClusterIndex, ChannelIndex, etc.

⁴ Since this table contains function pointers to the lower layer BSW modules' API services, it obviously has to be linked against the linked and located code of the lower layer BSW modules.

Figure 7-2: CC Indexing Scheme of the FlexRay Interface

Frlf05060:

In order to abstract for upper layer [BSW](#) modules the various CCs, which the [Frlf](#) controls via the FlexRay Drivers, the [Frlf](#) generates an abstract, unique, zero-based consecutive index [Frlf_Ctrldx](#), which maps to a tuple of FlexRay Driver API Service function pointer and CC index [Fr_Ctrldx](#).




Figure 7-3: Flexray Transceiver Indexing Scheme of the FlexRay Interface

Frlf05105:

In order to abstract for upper layer [BSW](#) modules the various FlexRay Transceivers, which the [Frlf](#) accesses via the FlexRay Transceiver Drivers, the [Frlf](#) takes advantage of the fact that each FlexRay Transceiver is unambiguously assigned to a specific Channel on a specific FlexRay [CC](#).

Frlf05106:

Therefore, the [Frlf](#) abstracts the various FlexRay Transceivers by **a combination** of the two indices [Frlf_Ctrldx](#) (Controller Index) and [Frlf_Chnlidx](#) (Channel Index) and maps this to a tuple of FlexRay Transceiver Driver API Service function pointer and FlexRay Transceiver index [FrTrcv_TrclvIdx](#). (Transceiver Index)

Frlf05107:

Besides hardware and software resources, the [Frlf](#) also numbers the logical structure elements presented by FlexRay with an abstract, unique, zero-based consecutive index.

Frlf05108:

The FlexRay Clusters are numbered with the index [Frif_ClstIdx](#) in order to provide Cluster-based API services

Frif05109:

The static configuration data of the [Frif](#) contains a data structure that specifies which FlexRay [CC](#) and which FlexRay Transceivers are connected to which Clusters, or in other words, that maps each value of [Frif_ClstIdx](#) to (one, or in general) a set of values for [Frif_CtrllIdx](#) and tuples of ([FrifCtrlIdx](#), [Frif_ChnlIdx](#)).

Frif05110:

The [Frif](#) numbers all PDUs to be transmitted with an abstract, unique, zero-based consecutive index [Frif_TxPduld](#).

Note:

This index is used in the [Frif](#) API service [Frif_Transmit\(\)](#) and allows the [Frif](#) to quickly identify (e.g. by a table look-up) the PDU that is passed to it by an upper layer [BSW](#) module, and to process it accordingly.

7.2.2 Supported Indexed Resources

Frif05057:

The [Frif](#) can be configured to support at least four (possibly different) **FlexRay Drivers** to access the FlexRay Communication Controllers.

Frif05053:

The [Frif](#) can be configured to support at least four (possibly different) **FlexRay CCs**.

Frif05111:

The [Frif](#) can be configured to support one of both or both **FlexRay Channels** as specified in [16].

Frif05112:

The [Frif](#) can be configured to support at least four **FlexRay Clusters**.

Frif05113:

The [Frif](#) can be configured to support at least one **absolute timer** per FlexRay [CCs](#).

Frif05114:

The [Frif](#) can be configured to support at least one **relative timer** per FlexRay [CCs](#).

7.3 FlexRay Interface State Machine

In order to allow to control the communication operations of the FlexRay system,

Frif05115:

the [Frif](#) implements a simple state machine (one per FlexRay cluster), called **FlexRay Interface State Machine**




Figure 7-4: FlexRay Interface State Machine

Figure 7-4 shows the states and transitions that are visible to the user of the [Frif](#). The two different states (`Frif_State`) represent the communication capabilities of the `Frif`.

State	Description
FRIF_STATE_OFFLINE	No communication services are executed (see chapter 7.6 for details).
FRIF_STATE_ONLINE	All communication services (reception, transmission, transmission confirmation) are executed (see chapter 7.6 for details).

Frif05116:

During initialization of the `Frif` by executing `Frif_Init()` (transition (1)) all CCs shall be offline (CC is brought to the POC-State 'Ready')

Frif05117:

and the `Frif_State` for each cluster is initialized with state 'FRIF_STATE_OFFLINE'.

The transitions are requested by an API service which takes the Cluster to process on and the Transition name to invoke.

The following table describes the transition names that can be passed to `Frif_SetState()`.

Transition Name	Transitions (see Figure 7-4)	Description
FRIF_GOTO_ONLINE	(2)	Transition resulting in <code>Frif_State</code> <code>FRIF_STATE_ONLINE</code>

<i>Transition Name</i>	<i>Transitions (see Figure 7-4)</i>	<i>Description</i>
FRIF_GOTO_OFFLINE	(3)	Transition resulting in Frif_State_FRIF_STATE_OFFLINE

7.3.1 FlexRay Interface Main Function

Frif05118:

The FlexRay Interface Main Function needs to be called cyclically from a task body provided by the [BSW](#) Scheduler with a calling period depending on the FlexRay Cycle length and configurable [at system configuration time](#).

Since the Cycle length of each Cluster is independent, and therefore the desired calling period of the FlexRay Interface Main Function might differ from Cluster to Cluster,

Frif05119:

there shall be one dedicated FlexRay Interface Main Function for each FlexRay Cluster that is controlled by the FlexRay Interface.

The API names of the FlexRay Interface Main Functions therefore are:

- Frif_MainFunction_0() for Cluster # 0 (Frif_ClstIdx = 0)
- Frif_MainFunction_1() for Cluster # 1 (Frif_ClstIdx = 1)
- Frif_MainFunction_2() for Cluster # 2 (Frif_ClstIdx = 2)
- Frif_MainFunction_3() for Cluster # 3 (Frif_ClstIdx = 3)
- ... and so on, if more than 4 FlexRay Clusters are supported.

The Main Function monitors and controls the continuous execution of the FlexRay Job List Execution Function, including the (re)synchronization if a loss of the JobList's synchronization (see [JobListAsyncFlag](#)) or a miss of execution was detected.

This is done by the following steps:

Frif05120:

The FlexRay Interface Main Function performs the following tasks at each invocation:

- Get the global time (Frif_GetGlobalTime())

- add some 'safety margin'
- search the FlexRay Job List for the subsequent job, i.e. that job with an invocation time greater than the current global time + safety margin. If the end of the Job List has been reached, wrap around to the beginning of the Job List.
- set the JobListPointer to that job and program the absolute timer with this job's invocation time (now the FlexRay Job List is synchronized again)
- clear the JobListAsyncFlag
- Enable the absolute timer interrupt

7.4 Implementation Requirements

Frlf05068:

Link-time and post-build-time configuration data shall be implemented as read-only data structures. Link-time configuration data shall be immediately referenced by the implementation, the start-address of post-build-time configuration data shall be passed during module initialization

Frlf05069:

The Frlf module shall support pre-compile time, link-time and post-build-time configuration.

Frlf05078:

The Frlf module shall implement the API functions specified by the Fr SWS as real C code functions and shall not implement the API functions as macros.

The rationale is to allow object code module integration.

Frlf05079:

The description of the configuration and initialization data itself is not part of this specification but very implementation specific. The generated configuration data should be “human-readable”.

Frlf05080:

The Frlf module’s implementation shall conform to the HIS subset of the MISRA C Standard.

Frlf05085:

In case development error detection is enabled for the Frlf module: the Frlf module shall check API parameters for validity and report detected errors to the DET.

Frlf05087:

The Frlf module source code file(s) shall include *SchM_Frlf.h* if data consistency mechanisms of the BSW scheduler are required as described in [13].

Frlf05088:

The Frlf module header file shall include *MemMap.h* and apply the memory mapping abstraction mechanisms as specified by [15].

Frlf05090:

The header file *Frlf.h* shall contain a software and specification version number.

Frlf05092:

The Frlf shall support dynamic payload length for LPdus whose associated parameter *FrlfAllowDynamicLsduLength* is set to true.

Frlf05143:

None of the Frlf module’s header files shall define global variables.

7.5 Configuration description

Frlf05089:

The Frlf module shall provide an XML file that contains the data which is required for the SW identification (it shall contain the vendor identification, module ID and software version information), configuration and integration process. This file should describe vendor specific configuration parameters as well as it should contain recommended configuration parameter values.

7.6 Data Communication via FlexRay

FlexRay in general is a deterministic time-driven communication system.

Frlf05067:

Each datum that should be transmitted or received has to be scheduled [at system configuration time](#). This even holds true for data that - from the application's point of view - are considered *event-driven*.

Note:

When looking only at specific instances of the AUTOSAR FlexRay software modules running on a specific ECU it is not possible to "anticipate" the **exact point in time** when a certain FlexRay frame is being sent (or received, respectively) in the Dynamic Segment of the FlexRay Cycle.

Frlf05054:

However, the resources (e.g. a buffer in the FlexRay Communication Controller or FlexRay Driver) needed for this data transmission (or reception, respectively) have to be defined [at system configuration time](#) specifically for this data transmission (or reception, respectively).

Note:

There is no true spontaneous event-driven data communication on FlexRay. Even application data that occur at unpredictable points in time (i.e. "event-driven"), and that should be transmitted via FlexRay, have to be scheduled for transmission [at system configuration time](#).

7.6.1 PDU Packing, PDU Update-Bits, and Frame Construction Plans

In accordance with basic AUTOSAR rules,

Frlf05055:

the API services that the [Frlf](#) provides to upper layer [BSW](#) modules for data transmission and data reception are PDU-based.

Note:

Since bus-independent AUTOSAR PDUs have a maximal length of 8 bytes, and since according to [16] a FlexRay Frame can contain as many as 254 bytes of payload data,

Frlf05121:

the [Frlf](#) shall be capable of packing multiple PDUs into one FlexRay Frame.

Note:

It is also allowed to define PDUs which are larger than 8 bytes. Please be aware that PDUs greater than 8 bytes are not bus independent any more!

Frlf05122:

The rules defining how to pack PDUs into FlexRay Frames, the so-called **Frame Construction Plans**, are defined [at system configuration time](#)

Frlf05123:

The Frame Construction Plan shall be stored in the static configuration of the [Frlf](#) (configuration parameter [FrlfFrameStructure](#)).

Frlf05124:

In cases where multiple PDUs are packed into a single FlexRay Frame, this FlexRay Frame has to be transmitted if at least one of the contained PDUs has been updated.

Note:

As a result, those PDUs in this FlexRay Frame that have not been updated by the upper layer BSW module will also be transmitted.

Frlf05056:

In order for the receiving [Frlf](#) to be able to determine which of the PDUs in a received FlexRay Frame have actually been updated by the upper layer BSW module (by a call of `Frlf_Transmit()`) on the transmitter side, additional update information, so called **PDU Update-Bits** within the FlexRay Frame, shall be transmitted to the receiving [Frlf](#).

Frlf05125:

For each PDU, a dedicated PDU Update-Bit in the FlexRay Frame can be configured (see configuration parameter [FrlfPduUpdateBitOffset](#)).

Frlf05126:

This PDU Update-Bit can be located at an arbitrary bit position in the Frame Construction Plan that is not occupied by any PDU.

Frlf05127:

The configuration of Update-Bits for the PDUs and the definition of the location of the Update-Bits within the FlexRay Frame are performed [at system configuration time](#) [Configuration Parameter [FrlfPduUpdateBitOffset](#)]

Frlf05128:

If no update bit is configured for a specific PDU, this PDU is always assumed to be valid and its reception is always indicated to the upper layer BSW module on the receiver side.

Frlf05129:

If Transmission with Immediate Buffer Access is used, only one PDU is allowed per FlexRay Frame (L-SDU).

Note:

Therefore, PDU Update-Bits can be omitted for Transmission with Immediate Buffer Access.

7.6.1.1 AlwaysTransmit

Note:

According to [16], a FlexRay [CC](#) might **only** support the so-called “continuous transmission mode” where a message is transmitted continuously until the host explicitly invalidates the transmit buffer. If such a FlexRay [CC](#) is being used for transmission, and the receiving [FrIf](#) should still be able to determine which of the PDUs in a received FlexRay Frame have actually been updated by an upper layer [BSW](#) module on the transmitter side, a special mechanism is needed in the transmitting [FrIf](#), called **AlwaysTransmit** (configuration parameter [FrIfAlwaysTransmit](#)). If [AlwaysTransmit](#) is enabled for an L-PDU that is transmitted using the Communication Operation [4], the FlexRay Driver’s API service [Fr_TransmitTxLPdu\(\)](#) is always called for this L-PDU, independent from any PDUs in this L-PDU having been updated by an upper layer [BSW](#) module. This enables resetting the PDU Update-Bits in the FlexRay [CC](#)s transmit buffer, even if none of the PDUs in the FlexRay Frame have actually been updated by an upper layer [BSW](#) module, and thus ensures the correct interpretation of the received Frame contents by the receiving [FrIf](#).

Since:

- in general, the transmit mode of a FlexRay [CC](#) can be configured (“continuous mode” / “single shot mode”), and
- [AlwaysTransmit](#) can be configured independently per L-PDU, and
- Update-Bits can be configured independently per PDU,

the [FrIf](#) can be tailored to exhibit exactly the behavior required by a certain use case. However, it is the responsibility of the [System Designer](#) to select the correct configuration of all these parameters. An incorrect configuration will lead to undesired results.

7.6.2 Realization of the Time-Driven FlexRay Schedule

According to [16], a FlexRay [CC](#) is **not** required to provide mechanisms in hardware to ensure asynchronous access to its transmit and receive buffers e.g. by providing shadow buffers that may be accessed asynchronously by the AUTOSAR FlexRay software modules.

[FrIf05130](#):

Therefore, the calling of all functions accessing these buffers (i.e. performing data transmission or reception, respectively) must be synchronous (i.e. synchronized to the FlexRay Global Time) in order to ensure buffer access taking place only at well-defined points in time⁵ and thus avoid concurrent access to the buffers by the hardware and the software.

Note:

In order to provide this necessary synchronicity, the [FrIf](#) defines for each Cluster a FlexRay Job List [Configuration Parameter [FrIfJobList](#)].

⁵ In FlexRay Global Time

The Cluster's FlexRay Job List is executed by its Job List Execution Function (see 8.5.1) using an absolute timer [Configuration Parameter [FrIfAbsTimerRef](#)] of a FlexRay [CC](#) connected to the respective Cluster.

7.6.2.1 FlexRay Job List

FrIf05131:

A FlexRay Job List is a list of Communication Jobs sorted according to their respective execution start time.

FrIf05132:

Each Communication Job [Configuration Parameter [FrIfJob](#)] contains the following properties:

- Job start time by means of
 - FlexRay Communication Cycle [Configuration Parameter [FrIfCycle](#)]
 - Macrotick Offset within the Communication Cycle [Configuration Parameter [FrIfMacrotick](#)].
- A list of Communication Operations [Configuration Parameter [FrIfCommunicationOperation](#)] sorted according to a configurable Communication operation index [Configuration Parameter [FrIfCommunicationOperationIdx](#)]. The sorting order defines the order of execution of the Communication Operations within a FlexRay Communication Job.

FrIf05133:

The execution start time assigned to each Communication Job defines when the respective Cluster's FlexRay Job List Execution Function shall be called to execute this FlexRay Communication Job.

Frlf05134:

The Communication Operations specify the actions to process within the Communication Job.

Frlf05135:

Each Communication Operation contains the following properties:

- Communication Operation Index [Configuration Parameter [FrlfCommunicationOperationIdx](#)], which determines the execution order of the Communication Operations.
- Communication Action [Configuration Parameter [FrlfCommunicationAction](#)], which specifies the actual action to perform (see 7.6.3):
 - DECOUPLED_TRANSMISSION
 - TX_CONFIRMATION
 - RECEIVE_AND_STORE
 - RX_INDICATION
 - RECEIVE_AND_INDICATE
 - PREPARE_LPDU
- A reference to a frame triggering (L-PDU) which is associated with the Communication Action to perform [Configuration parameter [FrlfLPduldx](#)]⁶.

Frlf05059:

7.6.2.2 FlexRay Job List Execution Function

Since the Communication Schedule of each FlexRay Cluster is independent, there is one dedicated FlexRay Job List and one dedicated FlexRay Job List Execution Function for each FlexRay Cluster that is controlled by the FlexRay Interface.

Frlf05136:

The API names of the FlexRay Job List Execution Functions therefore are:

- `Frlf_JobListExec_0()` for Cluster # 0 (`Frlf_ClstIdx = 0`)
- `Frlf_JobListExec_1()` for Cluster # 1 (`Frlf_ClstIdx = 1`)
- `Frlf_JobListExec_2()` for Cluster # 2 (`Frlf_ClstIdx = 2`)
- `Frlf_JobListExec_3()` for Cluster # 3 (`Frlf_ClstIdx = 3`)
- ... and so on, if more than 4 FlexRay Clusters are supported.

⁶ The LPDU is identified by a LPdu Index, which has a 1:1 association to a frame triggering for historical reasons. To obtain compatibility this configuration structure is not changed here. The L-PDU index is identified with a zero-based and dense index, which shall be used as the parameter `Fr_LPduldx` passed to the AUTOSAR FlexRay Driver when processing LPdus.

Frlf05137:

The FlexRay Job List Execution Function executes the Cluster's FlexRay Job List Jobs synchronously to the Cluster's global time (i.e. at well-defined points in time).

Frlf05138:

Upon invocation, the FlexRay Job List Execution Function performs the following steps:

1. Retrieve the FlexRay Global Time from the FlexRay [CC](#) providing the Cluster's absolute timer interrupt.
2. If the FlexRay Global Time cannot be retrieved or the global time delay compared to the jobs start time is larger than a maximum delay [Configuration Parameter [FrlfMaxLsrDelay](#)], the execution of the FlexRay Job List is considered to be asynchronous to the FlexRay Global Time and thus the following actions are performed:
 - Set a flag (JobListAsyncFlag) indicating that the execution of the FlexRay Job List of this Cluster is asynchronous
 - Call Dem_ReportErrorStatus(
FRIF_E_JLE_SYNC, DEM_EVENT_STATUS_FAILED)
 - Disable absolute Timer Interrupt
 - Terminate the execution of this FlexRay Job.

Otherwise, the FlexRay Job List Execution Function continues with step 3.

3. Retrieve the sorted list of Communication Operations of the current Job pointed to by the current job-list-pointer.
4. Forward the current job-list pointer to the next job-list entry. If the job-list pointer was at the end of the job-list, wrap around and set it to the first job-list entry.
5. Retrieve the execution start time of the job marked by the job-list pointer and set the absolute timer to this job's start time in order to invoke the FlexRay Job List Execution Function again.
6. Execute the retrieved Communication Operations in the correct order.

Note:

In order to keep the runtime of the JLEF short, it is acceptable to implement the described functionality of the JLEF into a separate, high priority task which has to be activated immediately in the JLEF.

Frlf05093:

In case the parameter 'FrlfAllowDynamicLSDuLength' is set to true for the associated frame triggering, the actual used L-PDU length shall be passed to the driver (Fr_TransmitTxLPdu()) taking into account the following for each PDU:

- the position of the PDU within the L-PDU
- the actual PDU length passed via Frlf_Transmit()

- the position of the update-bit information (if configured)

Frlf05094:

In case the parameter ‘FrlfAllowDynamicLSDuLength’ is set to true for the associated frame triggering for reception, PDUs in non received areas (PDU offset > actual L-PDU length) shall not be indicated to upper layer(s).

7.6.3 Communication Operations

This chapter describes each Communication Operation that is executed within the Job List Execution Function.

Frlf05058:

7.6.3.1 TransmitWithDecoupledBufferAccess

Frlf05063:

DECOUPLED_TRANSMISSION is executed if the related CC is in Frlf_State FRIF_STATE_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation DECOUPLED_TRANSMISSION the following steps are performed:

1. Iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering of this Communication Operation and
2. Check whether [TrigTxCounter](#) is > 0 or FrlfNoneMode == true for the PDU. If not, clear the update-bit for this PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and proceed with the next PDU.
3. Call the upper layer's function _TriggerTransmit() with the associated PDUId (Frlf_TxPdulId) and pass a pointer to a temporary buffer within the Frlf that assembles the L-SDU. The pointer shall consider the byte offset [Configuration Parameter [FrlfPduOffset](#)] of the PDU within the frame.
4. Decrement [TrigTxCounter](#) only if TrigTxCounter > 0.
5. Remember that a transmission for this PDU is pending if a transmission confirmation is needed for this PDU [Configuration Parameter [FrlfConfirm](#)] (increment TxConfCounter⁷).
6. Set the update-bit if configured for this PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] only in case the API _TriggerTransmit() returned E_OK for the corresponding PDU.
7. If at least one PDU was requested for transmission, or the FlexRay Driver's API service Fr_TransmitTxLPdu() shall always be called for this L-PDU [Configuration Parameter [FrlfAlwaysTransmit](#)] or FrlfNoneMode == true, the FlexRay Driver's API service Fr_TransmitTxLPdu() is called:
 - a. Fr_CtrldIdx is derived according to the indexing scheme described in 7.2
 - b. Fr_LPdulIdx is set to the configured L-PDU index [Configuration Parameter [FrlfLPdulIdx](#)] associated with the Communication Operation
 - c. Fr_LSDuPtr is set to the temporary Frlf L-SDU assembling buffer.

⁷ Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

- d. Fr_LSduLength is set to the L-SDU length [Configuration Parameter [FrIfLSDuLength](#)]
- 8. In case the Driver's API Fr_TransmitTxLPdu() returned E_NOT_OK (indicating that the transmission failed) **changes** on [TrigTxCounter](#) and [TxConfCounter](#) must be rolled back (see 4. and 5.) for each PDU contained in the FlexRay L-SDU.

All previously described actions are depicted in detail in the sequence chart in chapter 9.1.2.

7.6.3.2 ProvideTxConfirmation

FrIf05064:

TX_CONFIRMATION is executed if the related CC is in FrIf_State FRIF_STATE_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation TX_CONFIRMATION the following steps are performed:

1. Call the FlexRay Driver's API function Fr_CheckTxLPduStatus():
 - a. Fr_Ctrldx is derived according to the indexing scheme described in 7.2
 - b. Fr_LPduldx is set to the configured L-PDU buffer index [Configuration Parameter [FrIfLPduldx](#)] associated with the Communication Operation.
2. If the transmission was performed (Output parameter *Fr_TxLPduStatusPtr is successfully set to FR_TRANSMITTED) then iterate over all PDUs contained in the [FrIfFrameStructure](#) of the associated frame triggering. If [TxConfCounter](#) for a PDU is 0 proceed with the next PDU, otherwise
 - a. Call the upper layer's function _TxConfirmation() with the associated PDUId (FrIf_TxPduld).
 - b. Decrement [TxConfCounter](#).

7.6.3.3 ReceiveAndStore

RECEIVE_AND_STORE is executed if the related CC is in FrIf_State FRIF_STATE_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RECEIVE_AND_STORE the following steps are performed:

1. Call the FlexRay Driver's API function Fr_ReceiveRxLPdu():
 - a. Fr_Ctrldx is derived according to the indexing scheme described in 7.2
 - b. Fr_LPduldx is set to the configured L-PDU index [Configuration Parameter [FrIfLPduldx](#)] associated with the Communication Operation.
 - c. Fr_LSduPtr is set to a temporary buffer.

2. If a L-PDU was received (Output parameter *Fr_LPduStatusPtr is set to FR RECEIVED) iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering and:
 - a. If an update bit was configured for the PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and the update bit for the PDU is not set, continue with the next PDU. Otherwise,
 - b. Copy the PDU Payload from the temporary buffer considering the PDU offset within the L-SDU [Configuration Parameter [FrlfPduOffset](#)] into a Frlf PDU-related static buffer.
 - c. Mark the PDU-related static buffer as up-to-date.

7.6.3.4 ProvideRxIndication

Frlf05062:

RX_INDICATION is executed if the related CC is in Frlf_State FRIF_STATE_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RX_INDICATION the following steps are performed:

1. Iterate over all PDU-related static buffers of PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering
2. If the PDU-related static buffer is marked as outdated, continue with the next PDU. Otherwise if the buffer is marked up-to-date,
 - a. Call the upper layer's function _RxIndication() with the PDU Id the receiving module expects and a pointer to the PDU-related static buffer as parameters.
 - b. Mark the PDU-related static buffer as outdated.

7.6.3.5 ReceiveAndIndicate

RECEIVE_AND_INDICATE is executed if the related CC is in Frlf_State FRIF_STATE_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RECEIVE_AND_INDICATE the following steps are performed:

1. Call the FlexRay Driver's API function Fr_ReceiveRxLPdu():
 - a. Fr_Ctrldx is derived according to the indexing scheme described in 7.2
 - b. Fr_LPduldx is set to the configured L-PDU index [Configuration Parameter [FrlfLPduldx](#)] associated with the Communication Operation.
 - c. Fr_LsduPtr is set to a temporary buffer.
2. If an L-PDU was received (Output parameter *Fr_LPduStatusPtr is set to FR RECEIVED) iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering and:
 - a. If an update bit was configured for the PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and the update bit for the PDU is not set, continue with the next PDU. Otherwise,

- c. Call the upper layer's function _RxIndication() with the PDU Id the receiving module expects and a pointer to the temporary buffer considering the PDU offset within the L-SDU [Configuration Parameter [FrIfPduOffset](#)] as parameters.

7.6.3.6 PREPARE_LPDU

FrIf05061:

PREPARE_LPDU is executed in every FrIf_State.

For Communication Operation PREPARE_LPDU the following steps are performed:

1. Call the FlexRay Driver's API function Fr_PreparesLPdu():
 - a. Fr_Ctrldx is derived according to the indexing scheme described in 7.2
 - b. Fr_LPduldx is set to the configured L-PDU index [Configuration Parameter [FrIfLPduldx](#)] associated with the Communication Operation.

The Communication Operation PREPARE_LPDU enables hardware optimization purposes. Its purpose is to enable certain FlexRay CC hardware resources (e.g. a CC's message buffer) to be prepared (configured) for the transmission/reception of a certain L-PDU.

This Communication Operation enables the FlexRay Driver to optimize the usage of hardware resources if available at appropriate point of times. However, it is the responsibility of the FlexRay Driver to decide and validate resource allocation optimizations based on the PREPARE_LPDU Communication Operations. Practically the usage of this Communication Operation will introduce some runtime-overhead even if the FlexRay Driver does not use the opportunity for reconfiguration.

7.6.4 Transmission with Immediate Buffer Access

The FlexRay Job List Execution Function does not initiate transmission with immediate buffer access. Instead, the actions described here are carried out in the context of the FrIf_Transmit() API service, which in turn is called by an upper layer [BSW](#) module.

For PDUs transmitted with immediate buffer access, the following restriction regarding static configuration apply:

- The PDU must be **the only** PDU in a FlexRay Frame (L-SDU). It is **not** packed into a FlexRay Frame together with other PDUs (i.e., the mapping between this PDU and the respective L-SDU is a 1:1 association).
- The PDU must be located **at the beginning** of the L-SDU.
- There is no update-bit for immediate PDUs configured.

If an immediate PDU transmission is indicated by calling `Frlf_Transmit()` with `Frlf_TxPduld` being configured for an immediate PDU, the following steps are performed within the context of the `Frlf_Transmit()` API service:

1. Call the FlexRay Driver's API function `Fr_TransmitTxLPdu()`:
 - a. `Fr_Ctrldx` is derived according to the indexing scheme described in 7.2
 - b. `Fr_LPduldx` is set to the configured L-PDU index [Configuration Parameter [FrlfLPduldx](#)] associated with the `Frlf_TxPduld`.
 - c. `Fr_LSDuPtr` is set to the Pdu Payload pointer contained in the `PduInfoPtr` passed as parameter to `Frlf_Transmit`.
 - d. `Fr_LSDuLength` is set to the L-SDU length [Configuration Parameter [FrlfLSDuLength](#)]
2. In case the Driver's API `Fr_TransmitTxLPdu()` returned `E_OK` (indicating that the transmission request succeeded) the [TxConfCounter](#) is incremented⁸ for the respective PDU.

7.7 Error Classification

`Frlf05139`:

Values for production code Event Ids are assigned externally by the configuration of the [DEM](#). They are published in the file `Dem_IntErrId.h` and included via `Dem.h`.

`Frlf05142`:

The error values and EventIds are named in capital letters according to the scheme `FRIF_E_<NAME>`, where NAME describes the error/EventId and may consist of several words separated by underscores.

Development error values are of type `uint8`.

Type or error	Relevance	Related error code	Value [hex]
Invalid pointer	Development	<code>FRIF_E_INV_POINTER</code>	0x01
Invalid Controller index	Development	<code>FRIF_E_INV_CTRL_IDX</code>	0x02
Invalid Cluster index	Development	<code>FRIF_E_INV_CLST_IDX</code>	0x03
Invalid Channel index	Development	<code>FRIF_E_INV_CHNL_IDX</code>	0x04
Invalid timer index	Development	<code>FRIF_E_INV_TIMER_IDX</code>	0x05
Invalid <code>Frlf_TxPdu</code> Index	Development	<code>FRIF_E_INV_TXPDUID</code>	0x06
<code>Frlf</code> not initialized	Development	<code>FRIF_E_NOT_INITIALIZED</code>	0x08
Invalid Controller State	Development	<code>FRIF_E_INV_FRIF_CC_STATE</code>	0x09
Job List Execution lost synchronization to the FlexRay Global Time	Production	<code>FRIF_E_JLE_SYNC</code>	Assigned by DEM

Table 7-1: Definition of Error Codes

⁸ Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

7.8 Error Detection

Frlf05084:

The detection of development errors is configurable (ON / OFF) at pre-compile time. The switch [FRIF_DEV_ERROR_DETECT](#) shall activate or deactivate the detection of all development errors.

If the [FRIF_DEV_ERROR_DETECT](#) switch is set to ON, API parameter checking is enabled. The detailed description of the detected errors can be found in chapter 7.7 and chapter 8.

If the [FRIF_DEV_ERROR_DETECT](#) switch is set to ON, all [Frlf](#) API services other than Frlf_Init() and Frlf_GetVersionInfo() shall:

- not execute their normal operation,
- report to the DET module (using FRIF_E_NOT_INITIALIZED),
- and return E_NOT_OK,

unless the [Frlf](#) has been initialized with a preceding call of Frlf_Init().

7.9 Error Notification

Detected development errors shall be reported to the Det_ReportError() API service of the [DET](#) if the pre-processor switch [FRIF_DEV_ERROR_DETECT](#) is set to ON.

Production errors shall be reported to the [DEM](#).

8 API Service Specification

Frlf05083:

All AP functions or global variables, whether they are specified or not shall follow the naming scheme `FrIf_<name>`, where the first letter of each word in `<name>` is written uppercase and the remainder of the word lowercase.

8.1 Imported types

In this chapter all types included from the following files are listed:

Frlf05001:

Header file	Imported Type
Dem_Types.h	Dem_EventIdType
PrimitiveTypes.h	PduInfoType
FrTrcv_Types.h	FrTrcv_TrsvModeType FrTrcv_TrsvWUReasonType
Fr_Types.h	Fr_POCStatusType Fr_ChannelType Fr_RateCorrectionType Fr_OffsetCorrectionType Fr_SyncStateType
ComStack_Types.h	PduldType BusTrcvErrorType
Std_Types.h	Std_ReturnType Std_VersionInfoType

8.2 Type Definitions

This chapter lists the data types that the FlexRay Interface defines.

Frlf05082:

All types whether they are specified or implementation dependant shall follow the naming scheme `FrIf_<name>Type`, where the first letter of each word in `<name>` is written uppercase and the remainder of the word is written lowercase.

8.2.1 FrIf_ConfigType

Name:	FrIf_ConfigType
Type:	Structure
Range:	Implementation specific
Description:	This type contains the implementation-specific post build time configuration structure. Only pointers of this type are allowed.

8.2.2 FrIf_StateType

Name:	FrIf_StateType	
Type:	Enumeration	
Range:	FRIF_STATE_OFFLINE	The FlexRay CC is not ready for communication, the FlexRay cluster is not synchronized.
	FRIF_STATE_ONLINE	The FlexRay CC is ready for communication, the FlexRay cluster is synchronized.
Description:	Variables of this type are used to represent the FrIf_State of a FlexRay CC.	

8.2.3 FrIf_StateTransitionType

Name:	FrIf_StateTransitionType	
Type:	Enumeration	
Range:	FRIF_GOTO_OFFLINE	Literal for requesting transition into FRIF_STATE_OFFLINE
	FRIF_GOTO_ONLINE	Literal for requesting transition into FRIF_STATE_ONLINE state.
Description:	Variables of this type are used to represent the FrIf_State of a FlexRay CC.	

8.3 Function Definitions

This is a list of API services (functions) the [FrIf](#) provides to upper layer [BSW](#) modules.

8.3.1 FrIf_GetVersionInfo

FrIf05002:

Service name:	FrIf_GetVersionInfo
Syntax:	void FrIf_GetVersionInfo(Std_VersionInfoType* FrIf_VersionInfoPtr)
Service ID[hex]:	0x01
Sync/Async:	Synchronous
Reentrancy:	Non Reentrant
Parameters (in):	None
Parameters (inout):	None
Parameters (out):	FrIf_VersionInfoPtr Pointer to a memory location where the FlexRay Interface version information shall be stored.
Return value:	None
Description:	Returns the version information of this module.

Parameter `FrIf_VersionInfoPtr`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_POINTER](#)) if `FrIf_VersionInfoPtr` equals `NONE_PTR`.

This API service of the FlexRay Interface returns the version information of the FlexRay Interface. The version number consists of three parts:

- Two bytes for the vendor ID
- One byte for the module ID
- Three bytes version number.

The numbering shall be vendor specific; it shall consist of:

- the major version number of the module,
- the minor version number of the module,
- and the patch version number of the module
- The AUTOSAR specification version number shall not be included.

This API service shall be [pre compile time](#) configurable ON/OFF by the configuration parameter `FRIF_VERSION_INFO_API` (derived from configuration parameter [FrIfVersionInfoApi](#)).

Hint:

If source code for caller and callee of this API service is available, this function should be realized as a macro. The macro should be defined in the file `FrIf_Cfg.h`.

Configuration:

If pre-compile-time configuration parameter 'FRIF_VERSION_INFO_API' is 'ON' this API function is included in the compilation process.

If pre-compile-time configuration parameter 'FRIF_VERSION_INFO_API' is 'OFF' this API function is excluded from the compilation process.

8.3.2 FrIf_Init

FrIf05003:

Service name:	FrIf_Init
Syntax:	<pre>void FrIf_Init(const FrIf_ConfigType* FrIf_ConfigPtr)</pre>
Service ID[hex]:	0x02
Sync/Async:	Synchronous
Reentrancy:	Non Reentrant
Parameters (in):	FrIf_ConfigPtr Base pointer to the configuration structure of the FlexRay Interface.
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	Initializes the FlexRay Interface.

Parameter FrIf_ConfigPtr: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_POINTER) if FrIf_ConfigPtr equals NULL_PTR.

This API service of the FlexRay Interface is used to initialize the FlexRay Interface

This initialization is carried out by the following actions:

- Configure the FlexRay Interface: initialize the local memory space used to store the PDU data and the PDU properties and state variables and the FlexRay Interface State Machine.

The AUTOSAR ECU StateManager calls this FlexRay Interface API service with the address of the static configuration structure of the [FrIf](#) in parameter FrIf_ConfigPtr.

Caveats: Since during the execution of this API service, several hardware devices are accessed, the initialization order of [BSW](#) modules needs to ensure that those hardware devices can physically be accessed (e.g. the DIO Driver needs to be available, if applicable).

8.3.3 FrIf_ControllerInit

FrIf05004:

Service name:	FrIf_ControllerInit
Syntax:	Std_ReturnType FrIf_ControllerInit(uint8 FrIf_CtrlIdx)
Service ID[hex]:	0x03
Sync/Async:	Synchronous
Reentrancy:	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx
Parameters (in):	FrIf_CtrlIdx Index of the FlexRay CC to address.
Parameters (inout):	None
Parameters (out):	None
Return value:	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Initialized a FlexRay CC.

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e.

[FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_ControllerInit() by:

Translating (based on static [FrIf](#) configuration) the FlexRay [CC](#) index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific [CC](#) index Fr_CtrlIdx).

Setting parameters Fr_LowLevelConfSetIdx and Fr_BufConfSetIdx to 0.

Calling Fr_ControllerInit() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [\[FrIf05389\]](#).

8.3.4 FrIf_StartCommunication

FrIf05005:

Service name:	FrIf_StartCommunication
Syntax:	Std_ReturnType FrIf_StartCommunication(uint8 FrIf_CtrlIdx)
Service ID[hex]:	0x07
Sync/Async:	Asynchronous
Reentrancy:	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx
Parameters (in):	FrIf_CtrlIdx Index of the FlexRay CC to address.

Parameters (inout):	None
Parameters (out):	None
Return value:	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_StartCommunication().

Parameter Frlf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_CtrIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_StartCommunication() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).

Calling Fr_StartCommunication() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [[Frlf05389](#)].

8.3.5 Frlf_HaltCommunication

Frlf05006:

Service name:	Frlf_HaltCommunication	
Syntax:	Std_ReturnType Frlf_HaltCommunication(uint8 Frlf_CtrIdx)	
Service ID[hex]:	0x09	
Sync/Async:	Asynchronous	
Reentrancy:	non reentrant for identical values of Frlf_CtrIdx, reentrant for different values of Frlf_CtrIdx	
Parameters (in):	Frlf_CtrIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_HaltCommunication().	

Parameter Frlf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_CtrIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_HaltCommunication() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).

Calling Fr_HaltCommunication() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.6 FrIf_AbortCommunication

FrIf05007:

Service name:	FrIf_AbortCommunication
Syntax:	Std_ReturnType FrIf_AbortCommunication(uint8 FrIf_CtrIdx)
Service ID[hex]:	0x0b
Sync/Async:	Synchronous
Reentrancy:	non reentrant for identical values of FrIf_CtrIdx, reentrant for different values of FrIf_CtrIdx
Parameters (in):	FrIf_CtrIdx Index of the FlexRay CC to address.
Parameters (inout):	None
Parameters (out):	None
Return value:	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_AbortCommunication().

Parameter FrIf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_AbortCommunication() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).

Calling Fr_AbortCommunication() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.7 FrIf_GetState

Service name:	FrIf_GetState	
Syntax:	<pre>Std_ReturnType FrIf_GetState (uint8 FrIf_ClstIdx, FrIf_StateType *FrIf_StatePtr)</pre>	
Service ID[hex]:	0x35	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_ClstIdx	Index of the cluster addressed.
Parameters (inout):	None	
Parameters (out):	FrIf_StatePtr	Pointer to a memory location where the retrieved FrIf_State will be stored.
Return value:	Std_ReturnType	E_OK: Function was successfully executed. State transition request was accepted. E_NOT_OK: Function execution failed due to detected errors. State transition request was not accepted.
Description:	Get current FrIf state.	

Parameter FrIf_ClstIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CLST_IDX) if FrIf_CtrIdx has an invalid value.

Parameter FrIf_StatePtr: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_POINTER) if FrIf_StatePtr equals NULL_PTR.

This API service of the FlexRay Interface retrieves the FrIf_State of the FlexRay Cluster with index FrIf_ClstIdx.

2. Return the current state of the FrIf State Machine:

- a. FRIF_STATE_ONLINE
- b. FRIF_STATE_OFFLINE

The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.8 FrIf_SetState

Service name:	FrIf_SetState	
Syntax:	<pre>Std_ReturnType FrIf_SetState(FrIf_StateTransitionType FrIf_StateTransition, uint8 FrIf_ClstIdx)</pre>	
Service ID[hex]:	0x35	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	

Parameters (in):	Frlf_StateTransition	Requested Frlf state transition.
	Frlf_ClstIdx	Index of the cluster addressed.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: Function was successfully executed. State transition request was accepted. E_NOT_OK: Function execution failed due to detected errors. State transition request was not accepted.
Description:	Requests Frlf state machine transition.	

Parameter Frlf_StateTransition: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_FRIF_CC_STATE) if Frlf_StateTransition has an invalid value.

Parameter Frlf_ClstIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_ClstIdx has an invalid value.

This API service of the FlexRay Interface requests for FlexRay Cluster with index Frlf_ClstIdx the Frlf_State reached by the state transition according to Frlf_StateTransistion.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [[Frlf05389](#)].

8.3.9 Frlf_SetWakeupChannel

Frlf05010:

Service name:	Frlf_SetWakeupChannel	
Syntax:	Std_ReturnType Frlf_SetWakeupChannel(uint8 Frlf_CtrlIdx, Fr_ChannelType Frlf_ChnlIdx)	
Service ID[hex]:	0x11	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of Frlf_CtrlIdx, reentrant for different values of Frlf_CtrlIdx	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller Frlf_CtrlIdx.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_SetWakeupChannel().	

Parameter `Frlf_CtrIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_SetWakeupChannel()` by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrIdx`).

3. Setting parameters

- `Fr_ChnIdx` to `Frlf_ChnIdx`

4. Calling `Fr_SetWakeupChannel()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

8.3.10 Frlf_SendWUP

`Frlf05011`:

Service name:	<code>Frlf_SendWUP</code>	
Syntax:	Std_ReturnType <code>Frlf_SendWUP(</code> <code>uint8 Frlf_CtrIdx</code> <code>)</code>	
Service ID[hex]:	0x12	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of <code>Frlf_CtrIdx</code> , reentrant for different values of <code>Frlf_CtrIdx</code>	
Parameters (in):	<code>Frlf_CtrIdx</code>	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function <code>Fr_SendWUP()</code> .	

Parameter `Frlf_CtrIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_SendWUP()` by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrIdx`).

5. Calling `Fr_SendWUP()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.11 FrIf_GetSyncState

FrIf05012:

Service name:	FrIf_GetSyncState	
Syntax:	<pre>Std_ReturnType FrIf_GetSyncState(uint8 FrIf_CtrlIdx, Fr_SyncStateType* FrIf_SyncStatePtr)</pre>	
Service ID[hex]:	0x16	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	FrIf_SyncStatePtr	Pointer to a memory location where output value will be stored.
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_GetSyncState()	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

Parameter FrIf_SyncStatePtr: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_POINTER) if FrIf_SyncStatePtr has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_GetSyncState() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

6. Setting parameters

- Fr_SyncStatePtr to FrIf_SyncStatePtr

7. Calling Fr_GetSyncState() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.12 Frlf_SetExtSync

Frlf05013:

Service name:	Frlf_SetExtSync	
Syntax:	<pre>Std_ReturnType Frlf_SetExtSync(uint8 Frlf_CtrlIdx, Fr_OffsetCorrectionType Frlf_Offset, Fr_RateCorrectionType Frlf_Rate)</pre>	
Service ID[hex]:	0x17	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of Frlf_CtrlIdx, reentrant for different values of Frlf_CtrlIdx	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_Offset	Offset correction that shall be applied
	Frlf_Rate	Rate correction that shall be applied
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_SetExtSync().	

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if Frlf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function [Fr_SetExtSync\(\)](#) by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

8. Setting parameters

- Fr_Rate to Frlf_Rate
- Fr_Offset to Frlf_Offset
- Calling [Fr_SetExtSync\(\)](#) of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of [Frlf_Init\(\)](#) before this API service may be called, see [[Frlf05389](#)].

8.3.13 Frlf_GetPOCStatus

Frlf05014:

Service name:	Frlf_GetPOCStatus	
Syntax:	<pre>Std_ReturnType Frlf_GetPOCStatus(uint8 Frlf_CtrlIdx, Fr_POCStatusType* Frlf_POCStatusPtr)</pre>	
Service ID[hex]:	0x19	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of Frlf_CtrlIdx, reentrant for different values of Frlf_CtrlIdx	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	Frlf_POCStatusPtr	Pointer to a memory location where output value will be stored.
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_GetPOCStatus().	

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if Frlf_CtrlIdx has an invalid value.

Parameter Frlf_POCStatusPtr: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_POINTER](#)) if Frlf_POCStatusPtr has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_GetPOCStatus() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

9. Setting parameters

- Fr_POCStatusPtr to Frlf_POCStatusPtr

10. Calling Fr_GetPOCStatus() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [\[Frlf05389\]](#).

8.3.14 Frlf_GetGlobalTime

Frlf05015:

Service name:	Frlf_GetGlobalTime
----------------------	--------------------

Syntax:	Std_ReturnType FrIf_GetGlobalTime(uint8 FrIf_CtrlIdx, uint8* FrIf_CyclePtr, uint16* FrIf_MacroTickPtr)	
Service ID[hex]:	0x1a	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	FrIf_CyclePtr	Pointer to a memory location where output value will be stored.
	FrIf_MacroTickPtr	Pointer to a memory location where output value will be stored.
	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_GetGlobalTime().	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e.

[FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_GetGlobalTime() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

11. Setting parameters

- Fr_CyclePtr to FrIf_CyclePtr
- Fr_MacroTickPtr to FrIf_MacroTickPtr

12. Calling Fr_GetGlobalTime() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [\[FrIf05389\]](#).

8.3.15 FrIf_AllowColdstart

FrIf05017:

Service name:	FrIf_AllowColdstart
Syntax:	Std_ReturnType FrIf_AllowColdstart(uint8 FrIf_CtrlIdx)
Service ID[hex]:	0x35
Sync/Async:	Asynchronous

Reentrancy:	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_AllowColdstart().	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_AllowColdstart() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

13. Calling Fr__AllowColdstart() of the determined FlexRay Driver

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.16 FrIf_GetMacroticksDuration

FrIf0501x:

Service name:	FrIf_GetMacroticksDuration	
Syntax:	uint16 FrIf_GetMacroticksDuration(uint8 FrIf_CtrlIdx)	
Service ID[hex]:	0x1b	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	uint16	Number of nanoseconds of one Macrotick
Description:	Retrieves the duration of one Macrotick in nanoseconds	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface retrieves the number of Macroticks per FlexRay Cycle of the FlexRay Cluster with index FrIf_CtrlIdx out of the static configuration.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.17 FrIf_Transmit

FrIf05033:

Service name:	FrIf_Transmit	
Syntax:	<pre>Std_ReturnType FrIf_Transmit(PduIdType FrIf_TxPduId, const PduInfoType * FrIf_PduInfoPtr)</pre>	
Service ID[hex]:	0x06	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of FrIf_TxPduId, reentrant for different values of FrIf_TxPduId	
Parameters (in):	FrIf_TxPduId	ID of FlexRay PDU to be transmitted.
	FrIf_PduInfoPtr	Pointer to a structure with FlexRay PDU related data.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: No error has occurred during the execution of this API service. E_NOT_OK: An error occurred during execution of this API service: <ul style="list-style-type: none">• FlexRay Driver reported an error in case of immediate transmission• An error has been detected in development mode
Description:	Requests the sending of a PDU.	

Parameter FrIf_TxPduId: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_TXPDUID) if FrIf_TxPduId has an invalid value.

Parameter FrIf_PduInfoPtr:

FRIF_E_INV_POINTER shall be reported to DET in case FrIf_PduInfoPtr equals NULL_PTR

If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_POINTER) if SduDataPtr in FrIf_PduInfoPtr equals NULL_PTR.

This API service of the FlexRay Interface allows upper layer [BSW](#) modules to request the sending of a PDU via the FlexRay Communication System.

In case of decoupled transmission the PDU with index `Frlf_TxPduld` is **not yet** passed to the underlying FlexRay Driver for transmission. `Frlf` only remembers the PDU's transmission request (increment `TrigTxCounter`⁹). This decoupling mechanism between the call of `Frlf_Transmit()` and the execution of the [`FrlfCommunicationAction`](#) has some implications:

- The upper layer BSW module may operate asynchronously to the FlexRay Communication System and thus may call `Frlf_Transmit()` at any point in time.
- The upper layer [BSW](#) module must permanently buffer the PDU's payload data and must be able to handle a call of its `<UL_TriggerTransmit>()` API service at (from the [BSW](#)'s point of view) any arbitrary point in time.

In case of immediate transmission the PDU (single PDU, no Update bit) is passed to the underlying FlexRay Driver immediately for transmission.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [[Frlf05389](#)].

8.3.18 Frlf_SetTransceiverMode

`Frlf05034`:

Service name:	<code>Frlf_SetTransceiverMode</code>	
Syntax:	<pre>Std_ReturnType Frlf_SetTransceiverMode(uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx, FrTrcv_TrccvModeType FrIf_TrccvMode)</pre>	
Service ID[hex]:	0x28	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>FrIf_CtrlIdx</code> .
	<code>FrIf_TrccvMode</code>	Transceiver mode to be set.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
Description:	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_SetTransceiverMode()</code>	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

⁹ Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

Parameter `Frlf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `Frlf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_SetTransceiverMode()` by:

1. Translating (based on static `Frlf` configuration) the tuple (FlexRay [CC](#) index `Frlf_CtrllIdx` | FlexRay Channel index `Frlf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).
2. Setting parameters
 - `FrTrcv_TrcvMode` to `Frlf_TrcvMode`
3. Calling `FrTrcv_SetTransceiverMode()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [[Frlf05389](#)].

8.3.19 Frlf_GetTransceiverMode

`Frlf05035`:

Service name:	<code>Frlf_GetTransceiverMode</code>					
Syntax:	<pre>Std_ReturnType Frlf_GetTransceiverMode(uint8 Frlf_CtrllIdx, Fr_ChannelType Frlf_ChnlIdx, FrTrcv_TrcvModeType* Frlf_TrcvModePtr)</pre>					
Service ID[hex]:	0x2a					
Sync/Async:	Synchronous					
Reentrancy:	Reentrant					
Parameters (in):	<table border="1"> <tr> <td><code>Frlf_CtrllIdx</code></td> <td>Index of the FlexRay CC to address.</td> </tr> <tr> <td><code>Frlf_ChnlIdx</code></td> <td>Index of the FlexRay Channel to address in scope of the FlexRay controller <code>Frlf_CtrllIdx</code>.</td> </tr> </table>	<code>Frlf_CtrllIdx</code>	Index of the FlexRay CC to address.	<code>Frlf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>Frlf_CtrllIdx</code> .	
<code>Frlf_CtrllIdx</code>	Index of the FlexRay CC to address.					
<code>Frlf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>Frlf_CtrllIdx</code> .					
Parameters (inout):	None					
Parameters (out):	<code>Frlf_TrcvModePtr</code>	Pointer to a memory location where output value will be stored.				
Return value:	<code>Std_ReturnType</code>	<ul style="list-style-type: none"> E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR. 				
Description:	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_GetTransceiverMode()</code> .					

Parameter `Frlf_CtrllIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrllIdx` has an invalid value.

Parameter `Frlf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `Frlf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API

function FrTrcv_GetTransceiverMode() by:

1. Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index FrIf_CtrIdx | FlexRay Channel index FrIf_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv_TrcvIdx).
2. Setting parameters
 - FrTrcv_TrcvModePtr to FrIf_TrcvModePtr
3. Calling FrTrcv_GetTransceiverMode() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.20 FrIf_GetTransceiverWUReason

FrIf05036:

Service name:	FrIf_GetTransceiverWUReason	
Syntax:	<pre>Std_ReturnType FrIf_GetTransceiverWUReason(uint8 FrIf_CtrIdx, Fr_ChannelType FrIf_ChnlIdx, FrTrcv_TrcvWUReasonType* FrIf_TrcvWUReasonPtr)</pre>	
Service ID[hex]:	0x2b	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_CtrIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrIdx.
Parameters (inout):	None	
Parameters (out):	FrIf_TrcvWUReasonPtr	Pointer to a memory location where output value will be stored.
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
Description:	Wraps the FlexRay Transceiver Driver API function FrTrcv_GetTransceiverWUReason()	

Parameter FrIf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrIdx has an invalid value.

Parameter FrIf_ChnlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CHNL_IDX) if FrIf_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function FrTrcv_GetTransceiverWUReason() by:

1. Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index FrIf_CtrlIdx | FlexRay Channel index FrIf_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv_TrsvIdx).
2. Setting parameters
 - FrTrcv_TrsvWUReasonPtr to FrIf_WUReasonPtr
3. Calling FrTrcv_GetTransceiverWUReason() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.21 FrIf_EnableTransceiverWakeups

FrIf05037:

Service name:	FrIf_EnableTransceiverWakeups	
Syntax:	<pre>Std_ReturnType FrIf_EnableTransceiverWakeups(uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx)</pre>	
Service ID[hex]:	0x2c	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	<pre>Std_ReturnType E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.</pre>	
Description:	Wraps the FlexRay Transceiver Driver API function FrTrcv_EnableTransceiverWakeups().	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

Parameter FrIf_ChnlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CHNL_IDX) if FrIf_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function FrTrcv_EnableTransceiverWakeups() by:

Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index FrIf_CtrlIdx | FlexRay Channel index FrIf_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv_TrsvIdx).

Calling FrTrcv_EnableTransceiverWakeups() of the determined FlexRay Driver with

the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

8.3.22 FrIf_DisableTransceiverWakeup

FrIf05038:

Service name:	FrIf_DisableTransceiverWakeup	
Syntax:	<pre>Std_ReturnType FrIf_DisableTransceiverWakeup(uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx)</pre>	
Service ID[hex]:	0x2e	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
Description:	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_DisableTransceiverWakeup()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_DisableTransceiverWakeup()` by:

Translating (based on static `FrIf` configuration) the tuple (FlexRay CC index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).

Calling `FrTrcv_DisableTransceiverWakeup()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

8.3.23 FrIf_ClearTransceiverWakeUp

FrIf05039:

Service name:	FrIf_ClearTransceiverWakeUp	
Syntax:	<pre>Std_ReturnType FrIf_ClearTransceiverWakeUp(uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx)</pre>	
Service ID[hex]:	0x30	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
Description:	Wraps the FlexRay Transceiver Driver API function FrTrcv_EnableTransceiverWakeUp().	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

Parameter FrIf_ChnlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CHNL_IDX) if FrIf_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function FrTrcv_EnableTransceiverWakeUp() by:

Translating (based on static FrIf configuration) the tuple (FlexRay CC index FrIf_CtrlIdx | FlexRay Channel index FrIf_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv_TrsvIdx).

Calling FrTrcv_EnableTransceiverWakeUp() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.3.24 FrIf_GetCycleLength

Service name:	FrIf_GetCycleLength	
Syntax:	<pre>uint32 FrIf_GetCycleLength(uint8 FrIf_CtrlIdx)</pre>	
Service ID[hex]:	0x3a	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	uint32	Time in unit of nanoseconds
Description:	This API returns the configured time of the configuration parameter "GdCycle" in nanoseconds for the FlexRay controller with index FrIf_CtrlIdx.	

FrIf05237: If parameter FrIf_CtrlIdx of FrIf_GetCycleLength has an invalid value and if development error detection is enabled (i.e. FRIF_DEV_ERROR_DETECT equals ON), the function FrIf_GetCycleLength shall report development error code FRIF_E_INV_CTRL_IDX to the Det_ReportError service of the DET module.

FrIf05238: Caveats of FrIf_GetCycleLength: The FlexRay Interface module has to be initialized with a call of FrIf_Init() before this API service may be called, see FrIf05002.

8.4 Optional Function Definitions

8.4.1 Frlf_SetAbsoluteTimer

Frlf05021:

Service name:	Frlf_SetAbsoluteTimer	
Syntax:	<pre>Std_ReturnType Frlf_SetAbsoluteTimer(uint8 FrIf_CtrlIdx, uint8 FrIf_AbsTimerIdx, uint8 FrIf_Cycle, uint16 FrIf_Offset)</pre>	
Service ID[hex]:	0x1e	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_AbsTimerIdx	Index of the absolute timer to address.
	FrIf_Cycle	FlexRay Cycle number to be set.
Parameters (inout):	FrIf_Offset	Number of Macroticks to be set.
	None	
	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_SetAbsoluteTimer().	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. `FRIF_DEV_ERROR_DETECT` equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_SetAbsoluteTimer()` by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

2. Setting parameters

- `Fr_AbsTimerIdx` to `Frlf_AbsTimerIdx`
- `Fr_Cycle` to `Frlf_Cycle`
- `Fr_Offset` to `Frlf_Offset`

3. Calling `Fr_SetAbsoluteTimer()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [[Frlf05389](#)].

8.4.2 Frlf_SetRelativeTimer

Frlf05022:

Service name:	Frlf_SetRelativeTimer						
Syntax:	Std_ReturnType Frlf_SetRelativeTimer(uint8 Frlf_CtrlIdx, uint8 Frlf_RelTimerIdx, uint16 Frlf_Offset)						
Service ID[hex]:	0x1f						
Sync/Async:	Synchronous						
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs						
Parameters (in):	<table> <tr> <td>Frlf_CtrlIdx</td> <td>Index of the FlexRay CC to address.</td> </tr> <tr> <td>Frlf_RelTimerIdx</td> <td>Index of the relative timer to address.</td> </tr> <tr> <td>Frlf_Offset</td> <td>Number of Macroticks the relative timer shall be set to.</td> </tr> </table>	Frlf_CtrlIdx	Index of the FlexRay CC to address.	Frlf_RelTimerIdx	Index of the relative timer to address.	Frlf_Offset	Number of Macroticks the relative timer shall be set to.
Frlf_CtrlIdx	Index of the FlexRay CC to address.						
Frlf_RelTimerIdx	Index of the relative timer to address.						
Frlf_Offset	Number of Macroticks the relative timer shall be set to.						
Parameters (inout):	None						
Parameters (out):	None						
Return value:	Std_ReturnType <table> <tr> <td>E_OK:</td> <td>The call of the FlexRay Driver's API service has returned E_OK.</td> </tr> <tr> <td>E_NOT_OK:</td> <td>The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.</td> </tr> </table>	E_OK:	The call of the FlexRay Driver's API service has returned E_OK.	E_NOT_OK:	The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.		
E_OK:	The call of the FlexRay Driver's API service has returned E_OK.						
E_NOT_OK:	The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.						
Description:	Wraps the FlexRay Driver API function Fr_SetRelativeTimer().						

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if Frlf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_SetRelativeTimer() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

Setting parameters

- Fr_RelTimerIdx to Frlf_RelTimerIdx
- Fr_Offset to Frlf_Offset
- Calling Fr_SetRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [[Frlf05389](#)].

8.4.3 Frlf_CancelAbsoluteTimer

Frlf05023:

Service name:	Frlf_CancelAbsoluteTimer
Syntax:	Std_ReturnType Frlf_CancelAbsoluteTimer(uint8 Frlf_CtrlIdx, uint8 Frlf_AbsTimerIdx)
Service ID[hex]:	0x20
Sync/Async:	Synchronous

Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	Frlf_AbsTimerIdx Index of the absolute timer to address.	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_CancelAbsoluteTimer().	

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_CancelAbsoluteTimer() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

- Setting parameters
- Fr_AbsTimerIdx to Frlf_AbsTimerIdx
- Calling Fr_AbsoluteRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Calling Fr_AbsoluteRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [[Frlf05389](#)].

8.4.4 Frlf_CancelRelativeTimer

Frlf05024:

Service name:	Frlf_CancelRelativeTimer	
Syntax:	Std_ReturnType Frlf_CancelRelativeTimer(uint8 Frlf_CtrlIdx, uint8 Frlf_RelTimerIdx)	
Service ID[hex]:	0x21	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_RelTimerIdx	Index of the relative timer to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has

	returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_CancelAbsoluteTimer().

Parameter Frlf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if Frlf_CtrIdx has an invalid value. Frlf_EnableAbsoluteTimerIRQ

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_CancelRelativeTimer() by:

1. Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).
2. Setting parameters
 - Fr_RelTimerIdx to Frlf_RelTimerIdx
3. Calling Fr_CancelRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [\[Frlf05389\]](#).

8.4.5 Frlf_EnableAbsoluteTimerIRQ

Frlf05025:

Service name:	Frlf_EnableAbsoluteTimerIRQ					
Syntax:	<pre>Std_ReturnType Frlf_EnableAbsoluteTimerIRQ(uint8 Frlf_CtrIdx, uint8 Frlf_AbsTimerIdx)</pre>					
Service ID[hex]:	0x22					
Sync/Async:	Synchronous					
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs					
Parameters (in):	<table border="0"> <tr> <td>Frlf_CtrIdx</td> <td>Index of the FlexRay CC to address.</td> </tr> <tr> <td>Frlf_AbsTimerIdx</td> <td>Index of the absolute timer to address.</td> </tr> </table>		Frlf_CtrIdx	Index of the FlexRay CC to address.	Frlf_AbsTimerIdx	Index of the absolute timer to address.
Frlf_CtrIdx	Index of the FlexRay CC to address.					
Frlf_AbsTimerIdx	Index of the absolute timer to address.					
Parameters (inout):	None					
Parameters (out):	None					
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.				
Description:	Wraps the FlexRay Driver API function Fr_EnableAbsoluteTimerIRQ().					

Parameter Frlf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using [FRIF_E_INV_CTRL_IDX](#)) if Frlf_CtrIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_EnableAbsoluteTimerIRQ() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).
2. Setting parameters
 - Fr_AbsTimerIdx to FrIf_AbsTimerIdx
3. Calling Fr_EnableAbsoluteTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.4.6 FrIf_EnableRelativeTimerIRQ

FrIf05026:

Service name:	FrIf_EnableRelativeTimerIRQ				
Syntax:	Std_ReturnType FrIf_EnableRelativeTimerIRQ(uint8 FrIf_CtrlIdx, uint8 FrIf_RelTimerIdx)				
Service ID[hex]:	0x23				
Sync/Async:	Synchronous				
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs				
Parameters (in):	<table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>FrIf_CtrlIdx</td> <td>Index of the FlexRay CC to address.</td> </tr> </table> <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>FrIf_RelTimerIdx</td> <td>Index of the relative timer to address.</td> </tr> </table>	FrIf_CtrlIdx	Index of the FlexRay CC to address.	FrIf_RelTimerIdx	Index of the relative timer to address.
FrIf_CtrlIdx	Index of the FlexRay CC to address.				
FrIf_RelTimerIdx	Index of the relative timer to address.				
Parameters (inout):	None				
Parameters (out):	None				
Return value:	<table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>Std_ReturnType</td> <td>E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.</td> </tr> </table>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.		
Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.				
Description:	Wraps the FlexRay Driver API function Fr_EnableRelativeTimerIRQ() .				

Parameter `Frlf_CtrIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_EnableRelativeTimerIRQ()` by:

1. Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrIdx`).
2. Setting parameters
 - `Fr_AbsTimerIdx` to `Frlf_AbsTimerIdx`
3. Calling `Fr_EnableRelativeTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [[Frlf05389](#)].

8.4.7 Frlf_GetAbsoluteTimerIRQStatus

Frlf05027:

Service name:	<code>Frlf_GetAbsoluteTimerIRQStatus</code>	
Syntax:	<pre>Std_ReturnType Frlf_GetAbsoluteTimerIRQStatus(uint8 Frlf_CtrIdx, uint8 Frlf_AbsTimerIdx, boolean* Frlf_IRQStatusPtr)</pre>	
Service ID[hex]:	0x39	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	<code>Frlf_CtrIdx</code>	Index of the FlexRay CC to address.
	<code>Frlf_AbsTimerIdx</code>	Index of the absolute timer to address.
Parameters (inout):	None	
Parameters (out):	<code>Frlf_IRQStatusPtr</code>	Pointer to a memory location where output value will be stored.
Return value:	<code>Std_ReturnType</code>	<code>E_OK</code> : The call of the FlexRay Driver's API service has returned <code>E_OK</code> . <code>E_NOT_OK</code> : The call of the FlexRay Driver's API service has returned <code>E_NOT_OK</code> , or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function <code>Fr_GetAbsoluteTimerIRQStatus()</code>	

Parameter `Frlf_CtrIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_GetAbsoluteTimerIRQStatus() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).
2. Setting parameters
 - Fr_AbsTimerIdx to FrIf_AbsTimerIdx
 - Fr_IRQStatusPtr to FrIf_IRQStatusPtr
3. Calling Fr_GetAbsoluteTimerIRQStatus() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [\[FrIf05389\]](#).

8.4.8 FrIf_GetRelativeTimerIRQStatus

FrIf05028:

Service name:	FrIf_GetRelativeTimerIRQStatus	
Syntax:	<pre>Std_ReturnType FrIf_GetRelativeTimerIRQStatus(uint8 FrIf_CtrlIdx, uint8 FrIf_RelTimerIdx, boolean* FrIf_IRQStatusPtr)</pre>	
Service ID[hex]:	0x3a	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_RelTimerIdx	Index of the relative timer to address.
Parameters (inout):	None	
Parameters (out):	FrIf_IRQStatusPtr	Pointer to a memory location where output value will be stored.
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_GetRelativeTimerIRQStatus().	

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_GetRelativeTimerIRQStatus()` by:

1. Translating (based on static FrIf configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
 - `Fr_RelTimerIdx` to `FrIf_RelTimerIdx`
 - `Fr_IRQStatusPtr` to `FrIf_IRQStatusPtr`
3. Calling `Fr_GetRelativeTimerIRQStatus()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [[FrIf05389](#)].

8.4.9 `FrIf_AckAbsoluteTimerIRQ`

FrIf05029:

Service name:	<code>FrIf_AckAbsoluteTimerIRQ</code>	
Syntax:	<pre>Std_ReturnType FrIf_AckAbsoluteTimerIRQ(uint8 FrIf_CtrlIdx, uint8 FrIf_AbsTimerIdx)</pre>	
Service ID[hex]:	0x24	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	<code>FrIf_CtrlIdx</code> Index of the FlexRay CC to address. <code>FrIf_AbsTimerIdx</code> Index of the absolute timer to address.	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function <code>Fr_AckAbsoluteTimerIRQ()</code>	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_AckAbsoluteTimerIRQ() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).
2. Setting parameters
 - Fr_AbsTimerIdx to FrIf_AbsTimerIdx
3. Calling Fr_AckAbsoluteTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.4.10 FrIf_AckRelativeTimerIRQ

FrIf05030:

Service name:	FrIf_AckRelativeTimerIRQ				
Syntax:	Std_ReturnType FrIf_AckRelativeTimerIRQ(uint8 FrIf_CtrIdx, uint8 FrIf_RelTimerIdx)				
Service ID[hex]:	0x25				
Sync/Async:	Synchronous				
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs				
Parameters (in):	<table border="0"> <tr> <td>FrIf_CtrIdx</td> <td>Index of the FlexRay CC to address.</td> </tr> <tr> <td>FrIf_RelTimerIdx</td> <td>Index of the relative timer to address.</td> </tr> </table>	FrIf_CtrIdx	Index of the FlexRay CC to address.	FrIf_RelTimerIdx	Index of the relative timer to address.
FrIf_CtrIdx	Index of the FlexRay CC to address.				
FrIf_RelTimerIdx	Index of the relative timer to address.				
Parameters (inout):	None				
Parameters (out):	None				
Return value:	<table border="0"> <tr> <td>Std_ReturnType</td> <td>E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.</td> </tr> </table>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.		
Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.				
Description:	Wraps the FlexRay Driver API function Fr_AckRelativeTimerIRQ().				

Parameter FrIf_CtrIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_AckRelativeTimerIRQ() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrIdx).
2. Setting parameters
 - Fr_AbsTimerIdx to FrIf_AbsTimerIdx
3. Calling Fr_AckRelativeTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.4.11 FrIf_DisableAbsoluteTimerIRQ

FrIf05031:

Service name:	FrIf_DisableAbsoluteTimerIRQ
Syntax:	Std_ReturnType FrIf_DisableAbsoluteTimerIRQ(uint8 FrIf_CtrlIdx, uint8 FrIf_AbsTimerIdx)
Service ID[hex]:	0x26
Sync/Async:	Synchronous
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs
Parameters (in):	FrIf_CtrlIdx Index of the FlexRay CC to address. FrIf_AbsTimerIdx Index of the absolute timer to address.
Parameters (inout):	None
Parameters (out):	None
Return value:	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_DisableAbsoluteTimerIRQ().

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_DisableAbsoluteTimerIRQ() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).
2. Setting parameters
 - Fr_AbsTimerIdx to FrIf_AbsTimerIdx
3. Calling Fr_DisableAbsoluteTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.4.12 FrIf_DisableRelativeTimerIRQ

FrIf05032:

Service name:	FrIf_DisableRelativeTimerIRQ
Syntax:	Std_ReturnType FrIf_DisableRelativeTimerIRQ(uint8 FrIf_CtrlIdx, uint8 FrIf_RelTimerIdx)
Service ID[hex]:	0x27

Sync/Async:	Synchronous	
Reentrancy:	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_RelTimerIdx	Index of the relative timer to address.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
Description:	Wraps the FlexRay Driver API function Fr_DisableRelativeTimerIRQ().	

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr_DisableRelativeTimerIRQ() by:

1. Translating (based on static Frlf configuration) the FlexRay CC index Frlf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).
2. Setting parameters
 - Fr_RelTimerIdx to Frlf_RelTimerIdx
3. Calling Fr_DisableRelativeTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [\[Frlf05389\]](#).

8.4.13 Frlf_GetNmVector

Frlf05016:

Service name:	Frlf_GetNmVector	
Syntax:	<pre>Std_ReturnType Frlf_GetNmVector(uint8 Frlf_CtrlIdx, uint8* Frlf_CyclePtr, uint8* Frlf_NmVectorPtr)</pre>	
Service ID[hex]:	0x34	
Sync/Async:	Synchronous	
Reentrancy:	non reentrant for identical values of Frlf_CtrlIdx, reentrant for different values of Frlf_CtrlIdx	
Parameters (in):	Frlf_CtrlIdx	Index of the FlexRay CC to address.
Parameters (inout):	None	
Parameters (out):	Frlf_CyclePtr	Pointer to a memory location where output value will be stored.
	Frlf_NmVectorPtr	Pointer to a memory location where output value will be stored.
Return value:	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.

Description:	Derives the FlexRay NM Vector.
---------------------	--------------------------------

Parameter FrIf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if FrIf_CtrlIdx has an invalid value.

This API service of the FlexRay Interface derives the FlexRay NM Vector by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr_CtrlIdx).

14. Setting parameters

- Fr_CyclePtr to FrIf_CyclePtr
- Fr_NmVectorPtr to FrIf_NmVectorPtr

Calling Fr_GetNmVector() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.5 Interrupt Service Routines

8.5.1 FrIf_JobListExec_<ClstIdx>

FrIf05040:

Service name:	FrIf_JobListExec_<ClstIdx>
Syntax:	void FrIf_JobListExec_<ClstIdx>()
Service ID[hex]:	0x32
Sync/Async:	Synchronous
Reentrancy:	Non Reentrant
Parameters (in):	None
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	Processes the FlexRay Job List of the FlexRay Cluster with index ClstIdx.

This API service of the FlexRay Interface processes the FlexRay Job List of the FlexRay Cluster with index ClstIdx.

For a detailed description of this API service, please refer to chapter 7.6.2.2.

Caveats: This API service of the FlexRay Interface exists once per FlexRay Cluster. The API name contains the index of the respective FlexRay Cluster (ClstIdx).

For each FlexRay Cluster (identified by index ClstIdx), the respective API service FrIf_JobListExec_<ClstIdx> must be registered in the AUTOSAR OS as the [ISR](#) of an absolute timer of a FlexRay [CC](#) connected to the FlexRay Cluster with index ClstIdx, if the CC does **not guarantee asynchronous buffer access**.

The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

Note:

If the CC guarantees asynchronous buffer access, the execution of FrIf_JobListExec<ClstIdx> can run in a regular OS task.

8.6 Call-back Notifications

This is a list of functions provided for other modules. The function prototypes of the callback functions shall be provided in the file Frlf_Cbk.h

8.6.1 Frlf_Cbk_WakeupByTransceiver

Frlf05041:

Service name:	Frlf_Cbk_WakeupByTransceiver
Syntax:	void Frlf_Cbk_WakeupByTransceiver(uint8 Frlf_CtrlIdx, Fr_ChannelType Frlf_ChnlIdx)
Service ID[hex]:	0x3b
Sync/Async:	Synchronous
Reentrancy:	Reentrant
Parameters (in):	Frlf_CtrlIdx Index of the FlexRay CC to address. Frlf_ChnlIdx Index of the FlexRay Channel to address in scope of the FlexRay controller Frlf_CtrlIdx.
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	Wraps the FlexRay Transceiver Driver API function FrTrcv_Cbk_WakeupByTransceiver().

Parameter Frlf_CtrlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CTRL_IDX) if Frlf_CtrlIdx has an invalid value.

Parameter Frlf_ChnlIdx: If development error detection is enabled (i.e. [FRIF_DEV_ERROR_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF_E_INV_CHNL_IDX) if Frlf_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function FrTrcv_Cbk_WakeupByTransceiver() by:

Translating (based on static [Frlf](#) configuration) the tuple (FlexRay CC index Frlf_CtrlIdx | FlexRay Channel index Frlf_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv_TrsvIdx).

Calling FrTrcv_CbkWakeupByTransceiver() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf_Init() before this API service may be called, see [[Frlf05389](#)].

8.7 Scheduled Functions

8.7.1 FrIf_MainFunction_<ClstIdx>

FrIf05042:

Service name:	FrIf_MainFunction_<ClstIdx>
Syntax:	void FrIf_MainFunction_<ClstIdx>()
Service ID[hex]:	0x33
Timing:	VARIABLE_CYCLIC
Description:	This function will be called cyclically by a task body provided by the BSW Scheduler.

This cyclically executed API service of the FlexRay Interface serves the following purposes:

- Initially program the absolute timer interrupt in order to start the execution of FrIf_JobListExec_<ClstIdx>() if the CC does not support asynchronous buffer access.
- Monitoring the proper (in time) execution of the FrIf_JobListExec_<ClstIdx>() and resynchronize the Joblist if necessary.

Please refer to chapter 7.3 for a detailed description.

Pre condition: This API service of the FlexRay Interface is cyclically called from a task body provided by the [BSW](#) Scheduler.

Since the duration of a FlexRay Cycle may be different for two Clusters of an ECU, the calling period of this API service shall be configurable independently for each Cluster [at system configuration time](#).

Caveats: This API service of the FlexRay Interface exists once per FlexRay Cluster. The API name contains the index of the respective FlexRay Cluster (ClstIdx).

The FlexRay Interface has to be initialized with a call of FrIf_Init() before this API service may be called, see [[FrIf05389](#)].

8.8 Expected Interfaces

This chapter lists all API services required from other [BSW](#) modules.

8.8.1 Mandatory Interfaces

This chapter defines all API services which are required from other [BSW](#) modules to fulfill the core functionality of the FlexRay Interface.

FrIf05043:

API function	Description
Fr_PrepareLPdu	Prepares a LPdu.
Fr_DisableRelativeTimerIRQ	Disables the interrupt line of a timer.
Fr_SetWakeupChannel	Sets a wakeup channel.
Fr_GetNmVector	Gets the network management vector of the last communication cycle.
Fr_GetRelativeTimerIRQStatus	Gets IRQ status of a relative timer.
Fr_SetExtSync	Adjusts the global time of a FlexRay CC to an external clock source.
Fr_GetGlobalTime	Gets the current global FlexRay time.
Fr_SendWUP	Invokes the CC CHI command 'WAKEUP'.
Fr_GetAbsoluteTimerIRQStatus	Gets IRQ status of an absolute timer.
Fr_SetAbsoluteTimer	Sets the absolute FlexRay timer.
Fr_SendMTS	Triggers a MTS.
Fr_AllowColdstart	Invokes the CC CHI command 'ALLOW_COLDSTART'.
Fr_StopMTS	Stops the periodic transmission of MTS symbols.
Fr_StartCommunication	Starts communication.
Fr_DisableAbsoluteTimerIRQ	Disables the interrupt line of an absolute timer.
Fr_GetVersionInfo	Returns the version information of this module.
Fr_AckRelativeTimerIRQ	Resets the interrupt condition of a relative timer.
Fr_CancelAbsoluteTimer	Stops an absolute timer.
Fr_AckAbsoluteTimerIRQ	Resets the interrupt condition of an absolute timer.
Fr_ControllerInit	Initializes a FlexRay CC.
Fr_Init	Initializes the Fr.
Fr_EnableRelativeTimerIRQ	Enables the interrupt line of a relative timer.
Fr_GetPOCStatus	Gets the POC status.
Fr_SetRelativeTimer	Sets the FlexRay timer.
Fr_CancelRelativeTimer	Stops a relative timer.
Fr_HaltCommunication	Invokes the CC CHI command 'HALT'.
Fr_GetSyncState	Gets the sync state.
Fr_CheckMTS	Checks the MTS.
Fr_CheckTxLPduStatus	Checks the transmit status of the LSdu.
Fr_TransmitTxLPdu	Transmits data on the FlexRay network.
Fr_ReceiveRxLPdu	Receives data from the FlexRay network.
Fr_AbortCommunication	Invokes the CC CHI command 'FREEZE'.
Fr_EnableAbsoluteTimerIRQ	Enables the interrupt line of an absolute timer.
FrTrcv_MainFunction	--
FrTrcv_SetTransceiverMode	This service returns the transceiver mode.
FrTrcv_ClearTransceiverWakeups	This function clears a pending wake up event.
FrTrcv_DisableTransceiverWakeups	This function disables the notification for wake up events on the addressed bus.
FrTrcv_EnableTransceiverWakeups	This function enables the notification for wake up events on the addressed bus.
FrTrcv_GetTransceiverWUReason	This function returns the wakeup reason.
FrTrcv_GetVersionInfo	This service returns the version information of this module.
FrTrcv_TrcvInit	This service initializes the FrTrcv.

FrTrcv_GetTransceiverMode	This function returns the actual state of the transceiver.
Dem_ReportErrorStatus	Reports errors to the DEM.

8.8.2 Optional Interfaces

This chapter defines all API services which are required from other [BSW](#) modules to fulfill an optional functionality of the FlexRay Interface

FrIf05044:

API function	Description
Det_ReportError	Service to report development errors.

8.8.3 Configurable Interfaces

This chapter lists all interfaces where the target API service of any upper layer, which require one or more of these mentioned interfaces to be called has to be set up by static configuration of the FlexRay Interface.

These call-out services are specified and implemented in the upper layer BSW modules, which use the FlexRay Interface according to [2]. The specific call-out notification is specified in the corresponding AUTOSAR SWS document (see chapter 3).

In addition to upper layer AUTOSAR BSW modules, the FrIf shall, with the functionality described within the specification in hand, also support other non-AUTOSAR upper layer software modules, provided that these modules interact with the FrIf in the same manner as the upper layer AUTOSAR BSW modules. In particular, those non-AUTOSAR modules need to provide APIs as described in this chapter. One example for such a non-AUTOSAR software module is a proprietary XCPonFlexRay module that users may add to their AUTOSAR BSW stack.

8.8.3.1 <UL_RxIndication>

FrIf05045:

Service name:	<UL_RxIndication>	
Syntax:	<pre>void <UL_RxIndication>(PduIdType FrIf_RxPduId, const PduInfoType* PduInfoPtr)</pre>	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_RxPduId, Non reentrant for the same FrIf_RxPduId	
Parameters (in):	FrIf_RxPduId	PDU-ID of FlexRay PDU that has been received

	PduInfoPtr	Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Indication of a received I-PDU from a lower layer communication module.	

Caveats: This API service is called during the execution of the FlexRay Job List Execution Function.

8.8.3.2 <UL_TxConfirmation>

FrIf05046:

Service name:	<UL_TxConfirmation>	
Syntax:	void <UL_TxConfirmation>(PduIdType FrIf_TxPduId)	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_TxPduId, Non reentrant for the same FrIf_TxPduId	
Parameters (in):	FrIf_TxPduId	PDU-ID of FlexRay PDU whose transmission is being confirmed
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	This API service of an upper layer BSW module (e.g. PduR, FrTp, FrNm) is called by the FlexRay Interface to confirm to this upper layer BSW module that the PDU with index FrIf_TxPduId has been transmitted via the FlexRay Communication System.	

Caveats: This API service is called during the execution of the FlexRay Job List Execution Function.

8.8.3.3 <UL_TriggerTransmit>

FrIf05047:

Service name:	<UL_TriggerTransmit>
---------------	----------------------

Syntax:	Std_ReturnType <UL_TriggerTransmit>(PduIdType FrIf_TxPduId, PduInfoType* PduInfoPtr)	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_TxPduId, Non reentrant for the same FrIf_TxPduId	
Parameters (in):	FrIf_TxPduId	PDU-ID of FlexRay PDU that shall be copied to the FrIf
Parameters (inout):	PduInfoPtr	Contains a pointer to a buffer (SduDataPtr) to where the SDU shall be copied to. On return, the service will indicate the length of the copied SDU data in SduLength.
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: SDU has been copied and SduLength indicates the number of copied bytes. E_NOT_OK: No SDU has been copied. PduInfoPtr must not be used since it may contain a NULL pointer or point to invalid data.
Description:	The lower layer communication module requests the buffer of the SDU for transmission from the upper layer module.	

Caveats: This API service is called during the execution of the FlexRay Job List Execution Function.

9 Sequence Diagrams

The sequence diagrams in this chapter show the basic operations carried out in a FlexRay Cluster's FlexRay Job List Execution Function when executing the various Communication Operations. They also show the interaction of the [FrIf](#) with the upper layer [BSW](#) module and with the underlying FlexRay Driver.

Please note that the sequence diagrams are an extension for illustrational purposes to ease understanding of the specification.

9.1 Data Transmission

9.1.1 TransmitWithImmediateBufferAccess




Figure 9-1: TransmitWithImmediateBufferAccess

9.1.2 TransmitWithDecoupledBufferAccess




Figure 9-2: TransmitWithDecoupledBufferAccess

9.1.3 ProvideTxConfirmation




Figure 9-3: ProvideTxConfirmation

9.2 Data Reception

9.2.1 ReceiveAndIndicate




Figure 9-4: ReceiveAndIndicate

9.2.2 ReceiveAndStore




Figure 9-5: ReceiveAndStore

9.2.3 ProvideRxIndication




Figure 9-6: ProvideRxIndication

10 Configuration Specification

This chapter defines configuration parameters and their clustering into containers.

Chapter 10.1 gives information to help understanding the subsequent chapters.

Chapter 10.2 specifies the structure (containers) and the parameters of the FlexRay Interface.

Chapter 10.3 specifies published information of the FlexRay Interface.

10.1 How to Read this Chapter

In addition to this section, it is highly recommended to read the documents:

- AUTOSAR Layered Software Architecture [2]
- AUTOSAR ECU Configuration Specification [13]

This document describes the AUTOSAR configuration methodology and the AUTOSAR configuration metamodel in detail.

The following is only a short survey of the topic and it will not replace the ECU Configuration Specification document.

10.1.1 Configuration and Configuration Parameters

Configuration parameters define the variability of the generic part(s) of an implementation of a module. This means that only generic or configurable module implementation can be adapted to the environment (software/hardware) in use during system and/or ECU configuration.

The configuration of parameters can be achieved at different times during the software process: [pre compile time](#), before [link time](#) or [post build time](#). In the following, the term "configuration class" (of a parameter) shall be used in order to refer to a specific configuration point in time.

Frlf05144:

All configuration data of the [Frlf](#) that is definable [at system configuration time](#) shall be re-loadable into the ECU [by a flashing process](#).

10.1.2 Variants

Variants describe sets of configuration parameters. E.g., variant 1: only pre-compile time configuration parameters; variant 2: mix of [pre compile-](#) and [post build time](#)-configuration parameters. In one variant, a parameter can only be of one configuration class.

10.1.3 Containers

FrIf05077:

Containers structure the set of configuration parameters. This means:

- all configuration parameters are kept in containers.
- (sub-) containers can reference (sub-) containers. It is possible to assign a multiplicity to these references. The multiplicity then defines the possible number of instances of the contained parameters.

10.1.4 Specification Template for Configuration Parameters

The following tables consist of three sections:

- the general section
- the configuration parameter section
- the section of included/referenced containers

Pre compile time

- specifies whether the configuration parameter shall be of configuration class [Pre-compile time](#) or not

Label	Description
X	The configuration parameter shall be of configuration class <u>Pre-compile time</u> .
--	The configuration parameter shall never be of configuration class <u>Pre-compile time</u> .

Link time

- specifies whether the configuration parameter shall be of configuration class [link time](#) or not

Label	Description
x	The configuration parameter shall be of configuration class <u>link time</u> .
--	The configuration parameter shall never be of configuration class <u>link time</u> .

Post build time

- specifies whether the configuration parameter shall be of configuration class [post build time](#) or not

Label	Description
x	The configuration parameter shall be of configuration class <u>post build time</u> and no specific implementation is required.
L	<i>Loadable</i> - the configuration parameter shall be of configuration class <u>post build time</u> and only one configuration parameter set resides in the ECU.
M	<i>Multiple</i> - the configuration parameter shall be of configuration class <u>post build time</u> and is selected out of a set of multiple parameters by passing a dedicated pointer to the init function of the module.
--	The configuration parameter shall never be of configuration class <u>post build time</u> .

10.2 Containers and Configuration Parameters

Frlf05070:

The following chapters summarize all configuration parameters. The detailed meanings of the parameters are described in chapter 7 and chapter 8.

The listed configuration items can be derived from a network description database, which is based on the EcuConfigurationTemplate. The configuration tool shall extract all information to configure the [Frlf](#).

Frlf05071:

The configuration tool must check the consistency of the configuration at configuration time.

Frlf05072:

Configuration rules and constraints for plausibility checks shall be performed during configuration time, wherever possible.

Frlf05073:

These dependencies between FlexRay Interface and FlexRay Driver configuration must be provided at configuration time by the configuration tools.

10.2.1 Variants

VARIANT-POST-BUILD: All configuration parameters in container 'FrlfGeneral' shall be configurable at pre-compile time. All other configuration parameters shall be configurable at post-build-time.

Use case: Object code delivery, selectable configuration

VARIANT-PRE-COMPILe: All configuration parameters shall be configurable at pre-compile time.

Use case: Execution time optimizations

10.2.2 Frlf

Module Name	<i>Frlf</i>
Module Description	Configuration of the Frlf (FlexRay Interface) module.

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrlfConfig	1	Configuration of the FlexRay Interface. This container is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.
FrlfGeneral	1	This container contains the general configuration parameters of the FlexRay Interface.

10.2.3 FrIfGeneral

SWS Item	FrIf05360 :		
Container Name	FrIfGeneral{FRIF_GENERAL_CONFIGURATION}		
Description	This container contains the general configuration parameters of the FlexRay Interface.		
Configuration Parameters			

SWS Item	FrIf06080 :		
Name	FrIfDevErrorDetect {FRIF_DEV_ERROR_DETECT}		
Description	Switches the Development Error Detection and Notification on or off true: Development Error Detection and Notification on false: Development Error Detection and Notification off		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrIf06114 :		
Name	FrIfGetNmVectorSupport {FRIF_GET_NM_VECTOR_SUPPORT}		
Description	Configuration parameter to enable/disable FrIf support to request the FlexRay hardware NMVector.		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrIf06081 :		
Name	FrIfNumClstSupported {FRIF_CLST_IDX_MAX_SUPPORTED}		
Description	Maximum number of FlexRay Clusters that the FlexRay Interface supports.		
Multiplicity	1		
Type	IntegerParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrIf06082 :		
Name	FrIfNumCtrlSupported {FRIF_CTRL_IDX_MAX_SUPPORTED}		
Description	Maximum number of FlexRay CCs that the FlexRay Interface supports		
Multiplicity	1		
Type	IntegerParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	FrIf06083 :		
Name	FrIfVersionInfoApi {FRIF_VERSION_INFO_API}		

Description	Enables/disables the existence of the FrIf_GetVersionInfo() API service true: FrIf_GetVersionInfo() API service exists false: FrIf_GetVersionInfo() API service does not exist		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

No Included Containers
10.2.4 FrIfCluster

SWS Item	FrIf05366 :		
Container Name	FrIfCluster{FRIF_CLUSTER}		
Description	This container specifies a FrIf Cluster and all related data which is required to enable communication of the Cluster. A Cluster may consist of more than one Controller.		
Configuration Parameters			

SWS Item	FrIf06002 :		
Name	FrIfClstIdx {FRIF_CLST_IDX}		
Description	This parameter provides a zero-based consecutive index of the FlexRay Clusters. Upper layer BSW modules and the FrIf itself use this index to identify a FlexRay Cluster.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILe
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIf06003 :		
Name	FrIfMainFunctionPeriod {FRIF_MAINFUNCTION_PERIOD}		
Description	The execution cycle of the FrIf_MainFunction_<cluster>() in seconds. The FrIf does not require this information but the BSW scheduler, which invokes the cluster main functions, needs it in order to plan its tasks.		
Multiplicity	1		
Type	FloatParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILe
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIf06004 :		
Name	FrIfMaxIsrDelay {FRIF_MAX_ISR_DELAY}		
Description	The maximum delay in macroticks the FrIf_JoblistExec_<cluster>() function is processed after the absolute timer interrupt was triggered.		
Multiplicity	1		
Type	IntegerParamDef		
Default value	--		

ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06005 :		
Name	GAssumedPrecision {G_ASSUMED_PRECISION}		
Description	Assumed precision of the application network		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 65535		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06006 :		
Name	GChannels {G_CHANNELS}		
Description	The channels that are used by the cluster. Implementation Type: Fr_ChannelType		
Multiplicity	FR_CHANNEL_A	Cluster uses channel A	
	FR_CHANNEL_AB	Cluster uses channel A and B Implementation Type: Fr_ChannelType	
	FR_CHANNEL_B	Cluster uses channel B	
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06007 :		
Name	GClusterDriftDamping {G_CLUSTER_DRIFT_DAMPING}		
Description	The cluster drift damping factor, based on the longest microtick gdMaxMicrotick used in the cluster. Used to compute the local cluster drift damping factor pClusterDriftDamping [Microticks].		
Multiplicity	1		
	Type	IntegerParamDef	
	Range	0 .. 5	
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06008 :		
Name	GColdStartAttempts {G_COLD_START_ATTEMPTS}		
Description	Maximum number of times a node in the cluster is permitted to attempt to start the cluster by initiating schedule synchronization		
Multiplicity	1		
	Type	IntegerParamDef	
	Range	2 .. 31	
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	

	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06009 :		
Name	GListenNoise {G_LISTEN_NOISE}		
Description	Upper limit for the start up listen timeout and wake up listen timeout in the presence of noise. It is used as a multiplier of the cluster parameter pdListenTimeout.		
Multiplicity	1		
Type	IntegerParamDef		
Range	2 .. 16		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06010 :		
Name	GMacroPerCycle {G_MACRO_PER_CYCLE}		
Description	Number of macroticks in a communication cycle.		
Multiplicity	1		
Type	IntegerParamDef		
Range	10 .. 16000		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module/Fr		

SWS Item	Frlf06011 :		
Name	GMaxWithoutClockCorrectFatal {G_MAX_WITHOUT_CLOCK_CORRECTION_FATAL}		
Description	Threshold used for testing the vClockCorrectionFailed counter. Defines the number of consecutive even/odd Cycle pairs with missing clock correction terms that will cause the protocol to transition from the POC:normal active or POC:normal passive state into the POC:halt state. [Even/odd cycle pairs].		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 15		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06012 :		
Name	GMaxWithoutClockCorrectPassive {G_MAX_WITHOUT_CLOCK_CORRECTION_PASSIVE}		
Description	Threshold used for testing the vClockCorrectionFailed counter. Defines the number of consecutive even/odd Cycle pairs with missing clock correction terms that will cause the protocol to transition from the POC:normal active state to the POC:normal passive state. [Even/Odd cycle pairs]		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 15		

Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06013 :		
Name	GNetworkManagementVectLength {G_NETWORK_MANAGEMENT_VECTOR_LENGTH}		
Description	Length of the Network Management vector in a cluster [bytes]		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 12		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06014 :		
Name	GNumberOfMinislots {G_NUMBER_OF_MINISLOTS}		
Description	Number of minislots in the dynamic segment		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 7986		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06015 :		
Name	GNumberOfStaticSlots {G_NUMBER_OF_STATIC_SLOTS}		
Description	Number of static slots in the static segment		
Multiplicity	1		
Type	IntegerParamDef		
Range	2 .. 1023		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06016 :		
Name	GOffsetCorrectionMax {G_OFFSET_CORRECTION_MAX}		
Description	describes the maximum value which the offset correction should assume in seconds.		
Multiplicity	1		
Type	FloatParamDef		
Range	5.0E-7 .. 3.811E-4		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06017 :		
Name	GOffsetCorrectionStart {G_OFFSET_CORRECTION_START}		
Description	Start of the offset correction phase within the NIT, expressed as the number of macroticks from the start of cycle.		
Multiplicity	1		
Type	IntegerParamDef		
Range	9 .. 15999		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06018 :		
Name	GPayloadLengthStatic {G_PAYLOAD_LENGTH_STATIC}		
Description	Payload length of a static frame [16 bit words]		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 127		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06019 :		
Name	GSyncNodeMax {G_SYNC_NODE_MAX}		
Description	Maximum number of nodes that may send frames with the sync frame indicator bit set to one.		
Multiplicity	1		
Type	IntegerParamDef		
Range	2 .. 15		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06020 :		
Name	GdActionPointOffset {GD_ACTION_POINT_OFFSET}		
Description	Number of Macroticks the action point is offset from the beginning of a Static Slots or symbol window.		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 63		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module/Fr		

SWS Item	Frlf06021 :		
Name	GdBit {GD_BIT}		
Description	Nominal bit time in seconds		
Multiplicity	1		
Type	FloatParamDef		

Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06022 :		
Name	GdBitMax {GD_BIT_MAX}		
Description	Maximum bit time taking into account the allowable clock deviation of each node (in seconds).		
Multiplicity	1		
Type	FloatParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06023 :		
Name	GdBitMin {GD_BIT_MIN}		
Description	Minimum bit time taking into account the allowable clock deviation of each node (in seconds).		
Multiplicity	1		
Type	FloatParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06024 :		
Name	GdCasRxLowMax {GD_CAS_RX_LOW_MAX}		
Description	Upper limit of the CAS acceptance window [gdBit]		
Multiplicity	1		
Type	IntegerParamDef		
Range	67 .. 99		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module/Fr		

SWS Item	Frlf06025 :		
Name	GdCycle {GD_CYCLE}		
Description	Length of the cycle, expressed in s		
Multiplicity	1		
Type	FloatParamDef		
Range	1.0E-5 .. 0.016		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06026 :		
Name	GdDynamicSlotIdlePhase {GD_DYNAMIC_SLOT_IDLE_PHASE}		

Description	Duration of the idle phase within a dynamic slot [Minislots].		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 2		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06027 :		
Name	GdMacrotick {GD_MACROTICK}		
Description	Duration of the cluster wide nominal macrotick, expressed in s		
Multiplicity	1		
Type	FloatParamDef		
Range	1.0E-6 .. 6.0E-6		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06028 :		
Name	GdMaxInitializationError {GD_MAX_INITIALIZATION_ERROR}		
Description	Maximum error that a node may have following integration in seconds.		
Multiplicity	1		
Type	FloatParamDef		
Range	0.0 .. 65535.0		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06029 :		
Name	GdMaxMicrotick {GD_MAX_MICROTICK}		
Description	Maximum Microtick length of all Microticks configured within a Cluster.		
Multiplicity	1		
Type	EnumerationParamDef		
Range	T100NS		
	T12_5NS		
	T200NS		
	T25NS		
	T50NS		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06030 :		
Name	GdMaxPropagationDelay {GD_MAX_PROPAGATION_DELAY}		
Description	Maximum propagation delay of a Cluster (in seconds).		
Multiplicity	1		
Type	FloatParamDef		

Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06031 :		
Name	GdMinPropagationDelay {GD_MIN_PROPAGATION_DELAY}		
Description	Minimum propagation delay of a Cluster (in seconds).		
Multiplicity	1		
Type	FloatParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06032 :		
Name	GdMiniSlotActionPointOffset {GD_MINI_SLOT_ACTION_POINT_OFFSET}		
Description	Number of Macroticks the Minislot action point is offset from the beginning of a Minislot [Macroticks].		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 31		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06033 :		
Name	GdMinislot {GD_MINISLOT}		
Description	Duration of a minislot [Macroticks]		
Multiplicity	1		
Type	IntegerParamDef		
Range	2 .. 63		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module/Fr		

SWS Item	Frlf06034 :		
Name	GdNit {GD_NIT}		
Description	Duration of the Network Idle Time [Macroticks]		
Multiplicity	1		
Type	IntegerParamDef		
Range	2 .. 767		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06035 :		
-----------------	--------------------	--	--

Name	GdSampleClockPeriod {GD_SAMPLE_CLOCK_PERIOD}		
Description	Sample clock period		
Multiplicity	1		
Type	EnumerationParamDef		
Range	T12_5NS		
	T25NS		
	T50NS		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIIf06036 :		
Name	GdStaticSlot {GD_STATIC_SLOT}		
Description	Duration of a Static Slot [Macroticks].		
Multiplicity	1		
Type	IntegerParamDef		
Range	4 .. 659		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIIf06037 :		
Name	GdSymbolWindow {GD_SYMBOL_WINDOW}		
Description	Duration of the symbol window [Macroticks].		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 139		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIIf06038 :		
Name	GdTssTransmitter {GD_TSS_TRANSMITTER}		
Description	Number of bits in the Transmission Start Sequence [gdBits].		
Multiplicity	1		
Type	IntegerParamDef		
Range	3 .. 15		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIIf06039 :		
Name	GdWakeupSymbolRxIdle {GD_WAKEUP_SYMBOL_RX_IDLE}		
Description	Number of bits used by the node to test the duration of the 'idle' portion of a received wakeup symbol. Duration is equal to (gdWakeupSymbolTxIdle - gdWakeupSymbolTxLow)/2 minus a safe part. (Collisions, clock differences, and other effects can deform the Tx-wakeup pattern.) [gdBit].		
Multiplicity	1		

Type	IntegerParamDef		
Range	14 .. 59		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06040 :		
Name	GdWakeUpSymbolRxLow {GD_WAKEUP_SYMBOL_RX_LOW}		
Description	Number of bits used by the node to test the LOW portion of a received wakeup symbol. This lower limit of zero bits has to be received to detect the LOW portion by the receiver. The duration is equal to gdWakeUpSymbolTxLow minus a safe part. (Active stars, clock differences, and other effects can deform the Tx-wakeup pattern.) [gdBits].		
Multiplicity	1		
	Type	IntegerParamDef	
	Range	10 .. 55	
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06041 :		
Name	GdWakeUpSymbolRxWindow {GD_WAKEUP_SYMBOL_RX_WINDOW}		
Description	The size of the window used to detect wakeups. Detection of a wakeup requires a low and idle period (from one WUS) and a low period (from another WUS) to be detected entirely within a window of this size. The duration is equal to gdWakeUpSymbolTxIdle + 2 * gdWakeUpSymbolTxLow plus a safe part. (Clock differences and other effects can deform the Tx-wakeup pattern.) [gdBit].		
Multiplicity	1		
	Type	IntegerParamDef	
	Range	76 .. 301	
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06042 :		
Name	GdWakeUpSymbolTxIdle {GD_WAKEUP_SYMBOL_TX_IDLE}		
Description	Number of bits used by the node to transmit the 'idle' part of a wakeup symbol. The duration is equal to cdWakeUpSymbolTxIdle [gdBit].		
Multiplicity	1		
	Type	IntegerParamDef	
	Range	45 .. 180	
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06043 :		
Name	GdWakeUpSymbolTxLow {GD_WAKEUP_SYMBOL_TX_LOW}		

Description	Number of bits used by the node to transmit the LOW part of a wakeup symbol. The duration is equal to cdWakeupSymbolTxLow [gdBit].		
Multiplicity	1		
Type	IntegerParamDef		
Range	15 .. 60		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrlfController	1..*	This container contains the configuration of FlexRay CC.
FrlfJobList	1	This container specifies a list of all FlexRay Jobs of the Cluster to be performed by Frlf_JobListExec <ClstIdx>().

10.2.5 FrlfController

SWS Item	Frlf05363 :		
Container Name	FrlfController		
Description	This container contains the configuration of FlexRay CC.		
Configuration Parameters			

SWS Item	Frlf06045 :		
Name	FrlfCtrlIdx {FRIF_CTRL_IDX}		
Description	This parameter provides a zero-based consecutive index of the FlexRay Communication Controllers. Upper layer BSW modules and the Frlf itself use this index to identify a FlexRay CC.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

SWS Item	Frlf06044 :		
Name	FrlfFrCtrlRef {FRIF_FR_CTRL}		
Description	Reference to a Controller, which is handled by a specific Driver. This reference is unique for the ECU.		
Multiplicity	1		
Type	Reference to FrController		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrlfAbsTimer	1..*	This container contains the configuration of an absolute timer of a FlexRay CC.
FrlfFrameTriggering	1..*	A Frame triggering contains the communication parameters of the FlexRay Frame as well as a reference to the Frame Construction Plan.

FrlfLPdu	1..*	LPdu is an abstraction of all FlexRay Frames (L-PDUs) belonging to the same Frame Triggering FrlfFrameTriggering.
FrlfRelTimer	0..*	This container contains the configuration of a relative timer of a FlexRay CC.
FrlfTransceiver	0..2	Up to two FlexRay Transceivers may connect a Controller to a Cluster. This container realizes a Controller-Transceiver assignment.

10.2.6 FrlfAbsTimer

SWS Item	frlf05361 :
Container Name	FrlfAbsTimer{FRIF_ABS_TIMER}
Description	This container contains the configuration of an absolute timer of a FlexRay CC.
Configuration Parameters	

SWS Item	frlf06047 :		
Name	FrlfAbsTimerIdx {FRIF_ABS_TIMER_IDX}		
Description	This parameter provides a zero-based consecutive index of the absolute timers. Upper layer BSW modules use this index to identify an absolute timer.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

SWS Item	frlf06046 :		
Name	FrlfFrAbsTimerRef {FRIF_FR_ABS_TIMER}		
Description	Reference to an absolute timer, which is handled by a specific FlexRay Driver. This reference is unique for the ECU, therefore, an explicit reference to the FlexRay Driver is not necessary.		
Multiplicity	1		
Type	Reference to FrAbsoluteTimer		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

No Included Containers

10.2.7 FrlfRelTimer

SWS Item	frlf05362 :		
Container Name	FrlfRelTimer{FRIF_REL_TIMER_IDX}		
Description	This container contains the configuration of a relative timer of a FlexRay CC.		
Configuration Parameters			

SWS Item	frlf06060 :		
Name	FrlfRelTimerIdx {FRIF_REL_TIMER_IDX}		
Description	This parameter provides a zero-based consecutive index of the relative		

	timers. Upper layer BSW modules use this index to identify a relative timer.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

SWS Item	Frlf06059 :		
Name	FrlfFrRelTimerRef {FRIF_FR_REL_TIMER}		
Description	Reference to a relative timer, which is handled by a specific FlexRay Driver. This reference is unique for the ECU, therefore, an explicit reference to the FlexRay Driver is not necessary.		
Multiplicity	1		
Type	Reference to FrRelativeTimer		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

No Included Containers

10.2.8 FrlfFrameTriggering

SWS Item	FRIF_FRAME_TRIGGERING :		
Container Name	FrlfFrameTriggering		
Description	A Frame triggering contains the communication parameters of the FlexRay Frame as well as a reference to the Frame Construction Plan.		
Configuration Parameters			

SWS Item	Frlf06049 :		
Name	FrlfAllowDynamicLsduLength {FRIF_ALLOW_DYNAMIC_LSDU_LENGTH}		
Description	Allows L-PDU length reduction ('FrlfLsduLength' defines max. length) and indicates that the related CC buffer has to be reconfigured for the actual length and Header-CRC before transmission of the L-PDU.		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06050 :		
Name	FrlfAlwaysTransmit {FRIF_ALWAYS_TRANSMIT}		
Description	Defines whether the driver's API function Fr_TransmitTxLPdu() shall always be called for this L-PDU.		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD

Scope / Dependency	scope: Module		
---------------------------	---------------	--	--

SWS Item	Frlf06051 :		
Name	FrlfBaseCycle {FRIF_BASE_CYCLE}		
Description	This parameter contains the FlexRay Base Cycle used to transmit this FlexRay Frame.		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 63		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06052 :		
Name	FrlfChannel {FRIF_CHANNEL_ID}		
Description	This parameter contains the FlexRay Channel used to transmit this FlexRay Frame.		
Multiplicity	1		
Type	EnumerationParamDef		
Range	FRIF_CHANNEL_A	Channel A	
	FRIF_CHANNEL_AB	Channel A and B	
	FRIF_CHANNEL_B	Channel B	
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06053 :		
Name	FrlfCycleRepetition {FRIF_CYCLE_REPETITION}		
Description	This parameter contains the FlexRay Cycle Repetition used to transmit this FlexRay Frame.. possible Values: 1,2,4,8,16,32,64		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 64		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06054 :		
Name	FrlfLsduLength {FRIF_LSDU_LENGTH}		
Description	The payload length of the Frame is given here. This parameter is required for validation if configured PDUs and update information fits into the Frame at configuration time [bytes].		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 254		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

	dependency: The parameter depends on the low level parameters of the FlexRay CC.		
--	--	--	--

SWS Item	Frlf06050 :		
Name	FrlfNoneMode {FRIF_NONE_MODE}		
Description	Using the "None-Mode" which means that there is no API Frlf_Transmit call of the upper layer for this PDU.		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06055 :		
Name	FrlfPayloadPreamble {FRIF_PAYLOADPREAMBLE_ID}		
Description	Switching the Payload Preamble bit.		
Multiplicity	1		
Type	BooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06056 :		
Name	FrlfSlotId {FRIF_SLOT_ID}		
Description	This parameter contains the FlexRay Slot ID used to transmit this FlexRay Frame.		
Multiplicity	1		
Type	IntegerParamDef		
Range	1 .. 2047		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06048 :		
Name	FrlfFrameStructureRef {FRIF_FRAME_STRUCTURE}		
Description	Reference to the Construction Plan of the FlexRay Frame.		
Multiplicity	1		
Type	Reference to FrlfFrameStructure		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

No Included Containers

10.2.9 FrlfJobList

SWS Item	Frlf05367 :		
Container Name	FrlfJobList{FRIF_JOBLIST}		

Description	This container specifies a list of all FlexRay Jobs of the Cluster to be performed by FrIf_JobListExec_<ClstIdx>().		
Configuration Parameters			

SWS Item	FrIf06063 :		
Name	FrIfAbsTimerRef {FRIF_ABS_TIMER}		
Description	Reference to the absolute timer to be used to trigger the interrupt whose ISR contains the FrIf_JobListExec_<ClstIdx>() function.		
Multiplicity	1		
Type	Reference to FrIfAbsTimer		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
FrIfJob	1..*	A job may contain more than one operation that are executed at a specific point in time.	

10.2.10 FrIfJob

SWS Item	FrIf05368 :		
Container Name	FrIfJob{FRIF_JOB}		
Description	A job may contain more than one operation that are executed at a specific point in time.		
Configuration Parameters			

SWS Item	FrIf06064 :		
Name	FrIfCycle {FRIF_CYCLE}		
Description	The FlexRay Cycle in which the communication operation will execute this job		
Multiplicity	1		
Type	IntegerParamDef		
Range	0 .. 63		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	FrIf06065 :		
Name	FrIfMacrotick {FRIF_MACROTICK}		
Description	Macrotick offset in the Cycle [Macrotick]		
Multiplicity	1		
Type	IntegerParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
FrIfCommunicationOperation	1..*	A separate operation which is part of a FlexRay Job and	

	defines what type of action is executed.
--	--

10.2.11 FrIfCommunicationOperation

SWS Item	Frlf05369 :
Container Name	FrIfCommunicationOperation{FRIF_COMMUNICATION_OPERATION}
Description	A separate operation which is part of a FlexRay Job and defines what type of action is executed.
Configuration Parameters	

SWS Item	Frlf06067 :		
Name	FrIfCommunicationAction {FRIF_COMMUNICATION_ACTION}		
Description	The action to be performed in the FlexRay Operation		
Multiplicity	1		
Type	EnumerationParamDef		
Range	DECOUPLED_TRANSMISSION	Decoupled transmission	
	PREPARE_LPDU	Prepare message buffer of CC	
	RECEIVE_AND_INDICATE	Immediate reception	
	RECEIVE_AND_STORE	Decoupled reception	
	RX_INDICATION	Reception indication	
	TX_CONFIRMATION	Transmission confirmation	
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06068 :		
Name	FrIfCommunicationOperationIdx {FRIF_COMMUNICATION_OPERATION_IDX}		
Description	For each FlexRay Communication Job, this index spans a range of zero-based consecutive values and thus defines the order of the FlexRay Communication Operation in the respective FlexRay Communication Job.		
Multiplicity	1		
Type	IntegerParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06066 :		
Name	FrIfLPdulidxRef		
Description	Reference to a L-PDU index		
Multiplicity	1		
Type	Reference to FrIfLPdu		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPIL
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

No Included Containers

10.2.12 FrlfFrameStructure

SWS Item	Frlf05370 :
Container Name	FrlfFrameStructure{FRIF_FRAME_STRUCTURE}
Description	The Frame structure specifies a Construction Plan how a Frame is assembled with PDUs and their respective Update-Bits.
Configuration Parameters	

SWS Item	Frlf06113 :	
Name	FrlfByteOrder {FRIF_BYTE_ORDER}	
Description	<p>This parameter defines the ByteOrder of all Pdus that are mapped into the Frame.</p> <p>The absolute position of a Pdu in the Frame is determined by the definition of the ByteOrder parameter: If BIG_ENDIAN is specified, the FrlfPduOffset indicates the position of the most significant bit in the Frame. If LITTLE_ENDIAN is specified, the FrlfPduOffset indicates the position of the least significant bit in the Frame.</p>	
Multiplicity	1	
Type	EnumerationParamDef	
Range	BIG_ENDIAN	
	LITTLE_ENDIAN	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: Module	

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrlfPdusInFrame	1..*	This container holds all the information about a PDU in a FlexRay Frame.

10.2.13 FrlfPdusInFrame

SWS Item	Frlf05371 :	
Container Name	FrlfPdusInFrame{FRIF_PDUS_IN_FRAME}	
Description	This container holds all the information about a PDU in a FlexRay Frame.	
Configuration Parameters		

SWS Item	Frlf06070 :	
Name	FrlfPduOffset {FRIF_PDU_OFFSET}	
Description	The value specifies the offset of the PDU within the Frame [bytes].	
Multiplicity	1	
Type	IntegerParamDef	
Range	0 .. 253	
Default value	--	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	<p>scope: Module</p> <p>dependency: This parameter depends on the number of PDUs contained in the Frame, PDU length, and Update-Bits of other PDUs in the Frame. In addition, if the Frame will be sent in static segment, this parameter depends on GPayloadLengthStatic.</p>	

SWS Item	Frlf06071 :	
Name	FrlfPduUpdateBitOffset {FRIF_PDU_UPDATE_BIT_OFFSET}	
Description	This value specifies where the PDU's Update-Bit is stored in the Frame (bit	

	location of PDU's Update-Bit in the FlexRay Frame).		
Multiplicity	0..1		
Type	IntegerParamDef		
Range	0 .. 2031		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module dependency: This parameter depends on the number of PDUs contained in the Frame, PDU length, and Update-Bits of other PDUs in the Frame. In addition, if the Frame will be sent in static segment, this parameter depends on GPayloadLengthStatic.		

SWS Item	Frlf06069 :		
Name	FrFrlfPduRef {FRIF_PDU}		
Description	This is the reference to the local definition of a PDU.		
Multiplicity	1		
Type	Reference to FrlfPdu		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

No Included Containers

10.2.14 FrlfLPdu

SWS Item	Frlf05364 :		
Container Name	FrlfLPdu		
Description	LPdu is an abstraction of all FlexRay Frames (L-PDUs) belonging to the same Frame Triggering FrlfFrameTriggering.		
Configuration Parameters			

SWS Item	Frlf06058 :		
Name	FrlfLPduldx {FRIF_LPDU_IDX}		
Description	This parameter identifies the L-PDU in the interaction between FlexRay Interface and FlexRay Driver.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	Frlf06057 :		
Name	FrlfVBTriggeringRef {FRIF_FRAME_TRIGGERING}		
Description	Reference to the assigned Frame triggering.		
Multiplicity	1		
Type	Reference to FrlfFrameTriggering		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

No Included Containers
10.2.15 FrlfPdu

SWS Item	Frlf05372 :	
Container Name	FrlfPdu{FRIF_PDU}	
Description	Contains PDU information. A PDU may be either a transmission PDU or a reception PDU.	
Configuration Parameters		

Included Containers

Container Name	Multiplicity	Scope / Dependency
FrlfPduDirection	1	A PDU is either transmit or receive

10.2.16 FrlfTxPdu

SWS Item	Frlf05374 :	
Container Name	FrlfTxPdu{FRIF_TX_PDU}	
Description	This container specifies transmission PDUs.	
Configuration Parameters		

SWS Item	Frlf06075 :	
Name	FrlfConfirm {FRIF_CONFIRM}	
Description	Defines whether the transmission of a PDU should be checked and confirmed to the PDU owning BSW module.	
Multiplicity	1	
Type	BooleanParamDef	
Default value	--	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: Module	

SWS Item	Frlf06076 :	
Name	FrlfCounterLimit {FRIF_COUNTER_LIMIT}	
Description	This value states the maximum number of indication of ready PDU data to the Frlf (i.e. maximum number of invocations of Frlf_Transmit) without an intermediate transmission of the PDU.	
Multiplicity	1	
Type	IntegerParamDef	
Default value	--	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: Module	

SWS Item	Frlf06077 :	
Name	FrlfImmediate	
Description	Defines whether the the PDU is transmitted immediate or decoupled.	
Multiplicity	1	
Type	BooleanParamDef	
Default value	--	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: Module	

SWS Item	Frlf06078 :		
Name	FrlfTxPduld {FRIF_TX_PDU_ID}		
Description	The global PDU identifier, which has to be used by the upper layer BSW module. The identifier has to be zero based and consecutive.		
Multiplicity	1		
Type	IntegerParamDef (Symbolic Name generated for this parameter)		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Frlf and PduR/FrNm/FrTp		

SWS Item	Frlf06074 :		
Name	FrlfPduRef {FRIF_PDU_REF}		
Description	Reference to the external PDU definition.		
Multiplicity	1		
Type	Reference to Pdu		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

No Included Containers
10.2.17 FrlfRxPdu

SWS Item	Frlf05373 :		
Container Name	FrlfRxPdu{FRIF_RX_PDU}		
Description	Receive PDU		
Configuration Parameters			

SWS Item	Frlf06073 :		
Name	FrlfPduRef {FRIF_PDU_REF}		
Description	Reference to the external PDU definition.		
Multiplicity	1		
Type	Reference to Pdu		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	--	
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: ECU		

No Included Containers
10.2.18 FrlfPduDirection

SWS Item	Frlf06072 :		
Choice Container Name	FrlfPduDirection		
Description	A PDU is either transmit or receive		

Container Choices		
Container Name	Multiplicity	Scope / Dependency
FrlfRxPdu	0..1	Receive PDU

FrlfTxPdu	0..1	This container specifies transmission PDUs.
-----------	------	---

10.2.19 FrlfTransceiver

SWS Item	Frlf05391 :	
Container Name	FrlfTransceiver{FRIF_TRANSCEIVER}	
Description	Up to two FlexRay Transceivers may connect a Controller to a Cluster. This container realizes a Controller-Transceiver assignment.	
Configuration Parameters		

SWS Item	Frlf06062 :	
Name	FrlfClusterChannel {FRIF_TRCV_CLUSTER_CHANNEL}	
Description	This parameter identifies to which one of the two Channels "A" or "B" of the Cluster the Transceiver is connected.	
Multiplicity	1	
Type	EnumerationParamDef	
Range	FRIF_CHANNEL_A	Channel A
	FRIF_CHANNEL_B	Channel B
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: ECU	

SWS Item	Frlf06061 :	
Name	FrlfFrTrcvChannelRef {FRIF_TRCV_CHANNEL}	
Description	Reference to a Transceiver Driver Channel. This reference is unique for the ECU.	
Multiplicity	1	
Type	Reference to FrTrcvNode	
ConfigurationClass	Pre-compile time	X VARIANT-PRE-COMPIL
	Link time	--
	Post-build time	X VARIANT-POST-BUILD
Scope / Dependency	scope: ECU	

No Included Containers

10.2.20 FrlfConfig

SWS Item	Frlf06001 :	
Container Name	FrlfConfig [Multi Config Container]	
Description	Configuration of the FlexRay Interface. This container is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.	
Configuration Parameters		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
FrlfCluster	1..*	This container specifies a Frlf Cluster and all related data which is required to enable communication of the Cluster. A Cluster may consist of more than one Controller.
FrlfFrameStructure	0..*	The Frame structure specifies a Construction Plan how a Frame is assembled with PDUs and their respective Update-Bits.
FrlfPdu	1..*	Contains PDU information. A PDU may be either a

	transmission PDU or a reception PDU.
--	--------------------------------------

10.3 Published Information

Published information contains data defined by the implementer of the SW module that does not change when the module is adapted (i.e. configured) to the actual HW/SW environment. It thus contains version and manufacturer information. In addition, the published information contains some [link time](#) configuration data that is needed by the configuration tools.

The standard common published information like

```
vendorId (<Module>_VENDOR_ID),  
moduleId (<Module>_MODULE_ID),  
arMajorVersion (<Module>_AR_MAJOR_VERSION),  
arMinorVersion (<Module>_AR_MINOR_VERSION),  
arPatchVersion (<Module>_AR_PATCH_VERSION),  
swMajorVersion (<Module>_SW_MAJOR_VERSION),  
swMinorVersion (<Module>_SW_MINOR_VERSION),  
swPatchVersion (<Module>_SW_PATCH_VERSION),  
vendorApiInfix (<Module>_VENDOR_API_INFIX)
```

is provided in the BSW Module Description Template (see [15] Figure 4.1 and Figure 7.1).

Additional published parameters are listed below if applicable for this module.

11 Changes during SWS Improvements by Technical Office

11.1 Deleted SWS Items

None

11.2 Replaced SWS Items

None

11.3 Changed SWS Items

None

11.4 Added SWS Items

SWS Item	Rationale
Frif05001	UML model linking of imported types
Frif05002	UML model linking of Frif_GetVersionInfo
Frif05003	UML model linking of Frif_Init
Frif05004	UML model linking of Frif_ControllerInit
Frif05005	UML model linking of Frif_StartCommunication
Frif05006	UML model linking of Frif_HaltCommunication
Frif05007	UML model linking of Frif_AbortCommunication
Frif05008	UML model linking of Frif_RequestControllerStateTransition
Frif05009	UML model linking of Frif_GetControllerState
Frif05010	UML model linking of Frif_SetWakeupChannel
Frif05011	UML model linking of Frif_SendWUP
Frif05012	UML model linking of Frif_GetSyncState
Frif05013	UML model linking of Frif_SetExtSync
Frif05014	UML model linking of Frif_GetPOCStatus
Frif05015	UML model linking of Frif_GetGlobalTime
Frif05016	UML model linking of Frif_GetNmVector
Frif05017	UML model linking of Frif_AllowColdstart
Frif05018	UML model linking of Frif_GetMacroticksPerCycle
Frif05019	UML model linking of Frif_ConvertNanosecToMacroticks
Frif05020	UML model linking of Frif_ConvertMacroticksToNanosec
Frif05021	UML model linking of Frif_SetAbsoluteTimer
Frif05022	UML model linking of Frif_SetRelativeTimer
Frif05023	UML model linking of Frif_CancelRelativeTimer
Frif05024	UML model linking of Frif_CancelAbsoluteTimer
Frif05025	UML model linking of Frif_EnableAbsoluteTimerIRQ
Frif05026	UML model linking of Frif_EnableRelativeTimerIRQ
Frif05027	UML model linking of Frif_GetAbsoluteTimerIRQStatus
Frif05028	UML model linking of Frif_GetRelativeTimerIRQStatus
Frif05029	UML model linking of Frif_AckAbsoluteTimerIRQ
Frif05030	UML model linking of Frif_AckRelativeTimerIRQ
Frif05031	UML model linking of Frif_DisableAbsoluteTimerIRQ
Frif05032	UML model linking of Frif_DisableRelativeTimerIRQ
Frif05033	UML model linking of Frif_Transmit
Frif05034	UML model linking of Frif_SetTransceiverMode
Frif05035	UML model linking of Frif_GetTransceiverMode

Frif05036	UML model linking of Frif_GetTransceiverWUReason
Frif05037	UML model linking of Frif_EnableTransceiverWakeups
Frif05038	UML model linking of Frif_DisableTransceiverWakeups
Frif05039	UML model linking of Frif_ClearTransceiverWakeups
Frif05040	UML model linking of Frif_JobListExec_<ClstIdx>
Frif05041	UML model linking of Frif_Cbk_WakeupByTransceiver
Frif05042	UML model linking of Frif_MainFunction_<ClstIdx>
Frif05043	UML model linking of mandatory interfaces
Frif05044	UML model linking of optional interfaces
Frif05045	UML model linking of <UL_RxIndication>
Frif05046	UML model linking of <UL_TxConfirmation>
Frif05047	UML model linking of <UL_TriggerTransmit>