

<b>Document Title</b>	AUTOSAR Specification of ICU Driver
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	023
<b>Document Classification</b>	Standard

<b>Document Version</b>	3.3.0
<b>Document Status</b>	Final
<b>Part of Release</b>	3.2
<b>Revision</b>	3

## Document Change History

Date	Version	Changed by	Change Description
28.02.2014	3.3.0	AUTOSAR Release Management	<ul style="list-style-type: none"><li>• Changed Icu Edge Counting Requirement</li><li>• Editorial changes</li><li>• Removed chapter(s) on change documentation</li></ul>
05.06.2012	3.2.0	AUTOSAR Administration	<ul style="list-style-type: none"><li>• Updated description of Icu_IndexType</li></ul>
27.04.2011	3.1.0	AUTOSAR Administration	<ul style="list-style-type: none"><li>• Added requirements ICU251 and ICU252</li><li>• Update Chapter 8 and 10</li><li>• Legal disclaimer revised</li></ul>
23.06.2008	3.0.1	AUTOSAR Administration	Legal disclaimer revised
07.12.2007	3.0.0	AUTOSAR Administration	<ul style="list-style-type: none"><li>• The code file structure of the module was completely reworked.</li><li>• The following requirements were added: ICU088, ICU220, ICU221, ICU228 and ICU229.</li><li>• The flow charts related to the ECU Wake-Up moved to the SWS document of the ECU State Manager.</li><li>• Document meta information extended</li><li>• Small layout adaptations made</li></ul>
28.04.2006	2.0.0	AUTOSAR Administration	<p>Document structure adapted to common Release 2.0 SWS Template.</p> <ul style="list-style-type: none"><li>• Major changes in chapter 10</li><li>• Structure of document changed partly</li><li>• Other changes see chapter 11</li></ul>

<b>Document Change History</b>			
<b>Date</b>	<b>Version</b>	<b>Changed by</b>	<b>Change Description</b>
30.01.2006	2.0.0	AUTOSAR Administration	<p>Added the following services</p> <ul style="list-style-type: none"><li>- Icu_SetActivationCondition</li><li>- Icu_StartTimeStamp</li><li>- Icu_StopTimeStamp</li><li>- Icu_GetTimestampIndex</li><li>- Icu_ResetEdgeCount</li><li>- Icu_EnableEdgeCount</li><li>- Icu_DisableEdgeCount</li><li>- Icu_GetEdgeNumbers</li><li>- Icu_GetTimeElapsed</li><li>- Icu_GetDutyCycleValues</li><li>- Icu_GetVersionInfo</li></ul>
30.06.2005	1.0.0	AUTOSAR Administration	Initial Release

## Disclaimer

This specification and the material contained in it, as released by AUTOSAR is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.

For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## Advice for users

AUTOSAR Specification Documents may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the Specification Documents for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such Specification Documents, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

## Table of Contents

1	Introduction and functional overview .....	7
2	Acronyms and abbreviations .....	8
3	Related documentation.....	9
3.1	Input documents.....	9
4	Constraints and assumptions .....	10
4.1	Limitations .....	10
4.2	Applicability to car domains .....	10
5	Dependencies to other modules.....	11
5.1	File structure .....	12
5.1.1	Code file structure .....	12
5.1.2	Header file structure .....	12
6	Requirements traceability .....	14
6.1	Chapter 10.3 “Published Information.....	20
7	Functional specification .....	23
7.1	General behavior.....	23
7.1.1	Background & Rationale .....	23
7.1.2	Requirements.....	23
7.1.3	Version check.....	24
7.1.3.1	Background & Rationale .....	24
7.1.3.2	Requirements .....	24
7.1.4	Time Unit Ticks .....	24
7.1.4.1	Background & Rationale .....	24
7.1.4.2	Requirements .....	24
7.2	Error classification .....	24
7.2.1	Background & Rationale .....	24
7.2.2	Requirements.....	25
7.3	Error detection.....	26
7.4	Error notification .....	26
8	API specification .....	27
8.1	Imported types.....	27
8.2	Type definitions .....	27
8.2.1	Icu_ModeType .....	27
8.2.2	Icu_ChannelType .....	27
8.2.3	Icu_InputStateType .....	27
8.2.4	Icu_ConfigType .....	27
8.2.5	Icu_ActivationType .....	29
8.2.6	Icu_ValueType .....	29
8.2.7	Icu_DutyCycleType .....	29
8.2.8	Icu_IndexType.....	29
8.2.9	Icu_EdgeNumberType .....	29
8.2.10	Icu_MeasurementModeType.....	29
8.2.11	Icu_SignalMeasurementPropertyType .....	30
8.2.12	Icu_TimestampBufferType .....	30

8.3	Function definitions .....	30
8.3.1	Icu_Init .....	30
8.3.2	Icu_DelInit.....	31
8.3.3	Icu_SetMode .....	32
8.3.4	Icu_DisableWakeup .....	33
8.3.5	Icu_EnableWakeup .....	34
8.3.6	Icu_SetActivationCondition .....	35
8.3.7	Icu_DisableNotification.....	36
8.3.8	Icu_EnableNotification .....	36
8.3.9	Icu_GetInputState .....	37
8.3.10	Icu_StartTimestamp .....	38
8.3.11	Icu_StopTimestamp .....	39
8.3.12	Icu_GetTimestampIndex .....	40
8.3.13	Icu_ResetEdgeCount .....	41
8.3.14	Icu_EnableEdgeCount .....	42
8.3.15	Icu_DisableEdgeCount .....	43
8.3.16	Icu_GetEdgeNumbers.....	43
8.3.17	Icu_StartSignalMeasurement .....	44
8.3.18	Icu_StopSignalMeasurement .....	45
8.3.19	Icu_GetTimeElapsed.....	45
8.3.20	Icu_GetDutyCycleValues .....	46
8.3.21	Icu_GetVersionInfo .....	47
8.4	Callback notifications.....	48
8.5	Scheduled functions .....	48
8.6	Expected Interfaces.....	48
8.6.1	Mandatory Interfaces .....	48
8.6.2	Optional Interfaces .....	49
8.6.3	Configurable interfaces .....	49
9	Sequence diagrams .....	51
9.1	Icu_Init.....	51
9.2	Icu_DelInit .....	51
9.3	Validate Wakeup Events .....	52
9.4	Icu_SetMode .....	52
9.5	Icu_DisableWakeup .....	59
9.6	Icu_EnableWakeup .....	60
9.7	Icu_SetActivationCondition .....	63
9.8	Icu_DisableNotification.....	64
9.9	Icu_EnableNotification .....	65
9.10	Icu_GetInputState .....	67
9.11	Icu Timestamping .....	68
9.12	Icu Edge Counting.....	70
9.13	Icu_GetTimeElapsed.....	70
9.14	Icu_GetDutyCycleValues .....	74
9.15	Icu_SignalNotification and Icu_GetInputState .....	75
10	Configuration specification .....	76
10.1	How to read this chapter .....	76
10.1.1	Configuration and configuration parameters .....	76
10.1.2	Variants.....	76
10.1.3	Containers.....	77

10.2	Containers and configuration parameters .....	78
10.2.1	Variants.....	78
10.2.2	Icu .....	78
10.2.3	IcuGeneral.....	78
10.2.4	IcuOptionalApis .....	79
10.2.5	IcuChannel.....	82
10.2.6	IcuSignalEdgeDetection .....	84
10.2.7	IcuSignalMeasurement .....	85
10.2.8	IcuTimestampMeasurement.....	85
10.2.9	IcuEdgeCounterMeasurement .....	86
10.2.10	IcuWakeup.....	86
10.2.11	IcuConfigSet.....	87
10.3	Published Information.....	88

## 1 Introduction and functional overview

This specification specifies the functionality, API and configuration of the AUTOSAR Basic Software module ICU driver.

The ICU driver is a module using the input capture unit (ICU) for demodulation of a PWM signal, counting pulses, measuring of frequency and duty cycle, generating simple interrupts and also wakeup interrupts.

The ICU driver provides services for

- Signal edge notification
- Controlling wakeup interrupts
- Periodic signal time measurement
- Edge timestamping, usable for the acquisition of non-periodic signals
- Edge counting

## 2 Acronyms and abbreviations

Abbreviation / Acronym:	Description:
Active Time	This depends on the starting edge of the signal to be captured. <ul style="list-style-type: none"><li>▪ Start edge = falling edge =&gt; Active Time = Low Time</li><li>▪ Start edge = rising edge =&gt; Active Time = High Time</li></ul>
DEM	Diagnostic Event Manager
DET	Development Error Tracer
EcuM	ECU State Manager
Enumeration	This can be in "C" programming language an enum or a #define.
ICU	Input Capture Unit (not Intensive Care Unit)
ICU Channel	Represents a logical ICU entity bound to one input signal and the hardware resources for the configured measurement mode.
ICU State	Logical input state of an ICU Channel. It can be ICU_ACTIVE or ICU_IDLE.
ICU_ACTIVE	Input state of an ICU Channel, an activation edge has been detected.
ICU_IDLE	Input state of an ICU Channel, no activation edge has been detected since the last call of Icu_GetInputState() or Icu_Init().
Symbolic name for a channel	A symbolic name is a substitution of a handle with a name. With this handle each channel and its related properties can be found within the configuration structure.  In "C" programming language this can be realized e.g. by #defines and enums.
Wakeup event	A wakeup event is understood as a pattern of edges, which will lead to the wake up of this driver. Nevertheless the decision whether a pattern is valid or <u>not</u> isn't done by this driver. This shall be done by an upper layer.

## 3 Related documentation

### 3.1 Input documents

- [1] General Requirements on Basic Software Modules,  
AUTOSAR\_SRS\_General.pdf
- [2] General Requirements on SPAL,  
AUTOSAR\_SRS\_SPAL\_General.pdf
- [3] Specification of Standard Types,  
AUTOSAR\_SWS\_StandardTypes.pdf
- [4] List of Basic Software Modules,  
AUTOSAR\_BasicSoftwareModules.pdf
- [5] Specification of Diagnostics Event Manager (DEM),  
AUTOSAR\_SWS\_DEM.pdf
- [6] Specification of Development Error Tracer,  
AUTOSAR\_SWS\_Development\_Error\_Tracer.pdf
- [7] Requirements on ICU Driver,  
AUTOSAR\_SRS\_ICU\_Driver.pdf
- [8] Specification of ECU Configuration,  
AUTOSAR\_ECU\_Configuration.pdf
- [9] Layered Software Architecture,  
AUTOSAR\_LayeredSoftwareArchitecture.pdf
- [10] Specification of ECU State Manager,  
AUTOSAR\_SWS\_EcuStateManager.pdf
- [11] AUTOSAR Basic Software Module Description Template,  
AUTOSAR\_BSW\_Module\_Description.pdf

## 4 Constraints and assumptions

### 4.1 Limitations

No limitations.

### 4.2 Applicability to car domains

No restrictions.

## 5 Dependencies to other modules

### **Module DET (Development Error Tracer)**

In development mode the DET will be called.

### **Module MCU**

The ICU driver depends on the system clock, prescaler(s) and PLL. Hence the length of an ICU timer tick depends on the clock settings made in the module MCU.

The ICU driver will not take care of setting the registers which configure the global clock, global prescaler(s) and PLL in its Init function. This has to be done by the MCU module. The ICU driver only configures local (ICU peripheral specific) clocks, prescalers and so on.

### **OS (Operating System)**

The ICU driver uses interrupts and therefore there is a dependency on the OS which configures the interrupt sources. It will provide the call-back functions only.

The ICU driver will not take care of setting the registers for interrupt association in its Init function. The overall assignment and activation of the interrupt system is done by the Operating System.

### **Module PORT**

The configuration of port pins used for the ICU as inputs is done by the PORT driver. Hence the PORT driver has to be initialized prior to the use of ICU functions. Otherwise ICU functions will exhibit undefined behavior.

### **Module EcuM**

The ICU driver will do the reporting of wakeup interrupts to the EcuM.


## 5.1 File structure

### 5.1.1 Code file structure

**ICU115:** The code file structure shall not be defined within this specification.

### 5.1.2 Header file structure

**ICU219:** The code file structure shall be as follows:



**Figure 5.1: Header file structure**

- Icu.c shall include Icu.h
- Icu.h shall include Icu\_Cfg.h for the API pre-compiler switches.
- Icu\_Xcfg.h where X is a placeholder for 'L' or 'PB'

Icu.c has access to the Icu\_Cfg.h via the implicitly included Icu.h file.

Icu\_Irq.c shall include Icu.h for the function which shall be called in the interrupt function and Icu\_Irq.h for the declaration of interrupt functions.

The Type definitions for Icu\_Lcfg.c and Icu\_PBcfg.c are located in the file Icu\_Cfg.h or Icu.h.

Rather the implicit include of Icu\_Cfg.h via Icu.h in the files Icu\_Lcfg.c and Icu\_PBcfg.c is necessary to solve the following construct:

Icu.h shall include EcuM\_Cbk.h, if wakeup functionality is configured.

```
Icu.h
-----
#if defined ICU_VERSION_INFO_API
Icu_GetVersionInfo(...)
#endif

Icu_Cfg.h
-----
#include "Icu.h"
#define ICU_VERSION_INFO_API
```

Icu\_Lcfg.c shall include Icu\_Cbk.h for a link time configuration if the call back function is linked to the module via the ROM structure.

Icu\_PBcfg.c shall include Icu\_Cbk.h for post build time configuration if the call back function is linked to the module via the ROM structure.

Icu.c shall include Icu\_Cbk.h for pre-compile time configuration

**ICU116:** The module shall optionally include the Dem.h file if any production error will be issued by the implementation. By this inclusion, the API's to report errors as well as the required Event Id symbols are included.

This specification defines the name of the Event Id symbols, which are provided by XML to the [DEM](#) configuration tool. The [DEM](#) configuration tool assigns ECU dependent values to the Event Id symbols and publishes the symbols in Dem\_IntErrId.h.

## 6 Requirements traceability

Document: General Requirements on Basic Software Modules (see Literature [1])

<b>Requirement</b>	<b>Satisfied by</b>
[BSW003] Version identification	<a href="#">ICU028</a>
[BSW00300] Module naming convention	Not applicable (non-functional requirement)
[BSW00301] Limit imported information	Not applicable (non-functional requirement)
[BSW00302] Limit exported information	Not applicable (non-functional requirement)
[BSW00304] AUTOSAR integer data types	Not applicable (non-functional requirement)
[BSW00305] Self-defined data types naming convention	Not applicable (non-functional requirement)
[BSW00306] Avoid direct use of compiler and platform specific keywords	Not applicable (non-functional requirement)
[BSW00307] Global variables naming convention	Not applicable (non-functional requirement)
[BSW00308] Definition of global data	Not applicable (non-functional requirement)
[BSW00309] Global data with read-only constraint	Not applicable (non-functional requirement)
[BSW00310] API naming convention	Not applicable (non-functional requirement)
[BSW00312] Shared code shall be reentrant	Not applicable (non-functional requirement)
[BSW00314] Separation of interrupt frames and service routines	Not applicable (non-functional requirement)
[BSW00318] Format of module version numbers	Not applicable (non-functional requirement)
[BSW00321] Enumeration of module version numbers	Not applicable (non-functional requirement)
[BSW00323] API parameter checking	<a href="#">ICU022</a> , <a href="#">ICU023</a> , <a href="#">ICU024</a> , <a href="#">ICU043</a> , <a href="#">ICU048</a> , <a href="#">ICU120</a> , <a href="#">ICU125</a>
[BSW00324] Do not use HIS I/O Library	Not applicable (non-functional requirement)
[BSW00325] Runtime of interrupt service routines	Not applicable (implementation design requirement)
[BSW00326] Transition from ISRs to OS tasks	Not applicable (non-functional requirement)
[BSW00327] Error values naming convention	Not applicable (non-functional requirement)
[BSW00328] Avoid duplication of code	Not applicable (non-functional requirement)
[BSW00329] Avoidance of generic interfaces	Not applicable (non-functional requirement)

<b>Requirement</b>	<b>Satisfied by</b>
[BSW00330] Usage of macros / inline functions instead of functions	Not applicable (non-functional requirement)
[BSW00331] Separation of error and status values	Not applicable (non-functional requirement)
[BSW00333] Documentation of callback function context	Not applicable (non-functional requirement)
[BSW00334] Provision of XML file	Not applicable (non-functional requirement)
[BSW00335] Status values naming convention	Not applicable (non-functional requirement)
[BSW00336] Shutdown interface	<a href="#">ICU035</a> , <a href="#">ICU037</a>
[BSW00337] Classification of errors	<a href="#">ICU001</a> , <a href="#">ICU004</a>
[BSW00338] Detection and Reporting of development errors	<a href="#">ICU002</a> , <a href="#">ICU111</a>
[BSW00339] Reporting of production relevant errors and exceptions	<a href="#">ICU003</a>
[BSW00341] Microcontroller compatibility documentation	Not applicable (non-functional requirement)
[BSW00342] Usage of source code and object code	Not applicable (non-functional requirement)
[BSW00343] Specification and configuration of time	<a href="#">ICU085</a>
[BSW00344] Reference to link-time configuration	<a href="#">ICU027</a> , <a href="#">ICU006</a>
[BSW00345] Pre-compile-time configuration	<a href="#">ICU026</a> , Figure 5.1: Header file structure
[BSW00346] Basic set of module files	Figure 5.1: Header file structure
[BSW00347] Naming separation of different instances of BSW drivers	Not applicable (non-functional requirement)
[BSW00348] Standard type header	Not applicable (non-functional requirement)
[BSW00350] Development error detection keyword	Not applicable (non-functional requirement)
[BSW00353] Platform specific type header	Not applicable (non-functional requirement)
[BSW00355] Do not redefine AUTOSAR integer data types	Not applicable (non-functional requirement)
[BSW00357] Standard API return type	Not applicable (non-functional requirement)
[BSW00358] Return type of init() functions	Not applicable (non-functional requirement)
[BSW00359] Return type of callback functions	<a href="#">ICU187</a>
[BSW00360] Parameters of callback functions	Not applicable (non-functional requirement)
[BSW00361] Compiler specific language extension header	Not applicable (non-functional requirement)

<b>Requirement</b>	<b>Satisfied by</b>
[BSW00369] Do not return development error codes via API	<a href="#">ICU002</a> , <a href="#">ICU049</a>
[BSW00370] Separation of callback interface from API	Not applicable (non-functional requirement)
[BSW00371] Do not pass function pointers via API	Not applicable (non-functional requirement)
[BSW00373] Main processing function naming convention.	Not applicable (this module does not provide a schedulable main function)
[BSW00374] Module vendor identification	<a href="#">ICU028</a>
[BSW00376] Return type and parameters of main processing functions	Not applicable (non-functional requirement)
[BSW00377] Module specific API return types	Not applicable (non-functional requirement)
[BSW00378] AUTOSAR boolean type	Not applicable (non-functional requirement)
[BSW00379] Module identification	Not applicable (non-functional requirement)
[BSW00380] Separate C-File for configuration parameters	Figure 5.1: Header file structure
[BSW00381] Separate H-File for configuration parameters	Figure 5.1: Header file structure
[BSW00383] List dependent Files	Not applicable (this module does not use configuration files from other modules)
[BSW00384] List dependencies to other modules	<a href="#">ICU131</a>
[BSW00385] List possible error notifications	<a href="#">ICU001</a>
[BSW00386] Configuration for detecting an error	See chapter 7.2.1
[BSW00387] Specify the configuration class of callback function	Not applicable (this module does not provide any callback routines)
[BSW00388] Introduce containers	See chapter 10.2
[BSW00389] Containers shall have names	See chapter 10.2
[BSW00390] Parameter content shall be unique within the module	See chapter 8.3
[BSW00391] Parameter shall have unique names	See chapter 8.3See chapter 8.3
[BSW00392] Parameters shall have a type	See chapter 8.3
[BSW00393] Parameters shall have a range	See chapter 8.3
[BSW00394] Specify the scope of the parameters	See chapter 8.3

Requirement	Satisfied by
[BSW00395] List the required parameters (per parameter)	Not applicable (none of the parameters of this module are dependent on other parameters)
[BSW00396] Configuration classes	See chapter 10.2
[BSW00397] Pre-compile-time parameters	Not applicable (only #define's as pre-compile time parameters)
[BSW00398] Link-time parameters	Not applicable (this is just a definement)
[BSW00399] Loadable Post-build time parameters	Not applicable (this is just a definement)
[BSW004] Version check	<a href="#">ICU005</a>
[BSW00400] Selectable Post-build time parameters	Not applicable (this is just a definement)
[BSW00401] Documentation of multiple instances of configuration parameters	See chapter 10.2
[BSW00402] Published information	See chapter 10.3
[BSW00404] Reference to post build time configuration	<a href="#">ICU006</a>
[BSW00405] Reference to multiple configuration sets	<a href="#">ICU006</a>
[BSW00406] Check module initialization	<a href="#">ICU022</a>
[BSW00407] Function to read out published parameters	<a href="#">ICU182</a> , <a href="#">ICU183</a>
[BSW00408] Configuration parameter naming convention	Not applicable (non-functional requirement)
[BSW00409] Header files for production code error ID's	Not applicable (no production relevant error status, only error events)
[BSW00410] Compiler switches shall have specified values.	<a href="#">ICU055</a> , <a href="#">ICU090</a> , <a href="#">ICU092</a> , <a href="#">ICU094</a> , <a href="#">ICU095</a> , <a href="#">ICU096</a> , <a href="#">ICU097</a> , <a href="#">ICU122</a> , <a href="#">ICU063</a> , <a href="#">ICU099</a> , <a href="#">ICU100</a> , <a href="#">ICU101</a> , <a href="#">ICU102</a> , <a href="#">ICU103</a> , <a href="#">ICU104</a> , <a href="#">ICU105</a> , <a href="#">ICU106</a> , <a href="#">ICU111</a> ,
[BSW00411] Get version info keyword	<a href="#">ICU094</a>
[BSW00412] Separate H-File for configuration parameters	Figure 5.1: Header file structure
[BSW00413] Accessing instances of BSW modules	Not applicable (all configuration parameters are single instance only)
[BSW00414] Parameter of init function	Not applicable (Due to a SPAL Team decision, the parameter will be kept in any variant)
[BSW005] No hard coded horizontal interfaces within MCAL	Not applicable (non-functional requirement)
[BSW006] Platform independency	Not applicable (non-functional requirement)

<b>Requirement</b>	<b>Satisfied by</b>
[BSW007] HIS MISRA C	Not applicable (non-functional requirement)
[BSW009] Module User Documentation	Not applicable (non-functional requirement)
[BSW010] Memory resource documentation	Not applicable (non-functional requirement)
[BSW101] Initialization interface	<a href="#">ICU006</a>
[BSW158] Separation of configuration from implementation.	Figure 5.1: Header file structure
[BSW159] Tool-based configuration	Both, static and runtime configuration parameters are located outside the source code of the module. This is the prerequisite for automatic configuration. See Figure 5.1: Header file structure
[BSW160] Human-readable configuration data	Not applicable (non-functional requirement)
[BSW161] Microcontroller abstraction	Not applicable (non-functional requirement)
[BSW162] ECU layout abstraction	Not applicable (non-functional requirement)
[BSW164] Implementation of interrupt service routines	Not applicable (non-functional requirement)
[BSW167] Static configuration checking	Not applicable (requirement for a configuration tool)
[BSW168] Diagnostic interface	Not applicable (this module does not support a special diagnostic interface)
[BSW170] Data for reconfiguration of SW-components	Not applicable (this driver has no interdependencies on other drivers)
[BSW171] Configurability of optional functionality	<a href="#">ICU092</a> , <a href="#">ICU094</a> , <a href="#">ICU095</a> , <a href="#">ICU096</a> , <a href="#">ICU097</a> , <a href="#">ICU098</a> , <a href="#">ICU099</a> , <a href="#">ICU100</a> , <a href="#">ICU101</a> , <a href="#">ICU102</a> , <a href="#">ICU103</a> , <a href="#">ICU104</a> , <a href="#">ICU105</a> , <a href="#">ICU106</a> , <a href="#">ICU026</a> , <a href="#">ICU114</a> , <a href="#">ICU122</a> , <a href="#">ICU123</a> , <a href="#">ICU124</a>
[BSW172] Compatibility and documentation of scheduling strategy	Not applicable (non-functional requirement)
[BSW00375] Notification of wakeup reason	See 9.3
[BSW00415] User dependent include files	Not applicable (this is a basic software module)

<b>Requirement</b>	<b>Satisfied by</b>
[BSW00416] Sequence of Initialization	Not applicable (requirement on system design, not on a single module)
[BSW00417] Reporting of Error Events by Non-Basic Software	Not applicable (this is a basic software module)
[BSW00419] Separate C-Files for pre-compile time configuration parameters	See 9.3
[BSW00420] Production relevant error event rate detection	Not applicable (no production relevant error status, only error events)
[BSW00421] Reporting of production relevant error events	Not applicable (no production relevant error status, only error events)
[BSW00422] Debouncing of production relevant error status	Not applicable (no production relevant error status, only error events)
[BSW00423] Usage of SW-C template to describe BSW modules with AUTOSAR Interfaces.	Not applicable (non-functional requirement)
[BSW00424] BSW main processing function task allocation	Not applicable (this module does not provide a schedulable main function)
[BSW00425] Trigger conditions for schedulable objects	Not applicable (no internal scheduling policy)
[BSW00426] Exclusive areas in BSW modules	Not applicable (no exclusive areas specified for this module)
[BSW00427] ISR description for BSW modules	Not applicable (requirement on implementation, not on specification)
[BSW00428] Execution order dependencies of main processing functions	Not applicable (this module does not provide a schedulable main function)
[BSW00429] Restricted BSW OS functionality access	Not applicable (this module doesn't require OS objects/services)
[BSW00431] The BSW Scheduler module implements task bodies	Not applicable (requirement on system design, not on a single module)
[BSW00432] Modules should have separate main processing functions for read/receive and write/transmit data path	Not applicable (this module does not provide a schedulable main function)
[BSW00433] Calling of main processing functions	Not applicable (this module does not provide a schedulable main function)
[BSW00434] The Schedule Module shall provide an API for exclusive areas	Not applicable (no internal scheduling policy)

Document: General Requirements on SPAL (see Literature [2])

<b>Requirement</b>	<b>Satisfied by</b>
[BSW12056] Configuration of notification mechanisms	<a href="#">ICU018</a> , <a href="#">ICU020</a> , <a href="#">ICU027</a>
[BSW12057] Driver module initialization	<a href="#">ICU006</a> , <a href="#">ICU040</a> , <a href="#">ICU041</a> , <a href="#">ICU060</a> , <a href="#">ICU061</a>
[BSW12063] Raw value mode	<a href="#">ICU063</a> , <a href="#">ICU081</a> , <a href="#">ICU082</a> , <a href="#">ICU083</a>
[BSW12064] Change of operation mode during running operation	<a href="#">ICU133</a>
[BSW12067] Setting of wakeup conditions	<a href="#">ICU008</a> , <a href="#">ICU011</a> , <a href="#">ICU012</a>
[BSW12068] MCAL initialization sequence	Not applicable (requirement on system design, not on a single module)
[BSW12069] Wakeup notification of ECU State Manager	See 9.3, <a href="#">ICU055</a> , <a href="#">ICU056</a> , <a href="#">ICU057</a>
[BSW12075] Use of application buffers	<a href="#">ICU063</a> <a href="#">ICU110</a>
[BSW12077] Non-blocking implementation	Not applicable (requirement on implementation, not on specification)
[BSW12078] Runtime and memory efficiency	<a href="#">ICU114</a>
[BSW12092] Access to drivers	Not applicable (requirement on system design, not on a single module)
[BSW12125] Initialization of hardware resources	<a href="#">ICU054</a>
[BSW12129] Resetting of interrupt flags	<a href="#">ICU119</a>
[BSW12163] Driver module deinitialization	<a href="#">ICU035</a> , <a href="#">ICU036</a> , <a href="#">ICU037</a>
[BSW12169] Control of operation mode	<a href="#">ICU008</a>
[BSW12263] Object code compatible configuration concept	<a href="#">ICU027</a>
[BSW12264] Specification of configuration items	See chapter 10 “Configuration specification”
[BSW12265] Configuration data shall be kept constant	Not applicable (requirement on implementation, not on specification)
[BSW12267] Configuration of wakeup sources	<a href="#">ICU126</a>
[BSW12448] Behavior after development error detection	<a href="#">ICU048</a> , <a href="#">ICU049</a> , <a href="#">ICU107</a> , <a href="#">ICU108</a>
[BSW157] Notification mechanisms of drivers and handlers	<a href="#">ICU021</a> , <a href="#">ICU030</a> , <a href="#">ICU002</a> , <a href="#">ICU003</a>
[BSW12461] Responsibility for register initialization	<a href="#">ICU006</a> , <a href="#">ICU051</a> , <a href="#">ICU052</a> , <a href="#">ICU053</a> , <a href="#">ICU128</a> , <a href="#">ICU129</a>
[BSW12462] Provide settings for register initialization	<b>6.1 Chapter 10.3 “Published Information”</b>

<b>Requirement</b>	<b>Satisfied by</b>
[BSW12463] Combine and forward settings for register initialization	Not applicable (requirement for a configuration tool)

Document: Requirements on ICU Driver (see Literature [7])

<b>Requirement</b>	<b>Satisfied by</b>
[BSW12305] Enable/Disable notification during runtime	<a href="#">ICU009</a> , <a href="#">ICU010</a> , <a href="#">ICU042</a> , <a href="#">ICU044</a>
[BSW12327] ICU global configuration	<a href="#">ICU038</a>
[BSW12368] ICU channel/group configuration	<a href="#">ICU039</a>
[BSW12369] Notification on signal edge	<a href="#">ICU021</a> , <a href="#">ICU045</a>
[BSW12370] Sleep mode selection service	<a href="#">ICU008</a>
[BSW12371] ICU Channel status function	<a href="#">ICU030</a> , <a href="#">ICU031</a> , <a href="#">ICU032</a> , <a href="#">ICU033</a>
[BSW12407] Initialization of ICU	<a href="#">ICU040</a> , <a href="#">ICU041</a> , <a href="#">ICU061</a>
[BSW12408] Wakeup enable / disable service	<a href="#">ICU013</a> , <a href="#">ICU014</a>
[BSW12425] Measured property of ICU Channel	<a href="#">ICU039</a> , <a href="#">ICU088</a>
[BSW12429] ICU Deinitialization	<a href="#">ICU036</a>
[BSW12430] ICU start timestamp service	<a href="#">ICU063</a> , <a href="#">ICU066</a>
[BSW12431] ICU cancel timestamp service	<a href="#">ICU067</a>
[BSW12432] Enable ICU edge counting service	<a href="#">ICU078</a>
[BSW12433] Disable ICU edge counting service	<a href="#">ICU079</a>
[BSW12434] ICU edge counting read service	<a href="#">ICU080</a>
[BSW12435] Get elapsed Signal High Time for an ICU Channel	<a href="#">ICU082</a>
[BSW12436] Get Duty Cycle input values for an ICU Channel	<a href="#">ICU084</a>
[BSW12437] ICU driver time unit	<a href="#">ICU085</a>
[BSW12438] Timestamps of elapsed time	<a href="#">ICU063</a>
[BSW12439] Edge counting	<a href="#">ICU072</a> , <a href="#">ICU073</a> , <a href="#">ICU074</a>
[BSW12442] Get elapsed Signal Low Time for an ICU Channel	<a href="#">ICU081</a>
[BSW12443] Get elapsed Period Time for an ICU Channel	<a href="#">ICU083</a>
[BSW12444] ICU timestamp notification	<a href="#">ICU068</a>
[BSW12453] ICU get timestamp index service	<a href="#">ICU071</a>
[BSW12455] External circular buffer handling	<a href="#">ICU039</a>
[BSW12456] External linear buffer handling	<a href="#">ICU065</a> , <a href="#">ICU039</a>
[BSW13100] Reset the value of counted edges	<a href="#">ICU072</a>

## 7 Functional specification

### 7.1 General behavior

#### 7.1.1 Background & Rationale

To ensure data consistency re-entrant code shall be provided.

#### 7.1.2 Requirements

**ICU050:** The Icu module functions for different channel numbers shall be re-entrant, except for:

- Icu\_Init()
- Icu\_DelInit()
- Icu\_SetMode()
- Icu\_GetVersionInfo()

**ICU149:** The Icu module's environment shall check the integrity if several calls for the same ICU channel are used during runtime in different tasks or ISRs.

**ICU150:** The Icu module shall not check the integrity if several calls for the same ICU channel are used during runtime in different tasks or ISRs.

The Icu module has 2 modes: `ICU_MODE_NORMAL` and `ICU_MODE_SLEEP`.

**ICU011:** In `ICU_MODE_NORMAL` mode all notifications are available as

- configured by service `Icu_SetActivationCondition()` or `IcuDefaultStartEdge`.
- selected by the `Icu_DisableNotification()` and `Icu_EnableNotification()` services before or after the call of `Icu_SetMode()`.

**ICU012:** In `ICU_MODE_SLEEP` mode

- only those wakeup events are available which are configured as wakeup capable, enabled via `Icu_EnableWakeup()` after `Icu_Init()` and which are not disabled via service `Icu_DisableWakeup()`
- all other interrupts handled by this module are disabled and must not lead to an exit from the reduced power mode state (e.g. idle, halt) of the MCU if the event occurs.

All channels are stopped except those channels

- which have been configured as wakeup capable and
- which were explicitly enabled by the call of `Icu_EnableWakeup`.

**ICU088:** The module Icu shall allow the configuration per channel of the definition on which edge the period starts.

### 7.1.3 Version check

#### 7.1.3.1 Background & Rationale

The integration of incompatible files shall be avoided. Minimum implementation is the version check of the header file inside the C file (version numbers of C and H file shall be identical)

#### 7.1.3.2 Requirements

**ICU005:** The Icu module shall avoid the integration of incompatible files by implementing the following version check of the header file:

For included header files:

- ICU\_AR\_MAJOR\_VERSION
- ICU\_AR\_MINOR\_VERSION

shall be identical.

For the module internal c and h files:

- ICU\_SW\_MAJOR\_VERSION
- ICU\_SW\_MINOR\_VERSION
- ICU\_AR\_MAJOR\_VERSION
- ICU\_AR\_MINOR\_VERSION
- ICU\_AR\_PATCH\_VERSION

shall be identical.

### 7.1.4 Time Unit Ticks

#### 7.1.4.1 Background & Rationale

To get times out of register values it is necessary to know the oscillator frequency, prescalers and so on. Since these settings are made in the MCU module and/or in other modules it is not possible to calculate such times.

Hence the conversions between time and ticks shall be part of an upper layer.

#### 7.1.4.2 Requirements

**ICU085:** All time units used within the API services of the ICU driver are unit ticks.

## 7.2 Error classification

### 7.2.1 Background & Rationale

The error classification depends on the time of error occurrence according to product life cycle:

- Development Errors

Development errors shall be detected and fixed during the development phase.  
The detection of errors that shall only occur during development can be switched off for production code (by static configuration namely pre-processor switches).

- Production / series

Those errors are hardware errors and software exceptions that cannot be avoided.

## 7.2.2 Requirements

**ICU117:** Values for production code event ID's are assigned externally by the configuration of the [DEM](#). They are published in the file Dem\_IntErrId.h and included via Dem.h.

**ICU118:** Development error values are of type uint8.

**ICU001:** The following errors and exceptions shall be detectable by the ICU driver depending on its build version (development/production mode):

Type or error	Relevance	Related error code	Value [hex]
API Icu_Init service called with wrong parameter	Development	ICU_E_PARAM_CONFIG	0x0A
API service used with an invalid channel identifier or channel was not configured for the functionality of the calling API	Development	ICU_E_PARAM_CHANNEL	0x0B
API service used with an invalid or not feasible activation	Development	ICU_E_PARAM_ACTIVATION	0x0C
API service used with an invalid application-buffer pointer	Development	ICU_E_PARAM_BUFFER_PTR	0x0D
API service used with an invalid buffer size	Development	ICU_E_PARAM_BUFFER_SIZE	0x0E
API service Icu_SetMode used with an invalid mode	Development	ICU_E_PARAM_MODE	0x0F
API service used without module initialization	Development	ICU_E_UNINIT	0x14
API service Icu_StopTimestamp called on a channel which was not started or already stopped	Development	ICU_E_NOT_STARTED	0x15
API service Icu_SetMode is called while a running operation	Development	ICU_E_BUSY_OPERATION	0x16
API Icu_Init service called when the ICU driver and the Hardware are already initialized	Development	ICU_E_ALREADY_INITIALIZED	0x17
None	Production	None	Assigned

## 7.3 Error detection

**ICU111:** The detection of development errors is configurable (*ON / OFF*) at pre-compile time. The switch `IcuDevErrorDetect` shall activate or deactivate the detection of all development errors.

**ICU112:** If the switch `IcuDevErrorDetect` is enabled, API parameter checking is enabled.

The detailed description of the detected errors can be found in chapter 7.2 and chapter 8.

**ICU113:** The detection of production code errors cannot be switched off.

**ICU048:** If development error detection for the Icu module is enabled: All Icu module functions shall skip functionality and return without any action (except for raising the development error) if a development error is detected.

**ICU022:** If development error detection for the Icu module is enabled: All Icu module functions, except for `Icu_Init` and `Icu_GetVersionInfo`, shall raise development error `ICU_E_UNINIT` when the function `Icu_Init` has not been called.

## 7.4 Error notification

**ICU002:** Detected development errors shall be reported to the `Det_ReportError` service of the Development Error Tracer (DET) if the pre-processor switch `IcuDevErrorDetect` is set (see [ICU026](#))

**ICU003:** Production errors shall be reported to the Diagnostic Event Manager ([DEM](#)).

**ICU004:** Additional errors that are detected because of specific implementation and/or specific hardware properties shall be added in the ICU device specific implementation specification. The classification and enumeration shall be compatible with the errors listed above.

## 8 API specification

### 8.1 Imported types

In this chapter all types included from the following files are listed:

**ICU190:**

Module	Imported Type
Dem	Dem_EventIdType
EcuM	EcuM_WakeupSourceType
Std_Types	Std_VersionInfoType

### 8.2 Type definitions

#### 8.2.1 Icu\_ModeType

Name:	Icu_ModeType				
Type:	Enumeration				
Range:	<table border="1"> <tr> <td>ICU_MODE_NORMAL</td> <td>Normal operation, all used interrupts are enabled according to the notification requests.</td> </tr> <tr> <td>ICU_MODE_SLEEP</td> <td>Reduced power operation. In sleep mode only those notifications are available which are configured as wakeup capable.</td> </tr> </table>	ICU_MODE_NORMAL	Normal operation, all used interrupts are enabled according to the notification requests.	ICU_MODE_SLEEP	Reduced power operation. In sleep mode only those notifications are available which are configured as wakeup capable.
ICU_MODE_NORMAL	Normal operation, all used interrupts are enabled according to the notification requests.				
ICU_MODE_SLEEP	Reduced power operation. In sleep mode only those notifications are available which are configured as wakeup capable.				
Description:	Allow enabling / disabling of all interrupts which are not required for the ECU wakeup.				

#### 8.2.2 Icu\_ChannelType

Name:	Icu_ChannelType
Type:	Unsigned Integer
Range:	-- -- This is implementation specific but not all values may be valid within the type. This type shall be chosen in order to have the most efficient implementation on a specific microcontroller platform.
Description:	Numeric identifier of an ICU channel

#### 8.2.3 Icu\_InputStateType

Name:	Icu_InputStateType				
Type:	Enumeration				
Range:	<table border="1"> <tr> <td>ICU_ACTIVE</td> <td>An activation edge has been detected</td> </tr> <tr> <td>ICU_IDLE</td> <td>No activation edge has been detected since the last call of Icu_GetInputState() or Icu_Init().</td> </tr> </table>	ICU_ACTIVE	An activation edge has been detected	ICU_IDLE	No activation edge has been detected since the last call of Icu_GetInputState() or Icu_Init().
ICU_ACTIVE	An activation edge has been detected				
ICU_IDLE	No activation edge has been detected since the last call of Icu_GetInputState() or Icu_Init().				
Description:	Input state of an ICU channel				

#### 8.2.4 Icu\_ConfigType

Name:	Icu_ConfigType
Type:	Structure

<b>Range:</b>	--	Hardware and implementation dependent structure. The contents of the initialization data structure are microcontroller specific.
<b>Description:</b>	This type contains initialization data.	

**ICU038:** The Icu\_ConfigType shall contain the following initialization data.

- Wakeup Module Info (in case the wakeup-capability is true)
- MCU dependent properties for used HW units
- Clock source with optional prescaler (if provided by HW)

**ICU039:** The definition for each Channel within the Icu\_ConfigType shall contain:

#### Common parameters

- Wakeup capability (true / false)
- Default Start Edge
- Hardware Specific Settings per channel
- Measurement Mode
  - Signal Edge Detection / Notification
  - Signal Measurement
  - Timestamp
  - Edge Counter

#### Specific parameters

If measurement mode is “signal edge detection” the notification function for signal notification shall be configurable

If measurement mode is “signal measurement” the property that could be measured shall be configurable. The values shall be:

- High Time
- Low Time
- Period Time
- Duty Cycle Values (High Time and Period Time)

If measurement mode is “timestamp measurement”, buffer handling shall be configurable. The values shall be:

- Circular buffer handling
- Linear buffer handling

Also the notification function for notifying the number of requested timestamps shall be configurable

If measurement mode is “edge counter”, the counting mode (activation edge) shall be configurable. The values shall be:

- Rising Edge
- Falling Edge
- Both edges

If the channel is configured as wakeup capable,

- the callout function for validation of wakeup reason shall be configurable
- The value transmitted to the EcuM shall be configurable

Assigned capture register(s) (can also be none for channels which provide only edge detection like an external interrupt)

Assigned capture timer (can also be none for channels which provide only edge detection like an external interrupt)

### 8.2.5 Icu\_ActivationType

<b>Name:</b>	Icu_ActivationType	
<b>Type:</b>	Enumeration	
<b>Range:</b>	ICU_RISING_EDGE	An appropriate action shall be executed when a rising edge occurs on the ICU input signal.
	ICU_FALLING_EDGE	An appropriate action shall be executed when a falling edge occurs on the ICU input signal.
	ICU_BOTH_EDGES	An appropriate action shall be executed when either a rising or falling edge occur on the ICU input signal.
<b>Description:</b>	Definition of the type of activation of an ICU channel.	

### 8.2.6 Icu\_ValueType

<b>Name:</b>	Icu_ValueType	
<b>Type:</b>	Unsigned Integer	
<b>Range:</b>	0 ... <width of the timer register>	Implementation specific. This type shall be chosen in order to have the most efficient implementation on a specific microcontroller platform.
<b>Description:</b>	Width of the buffer for timestamp ticks and measured elapsed timeticks.	

### 8.2.7 Icu\_DutyCycleType

<b>Name:</b>	Icu_DutyCycleType		
<b>Type:</b>	Structure		
<b>Element:</b>	Icu_ValueType	ActiveTime	This shall be the coherent active-time measured on a channel
	Icu_ValueType	PeriodTime	This shall be the coherent period-time measured on a channel
<b>Description:</b>	Type which shall contain the values, needed for calculating duty cycles.		

### 8.2.8 Icu\_IndexType

<b>Name:</b>	Icu_IndexType		
<b>Type:</b>	Unsigned Integer		
<b>Range:</b>	--	--	Implementation specific. This type shall be chosen in order to have the most efficient implementation on a specific microcontroller platform.
<b>Description:</b>	Type, to abstract the return value of the service Icu_GetTimestampIndex(). Since circular buffer handling is supported and Icu_GetTimestampIndex can return '0' as a legally true value (not as an error according to ICU107 and ICU135), Icu_IndexType may be implemented to have values 1..xyz.		

### 8.2.9 Icu\_EdgeNumberType

<b>Name:</b>	Icu_EdgeNumberType		
<b>Type:</b>	Unsigned Integer		
<b>Range:</b>	--	--	Implementation specific. This type shall be chosen in order to have the most efficient implementation on a specific microcontroller platform.
<b>Description:</b>	Type, to abstract the return value of the service Icu_GetEdgeNumbers().		

### 8.2.10 Icu\_MeasurementModeType

<b>Name:</b>	Icu_MeasurementModeType
--------------	-------------------------

<b>Type:</b>	Enumeration	
<b>Range:</b>	ICU_MODE_SIGNAL_EDGE_DETECT	Mode for detecting edges
	ICU_MODE_SIGNAL_MEASUREMENT	Mode for measuring different times between various configurable edges
	ICU_MODE_TIMESTAMP	Mode for capturing timer values on configurable edges
	ICU_MODE_EDGE_COUNTER	Mode for counting edges on configurable edges
<b>Description:</b>	Definition of the measurement mode type	

### 8.2.11 Icu\_SignalMeasurementPropertyType

<b>Name:</b>	Icu_SignalMeasurementPropertyType	
<b>Type:</b>	Enumeration	
<b>Range:</b>	ICU_LOW_TIME	The channel is configured for reading the elapsed Signal Low Time
	ICU_HIGH_TIME	The channel is configured for reading the elapsed Signal High Time
	ICU_PERIOD_TIME	The channel is configured for reading the elapsed Signal Period Time
	ICU_DUTY_CYCLE	The channel is configured to read values which are needed for calculating the duty cycle (coherent Active and Period Time).
<b>Description:</b>	Definition of the measurement property type	

### 8.2.12 Icu\_TimestampBufferType

<b>Name:</b>	Icu_TimestampBufferType	
<b>Type:</b>	Enumeration	
<b>Range:</b>	ICU_LINEAR_BUFFER	The buffer will just be filled once
	ICU_CIRCULAR_BUFFER	After reaching the end of the buffer, the driver restarts at the beginning of the buffer
<b>Description:</b>	Definition of the timestamp measurement property type	

## 8.3 Function definitions

This is a list of functions provided for upper layer modules.

### 8.3.1 Icu\_Init

#### ICU191:

<b>Service name:</b>	Icu_Init	
<b>Syntax:</b>	<pre>void Icu_Init(     const Icu_ConfigType* ConfigPtr )</pre>	
<b>Service ID[hex]:</b>	0x00	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Non Reentrant	
<b>Parameters (in):</b>	ConfigPtr	Pointer to a selected configuration structure
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	None	
<b>Description:</b>	This function initializes the driver.	

**ICU006:** The function `Icu_Init` shall initialize all relevant registers of the configured hardware with the values of the structure referenced by the parameter `ConfigPtr`.

The following rules regarding initialization of controller registers shall apply to this driver implementation:

- **ICU051:** If the hardware allows for only one usage of the register, the driver module implementing that functionality is responsible for initializing the register.
- **ICU052:** If the register can affect several hardware modules and if it is an I/O register it shall be initialized by the PORT driver.
- **ICU053:** If the register can affect several hardware modules and if it is not an I/O register it shall be initialized by the MCU driver.
- **ICU128:** One-time writable registers that require initialization directly after reset shall be initialized by the start-up code.
- **ICU129:** All other registers shall be initialized by the startup code.

**ICU061:** The function `Icu_Init` shall disable all notifications.

**ICU121:** The function `Icu_Init` shall disable the wakeup-capability of all channels .

**ICU040:** The function `Icu_Init` shall set all used ICU channels to status `ICU_IDLE`.

**ICU060:** The function `Icu_Init` shall set the module mode to `ICU_MODE_NORMAL`.

**ICU054:** The function `Icu_Init` shall only set the resources that are configured in the configuration file (including clearing of pending interrupt flags).

**ICU151:** The `Icu` module's environment shall not call `Icu_Init` during a running operation (e. g. timestamp measurement or edge counting).

**ICU023:** If development error detection for the `Icu` module is enabled: The function `Icu_Init` shall check the parameter `ConfigPtr` for not being NULL and shall raise the development error code `ICU_E_PARAM_CONFIG` if the check fails.

**ICU220:** If development error detection for the ICU module is enabled and the function `Icu_Init` is called when the ICU driver and hardware are already initialized, the function `Icu_Init` shall raise development error `ICU_E_ALREADY_INITIALIZED` and return without any action.

**ICU048** applies to the function `Icu_Init`.

### 8.3.2 `Icu_DelInit`

**ICU193:**

<b>Service name:</b>	<code>Icu_DelInit</code>
----------------------	--------------------------

<b>Syntax:</b>	void Icu_DeInit( )
<b>Service ID[hex]:</b>	0x01
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non Reentrant
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function de-initializes the ICU module.

**ICU035:** The function Icu\_DeInit shall de-initialize the ICU module.

**ICU036:** The function Icu\_DeInit shall set the state of the peripherals used by configuration as the same after power on reset. Values of registers which are not writeable are excluded.

**ICU091:** The function Icu\_DeInit shall influence only the peripherals which are allocated by static configuration and/or the runtime configuration set passed by the previous call of Icu\_Init().

**ICU037:** The function Icu\_DeInit shall disable all used interrupts and notifications.

**ICU152:** The Icu module's environment shall not call Icu\_DeInit during a running operation (e. g. timestamp measurement or edge counting)

**ICU092:** The function Icu\_DeInit shall be pre compile time configurable On/Off by configuration parameter IcuDeInitApi.

**ICU221:** A re-initialization of the ICU module by executing the Icu\_Init() function requires a de-initialization before by executing the Icu\_DeInit() function.

[ICU022](#) and [ICU048](#) apply to the function Icu\_DeInit.

### 8.3.3 Icu\_SetMode

**ICU194:**

<b>Service name:</b>	Icu_SetMode
<b>Syntax:</b>	void Icu_SetMode( Icu_ModeType Mode )
<b>Service ID[hex]:</b>	0x02
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non Reentrant
<b>Parameters (in):</b>	Mode ICU_MODE_NORMAL: Normal operation, all used interrupts are enabled according to the notification requests. ICU_MODE_SLEEP: Reduced power mode. In sleep mode only those notifications are available which are configured as wakeup capable.
<b>Parameters (inout):</b>	None

<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function sets the ICU mode.

**ICU008:** The function Icu\_SetMode shall set the operation mode to the given mode parameter.

This function influences the functionality of the ICU channels. Therefore the mode switching of the module shall be compatible to the overall state of the ECU.

**ICU095:** The function Icu\_SetMode shall be pre-compile time configurable On/Off by the configuration parameter IcuSetModeApi.

**ICU125:** If development error detection is enabled for the module Icu: the function Icu\_SetMode shall check the parameter Mode and shall raise the error **ICU\_E\_PARAM\_MODE** if the parameter Mode is not within the allowed range set in the configuration.

**ICU133:** This service can be called during running operations. If so, an ongoing operation that generates interrupts on a wakeup capable channel like e.g. time stamping or edge counting might lead to the ICU module not being able to properly enter sleep mode. This is then a system or ECU configuration issue not a problem of this specification.

[ICU022](#) and [ICU048](#) apply to the function Icu\_SetMode.

### 8.3.4 Icu\_DisableWakeup

**ICU195:**

<b>Service name:</b>	Icu_DisableWakeup
<b>Syntax:</b>	void Icu_DisableWakeup( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x03
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function disables the wakeup capability of a single ICU channel.

**ICU013:** The function Icu\_DisableWakeup shall disable the wakeup capability of a single ICU channel but only for ICU channels configured statically as wakeup capable true.

**ICU096:** The function Icu\_DisableWakeup shall be pre compile time configurable On/Off by the configuration parameter IcuDisableWakeupApi.

The settings done by this function are only relevant after the ICU\_MODE\_SLEEP is set.

**ICU024:** If development error detection is enabled: The function Icu\_DisableWakeup shall check the parameter Channel and shall raise development error ICU\_E\_PARAM\_CHANNEL if Channel is not within the allowed range set in the configuration..

**ICU059:** If development error detection is enabled: The function Icu\_DisableWakeup shall check the parameter Channel. The function Icu\_DisableWakeup shall raise development error ICU\_E\_PARAM\_CHANNEL if Channel is indexing an ICU channel statically not configured as wakeup capable.

[ICU022](#) and [ICU048](#) apply to the function Icu\_DisableWakeup.

### 8.3.5 Icu\_EnableWakeup

**ICU196:**

<b>Service name:</b>	Icu_EnableWakeup
<b>Syntax:</b>	void Icu_EnableWakeup( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x04
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function (re-)enables the wakeup capability of the given ICU channel.

**ICU014:** The function Icu\_EnableWakeup shall re-enable the wakeup capability of a single ICU channel for the following ICU mode selection(s). This service is only feasible for ICU channels configured as wakeup capable true.

To make the selection effective a call of the function Icu\_SetMode, requesting the mode ICU\_MODE\_SLEEP is required.

**ICU097:** The function Icu\_EnableWakeup shall be pre compile time configurable On/Off by configuration parameter IcuEnableWakeupApi.

**ICU155:** If development error detection is enabled: The function Icu\_EnableWakeup shall check the parameter Channel and shall raise the error ICU\_E\_PARAM\_CHANNEL if Channel is invalid.

**ICU156:** If development error detection is enabled: The function Icu\_EnableWakeup shall check the parameter Channel. The function Icu\_EnableWakeup shall raise the

error `ICU_E_PARAM_CHANNEL` if `Channel` is indexing an ICU channel statically not configured as wakeup capable.

[ICU022](#) and [ICU048](#) apply to the function `Icu_EnableWakeup`.

### 8.3.6 Icu\_SetActivationCondition

#### ICU197:

<b>Service name:</b>	Icu_SetActivationCondition	
<b>Syntax:</b>	<pre>void Icu_SetActivationCondition(     Icu_ChannelType Channel,     Icu_ActivationType Activation )</pre>	
<b>Service ID[hex]:</b>	0x05	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)	
<b>Parameters (in):</b>	Channel	Numeric identifier of the ICU channel
	Activation	Type of activation (if supported by hardware) - ICU_RISING_EDGE - ICU_FALLING_EDGE - ICU_BOTH_EDGES
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	None	
<b>Description:</b>	This function sets the activation-edge for the given channel.	

**ICU090:** The function `Icu_SetActivationCondition` shall set the activation-edge according to Activation parameter for the given channel. This service shall support channels which are configured for the following 8.2.10

:

- `ICU_MODE_SIGNAL_EDGE_DETECT`
- `ICU_MODE_TIMESTAMP`
- `ICU_MODE_EDGE_COUNTER`

**ICU139:** The function `Icu_SetActivationCondition` shall reset the state for the given channel to `ICU_IDLE`.

**ICU159:** If development error detection is enabled: The function `Icu_SetActivationCondition` shall check the parameter `Channel` and shall raise the error `ICU_E_PARAM_CHANNEL` if `Channel` is not within the range set in the configuration..

**ICU043:** If development error detection is enabled: The function `Icu_SetActivationCondition` shall check the parameter `Activation`. The function `Icu_SetActivationCondition` shall raise the error `ICU_E_PARAM_ACTIVATION` if `Activation` is invalid but only for the requested ICU channel.

[ICU022](#) and [ICU048](#) apply to the function `Icu_SetActivationCondition`.

### 8.3.7 Icu\_DisableNotification

**ICU198:**

<b>Service name:</b>	Icu_DisableNotification
<b>Syntax:</b>	void Icu_DisableNotification( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x06
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function disables the notification of a channel.

**ICU009:** The function Icu\_DisableNotification shall disable the notification on the given channel.

**ICU251:** If IcuWakeupCapability is TRUE and Icu\_DisableNotification is called, ICU driver shall call the API EcuM\_CheckWakeup().

This is done to avoid possible loss of wakeup events during a shutdown sequence.

**ICU160:** If development error detection is enabled: The function Icu\_DisableNotification shall check the parameter Channel and shall raise the error ICU\_E\_PARAM\_CHANNEL if Channel is invalid (invalid identifier).

[ICU022](#) and [ICU048](#) apply to the function Icu\_DisableNotification.

### 8.3.8 Icu\_EnableNotification

**ICU199:**

<b>Service name:</b>	Icu_EnableNotification
<b>Syntax:</b>	void Icu_EnableNotification( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x07
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function enables the notification on the given channel.

**ICU010:** The function Icu\_EnableNotification shall enable the notification on the given channel.

**ICU127:** The function Icu\_EnableNotification shall cancel pending interrupts in case the channel is configured for edge detection functionality.

**ICU252:** If IcuWakeupCapability is TRUE and Icu\_EnableNotification is called, ICU driver shall call the API EcuM\_CheckWakeup().

This is done to avoid possible loss of wakeup events during a shutdown sequence.

**ICU161:** If development error detection is enabled: The function Icu\_EnableNotification shall check the parameter Channel and shall raise the error ICU\_E\_PARAM\_CHANNEL if Channel is invalid (invalid identifier).

[ICU022](#) and [ICU048](#) apply to the function Icu\_EnableNotification.

### 8.3.9 Icu\_GetInputState

#### ICU200:

<b>Service name:</b>	Icu_GetInputState
<b>Syntax:</b>	Icu_InputStateType Icu_GetInputState( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x08
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	Icu_InputStateType   ICU_ACTIVE: An activation edge has been detected   ICU_IDLE: No activation edge has been detected since the last call of Icu_GetInputState() or Icu_Init().
<b>Description:</b>	This function returns the status of the ICU input.

**ICU030:** The function Icu\_GetInputState shall return the status of the ICU input. Only channels which are configured for the following IcuMeasurementMode shall be supported:

- ICU\_MODE\_SIGNAL\_EDGE\_DETECT
- ICU\_MODE\_SIGNAL\_MEASUREMENT

**ICU031:** If an activation edge has been detected the function Icu\_GetInputState shall return ICU\_ACTIVE for Edge Detection channels. For Signal Measurement a channel should be set to ICU\_ACTIVE not until this measurement has completed and the driver is able to provide useful information on the input signal.

**ICU032:** Once the function Icu\_GetInputState has returned the status ICU\_ACTIVE, the function Icu\_GetInputState shall set the stored status to ICU\_IDLE until the next edge is detected.

**ICU033:** If no activation edge has been detected the function Icu\_GetInputState shall return ICU\_IDLE.

**ICU122:** The function Icu\_GetInputState shall be pre compile time configurable On/Off by the configuration parameter IcuGetInputStateApi.

**ICU162:** If development error detection is enabled: The function Icu\_GetInputState shall check the parameter Channel and shall raise the error

ICU\_E\_PARAM\_CHANNEL if Channel is invalid (invalid identifier or channel not configured for modes ICU\_MODE\_SIGNAL\_EDGE\_DETECT or ICU\_MODE\_SIGNAL\_MEASUREMENT)

**ICU049:** If development error detection is enabled: The function Icu\_GetInputState shall return ICU\_IDLE if an error is detected.

[ICU022](#) and [ICU048](#) apply to the function Icu\_GetInputState.

### 8.3.10 Icu\_StartTimestamp

**ICU201:**

<b>Service name:</b>	Icu_StartTimestamp	
<b>Syntax:</b>	<pre>void Icu_StartTimestamp(     Icu_ChannelType Channel,     Icu_ValueType* BufferPtr,     uint16 BufferSize,     uint16 NotifyInterval )</pre>	
<b>Service ID[hex]:</b>	0x09	
<b>Sync/Async:</b>	Asynchronous	
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)	
<b>Parameters (in):</b>	Channel	Numeric identifier of the ICU channel
	BufferPtr	Pointer to the buffer-array where the timestamp values shall be placed.
	BufferSize	Size of the external buffer (number of entries)
	NotifyInterval	Notification interval (number of events). This parameter can not be checked in a reasonable way.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	None	
<b>Description:</b>	This function starts the capturing of timer values on the edges.	

**ICU063:** The function Icu\_StartTimestamp shall start the capturing of timer values on the edges

- activated by the service Icu\_SetActivationCondition ()  
(rising / falling / both edges)
- to an external buffer
- at the beginning of the buffer

**ICU064:** If circular buffer handling is configured (for the given channel), when the capture functionality reaches the end of the buffer, the Icu module shall start at the beginning of the buffer.

**ICU065:** If linear buffer handling is configured, when the capture functionality reaches the end of the buffer, the Icu module shall stop capturing timer values.

**ICU134:** The Icu module shall only call a notification function if the following facts are given:

- A notification function is configured
- The notification has been enabled by the call of Icu\_EnableNotification()
- NotifyInterval > 0
- The number of events specified by NotifyInterval has been captured

**ICU066:** The function Icu\_StartTimeStamp shall only be available in Measurement Mode “ICU\_MODE\_TIMESTAMP”.

**ICU098:** The function Icu\_StartTimestamp shall be pre compile time configurable On/Off by the configuration parameter: ICU\_TIMESTAMP\_API

**ICU163:** If development error detection is enabled: The function Icu\_StartTimestamp shall check the parameter Channel and shall raise the error ICU\_E\_PARAM\_CHANNEL if Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_TIMESTAMP).

**ICU120:** If development error detection is enabled: The function Icu\_StartTimestamp shall check the parameter BufferPtr. The function Icu\_StartTimestamp shall raise the error ICU\_E\_PARAM\_BUFFER\_PTR if BufferPtr is invalid (e.g. “0”).

**ICU108:** If development error detection is enabled: The function Icu\_StartTimestamp shall check the parameter BufferSize (check that size > 0). The function Icu\_StartTimestamp shall raise the error ICU\_E\_PARAM\_BUFFER\_SIZE if BufferSize is invalid (e.g. “0”).

[ICU022](#) and [ICU048](#) apply to the function Icu\_StartTimestamp.

### 8.3.11 Icu\_StopTimestamp

**ICU202:**

<b>Service name:</b>	Icu_StopTimestamp
<b>Syntax:</b>	void Icu_StopTimestamp (

	Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0a
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function stops the timestamp measurement of the given channel.

**ICU067:** The function Icu\_StopTimestamp shall stop the timestamp measurement of the given channel.

**ICU168:** In production mode the function Icu\_StopTimestamp shall not return an error when the Channel is not active (has not started or has already stopped).

**ICU165:** The function Icu\_StopTimestamp shall only be available in Measurement Mode: ICU\_MODE\_TIMESTAMP.

**ICU099:** The function Icu\_StopTimestamp shall be pre compile time configurable On/Off by the configuration parameter: IcuTimestampApi (see also chapter 10.2.8. [Configuration of optional API services](#))

**ICU164:** If development error detection is enabled: The function Icu\_StopTimestamp shall check the parameter Channel and shall raise development error ICU\_E\_PARAM\_CHANNEL if Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_TIMESTAMP)

**ICU166:** If development error detection is enabled: The function Icu\_StopTimestamp shall raise development error ICU\_E\_NOT\_STARTED if Channel is not active (has not started or is already stopped).

[ICU022](#) and [ICU048](#) apply to the function Icu\_StopTimestamp.

### 8.3.12 Icu\_GetTimestampIndex

**ICU203:**

<b>Service name:</b>	Icu_GetTimestampIndex
<b>Syntax:</b>	Icu_IndexType Icu_GetTimestampIndex( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0b
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	Icu_IndexType      Abstract return type to cover different microcontrollers.

<b>Description:</b>	This function reads the timestamp index of the given channel.
---------------------	---

**ICU071:** The function Icu\_GetTimestampIndex shall read the timestamp index of the given channel, which is the next to be written.

**ICU135:** The function Icu\_GetTimestampIndex shall return “0” in case the service is called before Icu\_StartTimestamp() (no buffer is defined in this case).

**ICU170:** The function Icu\_GetTimestamp shall only be available in Measurement Mode ICU\_MODE\_TIMESTAMP.

**ICU100:** The function Icu\_GetTimestamp shall be pre compile time configurable On/Off by the configuration parameter: IcuTimestampApi

**ICU169:** If development error detection is enabled: the function Icu\_GetTimestamp shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode Icu\_GetTimestamp), the function Icu\_GetTimeStamp shall raise development error ICU\_E\_PARAM\_CHANNEL.

**ICU107:** If development error detection is enabled: The function Icu\_GetTimestampIndex shall return “0” if an error is detected.

[ICU022](#) and [ICU048](#) apply to the function Icu\_GetTimestampIndex.

### 8.3.13 Icu\_ResetEdgeCount

**ICU204:**

<b>Service name:</b>	Icu_ResetEdgeCount
<b>Syntax:</b>	void Icu_ResetEdgeCount( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0c
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function resets the value of the counted edges to zero.

**ICU072:** The function Icu\_ResetEdgeCount shall reset the value of the counted edges to zero.

**ICU101:** The function Icu\_ResetEdgeCount shall be pre compile time configurable On/Off by the configuration parameter: ICU\_EDGE\_COUNT\_API

**ICU171:** If development error detection is enabled: the function Icu\_ResetEdgeCount shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode `ICU_MODE_EDGE_COUNTER`), then Icu\_ResetEdgeCount shall raise development error `ICU_E_PARAM_CHANNEL`.

[ICU022](#) and [ICU048](#) apply to the function Icu\_ResetEdgeCount.

### 8.3.14 Icu\_EnableEdgeCount

**ICU205:**

<b>Service name:</b>	Icu_EnableEdgeCount
<b>Syntax:</b>	void Icu_EnableEdgeCount( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0d
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function enables the counting of edges of the given channel.

**ICU078:** The function Icu\_EnableEdgeCount shall enable the counting of edges of the given channel.

Note: This service does not do the real counting itself.

**ICU073:** The function Icu\_EnableEdgeCount shall only count the configured<sup>1</sup> edges (rising edge / falling edge / both edges).

**ICU074:** The function IcuEnableEdgeCount shall be available for each ICU channel in Measurement Mode “Edge Counter”.

**ICU102:** The function Icu\_EnableEdgeCount shall be pre compile time configurable On/Off by the configuration parameter: `ICU_EDGE_COUNT_API`

**ICU172:** If development error detection is enabled, the function Icu\_EnableEdgeCount shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode `ICU_MODE_EDGE_COUNTER`), then the function Icu\_EnableEdgeCount shall raise development error `ICU_E_PARAM_CHANNEL`

[ICU022](#) and [ICU048](#) apply to the function Icu\_EnableEdgeCount.

---

<sup>1</sup> Configured edge after the call of Icu\_Init() (default-edge) or Icu\_SetActivationCondition().

### 8.3.15 Icu\_DisableEdgeCount

**ICU206:**

<b>Service name:</b>	Icu_DisableEdgeCount
<b>Syntax:</b>	void Icu_DisableEdgeCount( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0e
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function disables the counting of edges of the given channel.

**ICU079:** The function Icu\_DisableEdgeCount shall disable the counting of edges of the given channel.

To reset the edge counter, the service **Icu\_ResetEdgeCount()** is available.

**ICU103:** The function Icu\_DisableEdgeCount shall be pre compile time configurable On/Off by the configuration parameter IcuEdgeCountApi.

**ICU173:** If development error detection is enabled: the function Icu\_DisableEdgeCount shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_EDGE\_COUNTER), the function Icu\_DisableEdgeCount shall raise development error ICU\_E\_PARAM\_CHANNEL.

[ICU022](#) and [ICU048](#) apply to the function Icu\_DisableEdgeCount.

### 8.3.16 Icu\_GetEdgeNumbers

**ICU207:**

<b>Service name:</b>	Icu_GetEdgeNumbers
<b>Syntax:</b>	Icu_EdgeNumberType Icu_GetEdgeNumbers( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x0f
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	Icu_EdgeNumberType Abstract return type to cover different microcontrollers.
<b>Description:</b>	This function reads the number of counted edges.

**ICU080:** The function Icu\_GetEdgeNumbers shall read the number of counted edges after the last call of **Icu\_ResetEdgeCount ()**.

**ICU104:** The function Icu\_GetEdgeNumbers shall be pre compile time configurable On/Off by the configuration parameter: **ICU\_EDGE\_COUNT\_API**

**ICU174:** If development error detection is enabled, the function Icu\_GetEdgeNumbers shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode **ICU\_MODE\_EDGE\_COUNTER**), the function Icu\_GetEdgeNumbers shall raise development error **ICU\_E\_PARAM\_CHANNEL**.

**ICU175:** If development error detection is enabled: The function Icu\_GetEdgeNumbers shall return "0" if an error is detected.

[ICU022](#) and [ICU048](#) apply to the function Icu\_GetEdgeNumbers.

### 8.3.17 Icu\_StartSignalMeasurement

**ICU208:**

<b>Service name:</b>	Icu_StartSignalMeasurement
<b>Syntax:</b>	void Icu_StartSignalMeasurement( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x13
<b>Sync/Async:</b>	Asynchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function starts the measurement of signals.

**ICU140:** The function Icu\_StartSignalMeasurement shall start the measurement of signals beginning with the configured default start edge which occurs first after the call of this service.

**ICU141:** The function Icu\_StartSignalMeasurement shall only be available in Measurement Mode "**ICU\_MODE\_SIGNAL\_MEASUREMENT**".

**ICU146:** The function Icu\_StartSignalMeasurement shall reset the state for the given channel to **ICU\_IDLE**.

**ICU142:** The function Icu\_StartSignalMeasurement shall be pre compile time configurable On/Off by the configuration parameter **IcuSignalMeasurementApi\_**

**ICU176:** If development error detection is enabled, the function Icu\_StartSignalMeasurement shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode

ICU\_MODE\_SIGNAL\_MEASUREMENT), the function Icu\_StartSignalMeasurement shall raise development error [ICU\\_E\\_PARAM\\_CHANNEL](#).

[ICU022](#) and [ICU048](#) apply to the function Icu\_StartSignalMeasurement.

### 8.3.18 Icu\_StopSignalMeasurement

#### ICU209:

<b>Service name:</b>	Icu_StopSignalMeasurement
<b>Syntax:</b>	void Icu_StopSignalMeasurement( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x14
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This function stops the measurement of signals of the given channel.

**ICU143:** The function Icu\_StopSignalMeasurement shall stop the measurement of signals of the given channel.

**ICU144:** The function Icu\_StopSignalMeasurement shall only be available in Measurement Mode "ICU\_MODE\_SIGNAL\_MEASUREMENT"

**ICU145:** The function Icu\_StopSignalMeasurement shall be pre compile time configurable On/Off by the configuration parameter [IcuSignalMeasurementApi](#)

**ICU177:** If development error detection is enabled: the function Icu\_StopSignalMeasurement shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_SIGNAL\_MEASUREMENT), the function Icu\_StopSignalMeasurement shall raise development error [ICU\\_E\\_PARAM\\_CHANNEL](#).

[ICU022](#) and [ICU048](#) apply to the function Icu\_StopSignalMeasurement.

### 8.3.19 Icu\_GetTimeElapsed

#### ICU210:

<b>Service name:</b>	Icu_GetTimeElapsed
<b>Syntax:</b>	Icu_ValueType Icu_GetTimeElapsed( Icu_ChannelType Channel )
<b>Service ID[hex]:</b>	0x10
<b>Sync/Async:</b>	Synchronous

<b>Reentrancy:</b>	Reentrant (limited according to ICU050)	
<b>Parameters (in):</b>	Channel	Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Icu_ValueType	see Description
<b>Description:</b>	This function reads the elapsed Signal Low Time for the given channel.	

**ICU081:** The function Icu\_GetTimeElapsed shall read the elapsed Signal Low Time for the given channel that is configured in Measurement Mode “Signal Measurement, Signal Low Time”. The elapsed time is measured between a falling edge and the consecutive rising edge of the channel.

**ICU082:** The function Icu\_GetTimeElapsed shall read the elapsed Signal High Time for the given channel that is configured in Measurement Mode “Signal Measurement, Signal High Time”. The elapsed time is measured between a rising edge and the consecutive falling edge of the channel.

**ICU083:** The function Icu\_GetTimeElapsed shall read the elapsed Signal Period Time for the given channel that is configured in Measurement Mode “Signal Measurement, Signal Period Time”. The elapsed time is measured between consecutive rising (or falling) edges of the channel. The period start edge is configurable.

**ICU136:** The function Icu\_GetTimeElapsed shall return “0” in case

- no requested time has been captured (see Figure 9.19, letter “A”)
- the capturing of a requested time is ongoing and not finished (see Figure 9.19, letter “B”)
- a captured time was already returned once by this service and this service is called again (see Figure 9.19, letter “D”)

**ICU105:** The function Icu\_GetTimeElapsed shall be pre compile time configurable On/Off by the configuration parameter IcuGetTimeElapsedApi.

**ICU178:** If development error detection is enabled, the parameter Channel shall be checked by this service. If Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_SIGNAL\_MEASUREMENT), then the error [ICU\\_E\\_PARAM\\_CHANNEL](#) shall be reported to the Development Error Tracer.

**ICU179:** If development error detection is enabled and an error is detected this service shall return “0”.

[ICU022](#) and [ICU048](#) apply to the function Icu\_GetTimeElapsed.

### 8.3.20 Icu\_GetDutyCycleValues

**ICU211:**

<b>Service name:</b>	Icu_GetDutyCycleValues
----------------------	------------------------

<b>Syntax:</b>	void Icu_GetDutyCycleValues( Icu_ChannelType Channel, Icu_DutyCycleType* DutyCycleValues )
<b>Service ID[hex]:</b>	0x11
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrant (limited according to ICU050)
<b>Parameters (in):</b>	Channel      Numeric identifier of the ICU channel
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	DutyCycleValues      Pointer to a buffer where the results (high time and period time) shall be placed.
<b>Return value:</b>	None
<b>Description:</b>	This function reads the coherent active time and period time for the given ICU Channel.

**ICU084:** The function Icu\_GetDutyCycleValues shall read the coherent active time and period time for the given ICU Channel, if it is configured in Measurement Mode “Signal Measurement, Duty Cycle Values”.

**ICU137:** The function Icu\_GetDutyCycleValues shall return “0” in case

- no coherent active- and period time has been captured (similar to Figure 9.19, letter “A”)
- the capturing of a requested high- and period time is ongoing and not finished (meant: the function shall return “0” until the first valid value has been captured and the captured value shall be stored until a new value is captured) (similar to Figure 9.19, letter “B”)
- captured duty cycle values were already returned once by this service and this service is called again (similar to Figure 9.19, letter “D”)

**ICU106:** The function Icu\_GetDutyCycleValues shall be pre compile time configurable On/Off by the configuration parameter IcuGetDutyCycleValuesApi.

**ICU180:** If development error detection is enabled: the function Icu\_GetDutyCycleValues shall check the parameter Channel. If Channel is invalid (invalid identifier or channel not configured for mode ICU\_MODE\_SIGNAL\_MEASUREMENT, Duty Cycle Values), the function Icu\_GetDutyCycleValues shall raise development error [ICU\\_E\\_PARAM\\_CHANNEL](#).

**ICU181:** If development error detection is enabled, the function Icu\_GetDutyCycleValues shall check the parameter DutyCycleValues. If DutyCycleValues is invalid, the function Icu\_GetDutyCycleValues shall raise development error [ICU\\_E\\_PARAM\\_BUFFER\\_PTR](#).

[ICU022](#) and [ICU048](#) apply to the function Icu\_GetDutyCycleValues.

### 8.3.21 Icu\_GetVersionInfo

**ICU212:**

<b>Service name:</b>	Icu_GetVersionInfo
<b>Syntax:</b>	void Icu_GetVersionInfo(

	Std_VersionInfoType* versioninfo )
<b>Service ID[hex]:</b>	0x12
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non reentrant
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	versioninfo   Pointer to where to store the version information of this module.
<b>Return value:</b>	None
<b>Description:</b>	This function returns the version information of this module.

**ICU182:** The function Icu\_GetVersionInfo shall return the version information of this module. The version information includes:

- Module Id (See Literature [4])
- Vendor Id
- Vendor specific version numbers.

**ICU183:** The Icu module's environment may call the function Icu\_GetVersionInfo at any time.

Hint:

If source code for caller and callee of this function is available this function should be realized as a macro. The macro should be defined in the modules header file.

**ICU094:** The function Icu\_GetVersionInfo shall be pre compile time configurable On/Off by the configuration parameter IcuGetVersionInfoApi.

## 8.4 Callback notifications

Since the ICU is a driver module, it doesn't provide any callback functions for lower layer modules.

## 8.5 Scheduled functions

None

## 8.6 Expected Interfaces

In this chapter, all interfaces required from other modules are listed.

### 8.6.1 Mandatory Interfaces

None

## 8.6.2 Optional Interfaces

This chapter defines all interfaces which are required to fulfill an optional functionality of the module.

### ICU213:

<i>API function</i>	<i>Description</i>
Dem_ReportErrorStatus	Reports errors to the DEM.
Det_ReportError	Service to report development errors.
EcuM_ValidateWakeupEvent	After wakeup, the ECU State Manager will stop the process during the WAKEUP VALIDATION state to wait for validation of the wakeup event. The validation is carried out with a call to this API service.

This service will be called if all of the following are true:

- **ICU055**: the static configuration parameter IcuReportWakeupSource is set to “ON”
- **ICU056**: the module is in mode ICU\_MODE\_SLEEP
- **ICU057**: a wakeup event occurs on a wakeup capable ICU channel.

ICU228: EcuM\_CheckWakeup shall be called within the Interrupt Service Routine servicing the ICU channel wakeup event on wakeup-capable channel.

ICU229: The ISR's, providing the wakeup events, shall be responsible for resetting the interrupt flags if required by hardware.

## 8.6.3 Configurable interfaces

In this chapter all interfaces are listed where the target function could be configured. The target function is usually a call-back function. The names of these kind of interfaces are not fixed because they are configurable.

**ICU119**: The ISRs shall reset the interrupt flags (if needed by hardware) and call the corresponding notification functions.

**ICU018**: The Icu notification functions shall be configurable as function pointers within the initialization data structure (`Icu_ConfigType`).

**ICU020**: If a notification function is configured as a null pointer, no call shall be executed.

**ICU187**: The Icu module's notification functions shall have no parameters and no return value.

### ICU214:

<b>Service name:</b>	Icu_SignalNotification_<Channel>
<b>Syntax:</b>	void Icu_SignalNotification_<Channel>( )
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrancy of interface not relevant for this module. (in general it is in this case)

	not reentrant).
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	According to the last call of Icu_EnableNotification, this notification function to be called if the requested signal edge (rising / falling / both edges) occurs (once per edge).

**ICU021:** According to the last call of Icu\_EnableNotification(), the Icu module shall call the notification function Icu\_SignalNotification\_<Channel> if the requested signal edge (rising / falling / both edges) occurs (once per edge).

**ICU044:** Only those edge notifications shall be provided, which are supported by hardware.

**ICU042:** After a call of Icu\_DisableNotification ,the Icu module shall not call the the notification function Icu\_SignalNotification\_<Channel>.

**ICU215:**

<b>Service name:</b>	Icu_TimestampNotification_<Channel>
<b>Syntax:</b>	void Icu_TimestampNotification_<Channel>( )
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Reentrancy of interface not relevant for this module. (in general it is in this case not reentrant).
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	This notification to be called if the number of requested timestamps (Notification interval > 0) are acquired and if the notification has been enabled by the call of Icu_EnableNotification().

**ICU216:** The Icu module shall call the notification Icu\_TimestampNotification\_<Channel> if the number of requested timestamps (Notification interval > 0) are acquired and if the notification has been enabled by the call of Icu\_EnableNotification().

**ICU217:** After a call of Icu\_DisableNotification the Icu module shall NOT call the notification Icu\_TimestampNotification\_<Channel>.

**ICU218:** The Icu module's notification Icu\_TimestampNotification\_<Channel> depends on pre-processor switch IcuTimestampApi

## 9 Sequence diagrams

### 9.1 Icu\_Init




Figure 9.1: Initialization of the ICU driver

### 9.2 Icu\_DelInit





Figure 9.2: De-Initialization of the ICU driver


## 9.3 Validate Wakeup Events

Note: The Sequence charts for the ICU can be found in the ECU State Manager specification [10]


## 9.4 Icu\_SetMode




**Figure 9.3: Enabled notifications in SLEEP mode**



**Figure 9.4: Disabled reporting of wakeup sources in SLEEP mode**



**Figure 9.5: Disabled edge notification in SLEEP mode**

**Figure 9.6: Un-Enabled reporting of notifications in SLEEP mode**

## 9.5 Icu\_DisableWakeup






Figure 9.7: Disabling of wakeup-capabilities

## 9.6 Icu\_EnableWakeup




**Figure 9.8: Enabling of wakeup-capabilities**

## 9.7 Icu\_SetActivationCondition




**Figure 9.9: Setting up the activation condition for a channel**

## 9.8 Icu\_DisableNotification




**Figure 9.10: Disabling of the notification for a channel**

## 9.9 Icu\_EnableNotification




**Figure 9.11: Enabling of the edge-notification for a channel**



**Figure 9.12: Re-enabling of the notification for a channel**

## 9.10 Icu\_GetInputState



**Figure 9.13: Polling of the channel status**

## 9.11 Icu Timestamping

The following figure shall show the interactions between the different timestamp API-services.





Figure 9.14: Overview of the timestamping functionality of the ICU driver

The Timestamping in general is shown in the following figure:



**Figure 9.15: Timestamping overview**

## 9.12 Icu Edge Counting






Figure 9.16: Inquire the number of counted edges

## 9.13 Icu\_GetTimeElapsed



**Figure 9.17: Inquire the elapsed level-time of a channel**



**Figure 9.18: Inquire the elapsed period time of a channel**

The following example shows the exemplary behaviour before, while and after capturing the “high time” of a signal.

**The shown behaviour is also appropriate for the service  
Icu\_GetDutyCycleValues()!**




Figure 9.19: Inquire the elapsed high time of a channel

## 9.14 Icu\_GetDutyCycleValues




Figure 9.20: Measure the values needed for calculation of duty cycles

## 9.15 Icu\_SignalNotification and Icu\_GetInputState




Figure 9.21: Cooperative usage of notification and polling mechanism

## 10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification, Chapter 10.1 describes fundamentals. It also specifies a template (table) you shall use for the parameter specification. We intend to leave Chapter 10.1 in the specification to guarantee comprehension.

Chapter 10.2 specifies the structure (containers) and the parameters of the module ICU.

Chapter 10.3 specifies published information of the module ICU.

### 10.1 How to read this chapter

In addition to this section, it is highly recommended to read the documents:

- AUTOSAR Layered Software Architecture [9]
- AUTOSAR ECU Configuration Specification [8]. This document describes the AUTOSAR configuration methodology and the AUTOSAR configuration metamodel in detail.

The following is only a short survey of the topic and it will not replace the ECU Configuration Specification document.

#### 10.1.1 Configuration and configuration parameters

Configuration parameters define the variability of the generic part(s) of an implementation of a module. This means that only generic or configurable module implementation can be adapted to the environment (software/hardware) in use during system and/or ECU configuration.

The configuration of parameters can be achieved at different times during the software process: before compile time, before link time or after build time. In the following, the term “*configuration class*” (of a parameter) shall be used in order to refer to a *specific configuration point in time*.

#### 10.1.2 Variants

Variants describe sets of configuration parameters. E.g., variant 1: only pre-compile time configuration parameters; variant 2: mix of pre-compile- and post build time-configuration parameters. In one variant a parameter can only be of one configuration class.

Thus describe the possible configuration variants of this module. Each Variant must have a unique name which could be referenced to in later chapters. The maximum number of allowed variants is 3.

### 10.1.3 Containers

Containers structure the set of configuration parameters. This means:

- all configuration parameters are kept in containers.
- (sub-) containers can reference (sub-) containers. It is possible to assign a multiplicity to these references. The multiplicity then defines the possible number of instances of the contained parameters.

## 10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe Chapters 7 and Chapter 8.

### 10.2.1 Variants

**ICU188:** Variant PC (**Pre Compile**): Only pre-compile time parameters

**ICU189:** Variant PB (**Post Build**): This variant allows a mix of pre-compile time- and post build time-configuration parameters (multiple-selectable configurable configuration parameter sets).

**ICU138:** The initialization function of this module shall always have a pointer as a parameter, even though for Variant PC no configuration set shall be given. Instead a NULL pointer shall be passed to the initialization function.

**ICU148:** If not applicable, a NULL pointer shall be passed to the initialization routine. In this case the check for this NULL pointer ([ICU023](#)) has to be omitted

### 10.2.2 Icu

<b>Module Name</b>	Icu
<b>Module Description</b>	Configuration of the Icu (Input Capture Unit) module.

#### Included Containers

<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
IcuConfigSet	1	This container is the base for a multiple configuration set
IcuGeneral	1	Configuration of general ICU parameters.
IcuOptionalApis	1	This container contains all configuration switches for configuring optional API services of the ICU driver.

### 10.2.3 IcuGeneral

<b>SWS Item</b>	ICU026 :
<b>Container Name</b>	IcuGeneral{General Configuration}
<b>Description</b>	Configuration of general ICU parameters.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	ICU232 :		
<b>Name</b>	IcuDevErrorDetect {ICU_DEV_ERROR_DETECT}		
<b>Description</b>	Switches the Development Error Detection and Notification on or off. true: Enabled. false: Disabled.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU221 :
-----------------	----------

<b>Name</b>	IcuIndex		
<b>Description</b>	Specifies the Instanceld of this module instance. If only one instance is present it shall have the Id 0.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	..		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>			

<b>SWS Item</b>	ICU233 :		
<b>Name</b>	IcuReportWakeupSource {ICU_REPORT_WAKEUP_SOURCE}		
<b>Description</b>	Switch for enabling Wakeup source reporting. true: Report Wakeup source. false: Do not report Wakeup source.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

#### No Included Containers

#### 10.2.4 IcuOptionalApis

<b>SWS Item</b>	ICU114 :		
<b>Container Name</b>	IcuOptionalApis{Configuration of optional API services}		
<b>Description</b>	This container contains all configuration switches for configuring optional API services of the ICU driver.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	ICU234 :		
<b>Name</b>	IcuDelInitApi {ICU_DE_INIT_API}		
<b>Description</b>	Adds / removes the service Icu_Delinit() from the code. true: Icu_Delinit() can be used. false: Icu_Delinit() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU235 :		
<b>Name</b>	IcuDisableWakeupApi {ICU_DISABLE_WAKEUP_API}		
<b>Description</b>	Adds / removes the service Icu_DisableWakeup() from the code. true: Icu_DisableWakeup() can be used. false: Icu_DisableWakeup() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		

<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU124 :		
<b>Name</b>	IcuEdgeCountApi {ICU_EDGE_COUNT_API}		
<b>Description</b>	Adds / removes all services related to the edge counting functionality as listed below, from the code: Icu_ResetEdgeCount(), Icu_EnableEdgeCount(), Icu_DisableEdgeCount(), Icu_GetEdgeNumbers(). true: The services listed above can be used. false: The services listed above can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU236 :		
<b>Name</b>	IcuEnableWakeupApi {ICU_ENABLE_WAKEUP_API}		
<b>Description</b>	Adds / removes the service Icu_EnableWakeup() from the code. true: Icu_EnableWakeup() can be used. false: Icu_EnableWakeup() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU237 :		
<b>Name</b>	IcuGetDutyCycleValuesApi {ICU_GET_DUTY_CYCLE_VALUES_API}		
<b>Description</b>	Adds / removes the service Icu_GetDutyCycleValues() from the code. true: Icu_GetDutyCycleValues() can be used. false: Icu_GetDutyCycleValues() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module dependency: If IcuSignalMeasurementApi==false this switch shall also be set to false.		

<b>SWS Item</b>	ICU238 :		
<b>Name</b>	IcuGetInputStateApi {ICU_GET_INPUT_STATE_API}		
<b>Description</b>	Adds / removes the service Icu_GetInputState() from the code. true:		

	lcu_GetInputState() can be used. false: lcu_GetInputState() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU239 :		
<b>Name</b>	lcuGetTimeElapsedApi {ICU_GET_TIME_ELAPSED_API}		
<b>Description</b>	Adds / removes the service lcu_GetTimeElapsed() from the code. true: lcu_GetTimeElapsed() can be used. false: lcu_GetTimeElapsed() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module dependency: If lcuSignalMeasurementApi==false this switch shall also be set to false.		

<b>SWS Item</b>	ICU240 :		
<b>Name</b>	lcuGetVersionInfoApi {ICU_GET_VERSION_INFO_API}		
<b>Description</b>	Adds / removes the service lcu_GetVersionInfo() from the code. true: lcu_GetVersionInfo() can be used. false: lcu_GetVersionInfo() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU241 :		
<b>Name</b>	lcuSetModeApi {ICU_SET_MODE_API}		
<b>Description</b>	Adds / removes the service lcu_SetMode() from the code. true: lcu_SetMode() can be used. false: lcu_SetMode() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU242 :		
<b>Name</b>	IcuSignalMeasurementApi {ICU_SIGNAL_MEASUREMENT_API}		
<b>Description</b>	Adds / removes the services Icu_StartSignalMeasurement() and Icu_StopSignalMeasurement() from the code. true: Icu_StartSignalMeasurement() and Icu_StopSignalMeasurement() can be used. false: Icu_StartSignalMeasurement() and Icu_StopSignalMeasurement() can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<i>Pre-compile time</i>	X	All Variants
	<i>Link time</i>	--	
	<i>Post-build time</i>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU123 :		
<b>Name</b>	IcuTimestampApi {ICU_TIMESTAMP_API}		
<b>Description</b>	Adds / removes all services related to the timestamping functionality as listed below from the code: Icu_StartTimestamp(), Icu_StopTimestamp(), Icu_GetTimestampIndex(). true: The services listed above can be used. false: The services listed above can not be used.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<i>Pre-compile time</i>	X	All Variants
	<i>Link time</i>	--	
	<i>Post-build time</i>	--	
<b>Scope / Dependency</b>	scope: Module		

#### No Included Containers

#### 10.2.5 IcuChannel

<b>SWS Item</b>	ICU027 :		
<b>Container Name</b>	IcuChannel		
<b>Description</b>	Configuration of an individual ICU channel.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	ECUC_Icu_00354 :		
<b>Name</b>	IcuChannelId		
<b>Description</b>	Channel Id of the ICU channel. This value will be assigned to the symbolic name derived of the IcuChannel container short name.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Range</b>	0 ..		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<i>Pre-compile time</i>	X	VARIANT-PRE-COMPIL
	<i>Link time</i>	--	
	<i>Post-build time</i>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU222 :		
<b>Name</b>	IcuDefaultStartEdge {Icu_DefaultStartEdge}		

<b>Description</b>	Configures the default-activation-edge which shall be used for this channel if there was no activation-edge configured by the call of service Icu_SetActivationCondition(). In case the Measurement Mode is "IcuSignalMeasurement" and the properties "DutyCycle" or "Period" are set, the edge configured here is used as Default Period Start Edge. Implementation Type: Icu_ActivationType		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	ICU_BOTH_EDGES	As default, both edges are used.	
	ICU_FALLING_EDGE	As default, falling edge is the used.	
	ICU_RISING_EDGE	As default, rising edge is the used.	
<b>ConfigurationClass</b>	<i>Pre-compile time</i>	X	VARIANT-PRE-COMPIL
	<i>Link time</i>	--	
	<i>Post-build time</i>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	ICU223 :		
<b>Name</b>	IcuMeasurementMode {Icu_MeasurementMode}		
<b>Description</b>	Configures the measurement mode of this channel. Implementation Type: Icu_MeasurementModeType		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	ICU_MODE_EDGE_COUNTER	The channel is used to count the edges which are configured by the call of the service Icu_SetActivationCondition(). The following API services support this mode: - Icu_EnableEdgeCount() - Icu_DisableEdgeCount() - Icu_GetEdgeNumbers() - Icu_ResetEdgeCount() This mode can only be configured if IcuEdgeVountApi is switched on.	
	ICU_MODE_SIGNAL_EDGE_DETECT	The channel is used for detecting the edges which are configured by the call of the service Icu_SetActivationCondition(). The following API services support this mode: - Icu_EnableNotification() - Icu_DisableNotification() - Icu_GetInputState()	
	ICU_MODE_SIGNAL_MEASUREMENT	The channel is used to measure different times between various configurable edges. The configuration of the period-start edges are done by configuration and cannot be changed during runtime. The following API services support this mode: - Icu_GetTimeElapsed() - Icu_GetDutyCycleValues() - Icu_GetInputState() This mode can only be configured if at least one of the following switches are set to "true": - IcuGetDutyCycleValuesApi - IcuGetTimeElapsedApi	
	ICU_MODE_TIMESTAMP	The channel is used to capture timer values on the edges which are configured by the call of the service	

		lcu_SetActivationCondition(). The following API services support this mode: - lcu_StartTimestamp() - lcu_StopTimestamp() - lcu_GetTimestampIndex() This mode can only be configured if lcuTimeStampApi is switched on.	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: The possible measurement modes are depending on the pre-processor switches, which enable/disable optional API services.		

<b>SWS Item</b>	ICU224 :		
<b>Name</b>	lcuWakeupCapability {lcu_WakeupCapability}		
<b>Description</b>	Information about the wakeup-capability of this channel. true: Channel is wakeup capable. false: Channel is not wakeup capable.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

Included Containers			
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>	
IcuEdgeCounterMeasurement	0..1	This container contains the configuration (parameters) in case the measurement mode is "IcuEdgeCounter"	
IcuSignalEdgeDetection	0..1	This container contains the configuration (parameters) in case the measurement mode is "IcuSignalEdgeDetection"	
IcuSignalMeasurement	0..1	This container contains the configuration (parameters) in case the measurement mode is "IcuSignalMeasurement"	
IcuTimestampMeasurement	0..1	This container contains the configuration (parameters) in case the measurement mode is "IcuTimestamp"	
IcuWakeup	0..1	This container contains the configuration (parameters) needed to configure a wakeup capable channel	

## 10.2.6 IcuSignalEdgeDetection

<b>SWS Item</b>	ICU021 :		
<b>Container Name</b>	IcuSignalEdgeDetection{Configuration of Signal Edge Detection}		
<b>Description</b>	This container contains the configuration (parameters) in case the measurement mode is "IcuSignalEdgeDetection"		
Configuration Parameters			

<b>SWS Item</b>	ICU225 :		
<b>Name</b>	lcuSignalNotification {lcu_SignalNotification_<Channel>}		
<b>Description</b>	Notification function for signal notification.		
<b>Multiplicity</b>	1		
<b>Type</b>	FunctionNameDef		
<b>Default value</b>	--		

<b>regularExpression</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: IcuMeasurementMode		

**No Included Containers**
**10.2.7 IcuSignalMeasurement**

<b>SWS Item</b>	ICU226 :		
<b>Container Name</b>	IcuSignalMeasurement{Configuration of Signal Measurement}		
<b>Description</b>	This container contains the configuration (parameters) in case the measurement mode is "IcuSignalMeasurement"		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	ICU227 :		
<b>Name</b>	IcuSignalMeasurementProperty {Icu_SignalMeasurementProperty}		
<b>Description</b>	Configures the property that could be measured in case the mode is "IcuSignalMeasurement". This property can not be changed during runtime. Implementation Type: Icu_SignalMeasurementPropertyType		
<b>Multiplicity</b>	1		
	<b>Type</b>	EnumerationParamDef	
	<b>Range</b>	ICU_DUTY_CYCLE	The channel is configured to read values which are needed for calculating the duty cycle (coherent Active and Period Time).
		ICU_HIGH_TIME	The channel is configured for reading the elapsed Signal High Time
		ICU_LOW_TIME	The channel is configured for reading the elapsed Signal Low Time
		ICU_PERIOD_TIME	The channel is configured for reading the elapsed Signal Period Time
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: IcuMeasurementMode, IcuGetDutyCycleValuesApi, IcuGetTimeElapsedApi		

**No Included Containers**
**10.2.8 IcuTimestampMeasurement**

<b>SWS Item</b>	ICU228 :		
<b>Container Name</b>	IcuTimestampMeasurement{Configuration of Timestamp Measurement}		
<b>Description</b>	This container contains the configuration (parameters) in case the measurement mode is "IcuTimestamp"		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	ICU229 :		
<b>Name</b>	IcuTimestampMeasurementProperty {Icu_TimestampMeasurementProperty}		
<b>Description</b>	Configures the handling of the buffer in case the mode is "Timestamp" Implementation Type: Icu_TimestampBufferType		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		

<b>Range</b>	ICU_CIRCULAR_BUFFER	After reaching the end of the buffer, the driver restarts at the beginning of the buffer	
	ICU_LINEAR_BUFFER	The buffer will just be filled once	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: IcuMeasurementMode		

<b>SWS Item</b>	ICU230 :		
<b>Name</b>	IcuTimestampNotification {Icu_TimestampNotification_<Channel>}		
<b>Description</b>	Notification function if the number of requested timestamps (Notification interval > 0) are acquired.		
<b>Multiplicity</b>	1		
<b>Type</b>	FunctionNameDef		
<b>Default value</b>	--		
<b>regularExpression</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: IcuTimestampApi		

#### No Included Containers

#### 10.2.9 IcuEdgeCounterMeasurement

<b>SWS Item</b>	ICU076 :		
<b>Container Name</b>	IcuEdgeCounterMeasurement{Configuration of Edge Counter Measurement}		
<b>Description</b>	This container contains the configuration (parameters) in case the measurement mode is "IcuEdgeCounter"		
<b>Configuration Parameters</b>			

#### No Included Containers

#### 10.2.10 IcuWakeup

<b>SWS Item</b>	ICU126 :		
<b>Container Name</b>	IcuWakeup{Wakeup Configuration}		
<b>Description</b>	This container contains the configuration (parameters) needed to configure a wakeup capable channel		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	ICU231 :		
<b>Name</b>	IcuChannelWakeuInfo {Icu_ChannelWakeuInfo}		
<b>Description</b>	If the wakeup-capability is true the wakeup source referenced is transmitted to the ECU State Manager (EcUM) . Implementation Type: reference to EcUM_WakeupSourceType		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to [ EcumWakeupSource ]		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	M	VARIANT-POST-BUILD

	<b>time</b>		
<b>Scope / Dependency</b>	scope: ECU dependency: IcuWakeupCapability and IcuReportWakeupSource		

**No Included Containers**
**10.2.11 IcuConfigSet**

<b>SWS Item</b>	ICU219 :
<b>Container Name</b>	IcuConfigSet [Multi Config Container]
<b>Description</b>	This container is the base for a multiple configuration set
<b>Configuration Parameters</b>	

<b>SWS Item</b>	ICU220 :									
<b>Name</b>	IcuMaxChannel {ICU_MAX_CHANNEL}									
<b>Description</b>	This parameter contains the number of Channels configured. It will be gathered by tools during the configuration stage. calculationFormula = Number of configured Icu Channels Implementation Type: Icu_ChannelType									
<b>Multiplicity</b>	1									
<b>Type</b>	DerivedIntegerParamDef									
<b>Range</b>	0 ..									
<b>Default value</b>	--									
<b>ConfigurationClass</b>	<table border="1"> <tr> <td><i>Pre-compile time</i></td> <td>X</td> <td>VARIANT-PRE-COMPILE</td> </tr> <tr> <td><i>Link time</i></td> <td>--</td> <td></td> </tr> <tr> <td><i>Post-build time</i></td> <td>M</td> <td>VARIANT-POST-BUILD</td> </tr> </table>	<i>Pre-compile time</i>	X	VARIANT-PRE-COMPILE	<i>Link time</i>	--		<i>Post-build time</i>	M	VARIANT-POST-BUILD
<i>Pre-compile time</i>	X	VARIANT-PRE-COMPILE								
<i>Link time</i>	--									
<i>Post-build time</i>	M	VARIANT-POST-BUILD								
<b>Scope / Dependency</b>	scope: Module									

**Included Containers**

<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
IcuChannel	1..*	Configuration of an individual ICU channel.

## 10.3 Published Information

Published information contains data defined by the implementer of the SW module that does not change when the module is adapted (i.e. configured) to the actual HW/SW environment. It thus contains version and manufacturer information.

The standard common published information like

```
vendorId (<Module>_VENDOR_ID),  
moduleId (<Module>_MODULE_ID),  
arMajorVersion (<Module>_AR_MAJOR_VERSION),  
arMinorVersion (<Module>_AR_MINOR_VERSION),  
arPatchVersion (<Module>_AR_PATCH_VERSION),  
swMajorVersion (<Module>_SW_MAJOR_VERSION),  
swMinorVersion (<Module>_SW_MINOR_VERSION),  
swPatchVersion (<Module>_SW_PATCH_VERSION),  
vendorApiInfix (<Module>_VENDOR_API_INFIX)
```

is provided in the BSW Module Description Template (see [11] Figure 4.1 and Figure 7.1).

Additional published parameters are listed below if applicable for this module.

### **ICU131:**

The ICU driver shall describe which other modules (in which versions) are required. This description shall be done by the implementer.