

| | |
|-----------------------------------|--|
| Document Title | Specification of FlexRay State Manager |
| Document Owner | AUTOSAR |
| Document Responsibility | AUTOSAR |
| Document Identification No | 254 |
| Document Classification | Standard |
| Document Version | 2.5.0 |
| Document Status | Final |
| Part of Release | 4.1 |
| Revision | 3 |

| Document Change History | | | |
|--------------------------------|----------------|----------------------------|---|
| Date | Version | Changed by | Change Description |
| 31.03.2014 | 2.5.0 | AUTOSAR Release Management | <ul style="list-style-type: none"> Removed Dual Channel Wakeup Echo |
| 31.10.2013 | 2.4.0 | AUTOSAR Release Management | <ul style="list-style-type: none"> Added immediate handling of NoCom requests in normal passive mode or key slot only mode Editorial changes Removed chapter(s) on change documentation |
| 27.02.2013 | 2.3.0 | AUTOSAR Administration | <ul style="list-style-type: none"> FlexRay Transceiver Mode Switch can be delayed Formal updates |
| 09.12.2011 | 2.2.0 | AUTOSAR Administration | <ul style="list-style-type: none"> Short term loss of synchronization is reported to DEM or DET. Number of startup frames can be monitored during normal operation. Revised production error handling. |
| 03.11.2010 | 2.1.0 | AUTOSAR Administration | <ul style="list-style-type: none"> The amount of wakeup patterns can be configured Clearing the Coldstart Inhibit Mode can be delayed also for passive wakeup. Removed enabling and disabling of transceiver wakeups |

| Document Change History | | | |
|--------------------------------|----------------|------------------------|--|
| Date | Version | Changed by | Change Description |
| 30.11.2009 | 2.0.0 | AUTOSAR Administration | <ul style="list-style-type: none">• Added support of FlexRay Dual Channel Wakeup• Added support of FlexRay Single Slot Mode• Added support of Passive Mode (Receive only)• Improved timeout supervision of FlexRay startup• Legal disclaimer revised |
| 23.06.2008 | 1.0.2 | AUTOSAR Administration | Legal disclaimer revised |
| 01.02.2008 | 1.0.1 | AUTOSAR Administration | Chapter 8 API Spelling harmonized |
| 20.11.2007 | 1.0.0 | AUTOSAR Administration | Initial Release |

Disclaimer

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.

For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

| | | |
|-------|--|----|
| 1 | Introduction and functional overview | 6 |
| 2 | Acronyms and abbreviations | 7 |
| 3 | Related documentation..... | 8 |
| 3.1 | Input documents..... | 8 |
| 3.2 | Related standards and norms | 8 |
| 3.3 | Related specification | 8 |
| 4 | Constraints and assumptions | 10 |
| 4.1 | Limitations | 10 |
| 4.2 | Applicability to car domains..... | 10 |
| 5 | Dependencies to other modules..... | 11 |
| 5.1 | AUTOSAR BSW Scheduler..... | 11 |
| 5.2 | Communication Manager | 11 |
| 5.3 | AUTOSAR FlexRay Interface..... | 11 |
| 5.4 | AUTOSAR Development Error Tracer..... | 11 |
| 5.5 | AUTOSAR Diagnostic Event Manager | 11 |
| 5.6 | AUTOSAR BSW Mode Manager..... | 11 |
| 5.7 | AUTOSAR FlexRay Network Management..... | 11 |
| 5.8 | File structure | 11 |
| 5.8.1 | Code file structure..... | 11 |
| 5.8.2 | Header file structure..... | 12 |
| 6 | Requirements traceability | 13 |
| 7 | Functional specification | 17 |
| 7.1 | Background & Rationale..... | 17 |
| 7.2 | Main Task of the FlexRay State Manager | 17 |
| 7.3 | State Machine of the FlexRay State Manager | 17 |
| 7.3.1 | General | 17 |
| 7.3.2 | States..... | 18 |
| 7.3.3 | Variables..... | 19 |
| 7.3.4 | State Machine Configuration..... | 20 |
| 7.3.5 | Conditions..... | 21 |
| 7.3.6 | Timers..... | 22 |
| 7.3.7 | Functional Elements | 22 |
| 7.3.8 | Wakeup Pattern Transmission..... | 25 |
| 7.3.9 | Transitions | 25 |
| 7.4 | Configuration description..... | 31 |
| 7.5 | Production Errors | 31 |
| 7.5.1 | FRSM_E_CLUSTER_STARTUP | 31 |
| 7.5.2 | FRSM_E_CLUSTER_SYNC_LOSS | 32 |
| 7.6 | Error classification..... | 32 |
| 7.7 | Error detection..... | 33 |
| 7.8 | Error notification | 33 |
| 7.9 | Debugging..... | 33 |

| | | |
|--------|---|----|
| 8 | API specification..... | 34 |
| 8.1 | Imported types..... | 34 |
| 8.2 | Type definitions | 34 |
| 8.2.1 | FrSM_ConfigType..... | 34 |
| 8.2.2 | FrSM_BswM_StateType | 34 |
| 8.3 | Function definitions | 35 |
| 8.3.1 | FrSM_Init | 35 |
| 8.3.2 | FrSM_RequestComMode | 36 |
| 8.3.3 | FrSM_GetCurrentComMode..... | 37 |
| 8.3.4 | FrSM_GetVersionInfo | 38 |
| 8.3.5 | FrSM_AllSlots | 39 |
| 8.3.6 | FrSM_SetEcuPassive | 40 |
| 8.4 | Call-back notifications | 40 |
| 8.5 | Scheduled functions | 40 |
| 8.5.1 | FrSM_MainFunction_<Cluster Id> | 40 |
| 8.6 | Expected Interfaces..... | 41 |
| 8.6.1 | Mandatory Interfaces | 42 |
| 8.6.2 | Optional Interfaces..... | 42 |
| 8.6.3 | Configurable Interfaces..... | 43 |
| 9 | Sequence diagrams | 44 |
| 9.1 | Initialization | 44 |
| 9.2 | Single Channel Wakeup..... | 45 |
| 9.3 | Single Channel Passive Startup..... | 47 |
| 9.4 | Dual Channel Wakeup | 50 |
| 9.5 | Dual Channel Wakeup Forward | 53 |
| 9.6 | Key Slot Only Mode..... | 55 |
| 9.7 | Transition from full communication to no communication..... | 56 |
| 10 | Configuration specification..... | 57 |
| 10.1 | How to read this chapter | 57 |
| 10.2 | Containers and configuration parameters | 57 |
| 10.2.1 | Variants | 57 |
| 10.2.2 | FrSM..... | 59 |
| 10.2.3 | FrSMConfig | 59 |
| 10.2.4 | FrSMGeneral | 60 |
| 10.2.5 | FrSMCluster | 63 |
| 10.2.6 | FrSMClusterDemEventParameterRefs..... | 69 |
| 10.3 | Published Information..... | 69 |
| 11 | Not applicable requirements | 70 |

1 Introduction and functional overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module "FlexRay State Manager".

In the AUTOSAR Layered Software Architecture, the FlexRay State Manager belongs to the Services Layer, or more precisely, to the Communication Services.




Figure 1 Software Architecture Overview

2 Acronyms and abbreviations

| Acronym/ Abbreviation | Description: |
|----------------------------------|--|
| API | Application Program Interface |
| AUTOSAR | Automotive Open System Architecture |
| BSW | Basic Software |
| CC | Communication Controller |
| CHI | Controller Host Interface |
| ComM | AUTOSAR Communication Manager |
| DCM | Diagnostic Communication Manager |
| Dem/DEM | Diagnostic Event Manager |
| Det/DET | Development Error Tracer |
| e.g. | [lat.] exempli gratia = [eng.] for example |
| ECU | Electronic Control Unit |
| EcuM | ECU State Manager |
| Fr | FlexRay Driver |
| FrIf | FlexRay Interface (AUTOSAR BSW module) |
| FrSM | FlexRay State Manager |
| FrTrcv | FlexRay Transceiver Driver |
| i.e. | [lat.] id est = [eng.] that is |
| Id/ID | Identifier |
| N/A | Not applicable |
| NM | Network Management |
| PDU | Protocol Data Unit |
| POC | Protocol Operation Control |
| POCState | Actual CC internal state of the POC. This state might differ from vPOC!State in certain cases, e.g. after FREEZE command invocation (see [11] for details). |
| RTE | Runtime Environment |
| RX | Reception |
| SchM | Schedule Manager |
| SW | Software |
| TX | Transmission |
| UML | Unified Modeling Language |
| vPOC | Data structure provided from the CC to the host at the CHI , which contains the actual POC status of the CC . |
| vPOC!Freeze | vPOC!Freeze denotes the Freeze bit that is part of the vPOC data structure. The Freeze bit is used by the CC to indicate that the HALT state has been entered due to an error condition. |
| vPOC!SlotMode | vPOC!SlotMode denotes the SlotMode field that is part of the vPOC data structure. |
| WUP | Wake-Up Pattern |
| XML | Extensible markup language |

| Term: | Description: |
|------------------------|---|
| Active wake-up | Wake-up caused by the ECU e.g. by a sensor. |
| Passive wake-up | Wakeup caused by another ECU and propagated (e.g. by bus or wakeup-line) to the ECU currently in focus. |
| Remote wake-up | A passive wake-up received by the FlexRay bus or wakeup-line. |

3 Related documentation

3.1 Input documents

- [1] List of Basic Software Modules
AUTOSAR_TR_BSWModuleList.pdf

- [2] Layered Software Architecture
AUTOSAR_EXP_LayeredSoftwareArchitecture.pdf

- [3] General Requirements on Basic Software Modules
AUTOSAR_SRS_BSWGeneral.pdf

- [4] Specification of ECU Configuration
UTOSAR_TPS_ECUConfiguration.pdf

- [5] Specification of Communication Stack Types
AUTOSAR_SWS_CommunicationStackTypes.pdf

- [6] Requirements on FlexRay
AUTOSAR_SRS_FlexRay.pdf

- [7] Specification of FlexRay Interface
AUTOSAR_SWS_FlexRayInterface.pdf

- [8] Specification of FlexRay Driver
AUTOSAR_SWS_FlexRayDriver.pdf

- [9] Specification of Communication Manager
AUTOSAR_SWS_ComManager.pdf

- [10] Requirements on Mode Management
AUTOSAR_SRS_ModeManagement.pdf

- [11] Basic Software Module Description Template,
AUTOSAR_TPS_BSWModuleDescriptionTemplate.pdf

- [12] General Specification of Basic Software Modules
AUTOSAR_SWS_BSWGeneral.pdf

3.2 Related standards and norms

- [13] FlexRay Communications System Protocol Specification Version 2.1 Rev A

3.3 Related specification

AUTOSAR provides a General Specification on Basic Software modules [12] (SWS BSW General), which is also valid for FlexRay State Manager.

Thus, the specification SWS BSW General shall be considered as additional and required specification for FlexRay State Manager.

4 Constraints and assumptions

4.1 Limitations

This specification only defines the straightforward case for starting and stopping the communication on a FlexRay cluster.

For the case of multiple [CC](#) of one ECU assigned to one FlexRay cluster some items are left open for the implementation:

- Which CC is used to transmit the wakeup pattern
- Handling of inconsistent POC states in the CCs

4.2 Applicability to car domains

The FlexRay Communication stack can be used wherever high data rates and fault tolerant communication (in conjunction with [11]) is required. Furthermore, it enables the synchronized operation of several ECUs within a car.

The FlexRay State Manager can be used for all domain applications which use the FlexRay Protocol.

5 Dependencies to other modules

5.1 AUTOSAR BSW Scheduler

The BSW Scheduler calls the main functions of the FrSM, which are necessary for the cyclic processes of the FrSM.

5.2 Communication Manager

The [ComM](#) requests network communication modes and is notified by the FrSM when a communication mode is reached.

5.3 AUTOSAR FlexRay Interface

The FrSM uses the API of the [Frlf](#) to initialize the FlexRay Communication Hardware and to control the operating modes of the FlexRay Controllers and FlexRay Transceivers assigned to the FlexRay Networks.

5.4 AUTOSAR Development Error Tracer

In order to be able to report development errors, the FlexRay State Manager has to have access to the error hook of the Development Error Tracer.

5.5 AUTOSAR Diagnostic Event Manager

In order to be able to report production errors the FlexRay State Manager has to have access to the Diagnostic Event Manager.

5.6 AUTOSAR BSW Mode Manager

In order to be able to report state changed the FlexRay State Manager has to have access to the BSW Mode Manager.

5.7 AUTOSAR FlexRay Network Management


In order to be able to report startup failures the FlexRay State Manager has to have access to the FlexRay Network Management.

5.8 File structure

5.8.1 Code file structure

For details refer to the chapter 5.1.6 “Code file structure” in *SWS_BSWGeneral*.

5.8.2 Header file structure



[SWS_FrSM_00120] [The header file FrSM.h shall export the API of the FrSM module.] ()

[SWS_FrSM_00121] [The header file FrSM.h shall include FrSM_Types.h and FrSm_Cfg.h.] ()

[SWS_FrSM_00054] [The header file FrSM_Types.h shall export the FrSM specific types.] ()

[SWS_FrSM_00055] [The FrSM implementation (FrSM.c) shall include its header file FrSM.h to get access to its own API declaration and to its configuration parameters.] ()

[SWS_FrSM_00058] [The FrSM implementation (FrSM.c) shall include the header file FrIf.h to get access to the FrIf API.] ()

[SWS_FrSM_00139] [The header file FrSM.h shall include a software and specification version number.] ()

[SWS_FrSM_00140] [The FrSM module shall perform a consistency check between code files and header files based on pre-process-checking the version numbers of related code files and header files.] (SRS_BSW_00004)

6 Requirements traceability

| Requirement | Description | Satisfied by |
|-------------|-------------|----------------|
| - | - | SWS_FrSM_00015 |
| - | - | SWS_FrSM_00019 |
| - | - | SWS_FrSM_00021 |
| - | - | SWS_FrSM_00022 |
| - | - | SWS_FrSM_00025 |
| - | - | SWS_FrSM_00026 |
| - | - | SWS_FrSM_00027 |
| - | - | SWS_FrSM_00030 |
| - | - | SWS_FrSM_00032 |
| - | - | SWS_FrSM_00047 |
| - | - | SWS_FrSM_00048 |
| - | - | SWS_FrSM_00054 |
| - | - | SWS_FrSM_00055 |
| - | - | SWS_FrSM_00058 |
| - | - | SWS_FrSM_00093 |
| - | - | SWS_FrSM_00095 |
| - | - | SWS_FrSM_00096 |
| - | - | SWS_FrSM_00097 |
| - | - | SWS_FrSM_00098 |
| - | - | SWS_FrSM_00105 |
| - | - | SWS_FrSM_00120 |
| - | - | SWS_FrSM_00121 |
| - | - | SWS_FrSM_00139 |
| - | - | SWS_FrSM_00141 |
| - | - | SWS_FrSM_00142 |
| - | - | SWS_FrSM_00143 |
| - | - | SWS_FrSM_00145 |
| - | - | SWS_FrSM_00149 |
| - | - | SWS_FrSM_00171 |
| - | - | SWS_FrSM_00176 |
| - | - | SWS_FrSM_00177 |
| - | - | SWS_FrSM_00178 |
| - | - | SWS_FrSM_00180 |
| - | - | SWS_FrSM_00190 |
| - | - | SWS_FrSM_00192 |
| - | - | SWS_FrSM_00197 |

| | | |
|---------------|--|--|
| - | - | SWS_FrSM_00198 |
| - | - | SWS_FrSM_00199 |
| - | - | SWS_FrSM_00208 |
| BSW00443 | - | SWS_FrSM_00186 |
| BSW00444 | - | SWS_FrSM_00186 |
| BSW00446 | - | SWS_FrSM_00186 |
| SRS_BSW_00004 | All Basic SW Modules shall perform a pre-processor check of the versions of all imported include files | SWS_FrSM_00140 |
| SRS_BSW_00005 | Modules of the æC Abstraction Layer (MCAL) may not have hard coded horizontal interfaces | SWS_FrSM_00186 |
| SRS_BSW_00101 | The Basic Software Module shall be able to initialize variables and hardware in a separate initialization function | SWS_FrSM_00126 |
| SRS_BSW_00159 | All modules of the AUTOSAR Basic Software shall support a tool based configuration | SWS_FrSM_00064 |
| SRS_BSW_00161 | The AUTOSAR Basic Software shall provide a microcontroller abstraction layer which provides a standardized interface to higher software layers | SWS_FrSM_00186 |
| SRS_BSW_00162 | The AUTOSAR Basic Software shall provide a hardware abstraction layer | SWS_FrSM_00186 |
| SRS_BSW_00164 | The Implementation of interrupt service routines shall be done by the Operating System, complex drivers or modules | SWS_FrSM_00186 |
| SRS_BSW_00167 | All AUTOSAR Basic Software Modules shall provide configuration rules and constraints to enable plausibility checks | SWS_FrSM_00065 |
| SRS_BSW_00168 | SW components shall be tested by a function defined in a common API in the Basis-SW | SWS_FrSM_00186 |
| SRS_BSW_00170 | The AUTOSAR SW Components shall provide information about their dependency from faults, signal qualities, driver demands | SWS_FrSM_00186 |
| SRS_BSW_00314 | All internal driver modules shall separate the interrupt frame definition from the service routine | SWS_FrSM_00186 |
| SRS_BSW_00323 | All AUTOSAR Basic Software Modules shall check passed API parameters for validity | SWS_FrSM_00018, SWS_FrSM_00028, SWS_FrSM_00168 |
| SRS_BSW_00325 | The runtime of interrupt service routines and functions that are running in interrupt context shall be kept short | SWS_FrSM_00186 |
| SRS_BSW_00326 | - | SWS_FrSM_00186 |
| SRS_BSW_00336 | Basic SW module shall be able to shutdown | SWS_FrSM_00186 |

| | | |
|---------------|--|---|
| SRS_BSW_00342 | It shall be possible to create an AUTOSAR ECU out of modules provided as source code and modules provided as object code, even mixed | SWS_FrSM_00099, SWS_FrSM_00100 |
| SRS_BSW_00347 | A Naming separation of different instances of BSW drivers shall be in place | SWS_FrSM_00186 |
| SRS_BSW_00359 | All AUTOSAR Basic Software Modules callback functions shall avoid return types other than void if possible | SWS_FrSM_00186 |
| SRS_BSW_00360 | AUTOSAR Basic Software Modules callback functions are allowed to have parameters | SWS_FrSM_00186 |
| SRS_BSW_00369 | All AUTOSAR Basic Software Modules shall not return specific development error codes via the API | SWS_FrSM_00018, SWS_FrSM_00028, SWS_FrSM_00168 |
| SRS_BSW_00370 | - | SWS_FrSM_00186 |
| SRS_BSW_00373 | The main processing function of each AUTOSAR Basic Software Module shall be named according the defined convention | SWS_FrSM_00118 |
| SRS_BSW_00375 | Basic Software Modules shall report wake-up reasons | SWS_FrSM_00186 |
| SRS_BSW_00377 | A Basic Software Module can return a module specific types | SWS_FrSM_00186 |
| SRS_BSW_00381 | The pre-compile time parameters shall be placed into a separate configuration header file | SWS_FrSM_00013 |
| SRS_BSW_00387 | The Basic Software Module specifications shall specify how the callback function is to be implemented | SWS_FrSM_00186 |
| SRS_BSW_00405 | BSW Modules shall support multiple configuration sets | SWS_FrSM_00013 |
| SRS_BSW_00406 | A static status variable denoting if a BSW module is initialized shall be initialized with value 0 before any APIs of the BSW module is called | SWS_FrSM_00060, SWS_FrSM_00061, SWS_FrSM_00169, SWS_FrSM_00179 |
| SRS_BSW_00407 | Each BSW module shall provide a function to read out the version information of a dedicated module implementation | SWS_FrSM_00029 |
| SRS_BSW_00413 | An index-based accessing of the instances of BSW modules shall be done | SWS_FrSM_00186 |
| SRS_BSW_00415 | Interfaces which are provided exclusively for one module shall be separated into a dedicated header file | SWS_FrSM_00186 |
| SRS_BSW_00416 | The sequence of modules to be initialized shall be configurable | SWS_FrSM_00186 |
| SRS_BSW_00417 | Software which is not part of the SW-C shall report error events only after the DEM is fully operational. | SWS_FrSM_00186 |
| SRS_BSW_00419 | If a pre-compile time configuration | SWS_FrSM_00186 |

| | | |
|-------------------|--|---|
| | parameter is implemented as "const" it should be placed into a separate c-file | |
| SRS_BSW_00422 | Pre-de-bouncing of error status information is done within the DEM | SWS_FrSM_00186 |
| SRS_BSW_00423 | BSW modules with AUTOSAR interfaces shall be describable with the means of the SW-C Template | SWS_FrSM_00186 |
| SRS_BSW_00425 | The BSW module description template shall provide means to model the defined trigger conditions of schedulable objects | SWS_FrSM_00186 |
| SRS_BSW_00427 | ISR functions shall be defined and documented in the BSW module description template | SWS_FrSM_00186 |
| SRS_BSW_00428 | A BSW module shall state if its main processing function(s) has to be executed in a specific order or sequence | SWS_FrSM_00186 |
| SRS_BSW_00429 | BSW modules shall be only allowed to use OS objects and/or related OS services | SWS_FrSM_00186 |
| SRS_BSW_00432 | Modules should have separate main processing functions for read/receive and write/transmit data path | SWS_FrSM_00186 |
| SRS_BSW_00437 | Memory mapping shall provide the possibility to define RAM segments which are not to be initialized during startup | SWS_FrSM_00186 |
| SRS_BSW_00438 | Configuration data shall be defined in a structure | SWS_FrSM_00013, SWS_FrSM_00126, SWS_FrSM_00127, SWS_FrSM_00128 |
| SRS_BSW_00439 | Enable BSW modules to handle interrupts | SWS_FrSM_00186 |
| SRS_BSW_00440 | The callback function invocation by the BSW module shall follow the signature provided by RTE to invoke servers via Rte_Call API | SWS_FrSM_00186 |
| SRS_BSW_00442 | The AUTOSAR architecture shall support standardized debugging and tracing features | SWS_FrSM_00137 |
| SRS_BSW_00449 | BSW Service APIs used by Autosar Application Software shall return a Std_ReturnType | SWS_FrSM_00186 |
| SRS_BSW_00450 | A Main function of a un-initialized module shall return immediately | SWS_FrSM_00181 |
| SRS_ModeMgm_09081 | The Communication Manager shall provide an API allowing collecting communication requests | SWS_FrSM_00020 |
| SRS_ModeMgm_09084 | The Communication Manager shall provide an API which allows application to query the current communication mode | SWS_FrSM_00024 |

7 Functional specification

7.1 Background & Rationale

FlexRay start-up is a complex process that is completely different from CAN. E.g. on CAN every message can wakeup the bus, on FlexRay a special wakeup pattern is needed. In order to make the FlexRay start-up process as reliable as possible, it has to be controlled by a BSW module with in-depth FlexRay knowledge. As the AUTOSAR Communication Manager has a completely abstracted bus view, it is the task of the FlexRay State Manager to map this abstracted view to the states of the FlexRay [POC](#) and to the [CHI](#) commands to change these states.

7.2 Main Task of the FlexRay State Manager

The main task of the FlexRay State Manager module can be summarized as follows:

The FlexRay State Manager module shall provide an abstract interface to the AUTOSAR Communication Manager module to startup or shutdown the communication on a FlexRay cluster.

The FlexRay State Manager module shall not directly access the FlexRay hardware (FlexRay Communication Controller and FlexRay Transceiver), but by means of the FlexRay Interface module.

The FlexRay Interface module redirects the request to the appropriate driver module.

7.3 State Machine of the FlexRay State Manager

7.3.1 General

[SWS_FrSM_00030] [The FlexRay State Manager shall implement one state machine for each FlexRay cluster.

The states of this state machine are to some extent derived from the [POC](#) states of the FlexRay [CC](#). This document is based on the assumption that there is always a unique [POC](#) state for every FlexRay cluster (see Limitations in section 4.1).

The state machine of each cluster is processed by the main function `FrSM_MainFunction_<Cluster Id>` assigned to that cluster (see section 8.5.1). However, as defined in section 8.3.2, some transitions of the state machine are processed in the context of the [FrSM_RequestComMode](#) function in order to achieve a deterministic behavior for shutdown.] ()

7.3.2 States

[SWS_FrSM_00032] [The state machine shall comprise the following states:

| <i>FrSM Cluster State</i> | <i>Mapped FlexRay CC state</i> | <i>Description</i> |
|---------------------------------|---|---|
| FRSM_READY | POC:ready | |
| FRSM_WAKEUP | POC:wake-up | FrSM performs wake-up |
| FRSM_STARTUP | POC:start-up | FrSM performs startup |
| FRSM_HALT_REQ | POC:normal active or POC:normal passive | FrSM performs a shutdown |
| FRSM_ONLINE | POC:normal active | Full Communication |
| FRSM_ONLINE_PASSIVE | POC:normal passive | Due to clock synchronization errors no data is transmitted or received. |
| FRSM_KEYSLOT_ONLY | POC:normal active ^ vPOC!SlotMode ≠ AllSlots | Data can only be transmitted in the key slots. |
| FRSM_LOW_NUMBER_OF_COLDSTARTERS | POC:normal active | Full communication; FlexRay is synchronized based on sync frames only. |

] ()

[SWS_FrSM_00176] [For controlling the passive mode (receive-only), the state machine shall additionally comprise the following states which concurrent to the states above:

| <i>Passive State</i> | <i>Description</i> |
|----------------------|---|
| FRSM_ECU_ACTIVE | When the FrSM is concurrently in state FRSM_READY , the transceivers are in set into mode FRTRCV_TRCVMODE_STANDBY, otherwise into mode FRTRCV_TRCVMODE_NORMAL |
| FRSM_ECU_PASSIVE | When the FrSM is concurrently in state FRSM_READY , the transceivers are in set into mode FRTRCV_TRCVMODE_STANDBY, otherwise into mode FRTRCV_TRCVMODE_RECEIVEONLY. |

] ()

[SWS_FrSM_00180] [For reporting these two concurrent states to the BswM, a corresponding value of FrSM_BswM_StateType shall be determined as follows:

| <i>FrSM Cluster State</i> | <i>Passive State</i> | <i>FrSM_BswM_StateType value</i> |
|-------------------------------------|----------------------------------|----------------------------------|
| FRSM_READY | FRSM ECU ACTIVE | FRSM_READY |
| FRSM_READY | FRSM ECU PASSIVE | FRSM_READY_ECU_PASSIVE |
| FRSM_WAKEUP | FRSM ECU ACTIVE | FRSM_WAKEUP |
| FRSM_WAKEUP | FRSM ECU PASSIVE | FRSM_WAKEUP_ECU_PASSIVE |
| FRSM_STARTUP | FRSM ECU ACTIVE | FRSM_STARTUP |
| FRSM_STARTUP | FRSM ECU PASSIVE | FRSM_STARTUP_ECU_PASSIVE |
| FRSM_ONLINE | FRSM ECU ACTIVE | FRSM_ONLINE |
| FRSM_ONLINE | FRSM ECU PASSIVE | FRSM_ONLINE_ECU_PASSIVE |
| FRSM_ONLINE_PASSIVE | FRSM ECU ACTIVE | FRSM_ONLINE_PASSIVE |
| FRSM_ONLINE_PASSIVE | FRSM ECU PASSIVE | FRSM_ONLINE_PASSIVE_ECU_PASSIVE |

| | | |
|--|----------------------------------|--|
| FRSM KEYSLOT ONLY | FRSM ECU ACTIVE | FRSM KEYSLOT ONLY |
| FRSM KEYSLOT ONLY | FRSM ECU PASSIVE | FRSM KEYSLOT ONLY ECU PASSIVE |
| FRSM HALT REQUEST | FRSM ECU ACTIVE | FRSM HALT REQUEST |
| FRSM HALT REQUEST | FRSM ECU PASSIVE | FRSM HALT REQUEST ECU PASSIVE |
| FRSM LOW NUMBER OF COLD-STARTERS | FRSM ECU ACTIVE | FRSM_LOW_NUMBER_OF_COLDSTARTERS |
| FRSM LOW NUMBER OF COLD-STARTERS | FRSM ECU PASSIVE | FRSM_LOW_NUMBER_OF_COLD-STARTERS ECU PASSIVE |

] ()

7.3.3 Variables

In addition to its state, the state machine description uses the following variables. Note that these variables are only auxiliary means for improving the clearness and the readability of the specification.

| <i>FrSM Variable</i> | <i>Type</i> | <i>Description</i> |
|----------------------|-------------------------------|--|
| reqComMode | ComM_ModeType | The communication mode that has been requested by the ComM . The communication modes are abbreviated in this document as follows: NoCom: COMM_NO_COMMUNICATION SilentCom: COMM_SILENT_COMMUNICATION FullCom: COMM_FULL_COMMUNICATION According to the definition of ComM_ModeType these modes are ordered as follows: NoCom < SilentCom < FullCom |
| startupCounter | Integer | The number of startup attempts that have been performed |
| wakeupType | Enum | The following values are supported: <ul style="list-style-type: none"> • SingleChannelWakeup • DualChannelWakeup • DualChannelWakeupForward • NoWakeup |
| wakeupTransmitted | Boolean | True if vPOC!WakeupStatus = FR_WAKEUP_TRANSMITTED for at least attempt to transmit a wakeup pattern, false otherwise |
| busTrafficDetected | Boolean | True if vPOC!WakeupStatus = FR_WAKEUP_RECEIVED_HEADER or FR_WAKEUP_RECEIVED_WUP for at least attempt to transmit a wakeup pattern, false otherwise |
| wakeupCounter | Integer | The number of attempts that have been performed for transmitting a wakeup pattern. |

Note that the silent communication mode is not supported on FlexRay; it may not be requested by the [ComM](#) module.

7.3.4 State Machine Configuration

The state machine description uses the following configuration parameters that are defined in chapter 10.2 for each FlexRay cluster:

| FrSM Configuration Parameter | Type | Description |
|-------------------------------------|-------------|---|
| FrSMIsWakeupEcu | Boolean | See chapter 10.2 |
| FrSMCheckWakeupReason | Boolean | See chapter 10.2 |
| FrSMIsColdstartEcu | Boolean | See chapter 10.2 |
| FrSMIsDualChannelNode | Boolean | This configuration parameter is derived from the FrIf configuration. If the corresponding FrIf cluster is connected to both channels of the FlexRay cluster, this parameter is TRUE. Otherwise, it is FALSE. |
| FrSMStartupRepetitionsWithWakeup | Integer | The number of times an ECU may repeat the startup procedure including a wakeup for a FlexRay cluster. If this optional configuration parameter is missing, there shall be no limitation, i.e. the configuration parameter shall be treated as having the value ∞ |
| FrSMStartupRepetitions | Integer | Determines how often the ECU can repeat the startup procedure by reinitializing the FlexRay CC , see chapter 10.2. This value must not be smaller than FrSMStartupRepetitionsWithWakeup . If this optional configuration parameter is missing, there shall be no limitation, i.e. the configuration parameter shall be treated as having the value ∞ |
| FrSMNumWakeupPatterns | Integer | Maximum number of Wakeup Patterns the node may send before going to FRSM_STARTUP . |

| | | |
|-------------------------------|---------|--|
| FrSMDelayStartupWithoutWakeup | Boolean | If true, timer t1 shall be started instead of immediately calling FrIf_AllowColdstart in case of a startup without wakeup. |
| FrSMMinNumberOfColdstarter | Integer | Minimum number of startup frames that have to be present, see chapter 10.2 |

7.3.5 Conditions

The state machine description uses the following conditions that are evaluated during runtime for each FlexRay cluster:

| FrSM Condition | Type | Description |
|----------------------------|-------------|--|
| WUReason | Enum | If FrSMCheckWakeupReason is false, WUReason evaluates to NO_WU_BY_BUS. Otherwise if FrSMCheckWakeupReason is true, determine the wakeup reason by calling FrIf_GetTransceiverWUReason for each transceiver of the FlexRay cluster and check for FRTRCV_WU_BY_BUS and evaluate WUReason to <ul style="list-style-type: none"> • NO_WU_BY_BUS in case no wakeup has been detected. • PARTIAL_WU_BY_BUS in case the ECU is connected to both FlexRay channels of the cluster and wakeup has been detected for exactly one channel • ALL_WU_BY_BUS in case wakeup has been detected for all of the FlexRay channels of the cluster to which the ECU is connected. |
| AllChannelsAwake | boolean | Determine the WakeupRxStatus by calling FrIf_GetWakeupRxStatus for each of the FlexRay controllers of the FlexRay cluster and return TRUE if the wakeup status is 1 for that FlexRay channel which has not been woken up by this ECU; otherwise return FALSE. |
| t1_IsActive | boolean | Evaluates to true if t1 has been started and has not expired yet, otherwise to false |
| t3_IsNotActive | boolean | Evaluates to false if t3 is running and has not expired, otherwise to true. |
| t_TrvcStdby-Delay_IsActive | boolean | Evaluates to true if t_TrvcStdbyDelay has been started and has not expired yet, otherwise to false. |
| wakeupFinished | boolean | Evaluates to false if the wakeup pattern |

| | | |
|-------------------------|---------|---|
| | | transmission as defined in section 7.3.8 is still in progress, otherwise to true. |
| lowNumberOfColdstarters | boolean | = FrIf_GetNumOfStartupFrames() < FrSMMinNumberOfColdstarter |

7.3.6 Timers

The state machine description uses the following timers for each FlexRay cluster:

| Timer | Description |
|-------------------|--|
| t1 | The timer t1 models the delay of clearing the coldstart inhibit mode (i.e. calling FrIf_AllowColdstart). The duration of this timer can be statically configured with the configuration parameter FrSMDurationT1. |
| t2 | The timer t2 models the time difference after which the FrSM will repeat the startup of the FlexRay cluster. The duration of this timer can be statically configured with the configuration parameter FrSMDurationT2. |
| t3 | The timer t3 supervises the transition to FullCom . The duration of this timer can be statically configured with the configuration parameter FrSMDurationT3. |
| t_TrcvStdbbyDelay | The timer t_TrcvStdbbyDelay models the time difference after which the FlexRay State Manager will reinitialize the FlexRay communication controllers and set the transceivers into STANDBY mode when FlexRay communication is stopped. |

[SWS_FrSM_00142] [If the configuration parameter FrSMDurationT1 is set to 0, timer t1 shall not be started. Instead, the call of FrIf_AllowColdstart shall immediately follow the call of FrIf_StartCommunication.] ()

[SWS_FrSM_00143] [If the duration FrSMDurationT2 of timer [t2](#) is set to 0, the startup of the FlexRay cluster shall not be supervised.

Note, that no assumption is made whether any of the timers is implemented in software or hardware.] ()

7.3.7 Functional Elements

The functionality being performed in the transitions of the state machine is partitioned into the following functional elements. I.e. the following table contains abbreviations used as actions in the FrSM state machine description, which reference one or more function calls visible at the interfaces of the FrSM module.

| Functional Element | Description |
|--------------------|--|
| FE_WAKEUP | Call FrIf_SendWUP for each controller of the |

| | |
|---------------------------|--|
| | FlexRay cluster. |
| FE_SET_WU_CHANNEL_INITIAL | In case of a single channel node, do nothing. In case of a dual channel node, call <code>FrIf_SetWakeupChannel</code> for each controller of the FlexRay cluster in order to set the wakeup channel to the channel A. |
| FE_SET_WU_CHANNEL_FORWARD | In case of a single channel node, do nothing. In case of a dual channel node, call <code>FrIf_SetWakeupChannel</code> for each controller of the FlexRay cluster in order to set the wakeup channel to the channel on which no wakeup has been detected while evaluating WUReason . |
| FE_CONFIG | Call <code>FrIf_ControllerInit</code> for each controller of the FlexRay cluster. |
| FE_START | Call <code>FrIf_StartCommunication</code> for each controller of the FlexRay cluster. |
| FE_ALLOW_COLDSTART | Call <code>FrIf_AllowColdstart</code> for each controller of the FlexRay cluster if the configuration parameter FrSMIsColdstartEcu is true. |
| FE_HALT | Call <code>FrIf_HaltCommunication</code> for each controller of the FlexRay cluster. |
| FE_TRCV_STANDBY | Call <code>FrIf_SetTransceiverMode</code> with <code>FrIf_TrcvMode</code> as <code>FRTRCV_TRCVMODE_STANDBY</code> for each transceiver of the FlexRay cluster. |
| FE_TRCV_NORMAL | In case the FrSM state machine is in state FRSM_ECU_ACTIVE , call <code>FrIf_SetTransceiverMode</code> with <code>FrIf_TrcvMode</code> as <code>FRTRCV_TRCVMODE_NORMAL</code> and <code>FrIf_ClearTransceiverWakeup</code> for each transceiver of the FlexRay cluster. In case the FrSM state machine is in state FRSM_ECU_PASSIVE , call <code>FrIf_SetTransceiverMode</code> with <code>FrIf_TrcvMode</code> as <code>FRTRCV_TRCVMODE_RECEIVEONLY</code> and <code>FrIf_ClearTransceiverWakeup</code> for each transceiver of the FlexRay cluster. |
| FE_START_FRIF | Set the FrIf state to ONLINE by calling <code>FrIf_SetState</code> with <code>FrIf_StateTransition</code> as <code>FRIF_GOTO_ONLINE</code> for the cluster. |
| FE_STOP_FRIF | Set the FrIf state to OFFLINE by calling <code>FrIf_SetState</code> with <code>FrIf_StateTransition</code> as <code>FRIF_GOTO_OFFLINE</code> for the cluster. |
| FE_DEM_STATUS_FAILED | Report status of production error FRSM_E_CLUSTER_STARTUP as failed. |
| FE_DEM_STATUS_PASSED | Report status of production error FRSM_E_CLUSTER_STARTUP as passed. |
| FE_DEM_SYNC_LOSS | Report the status of the production error FRSM_E_CLUSTER_SYNC_LOSS as failed. If the name of an indication function (see section 8.6.3) is configured, call the indication function with the parameter <code>SyncLossErrorStatus = true</code> . |
| FE_DEM_SYNC_LOSS_PASSED | If the name of an indication function (see section 8.6.3) is configured, call the indication function with the parameter <code>SyncLossErrorStatus = false</code> . |

| | |
|----------------------|--|
| | Additionally report the status of the production error FRSM_E_CLUSTER_SYNC_LOSS as passed. |
| FE_FULL_COM_IND | Indicate to the ComM that FullCom has been reached by calling ComM_BusSM_ModelIndication (FullCom) |
| FE_NO_COM_IND | Indicate to the ComM that FullCom has been left by calling ComM_BusSM_ModelIndication (NoCom). |
| FE_STARTUP_ERROR_IND | Call FrNm_StartupError. |

7.3.8 Wakeup Pattern Transmission

[SWS_FrSM_00208] The FlexRay State Manager shall repeat the transmission of wakeup patterns according to the configuration parameter [FrSMNumWakeupPatterns](#). I.e. the FlexRay State Manager shall perform the following actions while being in state FRSM_WAKEUP:

- Set counter wakeupCounter to 1 when the state FRSM_WAKEUP is entered
- While wakeupCounter ≤ [FrSMNumWakeupPatterns](#) and [busTrafficDetected](#) = false:
 - Wait until the FlexRay controllers of the FlexRay cluster are in state FR_READY
 - When the FlexRay controllers are in state FR_READY, check vPOC!WakeupStatus of the FlexRay controllers and act as follows:

| vPOC!WakeupStatus | Actions |
|---|--|
| FR_WAKEUP_RECEIVED_HEADER, FR_WAKEUP_RECEIVED_WUP | busTrafficDetected := true |
| FR_WAKEUP_TRANSMITTED | wakeupTransmitted := true |
| FR_WAKEUP_UNDEFINED FR_WAKEUP_COLLISION_HEADER FR_WAKEUP_COLLISION_WUP FR_WAKEUP_COLLISION_UNKNOWN | No action |

- If [busTrafficDetected](#) = false and wakeupCounter < [FrSMNumWakeupPatterns](#), execute [FE_WAKEUP](#)
- Increment the wakeupCounter

If any of the FlexRay controllers enters the HALT state due to an error condition, the wakeup pattern transmission shall be aborted and the [wakeupFinished](#) condition shall evaluate to true.>()

7.3.9 Transitions

[SWS_FrSM_00093] [The following FrSM state machine diagram defines source state and the target state of the transitions, which are defined in detail in the table following this diagram.




Figure 2 FrSM state machine of the FlexRay State Manager

Note that the states are described in section 7.3.2.

The following table defines the events and conditions that trigger the transitions of FrSM state machine and the actions that are executed within the transitions. Each row of the table contains a requirement which should be interpreted as follows. If the FrSM module is in the source state of the transition in column "Transition" as defined in [SWS FrSM_00093](#) and when the condition in column "Event [Condition]" holds and if the event in column "Event [Condition]" occurs, then the actions in column "Actions" shall be executed and afterwards the FrSM module shall change its state to the target state of the transition in column "Transition" as defined in [SWS FrSM_00093](#).

In case different actions have to be performed in a transition T, there can be multiple rows in the table. The rows are denoted as T (a), T (b) etc. in this case. Note that the conditions ensure that only one of the possibilities matches.] ()

[SWS_FrSM_00145] [After every transition to a different state, the FrSM shall inform the BswM by calling BswM_FrSM_CurrentState.] ()

[SWS_FrSM_00105] [The FrSM shall execute the actions of the transition in the order that is defined in the following table.

| Transition | Event [Condition] | Actions |
|------------|---|--|
| T00 | FrSM_Init() | FE_CONFIG |
| T01 (a) | [reqComMode = FullCom ^ FrSMIsWakeupEcu ^ WUReason = NO_WU_BY_BUS ^ \neg FrSMIsDualChannelNode] | FE_TRCV_NORMAL startupCounter := 1 wakeupType := SingleChannelWakeup wakeupTransmitted := false FE_WAKEUP start t1 start t3 |
| T01 (b) | [reqComMode = FullCom ^ FrSMIsWakeupEcu ^ WUReason = NO_WU_BY_BUS ^ FrSMIsDualChannelNode] | FE_TRCV_NORMAL startupCounter := 1 wakeupType := DualChannelWakeup FE_SET_WU_CHANNEL_INITIAL wakeupTransmitted := false FE_WAKEUP start t3 |
| T01 (c) | [reqComMode = FullCom ^ FrSMIsWakeupEcu ^ WUReason = PARTIAL_WU_BY_BUS] | FE_TRCV_NORMAL startupCounter := 1 wakeupType := DualChannelWakeupForward FE_SET_WU_CHANNEL_FORWARD FE_WAKEUPwakeupTransmitted := false FE_WAKEUP start t3 |
| T02 (a) | [reqComMode = FullCom ^ (\neg FrSMIsWakeupEcu v WUReason = ALL_WU_BY_BUS) ^ \neg FrSMDelayStartupWithoutWakeup] | FE_TRCV_NORMAL startupCounter := 1 wakeupType := NoWakeup FE_START FE_ALLOW_COLDSTART start t2 start t3 |
| T02 (b) | [reqComMode = FullCom ^ (\neg FrSMIsWakeupEcu v WUReason = ALL_WU_BY_BUS) ^ FrSMDelayStartupWithoutWakeup] | FE_TRCV_NORMAL startupCounter := 1 wakeupType := NoWakeup FE_START start t1 start t2 start t3 |
| T03 (a) | [wakeupFinished ^ reqComMode = FullCom ^ FrSMNumWakeupPatterns = 1 ^ wakeupType = SingleChannelWakeup] | FE_START cancel t1 start t1 start t2 |
| T03 (b) | [wakeupFinished ^ reqComMode = FullCom ^ FrSMNumWakeupPatterns > 1 ^ (wakeupTransmitted v \neg t1_IsActive) ^ wakeupType = SingleChannelWakeup] | FE_START cancel t1 start t2 FE_ALLOW_COLDSTART |

| Transition | Event [Condition] | Actions |
|------------|--|---|
| T03 (c) | [<u>wakeupFinished</u> \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge <u>FrSMNumWakeupPatterns</u> > 1 \wedge \neg <u>wakeupTransmitted</u> \wedge <u>wakeupType</u> = <u>SingleChannelWakeup</u>] | <u>FE_START</u> start <u>t2</u> |
| T03 (d) | [<u>wakeupFinished</u> \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge <u>wakeupType</u> = <u>DualChannelWakeup</u>] | <u>FE_START</u> start <u>t2</u> |
| T03 (e) | [<u>wakeupFinished</u> \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge <u>wakeupType</u> = <u>DualChannelWakeup-Forward</u>] | <u>FE_START</u> <u>FE_ALLOW_COLDSTART</u> start <u>t2</u> |
| T04 (a) | <u>t1</u> [<u>reqComMode</u> = <u>FullCom</u> \wedge <u>vPOC!State</u> \neq Normal Active] | <u>FE_ALLOW_COLDSTART</u> |
| T04 (b) | [<u>reqComMode</u> = <u>FullCom</u> \wedge <u>wakeupType</u> = <u>DualChannelWakeup</u> \wedge <u>AllChannelsAwake</u> \wedge <u>vPOC!State</u> \neq Normal Active] | <u>FE_ALLOW_COLDSTART</u> |
| T05 | <u>t2</u> [<u>startupCounter</u> \leq <u>FrSMStartupRepetitionsWithWakeup</u> \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge <u>wakeupType</u> \neq <u>NoWakeup</u> \wedge <u>vPOC!State</u> \neq Normal Active] | <u>FE_TRCV_NORMAL</u> <u>FE_CONFIG</u> <u>FE_WAKEUP</u> <u>startupCounter</u> := <u>startupCounter</u> + 1 |
| T06 | <u>t2</u> [(<u>FrSMStartupRepetitionsWithWakeup</u> $<$ <u>startupCounter</u> \vee <u>wakeupType</u> = <u>NoWakeup</u>) \wedge <u>startupCounter</u> \leq <u>FrSMStartupRepetitions</u> \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge <u>vPOC!State</u> \neq Normal Active] | <u>FE_TRCV_NORMAL</u> <u>FE_CONFIG</u> <u>FE_START</u> <u>FE_ALLOW_COLDSTART</u> <u>startupCounter</u> := <u>startupCounter</u> + 1 start <u>t2</u> |
| T08 | [<u>vPOC!State</u> = Normal Active \wedge \neg <u>vPOC!Freeze</u> \wedge <u>vPOC!SlotMode</u> = AllSlots \wedge <u>reqComMode</u> = <u>FullCom</u>] | cancel <u>t1</u> cancel <u>t2</u> <u>FE_START_FRIF</u> <u>FE_DEM_STATUS_PASSED</u> <u>FE_DEM_SYNC_LOSS_PASSED</u> <u>FE_FULL_COM_IND</u> cancel <u>t3</u> |
| T108 | [<u>vPOC!State</u> = Normal Active \wedge \neg <u>vPOC!Freeze</u> \wedge <u>vPOC!SlotMode</u> \neq AllSlots \wedge <u>reqComMode</u> = <u>FullCom</u>] | cancel <u>t1</u> cancel <u>t2</u> <u>FE_START_FRIF</u> <u>FE_DEM_STATUS_PASSED</u> <u>FE_DEM_SYNC_LOSS_PASSED</u> cancel <u>t3</u> |
| T09a | <u>FrSM_RequestComMode()</u> [<u>reqComMode</u> = <u>NoCom</u>] | <u>FE_STOP_FRIF</u> <u>FE_HALT</u> <u>FE_NO_COM_IND</u> |
| T09b | <u>FrSM_RequestComMode()</u> [<u>reqComMode</u> = <u>NoCom</u>] | <u>FE_STOP_FRIF</u> <u>FE_HALT</u> |
| T10a | [(<u>vPOC!State</u> = Halt \vee <u>vPOC!Freeze</u>) \wedge <u>reqComMode</u> = <u>FullCom</u> \wedge (<u>FrSmCheckWakeupReason</u> \vee \neg <u>FrSMIsWakeupEcu</u>)] | <u>FE_DEM_SYNC_LOSS</u> <u>FE_STOP_FRIF</u> <u>FE_NO_COM_IND</u> <u>FE_CONFIG</u> <u>FE_START</u> <u>startupCounter</u> := 1 start <u>t2</u> |

| Transition | Event [Condition] | Actions |
|------------|--|---|
| | | start t3 |
| T10b | [(vPOC!State = Halt \vee vPOC!Freeze) \wedge reqComMode = FullCom \wedge (FrSmCheckWakeupReason \vee \neg FrSMIsWakeupEcu)] | FE_DEM_SYNC_LOSS FE_STOP_FRIF FE_CONFIG FE_START startupCounter := 1 start t2 start t3 |
| T101 | [\vee vPOC!State = Normal Active \wedge \neg vPOC!Freeze \wedge vPOC!SlotMode = AllSlots]] | FE_FULL_COM_IND |
| T11a | t_TrcvStdbbyDelay | FE_TRCV_STANDBY FE_CONFIG |
| T11b | [(vPOC!State = Halt \vee vPOC!Freeze) \wedge reqComMode = FullCom] | cancel t_TrcvStdbbyDelay FE_TRCV_STANDBY FE_CONFIG |
| T12 | [reqComMode = NoCom] | cancel t1 cancel t2 cancel t3 FE_DEM_SYNC_LOSS_PASSED FE_TRCV_STANDBY FE_CONFIG |
| T13 | [reqComMode = NoCom] | FE_DEM_SYNC_LOSS_PASSED FE_TRCV_STANDBY FE_CONFIG cancel t3 cancel t1 |
| T14 | FrSM_RequestComMode() [reqComMode = NoCom] | FE_DEM_SYNC_LOSS_PASSED FE_HALT cancel t3 |
| T15 | [\vee vPOC!State = Normal Active \wedge \neg vPOC!Freeze \wedge vPOC!SlotMode = AllSlots]] | FE_DEM_SYNC_LOSS_PASSED FE_START_FRIF FE_FULL_COM_IND cancel t3 |
| T115 | [\vee vPOC!State = Normal Active \wedge \neg vPOC!Freeze \wedge vPOC!SlotMode \neq AllSlots] | FE_DEM_SYNC_LOSS_PASSED FE_START_FRIF cancel t3 |
| T16a | [\vee vPOC!State = Normal Passive \wedge \neg vPOC!Freeze]] | FE_DEM_SYNC_LOSS FE_STOP_FRIF FE_NO_COM_IND start t3 |
| T16b | [\vee vPOC!State = Normal Passive \wedge \neg vPOC!Freeze]] | FE_DEM_SYNC_LOSS FE_STOP_FRIF start t3 |
| T17 | [(vPOC!State = Halt \vee vPOC!Freeze) \wedge reqComMode = FullCom \wedge (FrSmCheckWakeupReason \vee \neg FrSMIsWakeupEcu)] | FE_CONFIG wakeupType := NoWakeup FE_START startupCounter := 1 start t2 |
| T20a | [(vPOC!State = Halt \vee vPOC!Freeze) \wedge reqComMode = FullCom \wedge \neg FrSmCheckWakeupReason \wedge FrSMIsWakeupEcu]] | wakeupType := SingleChannelWakeup FE_DEM_SYNC_LOSSFE_STOP_FRIF FE_NO_COM_IND FE_CONFIG FE_WAKEUP startupCounter := 1 start t1 |

| Transition | Event [Condition] | Actions |
|------------|--|--|
| | | start t3 |
| T20b | [(vPOC!State = Halt ∨ vPOC!Freeze) ∧ reqComMode = FullCom ∧ ¬ FrSmCheckWakeupReason ∧ FrSMIsWakeupEcu | wakeupType := SingleChannelWakeup FE_DEM_SYNC_LOSSFE_STOP_FRIF FE_CONFIG FE_WAKEUP startupCounter := 1 start t1 start t3 |
| T20c | [(vPOC!State = Halt ∨ vPOC!Freeze) ∧ reqComMode = FullCom ∧ ¬ FrSmCheckWakeupReason ∧ FrSMIsWakeupEcu | wakeupType := SingleChannelWakeup FE_CONFIG FE_WAKEUP startupCounter := 1 start t1 start t3 |
| T21 | [(vPOC!State = Halt ∨ vPOC!Freeze) ∧ ¬ t_TrcvStdbbyDelay_IsActive | start t_TrcvStdbbyDelay |
| T30 | t3 | FE_DEM_STATUS_FAILED FE_STARTUP_ERROR_IND |
| T31 | [t3_IsNotActive] | FE_STARTUP_ERROR_IND |
| T32 | [t3_IsNotActive] | FE_STARTUP_ERROR_IND |
| T33 | [t3_IsNotActive] | FE_STARTUP_ERROR_IND |
| T40 | [lowNumberOfColdstarters] | |
| T41 | [¬lowNumberOfColdstarters] | |

Legend: ∧ AND

∨ OR

¬ NOT

:= assignment

start t: start timer t

cancel t: stop timer t

[...] guard condition for transition

t1 [...] t1 has expired

] ()

Note: If synchronization is lost after FullCom has been reached, the FrSM module will first try to bring the FlexRay CC to the startup state without allowing cold start.

Rationale: The loss of synchronization may be a local problem of the ECU. Thus the ECU should first try to re-integrate without disturbing the cluster.

Note: If resynchronization cannot be achieved before [t2](#) expires (see [FrSm076](#) and [FrSm077](#)), the same wakeup and startup procedure as for the initial synchronization will be used.

Note: If the startup of a FlexRay cluster is not successful (i.e. timer [t2](#) expires), the FrSM module will repeat the startup procedure depending on the value of the counter [startupCounter](#):

- If [startupCounter](#) does not exceed the threshold [FrSMStartupRepetitionsWithWakeup](#), the startup procedure will be repeated including the wakeup.

- If [startupCounter](#) exceeds the threshold [FrSMStartupRepetitionsWithWakeup](#) but does not exceed the threshold [FrSMStartupRepetitions](#), the startup procedure will be repeated without wakeup.

Note: When the timer [t3](#) expires, the FrSM will report the production error [FRSM_E_CLUSTER_STARTUP](#).

Note: After timer [t3](#) has expired, the FrSM will call `FrNm_StartupError` until either synchronisation has been achieved or [NoCom](#) is requested (see [FrSm160](#) and [FrSm161](#)).

Note: When the counter [startupCounter](#) exceeds the threshold [FrSMStartupRepetitions](#), an ECU that has been configured as a coldstart node will stop performing coldstart attempts. However, if another ECU performs a coldstart, the ECU will join the coldstart.

Note: If no threshold [FrSMStartupRepetitions](#) has been configured, an ECU that has been configured as a coldstart node will not stop performing coldstart attempts until either synchronisation has been achieved or [NoCom](#) is requested.

Rationale: If the RX path of a FlexRay CC is faulty, an ECU performing a wakeup or coldstart could disturb the FlexRay communication as it will not be able to detect any collision. Thus, an unlimited number of coldstart attempts could lead to a continuous disturbance of the FlexRay communication.

[SWS_FrSM_00149] [When a call of a function of the FlexRay Interface API returns a failure (e.g. `E_NOT_OK`), the FrSM shall ignore this return value and continue with the transition.] ()

Rationale: When the FlexRay Interface returns `E_NOT_OK` in a production environment, a production error has been reported to DEM. This will usually trigger the reinitialization of the FlexRay stack.

7.4 Configuration description

The FlexRay State Manager configuration tool reads the ECU configuration description of the FlexRay Interface as the mapping of controllers to clusters is contained in the FlexRay Interface configuration description.

7.5 Production Errors

7.5.1 FRSM_E_CLUSTER_STARTUP

| | |
|---------------------------|---|
| Error Name: | FRSM_E_CLUSTER_STARTUP |
| Short Description: | FlexRay cluster startup failure. |
| Long Description: | FlexRay controller has not reached the state <i>normal active</i> within the configured time after FlexRay startup. |

| | | |
|------------------------------|-----------------|---|
| Recommended DTC: | Assigned by DEM | |
| Detection Criteria: | Fail | FlexRay controller has not reached the state normal active within the time t3 |
| | Pass | FlexRay controller has reached the state normal active |
| Secondary Parameters: | None | |
| Time Required: | FrSMDurationT3 | |
| Monitor Frequency | Continuous | |
| MIL illumination: | Assigned by DEM | |

7.5.2 FRSM_E_CLUSTER_SYNC_LOSS

| | | |
|------------------------------|---|--|
| Error Name: | FRSM_E_CLUSTER_SYNC_LOSS | |
| Short Description: | FlexRay synchronization loss. | |
| Long Description: | FlexRay controller has lost synchronization after successful startup. | |
| Recommended DTC: | Assigned by DEM | |
| Detection Criteria: | Fail | FlexRay controller has lost synchronization after it has reached state normal active. |
| | Pass | FlexRay controller has reached the state normal active or the request for FlexRay communication has been released. |
| Secondary Parameters: | None | |
| Time Required: | Depends on FlexRay configuration. | |
| Monitor Frequency | Continuous | |
| MIL illumination: | Assigned by DEM | |

7.6 Error classification

Values for production code Event Ids are assigned in the configuration, see section 10.2.6.

| Type of error | Relevance | Related error code | Value [hex] |
|---|-------------|--------------------|-------------|
| Invalid pointer in parameter list. In case of this error, the API service shall return immediately without any further action, beside reporting this development error. | Development | FRSM_E_NULL_PTR | 0x01 |
| Invalid network handle parameter | Development | FRSM_E_INV_HANDLE | 0x02 |
| FrSM module was not initialized | Development | FRSM_E_UNINIT | 0x03 |
| Invalid communication mode requested | Development | FRSM_E_INV_MODE | 0x04 |
| | | | |

()

7.7 Error detection

For details refer to the chapter 7.3 “Error Detection” in *SWS_BSWGeneral*.

7.8 Error notification

For details refer to the chapters 7.4 “Error notification” in *SWS_BSWGeneral*.

7.9 Debugging

[SWS_FrSM_00137] [The states of FrSM state machine shall be available for debugging.] (SRS_BSW_00442)

8 API specification

8.1 Imported types

In this chapter all types included from the following files are listed:

[SWS_FrSM_00095] [

| <i>Module</i> | <i>Imported Type</i> |
|----------------|--------------------------|
| ComM | ComM_ModeType |
| ComStack_Types | NetworkHandleType |
| Dem | Dem_EventIdType |
| | Dem_EventStatusType |
| Fr | Fr_ChannelType |
| | Fr_POCTestStatusType |
| FrIf | FrIf_StateTransitionType |
| FrTrcv | FrTrcv_TrvcModeType |
| | FrTrcv_TrvcWUReasonType |
| Std_Types | Std_ReturnType |
| | Std_VersionInfoType |

] ()

8.2 Type definitions

8.2.1 FrSM_ConfigType

[SWS_FrSM_00198] [

| | |
|---------------------|---|
| Name: | FrSM_ConfigType |
| Type: | Structure |
| Range: | Implementation specific. |
| Description: | This type contains the implementation-specific post build time configuration structure that is for FrSM_Init. |

] ()

8.2.2 FrSM_BswM_StateType

[SWS_FrSM_00199] [

| | | |
|---------------|--------------------------------|---|
| Name: | FrSM_BswM_StateType | |
| Type: | Enumeration | |
| Range: | FRSM_BSWM_READY | 0 |
| | FRSM_BSWM_READY_ECU_PASSIVE | 1 |
| | FRSM_BSWM_STARTUP | 2 |
| | FRSM_BSWM_STARTUP_ECU_PASSIVE | 3 |
| | FRSM_BSWM_WAKEUP | 4 |
| | FRSM_BSWM_WAKEUP_ECU_PASSIVE | 5 |
| | FRSM_BSWM_HALT_REQ | 6 |
| | FRSM_BSWM_HALT_REQ_ECU_PASSIVE | 7 |

| | | |
|---------------------|--|----|
| | FRSM_BSWM_KEYSLOT_ONLY | 8 |
| | FRSM_BSWM_KEYSLOT_ONLY_ECU_PASSIVE | 9 |
| | FRSM_BSWM_ONLINE | 10 |
| | FRSM_BSWM_ONLINE_ECU_PASSIVE | 11 |
| | FRSM_BSWM_ONLINE_PASSIVE | 12 |
| | FRSM_BSWM_ONLINE_PASSIVE_ECU_PASSIVE | 13 |
| | FRSM_LOW_NUMBER_OF_COLDSTARTERS | 14 |
| | FRSM_LOW_NUMBER_OF_COLDSTARTERS_ECU_PASSIVE | 15 |
| Description: | This type defines the states that are reported to the BswM using BswM_FrSM_CurrentState. | |

⌋()

8.3 Function definitions

This is a list of functions provided for upper layer modules.

8.3.1 FrSM_Init

[SWS_FrSM_00013] ⌈

| | | |
|----------------------------|--|---|
| Service name: | FrSM_Init | |
| Syntax: | <pre>void FrSM_Init(const FrSM_ConfigType* FrSM_ConfigPtr)</pre> | |
| Service ID[hex]: | 0x01 | |
| Sync/Async: | Synchronous | |
| Reentrancy: | Non Reentrant | |
| Parameters (in): | FrSM_ConfigPtr | Pointer to a selected configuration structure |
| Parameters (inout): | None | |
| Parameters (out): | None | |
| Return value: | None | |
| Description: | Initializes the FlexRay State Manager. | |

⌋ (SRS_BSW_00405, SRS_BSW_00381, SRS_BSW_00438)

[SWS_FrSM_00126] ⌈The [FrSM_Init](#) function shall initialize the state machines for all FlexRay clusters and set them into the state [FRSM_READY](#), i.e. perform transition [T00](#). ⌋ (SRS_BSW_00438, SRS_BSW_00101)

[SWS_FrSM_00127] ⌈The [FrSM_Init](#) function shall internally store the configuration data address to enable subsequent API calls to access the configuration data. ⌋ (SRS_BSW_00438)

[SWS_FrSM_00128] ⌈If development error detection is enabled (`FrSMDevErrorDetect` is ON), the [FrSM_Init](#) function shall remember internally the successful initialization for other API functions to check for proper module initialization. ⌋ (SRS_BSW_00438)

[SWS_FrSM_00015] [If development error detection is enabled (`FrSMDevErrorDetect` is ON) and `FrSM_ConfigPtr` equals `NULL_PTR`, the `FrSM_Init` function shall report the error [FRSM_E_NULL_PTR](#) to the DET and shall not perform the initialization. However, a value of `NULL_PTR` for `FrSM_ConfigPtr` shall not be treated as an error, if a configuration variant (see section 10.2.1) without post-build data is used.] ()

8.3.2 FrSM_RequestComMode

[SWS_FrSM_00020] [

| | | |
|----------------------------|---|--|
| Service name: | FrSM_RequestComMode | |
| Syntax: | <pre>Std_ReturnType FrSM_RequestComMode(NetworkHandleType NetworkHandle, ComM_ModeType ComM_Mode)</pre> | |
| Service ID[hex]: | 0x02 | |
| Sync/Async: | Asynchronous | |
| Reentrancy: | Reentrant for different FlexRay clusters | |
| Parameters (in): | NetworkHandle | This parameter identifies the FlexRay cluster for which a communication mode is requested. |
| | ComM_Mode | This parameter holds the requested communication mode. |
| Parameters (inout): | None | |
| Parameters (out): | None | |
| Return value: | Std_ReturnType | E_OK: Request accepted E_NOT_OK: Request not accepted |
| Description: | This API function is used by the ComM to startup or shutdown the communication on a FlexRay cluster. | |

] (`SRS_ModeMgm_09081`)

[SWS_FrSM_00021] [The [FrSM_RequestComMode](#) function shall store the requested communication mode.

The next activation of the [FrSM_MainFunction](#) will then process this request when processing the state machine of the corresponding cluster.

Note, that the state machine definition in section 7.2 refers to this stored request as [reqComMode](#).] ()

[SWS_FrSM_00022] [If [NoCom](#) is requested after [FullCom](#) has been reached (i.e. when the FrSM state machine of the corresponding cluster is in state [FRSM_ONLINE](#), `FRSM_KEYSLOT_ONLY`, `FRSM_LOW_NUMBER_OF_COLD-STARTERS` or `FRSM_ONLINE_PASSIVE`), the [FrSM_RequestComMode](#) function shall immediately process the corresponding transition of the state machine (see section 7.2).] ()

Rationale of [SWS_FrSM_00022](#): This shall ensure that the [NoCom](#) request will stop the participation of the ECU in the FlexRay communication at the end of the current FlexRay cycle.

[SWS_FrSM_00141] [If `ComM_Mode` has the value `COMM_SILENT_COMMUNICATION`, the FrSM shall not store the requested communication mode and return `E_NOT_OK`. In case development error detection is enabled, the FrSM shall additionally raise the development error code [FRSM_E_INV_MODE](#).] ()

[SWS_FrSM_00018] [If development error detection is enabled and the parameter `NetworkHandle` has an invalid value, the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_INV_HANDLE](#) and the [FrSM_RequestComMode](#) function shall return `E_NOT_OK`.] (`SRS_BSW_00369`, `SRS_BSW_00323`)

[SWS_FrSM_00019] [If development error detection is enabled and the parameter `ComM_Mode` has an invalid value, the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_INV_MODE](#) and the [FrSM_RequestComMode](#) function shall return `E_NOT_OK`.] ()

[SWS_FrSM_00061] [If development error detection is enabled and the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_RequestComMode](#) function shall raise the development error code [FRSM_E_UNINIT](#) and the function [FrSM_RequestComMode](#) shall return `E_NOT_OK`.] (`SRS_BSW_00406`)

8.3.3 FrSM_GetCurrentComMode

[SWS_FrSM_00024] [

| | | |
|----------------------------|--|--|
| Service name: | FrSM_GetCurrentComMode | |
| Syntax: | Std_ReturnType FrSM_GetCurrentComMode(NetworkHandleType NetworkHandle, ComM_ModeType* ComM_ModePtr) | |
| Service ID[hex]: | 0x03 | |
| Sync/Async: | Synchronous | |
| Reentrancy: | Reentrant for different FlexRay clusters | |
| Parameters (in): | NetworkHandle | Handle of communication network |
| Parameters (inout): | None | |
| Parameters (out): | ComM_ModePtr | Pointer to the memory location where the current communication mode shall be stored |
| Return value: | Std_ReturnType | E_OK: Request accepted E_NOT_OK: Request was not accepted as the FrSM has not been initialized using FrSM_Init. |
| Description: | This API function can be used to determine the current communication mode of a FlexRay cluster. | |

] (`SRS_ModeMgm_09084`)

[SWS_FrSM_00025] [The [FrSM_GetCurrentComMode](#) function shall write the current communication mode of the corresponding FlexRay cluster into the given memory location.] ()

[SWS_FrSM_00026] [The [FrSM_GetCurrentComMode](#) function shall determine the communication mode as follows:

- If the FrSM state machine for the FlexRay cluster determined by NetworkHandle is in state [FRSM_ONLINE](#) or [FRSM_LOW_NUMBER_OF_COLDSTARTERS](#), the communication mode is COMM_FULL_COMMUNICATION.
- In any other case, the communication mode is COMM_NO_COMMUNICATION.

] ()

[SWS_FrSM_00027] [If development error detection is enabled and the parameter NetworkHandle has an invalid value, the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_INV_HANDLE](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] ()

[SWS_FrSM_00028] [If development error detection is enabled and the parameter ComM_ModePtr equals NULL_PTR, the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_NULL_PTR](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] (SRS_BSW_00369, SRS_BSW_00323)

[SWS_FrSM_00060] [If development error detection is enabled and the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_GetCurrentComMode](#) function shall raise the development error code [FRSM_E_UNINIT](#) and the [FrSM_GetCurrentComMode](#) function shall return E_NOT_OK.] (SRS_BSW_00406)

8.3.4 FrSM_GetVersionInfo

[SWS_FrSM_00029] [

| | | |
|----------------------------|---|---|
| Service name: | FrSM_GetVersionInfo | |
| Syntax: | <pre>void FrSM_GetVersionInfo(Std_VersionInfoType* versioninfo)</pre> | |
| Service ID[hex]: | 0x04 | |
| Sync/Async: | Synchronous | |
| Reentrancy: | Reentrant | |
| Parameters (in): | None | |
| Parameters (inout): | None | |
| Parameters (out): | versioninfo | Pointer to where to store the version information of this module. |
| Return value: | None | |
| Description: | This service returns the version information of this module. The version information includes: - Module Id | |

| | |
|--|--|
| | <p>- Vendor Id - Vendor specific version numbers (BSW00407).</p> <p>This function shall be pre compile time configurable On/Off by the configuration parameter: FRSM_VERSION_INFO_API</p> <p>Hint: If source code for caller and callee of this function is available this function should be realized as a macro. The macro should be defined in the modules header file.</p> |
|--|--|

] (SRS_BSW_00407)

8.3.5 FrSM_AllSlots

[SWS_FrSM_00172] ?

| | | |
|----------------------------|---|--|
| Service name: | FrSM_AllSlots | |
| Syntax: | Std_ReturnType FrSM_AllSlots(NetworkHandleType NetworkHandle) | |
| Service ID[hex]: | 0x05 | |
| Sync/Async: | Asynchronous | |
| Reentrancy: | Reentrant for different FlexRay clusters | |
| Parameters (in): | NetworkHandle | This parameter identifies the FlexRay cluster for which a communication mode is requested. |
| Parameters (inout): | None | |
| Parameters (out): | None | |
| Return value: | Std_ReturnType | E_OK: Request accepted E_NOT_OK: Request not accepted |
| Description: | This API function can be used to leave the KeySlotOnlyMode. | |

] ()

[SWS_FrSM_00197] [The [FrSM_AllSlots](#) function shall be pre compile time configurable ON/OFF by the configuration parameter FrSMAllSlotsSupport]()

[SWS_FrSM_00171] [The [FrSM_AllSlots](#) function shall call FrIf_AllSlots for each controller of the FlexRay cluster. It shall return E_OK if each of these calls returned E_OK, otherwise [FrSM_AllSlots](#) shall return E_NOT_OK.] ()

[SWS_FrSM_00168] [If development error detection is enabled and the parameter NetworkHandle has an invalid value, the [FrSM_AllSlots](#) function shall raise the development error code FRSM_E_INV_HANDLE and the [FrSM_AllSlots](#) function shall return E_NOT_OK.] (SRS_BSW_00369, SRS_BSW_00323)

[SWS_FrSM_00169] [If development error detection is enabled and the FrSM module has not been initialized using FrSM_Init, the [FrSM_AllSlots](#) function shall raise the development error code FRSM_E_UNINIT and the [FrSM_AllSlots](#) function shall return E_NOT_OK.] (SRS_BSW_00406)

8.3.6 FrSM_SetEcuPassive

[SWS_FrSM_00174] [

| | | |
|----------------------------|--|---|
| Service name: | FrSM_SetEcuPassive | |
| Syntax: | Std_ReturnType FrSM_SetEcuPassive(boolean FrSM_Passive) | |
| Service ID[hex]: | 0x06 | |
| Sync/Async: | Synchronous | |
| Reentrancy: | Non Reentrant | |
| Parameters (in): | FrSM_Passive | This parameter determines whether all FlexRay clusters are set to passive, i.e. receive only. |
| Parameters (inout): | None | |
| Parameters (out): | None | |
| Return value: | Std_ReturnType | E_OK: Request accepted E_NOT_OK: Request not accepted |
| Description: | This API function can be used to set all FlexRay clusters of the ECU to a receive only mode. | |

? ()

[SWS_FrSM_00177] [The [FrSM_SetEcuPassive](#) function shall set the state of all FrSM state machines to [FRSM_ECU_PASSIVE](#) if the parameter FrSM_Passive evaluates to true, otherwise it shall set the state of all FrSM state machines to [FRSM_ECU_ACTIVE](#).] ()

[SWS_FrSM_00178] [If the state machine of a FlexRay cluster is not in state [FRSM_READY](#) (i.e. the transceivers of the FlexRay cluster are not in standby mode), the function shall execute [FE_TRCV_NORMAL](#) for this cluster.] ()

[SWS_FrSM_00179] [If development error detection is enabled and the FrSM module has not been initialized using FrSM_Init, the [FrSM_SetEcuPassive](#) function shall raise the development error code FRSM_E_UNINIT and the [FrSM_SetEcuPassive](#) function shall return E_NOT_OK.] (SRS_BSW_00406)

8.4 Call-back notifications

The FlexRay State Manager does not provide any call-back API services to other BSW modules. Therefore, the header file FrSM_Cbk.h is not needed.

8.5 Scheduled functions

These functions are directly called by Basic Software Scheduler. The following functions shall have no return value and no parameter. All functions shall be non reentrant.

8.5.1 FrSM_MainFunction_<Cluster Id>

[SWS_FrSM_00118] [

| | |
|----------------------|--------------------------------|
| Service name: | FrSM_MainFunction_<Cluster Id> |
|----------------------|--------------------------------|

| | |
|-------------------------|---|
| Syntax: | void FrSM_MainFunction_<Cluster Id>(void) |
| Service ID[hex]: | 0x80 |
| Description: | -- |

] (SRS_BSW_00373)

[SWS_FrSM_00047] [The [FrSM_MainFunction](#) shall determine the [POC](#) status of all FlexRay [CC](#) that are connected to the corresponding FlexRay cluster.

This document is based on the assumption that there is always a unique [POC](#) state for every FlexRay cluster (see Limitations in section 4.1).] ()

[SWS_FrSM_00192] [If the optional configuration parameter FrSMMinNumberOfColdstarter is configured, the [FrSM_MainFunction](#) shall determine the number startup frames by calling FrIf_GetNumOfStartupFrames.] ()

[SWS_FrSM_00048] [After determining the [POC](#) status and optionally the number of startup frames, the [FrSM_MainFunction](#) shall process the state machine of the corresponding cluster.] ()

Note: The [FrSM_MainFunction](#) shall be called cyclically with a cycle time that is shorter than or equal to the FlexRay cycle duration.

Rationale: The [FrSM_MainFunction](#) should be called at least once per FlexRay cycle. As the [POC](#) status only changes once per cycle, multiple invocations per FlexRay cycle have no benefit.

Note: After [FullCom](#) has been reached, the invocation of the [FrSM_MainFunction](#) can optionally be synchronized to the FlexRay global time to ensure that the [FrSM_MainFunction](#) is activated once per FlexRay cycle. However, this is outside of the scope of this specification.

Note: In case of very short FlexRay cycle times the [FrSM_MainFunction](#) can optionally be called with a cycle time that is larger than the FlexRay cycle time. However, this is outside of the scope of this specification as it can lead to increased startup time and to undetected [POC](#) status changes.

[SWS_FrSM_00181] [If the FrSM module has not been initialized using [FrSM_Init](#), the [FrSM_MainFunction](#) function shall return immediately without performing any functionality and without raising any errors.] (SRS_BSW_00450)

8.6 Expected Interfaces

In this chapter all interfaces required from other modules are listed.

8.6.1 Mandatory Interfaces

This chapter defines all interfaces which are required to fulfill the core functionality of the module.

[SWS_FrSM_00096] [

| API function | Description |
|-----------------------------|---|
| BswM_FrSM_CurrentState | Function called by FrSM to indicate its current state. |
| ComM_BusSM_ModelIndication | Indication of the actual bus mode by the corresponding Bus State Manager. ComM shall propagate the indicated state to the users with means of the RTE and BswM. |
| Dem_ReportErrorStatus | Queues the reported events from the BSW modules (API is only used by BSW modules). The interface has an asynchronous behavior, because the processing of the event is done within the Dem main function. OBD Events Suppression shall be ignored for this computation. |
| FrIf_AllowColdstart | Wraps the FlexRay Driver API function Fr_AllowColdstart(). |
| FrIf_ClearTransceiverWakeup | Wraps the FlexRay Transceiver Driver API function FrTrcv_ClearTransceiverWakeup(). The enum value "FR_CHANNEL_AB" shall not be used. |
| FrIf_ControllerInit | Initialized a FlexRay CC. |
| FrIf_GetPOCStatus | Wraps the FlexRay Driver API function Fr_GetPOCStatus(). |
| FrIf_GetTransceiverWUReason | Wraps the FlexRay Transceiver Driver API function FrTrcv_GetTransceiverWUReason(). The enum value "FR_CHANNEL_AB" shall not be used. |
| FrIf_HaltCommunication | Wraps the FlexRay Driver API function Fr_HaltCommunication(). |
| FrIf_SendWUP | Wraps the FlexRay Driver API function Fr_SendWUP(). |
| FrIf_SetState | Requests FrIf state machine transition. |
| FrIf_SetTransceiverMode | Wraps the FlexRay Transceiver Driver API function FrTrcv_SetTransceiverMode(). The enum value "FR_CHANNEL_AB" shall not be used. |
| FrIf_StartCommunication | Wraps the FlexRay Driver API function Fr_StartCommunication(). |

] ()

8.6.2 Optional Interfaces

This chapter defines all interfaces, which are required to fulfill an optional functionality of the module.

[SWS_FrSM_00097] [

| API function | Description |
|----------------------------|---|
| Det_ReportError | Service to report development errors. |
| FrIf_AllSlots | Wraps the FlexRay Driver API function Fr_AllSlots |
| FrIf_GetNumOfStartupFrames | Wraps the FlexRay Driver API function Fr_GetNumOfStartupFrames and gets a list of the the current number of startup frames seen on the cluster. See variable vStartupPairs of [12] for details. |
| FrIf_GetWakeupRxStatus | Wraps the FlexRay Driver API function Fr_GetWakeupRxStatus and gets the wakeup received information from the FlexRay controller. |
| FrIf_SetWakeupChannel | Wraps the FlexRay Driver API function Fr_SetWakeupChannel(). The enum value "FR_CHANNEL_AB" shall not be used. |
| FrNm_StartupError | This function is called by the FrSM when synchronization of the FlexRay cluster could not be achieved. |

] ()

8.6.3 Configurable Interfaces

8.6.3.1 <Cdd>_SyncLossErrorIndication

[SWS_FrSM_00190] [


| | | |
|----------------------------|---|--|
| Service name: | <Cdd>_SyncLossErrorIndication | |
| Syntax: | <pre>void <Cdd>_SyncLossErrorIndication(NetworkHandleType NetworkHandle, boolean SyncLossErrorStatus)</pre> | |
| Sync/Async: | Synchronous | |
| Reentrancy: | Reentrant for different FlexRay clusters | |
| Parameters (in): | NetworkHandle | Handle of FlexRay cluster |
| | SyncLossErrorStatus | true: ECU lost synchronization to the FlexRay cluster. false: ECU can synchronize to the FlexRay cluster or request for full communication has been released after the ECU lost its synchronization to the FlexRay cluster. |
| Parameters (inout): | None | |
| Parameters (out): | None | |
| Return value: | None | |
| Description: | This function is called with parameter SyncLossErrorStatus = true when the ECU loses its synchronization to the FlexRay cluster. The function is called with parameter SyncLossErrorStatus = false either when the ECU can synchronize to the FlexRay cluster or when the request for full communication has been released after the ECU lost its synchronization to the FlexRay cluster. | |

The name of this function can be configured using the configuration parameter FrMmSyncLossErrorIndicationName (see chapter 10). The FlexRay State Manager will call this function when the ECU loses its synchronization to the FlexRay cluster, after it could synchronize to the FlexRay cluster or when the FullCom request is released after the ECU lost its synchronization to the FlexRay cluster.


] ()

9 Sequence diagrams

9.1 Initialization



9.2 Single Channel Wakeup



(continued)





Figure 3 Transition from no communication to full communication for the case of an ECU that has a local wakeup reason.

9.3 Single Channel Passive Startup



continued on next page

(continued)





Figure 4 Transition from no communication to full communication for the case of an ECU that has been woken up by bus.

9.4 Dual Channel Wakeup



(continued on next page)





Figure 5 Transition from no communication to full communication for the case of a dual channel ECU with a local wakeup reason.

9.5 Dual Channel Wakeup Forward



(continued on next page)






Figure 6 Transition from no communication to full communication for the case of a dual channel that has been woken up by bus.

9.6 Key Slot Only Mode



9.7 Transition from full communication to no communication



10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals.

Chapter 10.2 specifies the structure (containers) and the parameters of the module FlexRay State Manager.

Chapter 10.3 specifies published information of the module FlexRay State Manager.

10.1 How to read this chapter

For details refer to the chapter 10.1 “Introduction to configuration specification” in *SWS_BSWGeneral*.

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters are described Chapters 7 and Chapter 8.

[SWS_FrSM_00064] [The [FrSM](#) module shall support tool based configuration.]
(SRS_BSW_00159)

[SWS_FrSM_00065] [The configuration tool shall check the consistency of the configuration parameters at system configuration time.] (SRS_BSW_00167)

10.2.1 Variants

10.2.1.1 VARIANT-PRE-COMPILE (Pre-compile Configuration)

[SWS_FrSM_00098] [In the variant VARIANT-PRE-COMPILE all parameters below that are marked as pre-compile configurable with “VARIANT-PRE-COMPILE“ shall be configurable in a pre-compile manner, for example as #defines.

The module is most likely delivered as source code.] ()

10.2.1.2 VARIANT-LINK-TIME (Link-time Configuration)

[SWS_FrSM_00099] [The variant VARIANT-LINK-TIME shall include all configuration options of the variant VARIANT-PRE-COMPILE. Additionally all parameters that are marked as link-time configurable with “VARIANT-LINK-TIME“

shall be configurable at link time for example by linking a special configured parameter object file.

The module is most likely delivered as object code.] (SRS_BSW_00342)

10.2.1.3 VARIANT-POST-BUILD (Post-build Configuration)

[SWS_FrSM_00100] [The variant VARIANT-POST-BUILD shall include all configuration options of the variant VARIANT-LINK-TIME. Additionally all parameters that are marked as post-build configurable with “VARIANT-POST-BUILD“ shall be configurable post build for example by flashing configuration data.

The module is most likely delivered as object code.] (SRS_BSW_00342)

10.2.2 FrSM

| | |
|---------------------------|--|
| Module Name | FrSM |
| Module Description | Configuration of the FlexRay State Manager |

| Included Containers | | |
|----------------------------|---------------------|--|
| Container Name | Multiplicity | Scope / Dependency |
| FrSMConfig | 1 | This container comprises the cluster specific configuration of the FlexRay State Manager. |
| FrSMGeneral | 1 | This container contains the general configuration parameters of the FlexRay State Manager. |




Figure 7 FlexRay State Manager Configuration

10.2.3 FrSMConfig

| | |
|---------------------------------|---|
| SWS Item | ECUC_FrSM_00146 : |
| Container Name | FrSMConfig{FRSM_CONFIG} [Multi Config Container] |
| Description | This container comprises the cluster specific configuration of the FlexRay State Manager. |
| Configuration Parameters | |

| Included Containers | | |
|----------------------------|---------------------|---|
| Container Name | Multiplicity | Scope / Dependency |
| FrSMCluster | 1..* | This container specifies a FlexRay cluster and all related data. A FlexRay cluster may consist of more than one controller per ECU. |

10.2.4 FrSMGeneral

| | | | |
|---------------------------------|--|--|--|
| SWS Item | ECUC_FrSM_00107 : | | |
| Container Name | FrSMGeneral{FRSM_GENERAL} | | |
| Description | This container contains the general configuration parameters of the FlexRay State Manager. | | |
| Configuration Parameters | | | |

| | | | |
|---------------------------|---|----|--------------|
| SWS Item | ECUC_FrSM_00172 : | | |
| Name | FrSMAllSlotsSupport {FRSM_ALL_SLOTS_SUPPORT} | | |
| Description | Configuration parameter to enable/disable FrSM support to enable/disable the switching from key-slot/single-slot mode to all-slot mode. | | |
| Multiplicity | 0..1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | All Variants |
| | Link time | -- | |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|----|--------------|
| SWS Item | ECUC_FrSM_00171 : | | |
| Name | FrSMCddHeaderFile {FRSM_CDD_HEADER_FILE} | | |
| Description | This parameter defines header files for callback functions which are implemented by CDD, e.g. <Cdd>_SyncLossErrorIndication. | | |
| Multiplicity | 0..1 | | |
| Type | EcucStringParamDef | | |
| Default value | -- | | |
| maxLength | -- | | |
| minLength | -- | | |
| regularExpression | -- | | |
| ConfigurationClass | Pre-compile time | X | All Variants |
| | Link time | -- | |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|----|--------------|
| SWS Item | ECUC_FrSM_00066 : | | |
| Name | FrSMDevErrorDetect {FRSM_DEV_ERROR_DETECT} | | |
| Description | Enables and disables the development error detection and notification mechanism. | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | false | | |
| ConfigurationClass | Pre-compile time | X | All Variants |
| | Link time | -- | |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|--------------------|--|--|--|
| SWS Item | ECUC_FrSM_00167 : | | |
| Name | FrSMSyncLossErrorIndicationName {FRSM_SYNC_LOSS_ERROR_INDICATION_NAME} | | |
| Description | Name of <Cdd>_SyncLossErrorIndication function that shall be called on loss of synchronization. If this parameter is omitted no indication shall take place. | | |

| | | | |
|---------------------------|-------------------------|----|---------------------------------------|
| Multiplicity | 0..1 | | |
| Type | EcucFunctionNameDef | | |
| Default value | -- | | |
| maxLength | -- | | |
| minLength | -- | | |
| regularExpression | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME, VARIANT-POST-BUILD |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|----|--------------|
| SWS Item | ECUC_FrSM_00108 : | | |
| Name | FrSMVersionInfoApi {FRSM_VERSION_INFO_API} | | |
| Description | Enables and disables the version info API | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | false | | |
| ConfigurationClass | Pre-compile time | X | All Variants |
| | Link time | -- | |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

No Included Containers




Figure 8 FrSMGeneral Container

10.2.5 FrSMCluster

| | |
|---------------------------------|---|
| SWS Item | ECUC_FrSM_00067 : |
| Container Name | FrSMCluster{FRSM_CLUSTER} |
| Description | This container specifies a FlexRay cluster and all related data. A FlexRay cluster may consist of more than one controller per ECU. |
| Configuration Parameters | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00001 : | | |
| Name | FrSMCheckWakeupReason {FRSM_CHECK_WAKEUP_REASON} | | |
| Description | If FrSMCheckWakeupReason is true, the FrSM will check the wakeup reason in order to skip the wakeup in case of wakeup by bus. If FrSMCheckWakeupReason is false, the FrSM will always try to perform a wakeup. | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00166 : | | |
| Name | FrSMDelayStartupWithoutWakeup {FRSM_DELAY_STARTUP_WITHOUT_WAKEUP} | | |
| Description | If true, timer t1 shall be started instead of immediately calling FrIf_AllowColdstart in case of a startup without wakeup. | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00102 : | | |
| Name | FrSMDurationT1 {FRSM_DURATION_T1} | | |
| Description | The duration of timer t1 in seconds. A value of 0 shall imply that the timer is not used. | | |
| Multiplicity | 1 | | |
| Type | EcucFloatParamDef | | |
| Range | 0 .. INF | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime). | | |

| | | | |
|-----------------|-----------------------------------|--|--|
| SWS Item | ECUC_FrSM_00089 : | | |
| Name | FrSMDurationT2 {FRSM_DURATION_T2} | | |

| | | | |
|---------------------------|--|---|---------------------|
| Description | The duration of timer t2 in seconds. A value of 0 shall imply that the timer is not used. The value of this parameter shall be larger than the value of FrSMDurationT1 parameter. | | |
| Multiplicity | 1 | | |
| Type | EcucFloatParamDef | | |
| Range | 0 .. INF | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime). | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00162 : | | |
| Name | FrSMDurationT3 {FRSM_DURATION_T3} | | |
| Description | The duration of timer t3 in seconds. The value of this parameter shall be larger than the value of FrSMDurationT1 parameter. A value of 0 shall imply that the timer is not used. It shall only be possible to configure a value 0 if no FrNm is used. | | |
| Multiplicity | 1 | | |
| Type | EcucFloatParamDef | | |
| Range | 0 .. INF | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local dependency: FrSMMainFunctionCycleTime (As timers are checked during the call of FrSM_MainFunction, the effective timer duration will always be a multiple of FrSMMainFunctionCycleTime). | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00068 : | | |
| Name | FrSMIsColdstartEcu {FRSM_IS_COLDSTART_ECU} | | |
| Description | True: The ECU is a coldstart node for this FlexRay cluster. False: The ECU is no coldstart node for this FlexRay cluster. | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00109 : | | |
| Name | FrSMIsWakeupEcu {FRSM_IS_WAKEUP_ECU} | | |
| Description | True: FrSM shall perform a wakeup for this cluster. False: FrSM shall never perform a wakeup for this FlexRay cluster. | | |
| Multiplicity | 1 | | |
| Type | EcucBooleanParamDef | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|----|---------------------------------------|
| SWS Item | ECUC_FrSM_00115 : | | |
| Name | FrSMMainFunctionCycleTime {FRSM_MAIN_FUNCTION_CYCLE_TIME} | | |
| Description | This parameter defines the cycle time in seconds of the periodic calling of FrSM main function. | | |
| Multiplicity | 1 | | |
| Type | EcucFloatParamDef | | |
| Range | 0 .. INF | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME, VARIANT-POST-BUILD |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00168 : | | |
| Name | FrSMMinNumberOfColdstarter {FRSM_MIN_NUMBER_OF_COLDSTARTER} | | |
| Description | This parameter defines the number of coldstarter that should not be underrun. If this parameter is not configured the mainfunction shall not check the number of startup frames. | | |
| Multiplicity | 0..1 | | |
| Type | EcucIntegerParamDef | | |
| Range | 0 .. 255 | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00165 : | | |
| Name | FrSMNumWakeupPatterns {FRSM_NUM_WAKEUP_PATTERNS} | | |
| Description | Maximum number of Wakeup Patterns the node may send before going to FRSM_STARTUP. | | |
| Multiplicity | 1 | | |
| Type | EcucIntegerParamDef | | |
| Range | 0 .. 65535 | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00069 : | | |
| Name | FrSMStartupRepetitions {FRSM_STARTUP_REPETITIONS} | | |
| Description | The number of times an ECU may repeat the startup procedure for a FlexRay cluster. | | |
| Multiplicity | 0..1 | | |
| Type | EcucIntegerParamDef | | |
| Range | 0 .. 65535 | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local dependency: This value must be greater or equal to FrSMStartupRepetitionsWithWakeup | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00094 : | | |
| Name | FrSMStartupRepetitionsWithWakeup {FRSM_STARTUP_REPETITIONS_WITH_WAKEUP} | | |
| Description | The number of times an ECU may repeat the startup procedure including a wakeup for a FlexRay cluster. | | |
| Multiplicity | 0..1 | | |
| Type | EcucIntegerParamDef | | |
| Range | 0 .. 65535 | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|---|---------------------|
| SWS Item | ECUC_FrSM_00170 : | | |
| Name | FrSMTrcvStdbyDelay {FRSM_TRCV_STDBY_DELAY} | | |
| Description | The duration of timer t_TrvcStdbyDelay in seconds. The granularity of this parameter shall be restricted to full FlexRay cycles (FrIfGdCycle). A value of 0 shall imply that the timer is not used. | | |
| Multiplicity | 0..1 | | |
| Type | EcucFloatParamDef | | |
| Range | 0 .. INF | | |
| Default value | -- | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local dependency: FrSmMainFunctionCycleTime | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00070 : | | |
| Name | FrSMComMNetworkHandleRef {FRSM_COMM_NETWORK_HANDLE_REF} | | |
| Description | Reference to the unique handle to identify one certain FlexRay network correspond to one of the network handles of the ComM configuration. | | |
| Multiplicity | 1 | | |
| Type | Symbolic name reference to [ComMChannel] | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|--|---|---------------------|
| SWS Item | ECUC_FrSM_00116 : | | |
| Name | FrSMFrIfClusterRef {FRSM_FRIF_CLUSTER_REF} | | |
| Description | References the cluster configuration in the FlexRay Interface configuration. Note that the assigned controllers and transceivers are defined in the FrIf configuration and can be accessed via this reference. | | |
| Multiplicity | 1 | | |
| Type | Symbolic name reference to [FrIfCluster] | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME |
| | Post-build time | X | VARIANT-POST-BUILD |
| Scope / Dependency | scope: local | | |

| | | |
|----------------------------|---------------------|---------------------------|
| Included Containers | | |
| Container Name | Multiplicity | Scope / Dependency |

| | | |
|----------------------------------|------|--|
| FrSMClusterDemEventParameterRefs | 0..1 | Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in this container and can be extended by vendor specific error references. |
|----------------------------------|------|--|




Figure 9 FrSMCluster Container

10.2.6 FrSMClusterDemEventParameterRefs

| | |
|---------------------------------|---|
| SWS Item | ECUC_FrSM_00163 : |
| Container Name | FrSMClusterDemEventParameterRefs |
| Description | Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in this container and can be extended by vendor specific error references. |
| Configuration Parameters | |

| | | | |
|---------------------------|---|----|---------------------------------------|
| SWS Item | ECUC_FrSM_00164 : | | |
| Name | FRSM_E_CLUSTER_STARTUP | | |
| Description | Reference to the DemEventParameter which shall be issued when the error "FRSM_E_CLUSTER_STARTUP" has occurred. If the reference is not configured the error shall be reported as DET error. | | |
| Multiplicity | 1 | | |
| Type | Symbolic name reference to [DemEventParameter] | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME, VARIANT-POST-BUILD |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

| | | | |
|---------------------------|---|----|---------------------------------------|
| SWS Item | ECUC_FrSM_00169 : | | |
| Name | FRSM_E_CLUSTER_SYNC_LOSS | | |
| Description | Reference to the DemEventParameter which shall be issued when the error "FRSM_E_CLUSTER_SYNC_LOSS" has occurred. If the reference is not configured the error shall be reported as DET error. | | |
| Multiplicity | 1 | | |
| Type | Symbolic name reference to [DemEventParameter] | | |
| ConfigurationClass | Pre-compile time | X | VARIANT-PRE-COMPILE |
| | Link time | X | VARIANT-LINK-TIME, VARIANT-POST-BUILD |
| | Post-build time | -- | |
| Scope / Dependency | scope: local | | |

No Included Containers

10.3 Published Information

For details refer to the chapter 10.3 "Published Information" in *SWS_BSWGeneral*.

11 Not applicable requirements

[SWS_FrSM_00186] [These requirements are not applicable to this specification.]

(SRS_BSW_00170, SRS_BSW_00419, SRS_BSW_00387, SRS_BSW_00375, SRS_BSW_00416, SRS_BSW_00437, SRS_BSW_00168, SRS_BSW_00423, SRS_BSW_00425, SRS_BSW_00427, SRS_BSW_00428, SRS_BSW_00429, SRS_BSW_00432, SRS_BSW_00336, SRS_BSW_00422, SRS_BSW_00417, SRS_BSW_00161, SRS_BSW_00162, SRS_BSW_00005, SRS_BSW_00415, SRS_BSW_00164, SRS_BSW_00325, SRS_BSW_00326, SRS_BSW_00413, SRS_BSW_00347, SRS_BSW_00314, SRS_BSW_00370, SRS_BSW_00439, SRS_BSW_00449, SRS_BSW_00377, SRS_BSW_00359, SRS_BSW_00360, SRS_BSW_00440, BSW00443, BSW00444, BSW00446)