

Document Title	Specification of NVRAM Manager
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	033
Document Classification	Standard
Document Status	Final
Part of AUTOSAR Release	4.2.2

Document Change History		
Release	Changed by	Change Description
4.2.2	AUTOSAR Release Management	<ul style="list-style-type: none"> • Clarified behavior related to restoring default data for blocks and for handling of MEMIF_BLOCK_INVALID job result • Added additional information related to the block states in chapter 7.2.2.14 and related subchapters • Updated NvM_Init and NvM_ValidateAll function prototypes • Debugging support marked as obsolete
4.2.1	AUTOSAR Release Management	<ul style="list-style-type: none"> • Detailed pass/fail conditions for production errors • Added the NvM_ValidateAll functionality • Updated return values for Init and SingleBlock callbacks • Other small clarifications
4.1.3	AUTOSAR Release Management	<ul style="list-style-type: none"> • Removed job postpone in case of explicit synchronization failed after configured number of retries • Updated Service Interfaces tables • Renamed configuration parameter NvMRamBlockHeaderInclude to NvMBlockHeaderInclude • Editorial changes
4.1.2	AUTOSAR Release Management	<ul style="list-style-type: none"> • Added NvMRamBlockHeaderInclude and NvMMainFunctionPeriod configuration parameters • Corrected bugs for NvMWriteVerificationDataSize and NvMNvramBlockIdentifier parameters • Other small clarifications in requirement • Editorial changes • Removed chapter(s) on change documentation

Document Change History		
Release	Changed by	Change Description
4.1.1	AUTOSAR Administration	<ul style="list-style-type: none"> • Added NvM_ReadPRAMBlock, NvM_WritePRAMBlock and NvM_RestorePRAMBlockDefaults APIs • Production Errors and Extended Production Errors classification • Clarifications for explicit synchronization mechanism • Modeling of Services: introduction of formal descriptions of service interfaces • Changes regarding NvM_CancelJobs API, NvmSetRamBlockStatus API, Init callback, handling of redundant blocks, queue sizes and usage of MemoryMapping • Reworked according to the new SWS_BSWGeneral
4.0.3	AUTOSAR Administration	<ul style="list-style-type: none"> • Added NvM_CancelJobs behaviour • Added NvM and BswM interaction • Added NvM_SetBlockLockStatus API functional description • Corrected inconsistency between C-interface and port interface • Updated Include structure • Updated configuration parameters description and range
3.1.5	AUTOSAR Administration	<ul style="list-style-type: none"> • Behavior specified to prevent possible loss of data during shutdown • References to DEM for production errors, new config container NvmDemEventParameterRefs • NvMMaxNoOfWriteRetries renamed to NvMMaxNumOfWriteRetries • Note in chapter 7.1.4.5 completed • Null pointer handling changed • Chapter “Version check” updated • New DET error NVM_E_PARAM_POINTER • Chapter 10 updated, NvMMainFunctionCycleTime moved, NvMSelectBlockForWriteAll added, some ranges corrected • Behavior specified when NVRAM block ID 1 shall be written • Chapter 12 updated • Handling of single-block callbacks during asynchronous multi-block specified. • Some minor changes, typos corrected

Document Change History		
Release	Changed by	Change Description
3.1.4	AUTOSAR Administration	<ul style="list-style-type: none"> The following features had impact on this document: Debugging concept Error handler concept Memory related concepts The following major features were necessary to implement these concepts: Static Block Id Check Write Verification Read Retry buffered read/write-operations Legal disclaimer revised
3.1.1	AUTOSAR Administration	<ul style="list-style-type: none"> Technical Office SWS Improvements are incorporated. Requirement IDs for configuration parameters (chapter 10) added. Management of the RAM block state specified more precisely. The NVRAM Manager doesn't support non-sequential NVRAM block IDs any longer. Document meta information extended Small layout adaptations made
3.0.1	AUTOSAR Administration	<ul style="list-style-type: none"> Legal disclaimer revised
2.1.15	AUTOSAR Administration	<ul style="list-style-type: none"> AUTOSAR service description added in chapter 11 Reentrancy of callback functions specified Details regarding memory hardware abstraction addressing scheme added Legal disclaimer revised “Advice for users” revised “Revision Information” added
2.0	AUTOSAR Administration	<ul style="list-style-type: none"> Document structure adapted to common Release 2.0 SWS Template. Major changes in chapter 10 Structure of document changed partly
1.0	AUTOSAR Administration	<ul style="list-style-type: none"> Initial release

Disclaimer

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

1	Introduction and functional overview	8
2	Acronyms and abbreviations	10
3	Related documentation	11
3.1	Input documents	11
3.2	Related specification.....	12
4	Constraints and assumptions	13
4.1	Limitations	13
4.2	Applicability to car domains	13
4.3	Conflicts.....	13
5	Dependencies to other modules	14
5.1	File structure	15
5.1.1	Header file structure	15
5.2	Memory abstraction modules.....	16
5.3	CRC module	17
5.4	Capability of the underlying drivers.....	17
6	Requirements traceability	18
7	Functional specification	40
7.1	Basic architecture guidelines	40
7.1.1	Layer structure.....	40
7.1.2	Addressing scheme for the memory hardware abstraction	40
7.1.3	Basic storage objects.....	42
7.1.4	Block management types	46
7.1.5	Scan order / priority scheme	52
7.2	General behavior	54
7.2.1	Functional requirements	54
7.2.2	Design notes.....	55
7.3	Development Errors.....	75
7.4	Production Errors.....	76
7.4.1	NVM_E_HARDWARE	76
7.5	Extended Production Errors.....	77
7.5.1	NVM_E_INTEGRITY_FAILED.....	78
7.5.2	NVM_E_REQ_FAILED	79
7.5.3	NVM_E_WRONG_BLOCK_ID.....	79
7.5.4	NVM_E_VERIFY_FAILED	80
7.5.5	NVM_E_LOSS_OF_REDUNDANCY.....	80
7.5.6	NVM_E_QUEUE_OVERFLOW	81
7.5.7	NVM_E_WRITE_PROTECTED.....	81
7.6	Error detection	82
7.7	Debugging	88
8	API specification	89
8.1	API.....	89
8.1.1	Imported types	89
8.1.2	Type definitions.....	89
8.1.3	Function definitions.....	91
8.1.4	Expected Interfaces	141
8.1.5	API Overview	146
8.2	Service Interfaces	147
8.2.1	Client-Server-Interfaces.....	147

8.2.2	Implementation Data Types	155
8.2.3	Ports	157
9	Sequence Diagrams	159
9.1	Synchronous calls.....	159
9.1.1	NvM_Init	159
9.1.2	NvM_SetDataIndex.....	159
9.1.3	NvM_GetDataIndex	160
9.1.4	NvM_SetBlockProtection	160
9.1.5	NvM_GetErrorStatus	161
9.1.6	NvM_GetVersionInfo	161
9.2	Asynchronous calls.....	162
9.2.1	Asynchronous call with polling.....	162
9.2.2	Asynchronous call with callback	163
9.2.3	Cancellation of a Multi Block Request	164
10	Configuration specification	165
10.1	How to read this chapter	165
10.2	Containers and configuration parameters.....	165
10.2.1	Variants	165
10.2.2	NvM	165
10.2.3	NvMCommon.....	166
10.2.4	NvMBlockDescriptor	171
10.2.5	NvMTargetBlockReference.....	182
10.2.6	NvMEaRef	182
10.2.7	NvMFeeRef.....	183
10.2.8	NvmDemEventParameterRefs.....	183
10.3	Common configuration options	186
10.4	Published parameters.....	187
11	Not applicable requirements	188

Figures

Figure 1: Memory Structure of Different Block Types	8
Figure 2: Logical Structure of Different Block Types	9
Figure 3: NvM Include structure	15
Figure 4: NVRAM Manager interactions overview	40
Figure 5: NV Block layout	42
Figure 6: RAM Block layout	43
Figure 7: ROM block layout	44
Figure 8: NV block layout with Static Block ID enabled	45
Figure 9: Redundant NVRAM Block layout	48
Figure 10: Dataset NVRAM block layout	50
Figure 11: RAM Block States	62
Figure 12: UML sequence diagram NvM_Init	159
Figure 13: UML sequence diagram NvM_SetDataIndex	159
Figure 14: UML sequence diagram NvM_GetDataIndex	160
Figure 15: UML sequence diagram NvM_SetBlockProtection	160
Figure 16: UML sequence diagram NvM_GetErrorStatus	161
Figure 17: UML sequence diagram NvM_GetVersionInfo	161
Figure 18: UML sequence diagram for asynchronous call with polling	162

Figure 19: UML sequence diagram for asynchronous call with callback	163
Figure 20: UML sequence diagram for cancellation of asynchronous call	164

1 Introduction and functional overview

This specification describes the functionality, API and the configuration of the AUTOSAR Basic Software module NVRAM Manager (NvM).

The NvM module shall provide services to ensure the data storage and maintenance of NV (non volatile) data according to their individual requirements in an automotive environment. The NvM module shall be able to administrate the NV data of an EEPROM and/or a FLASH EEPROM emulation device.

The NvM module shall provide the required synchronous/asynchronous services for the management and the maintenance of NV data (init/read/write/control).

The relationship between the different blocks can be visualized in the following picture:




Figure 1: Memory Structure of Different Block Types




Figure 2: Logical Structure of Different Block Types

2 Acronyms and abbreviations

Acronyms and abbreviations, which have a local scope and therefore are not contained in the AUTOSAR glossary, must appear in a local glossary.

Abbreviation/ Acronym:	Description:
Basic Storage Object	A “Basic Storage Object” is the smallest entity of a “NVRAM block”. Several “Basic Storage Objects” can be used to build a NVRAM Block. A “Basic Storage Object” can reside in different memory locations (RAM/ROM/NV memory).
NVRAM Block	The “NVRAM Block” is the entire structure, which is needed to administrate and to store a block of NV data.
NV data	The data to be stored in Non-Volatile memory.
Block Management Type	Type of the NVRAM Block. It depends on the (configurable) individual composition of a NVRAM Block in chunks of different mandatory/optional Basic Storage Objects and the subsequent handling of this NVRAM block.
RAM Block	The „RAM Block“ is a „Basic Storage Object“. It represents the part of a „NVRAM Block“ which resides in the RAM. See [SRS_LIBS_08534] . [SWS NvM_00126]
ROM Block	The „ROM Block“ is a „Basic Storage Object“. It represents the part of a „NVRAM Block“ which resides in the ROM. The „ROM Block“ is an optional part of a „NVRAM Block“. [SWS NvM_00020]
NV Block	The „NV Block“ is a „Basic Storage Object“. It represents the part of a „NVRAM Block“ which resides in the NV memory. The „NV Block“ is a mandatory part of a „NVRAM Block“. [SWS NvM_00125]
NV Block Header	Additional information included in the NV Block if the mechanism “Static Block ID” is enabled.
Administrative Block	The “Administrative Block” is a “Basic Storage Object”. It resides in RAM. The “Administrative Block” is a mandatory part of a “NVRAM Block”. [SWS NvM_00135]
DET	Development Error Tracer – module to which development errors are reported.
DEM	Diagnostic Event Manager – module to which production relevant errors are reported
NV	Non volatile
FEE	Flash EEPROM Emulation
EA	EEPROM Abstraction
FCFS	First come first served

3 Related documentation

3.1 Input documents

- [1] List of Basic Software Modules
AUTOSAR_TR_BSWModuleList.pdf
- [2] Layered Software Architecture
AUTOSAR_EXP_LayeredSoftwareArchitecture.pdf
- [3] General Requirements on Basic Software Modules
AUTOSAR_SRS_BSWGeneral.pdf
- [4] Requirements on Memory Services
AUTOSAR_SRS_MemoryServices.pdf
- [5] Specification of EEPROM Abstraction
AUTOSAR_SWS_EEPROMAbstraction
- [6] Specification of Flash EEPROM Emulation
AUTOSAR_SWS_FlashEEPROMEmulation
- [7] Specification of Memory Abstraction Interface
AUTOSAR_SWS_MemoryAbstractionInterface
- [8] Specification of Memory Mapping
AUTOSAR_SWS_MemoryMapping
- [9] Virtual Functional Bus
AUTOSAR_EXP_VFB.pdf
- [10] Software Component Template
AUTOSAR_TPS_SoftwareComponentTemplate
- [11] Specification of RTE Software
AUTOSAR_SWS_RTE.pdf
- [12] Specification of ECU Configuration
AUTOSAR_TPS_ECUConfiguration.pdf
- [13] Basic Software Module Description Template
AUTOSAR_TPS_BSWModuleDescriptionTemplate
- [14] Specification of CRC Routines
AUTOSAR_SWS_CRCLibrary
- [15] General Specification of Basic Software Modules
AUTOSAR_SWS_BSWGeneral.pdf

3.2 Related specification

AUTOSAR provides a General Specification on Basic Software modules [15] (SWS BSW General), which is also valid for NVRAM Manager.

Thus, the specification SWS BSW General shall be considered as additional and required specification for NVRAM Manager.

4 Constraints and assumptions

4.1 Limitations

Limitations are given mainly by the finite number of “Block Management Types” and their individual treatment of NV data. These limits can be reduced by an enhanced user defined management information, which can be stored as a structured part of the real NV data. In this case the user defined management information has to be interpreted and handled by the application at least.

4.2 Applicability to car domains

No restrictions.

4.3 Conflicts

None

5 Dependencies to other modules

This section describes the relations to other modules within the basic software.

5.1 File structure

5.1.1 Header file structure




Figure 3: NvM Include structure

The include file structure shall be as follows:

[SWS_NvM_00077] [An API interface NvM.h that provides the function prototypes to access the underlying NVRAM functions.] (SRS_BSW_00435, SRS_BSW_00436)

[SWS_NvM_00550] [A type header NvM_Types.h that provides the types for the NvM module.] ()

[SWS_NvM_00755] [The file NvM_Types.h shall include Rte_NvM_Type.h to include the types which are common used by BSW Modules and Software Components. NvM_Types.h and NvM.h shall only contain types, that are not already defined in Rte_NvM_Type.h.] (SRS_BSW_00447)

[SWS_NvM_00551] [A callback interface NvM_Cbk.h that provides the callback function prototypes to be used by the lower layers] ()

[SWS_NvM_00552] [A type header NvM_Cfg.h that provides the configuration parameters for the NvM module.] ()

[SWS_NvM_00689] [NvM_Cfg.h shall include NvM_Types.h.] ()

[SWS_NvM_00690] [NvM_Types.h shall include Std_Types.h.] ()

[SWS_NvM_00553] [NvM.h shall include NvM_Cfg.h.] ()

[SWS_NvM_00554] [NvM module shall include NvM.h, Dem.h, MemIf.h, SchM_NvM.h, NvM_MemMap.h.] ()

[SWS_NvM_00555] [NvM module shall include Crc.h.] ()

[SWS_NvM_00556] [NvM module shall include Det.h.] ()

[SWS_NvM_00691] [Only NvM.h shall be included by the upper layer.] ()

5.2 Memory abstraction modules

The memory abstraction modules abstract the NvM module from the subordinated drivers which are hardware dependent. The memory abstraction modules provide a runtime translation of each block access initiated by the NvM module to select the corresponding driver functions which are unique for all configured EEPROM or

FLASH storage devices. The memory abstraction module is chosen via the NVRAM block device ID which is configured for each NVRAM block.

5.3 CRC module

The NvM module uses CRC generation routines (8/16/32 bit) to check and to generate CRC for NVRAM blocks as a configurable option. The CRC routines have to be provided externally [ref. to ch. 8.1.4.2].

5.4 Capability of the underlying drivers

A set of underlying driver functions has to be provided for every configured NVRAM device as, for example, internal or external EEPROM or FLASH devices. The unique driver functions inside each set of driver functions are selected during runtime via a memory hardware abstraction module (see chapter 5.2). A set of driver functions has to include all the needed functions to write to, to read from or to maintain (e.g. erase) a configured NVRAM device.

6 Requirements traceability

Requirement	Description	Satisfied by
-	-	SWS_NvM_00000
-	-	SWS_NvM_00001
-	-	SWS_NvM_00006
-	-	SWS_NvM_00014
-	-	SWS_NvM_00020
-	-	SWS_NvM_00021
-	-	SWS_NvM_00030
-	-	SWS_NvM_00038
-	-	SWS_NvM_00040
-	-	SWS_NvM_00047
-	-	SWS_NvM_00052
-	-	SWS_NvM_00054
-	-	SWS_NvM_00069
-	-	SWS_NvM_00073
-	-	SWS_NvM_00083
-	-	SWS_NvM_00085
-	-	SWS_NvM_00088
-	-	SWS_NvM_00091
-	-	SWS_NvM_00092
-	-	SWS_NvM_00111
-	-	SWS_NvM_00112
-	-	SWS_NvM_00113
-	-	SWS_NvM_00118
-	-	SWS_NvM_00121
-	-	SWS_NvM_00125
-	-	SWS_NvM_00126
-	-	SWS_NvM_00127
-	-	SWS_NvM_00128
-	-	SWS_NvM_00129
-	-	SWS_NvM_00130
-	-	SWS_NvM_00133
-	-	SWS_NvM_00134
-	-	SWS_NvM_00135
-	-	SWS_NvM_00136
-	-	SWS_NvM_00138
-	-	SWS_NvM_00139

-	-	SWS_NvM_00140
-	-	SWS_NvM_00141
-	-	SWS_NvM_00143
-	-	SWS_NvM_00144
-	-	SWS_NvM_00146
-	-	SWS_NvM_00149
-	-	SWS_NvM_00150
-	-	SWS_NvM_00155
-	-	SWS_NvM_00158
-	-	SWS_NvM_00160
-	-	SWS_NvM_00168
-	-	SWS_NvM_00169
-	-	SWS_NvM_00175
-	-	SWS_NvM_00176
-	-	SWS_NvM_00179
-	-	SWS_NvM_00180
-	-	SWS_NvM_00181
-	-	SWS_NvM_00182
-	-	SWS_NvM_00184
-	-	SWS_NvM_00185
-	-	SWS_NvM_00192
-	-	SWS_NvM_00193
-	-	SWS_NvM_00198
-	-	SWS_NvM_00199
-	-	SWS_NvM_00200
-	-	SWS_NvM_00201
-	-	SWS_NvM_00202
-	-	SWS_NvM_00203
-	-	SWS_NvM_00204
-	-	SWS_NvM_00206
-	-	SWS_NvM_00209
-	-	SWS_NvM_00210
-	-	SWS_NvM_00212
-	-	SWS_NvM_00216
-	-	SWS_NvM_00217
-	-	SWS_NvM_00224
-	-	SWS_NvM_00225
-	-	SWS_NvM_00226
-	-	SWS_NvM_00227

-	-	SWS_NvM_00228
-	-	SWS_NvM_00229
-	-	SWS_NvM_00230
-	-	SWS_NvM_00231
-	-	SWS_NvM_00232
-	-	SWS_NvM_00233
-	-	SWS_NvM_00234
-	-	SWS_NvM_00235
-	-	SWS_NvM_00236
-	-	SWS_NvM_00237
-	-	SWS_NvM_00238
-	-	SWS_NvM_00239
-	-	SWS_NvM_00243
-	-	SWS_NvM_00244
-	-	SWS_NvM_00245
-	-	SWS_NvM_00246
-	-	SWS_NvM_00247
-	-	SWS_NvM_00248
-	-	SWS_NvM_00249
-	-	SWS_NvM_00251
-	-	SWS_NvM_00252
-	-	SWS_NvM_00254
-	-	SWS_NvM_00255
-	-	SWS_NvM_00256
-	-	SWS_NvM_00257
-	-	SWS_NvM_00258
-	-	SWS_NvM_00259
-	-	SWS_NvM_00260
-	-	SWS_NvM_00262
-	-	SWS_NvM_00263
-	-	SWS_NvM_00264
-	-	SWS_NvM_00265
-	-	SWS_NvM_00269
-	-	SWS_NvM_00270
-	-	SWS_NvM_00271
-	-	SWS_NvM_00272
-	-	SWS_NvM_00273
-	-	SWS_NvM_00274
-	-	SWS_NvM_00275

-	-	SWS_NvM_00278
-	-	SWS_NvM_00279
-	-	SWS_NvM_00280
-	-	SWS_NvM_00281
-	-	SWS_NvM_00284
-	-	SWS_NvM_00287
-	-	SWS_NvM_00288
-	-	SWS_NvM_00290
-	-	SWS_NvM_00291
-	-	SWS_NvM_00292
-	-	SWS_NvM_00293
-	-	SWS_NvM_00294
-	-	SWS_NvM_00295
-	-	SWS_NvM_00296
-	-	SWS_NvM_00298
-	-	SWS_NvM_00300
-	-	SWS_NvM_00301
-	-	SWS_NvM_00302
-	-	SWS_NvM_00303
-	-	SWS_NvM_00304
-	-	SWS_NvM_00305
-	-	SWS_NvM_00306
-	-	SWS_NvM_00307
-	-	SWS_NvM_00308
-	-	SWS_NvM_00309
-	-	SWS_NvM_00310
-	-	SWS_NvM_00311
-	-	SWS_NvM_00312
-	-	SWS_NvM_00313
-	-	SWS_NvM_00314
-	-	SWS_NvM_00315
-	-	SWS_NvM_00316
-	-	SWS_NvM_00317
-	-	SWS_NvM_00318
-	-	SWS_NvM_00328
-	-	SWS_NvM_00329
-	-	SWS_NvM_00333
-	-	SWS_NvM_00334
-	-	SWS_NvM_00337

-	-	SWS_NvM_00338
-	-	SWS_NvM_00339
-	-	SWS_NvM_00340
-	-	SWS_NvM_00341
-	-	SWS_NvM_00342
-	-	SWS_NvM_00343
-	-	SWS_NvM_00346
-	-	SWS_NvM_00347
-	-	SWS_NvM_00349
-	-	SWS_NvM_00350
-	-	SWS_NvM_00351
-	-	SWS_NvM_00353
-	-	SWS_NvM_00354
-	-	SWS_NvM_00355
-	-	SWS_NvM_00356
-	-	SWS_NvM_00357
-	-	SWS_NvM_00358
-	-	SWS_NvM_00359
-	-	SWS_NvM_00360
-	-	SWS_NvM_00361
-	-	SWS_NvM_00362
-	-	SWS_NvM_00363
-	-	SWS_NvM_00364
-	-	SWS_NvM_00365
-	-	SWS_NvM_00366
-	-	SWS_NvM_00367
-	-	SWS_NvM_00369
-	-	SWS_NvM_00370
-	-	SWS_NvM_00372
-	-	SWS_NvM_00373
-	-	SWS_NvM_00374
-	-	SWS_NvM_00375
-	-	SWS_NvM_00376
-	-	SWS_NvM_00377
-	-	SWS_NvM_00379
-	-	SWS_NvM_00380
-	-	SWS_NvM_00381
-	-	SWS_NvM_00383
-	-	SWS_NvM_00385

-	-	SWS_NvM_00386
-	-	SWS_NvM_00387
-	-	SWS_NvM_00388
-	-	SWS_NvM_00389
-	-	SWS_NvM_00390
-	-	SWS_NvM_00391
-	-	SWS_NvM_00392
-	-	SWS_NvM_00393
-	-	SWS_NvM_00394
-	-	SWS_NvM_00395
-	-	SWS_NvM_00396
-	-	SWS_NvM_00398
-	-	SWS_NvM_00406
-	-	SWS_NvM_00408
-	-	SWS_NvM_00416
-	-	SWS_NvM_00417
-	-	SWS_NvM_00418
-	-	SWS_NvM_00420
-	-	SWS_NvM_00422
-	-	SWS_NvM_00423
-	-	SWS_NvM_00424
-	-	SWS_NvM_00426
-	-	SWS_NvM_00427
-	-	SWS_NvM_00430
-	-	SWS_NvM_00431
-	-	SWS_NvM_00432
-	-	SWS_NvM_00433
-	-	SWS_NvM_00434
-	-	SWS_NvM_00435
-	-	SWS_NvM_00436
-	-	SWS_NvM_00438
-	-	SWS_NvM_00440
-	-	SWS_NvM_00441
-	-	SWS_NvM_00443
-	-	SWS_NvM_00444
-	-	SWS_NvM_00445
-	-	SWS_NvM_00446
-	-	SWS_NvM_00449
-	-	SWS_NvM_00452

-	-	SWS_NvM_00462
-	-	SWS_NvM_00470
-	-	SWS_NvM_00471
-	-	SWS_NvM_00474
-	-	SWS_NvM_00475
-	-	SWS_NvM_00510
-	-	SWS_NvM_00511
-	-	SWS_NvM_00512
-	-	SWS_NvM_00513
-	-	SWS_NvM_00514
-	-	SWS_NvM_00515
-	-	SWS_NvM_00516
-	-	SWS_NvM_00517
-	-	SWS_NvM_00522
-	-	SWS_NvM_00525
-	-	SWS_NvM_00530
-	-	SWS_NvM_00531
-	-	SWS_NvM_00537
-	-	SWS_NvM_00541
-	-	SWS_NvM_00542
-	-	SWS_NvM_00544
-	-	SWS_NvM_00546
-	-	SWS_NvM_00547
-	-	SWS_NvM_00549
-	-	SWS_NvM_00550
-	-	SWS_NvM_00551
-	-	SWS_NvM_00552
-	-	SWS_NvM_00553
-	-	SWS_NvM_00554
-	-	SWS_NvM_00555
-	-	SWS_NvM_00556
-	-	SWS_NvM_00560
-	-	SWS_NvM_00561
-	-	SWS_NvM_00562
-	-	SWS_NvM_00567
-	-	SWS_NvM_00568
-	-	SWS_NvM_00569
-	-	SWS_NvM_00570
-	-	SWS_NvM_00572

-	-	SWS_NvM_00573
-	-	SWS_NvM_00574
-	-	SWS_NvM_00575
-	-	SWS_NvM_00578
-	-	SWS_NvM_00579
-	-	SWS_NvM_00580
-	-	SWS_NvM_00583
-	-	SWS_NvM_00586
-	-	SWS_NvM_00587
-	-	SWS_NvM_00590
-	-	SWS_NvM_00591
-	-	SWS_NvM_00592
-	-	SWS_NvM_00594
-	-	SWS_NvM_00595
-	-	SWS_NvM_00598
-	-	SWS_NvM_00599
-	-	SWS_NvM_00601
-	-	SWS_NvM_00602
-	-	SWS_NvM_00604
-	-	SWS_NvM_00605
-	-	SWS_NvM_00606
-	-	SWS_NvM_00607
-	-	SWS_NvM_00608
-	-	SWS_NvM_00609
-	-	SWS_NvM_00610
-	-	SWS_NvM_00611
-	-	SWS_NvM_00612
-	-	SWS_NvM_00613
-	-	SWS_NvM_00614
-	-	SWS_NvM_00615
-	-	SWS_NvM_00616
-	-	SWS_NvM_00618
-	-	SWS_NvM_00619
-	-	SWS_NvM_00620
-	-	SWS_NvM_00622
-	-	SWS_NvM_00624
-	-	SWS_NvM_00625
-	-	SWS_NvM_00626
-	-	SWS_NvM_00628

-	-	SWS_NvM_00629
-	-	SWS_NvM_00630
-	-	SWS_NvM_00631
-	-	SWS_NvM_00632
-	-	SWS_NvM_00635
-	-	SWS_NvM_00636
-	-	SWS_NvM_00637
-	-	SWS_NvM_00638
-	-	SWS_NvM_00639
-	-	SWS_NvM_00642
-	-	SWS_NvM_00643
-	-	SWS_NvM_00644
-	-	SWS_NvM_00645
-	-	SWS_NvM_00646
-	-	SWS_NvM_00647
-	-	SWS_NvM_00648
-	-	SWS_NvM_00649
-	-	SWS_NvM_00651
-	-	SWS_NvM_00652
-	-	SWS_NvM_00653
-	-	SWS_NvM_00654
-	-	SWS_NvM_00655
-	-	SWS_NvM_00657
-	-	SWS_NvM_00658
-	-	SWS_NvM_00659
-	-	SWS_NvM_00661
-	-	SWS_NvM_00662
-	-	SWS_NvM_00663
-	-	SWS_NvM_00664
-	-	SWS_NvM_00665
-	-	SWS_NvM_00666
-	-	SWS_NvM_00667
-	-	SWS_NvM_00669
-	-	SWS_NvM_00670
-	-	SWS_NvM_00671
-	-	SWS_NvM_00672
-	-	SWS_NvM_00673
-	-	SWS_NvM_00674
-	-	SWS_NvM_00676

-	-	SWS_NvM_00677
-	-	SWS_NvM_00678
-	-	SWS_NvM_00679
-	-	SWS_NvM_00680
-	-	SWS_NvM_00681
-	-	SWS_NvM_00682
-	-	SWS_NvM_00683
-	-	SWS_NvM_00684
-	-	SWS_NvM_00685
-	-	SWS_NvM_00686
-	-	SWS_NvM_00688
-	-	SWS_NvM_00689
-	-	SWS_NvM_00690
-	-	SWS_NvM_00691
-	-	SWS_NvM_00692
-	-	SWS_NvM_00693
-	-	SWS_NvM_00694
-	-	SWS_NvM_00695
-	-	SWS_NvM_00697
-	-	SWS_NvM_00701
-	-	SWS_NvM_00702
-	-	SWS_NvM_00703
-	-	SWS_NvM_00704
-	-	SWS_NvM_00705
-	-	SWS_NvM_00706
-	-	SWS_NvM_00707
-	-	SWS_NvM_00708
-	-	SWS_NvM_00709
-	-	SWS_NvM_00710
-	-	SWS_NvM_00711
-	-	SWS_NvM_00712
-	-	SWS_NvM_00713
-	-	SWS_NvM_00714
-	-	SWS_NvM_00715
-	-	SWS_NvM_00716
-	-	SWS_NvM_00717
-	-	SWS_NvM_00718
-	-	SWS_NvM_00719
-	-	SWS_NvM_00720

-	-	SWS_NvM_00721
-	-	SWS_NvM_00722
-	-	SWS_NvM_00723
-	-	SWS_NvM_00724
-	-	SWS_NvM_00725
-	-	SWS_NvM_00726
-	-	SWS_NvM_00727
-	-	SWS_NvM_00728
-	-	SWS_NvM_00729
-	-	SWS_NvM_00730
-	-	SWS_NvM_00731
-	-	SWS_NvM_00732
-	-	SWS_NvM_00733
-	-	SWS_NvM_00734
-	-	SWS_NvM_00735
-	-	SWS_NvM_00736
-	-	SWS_NvM_00737
-	-	SWS_NvM_00738
-	-	SWS_NvM_00740
-	-	SWS_NvM_00741
-	-	SWS_NvM_00742
-	-	SWS_NvM_00745
-	-	SWS_NvM_00746
-	-	SWS_NvM_00747
-	-	SWS_NvM_00748
-	-	SWS_NvM_00749
-	-	SWS_NvM_00750
-	-	SWS_NvM_00751
-	-	SWS_NvM_00752
-	-	SWS_NvM_00753
-	-	SWS_NvM_00754
-	-	SWS_NvM_00756
-	-	SWS_NvM_00757
-	-	SWS_NvM_00758
-	-	SWS_NvM_00759
-	-	SWS_NvM_00760
-	-	SWS_NvM_00761
-	-	SWS_NvM_00762
-	-	SWS_NvM_00763

-	-	SWS_NvM_00767
-	-	SWS_NvM_00768
-	-	SWS_NvM_00769
-	-	SWS_NvM_00770
-	-	SWS_NvM_00771
-	-	SWS_NvM_00772
-	-	SWS_NvM_00773
-	-	SWS_NvM_00774
-	-	SWS_NvM_00775
-	-	SWS_NvM_00776
-	-	SWS_NvM_00777
-	-	SWS_NvM_00778
-	-	SWS_NvM_00779
-	-	SWS_NvM_00780
-	-	SWS_NvM_00781
-	-	SWS_NvM_00782
-	-	SWS_NvM_00783
-	-	SWS_NvM_00784
-	-	SWS_NvM_00785
-	-	SWS_NvM_00786
-	-	SWS_NvM_00787
-	-	SWS_NvM_00788
-	-	SWS_NvM_00789
-	-	SWS_NvM_00790
-	-	SWS_NvM_00791
-	-	SWS_NvM_00792
-	-	SWS_NvM_00796
-	-	SWS_NvM_00797
-	-	SWS_NvM_00799
-	-	SWS_NvM_00800
-	-	SWS_NvM_00801
-	-	SWS_NvM_00802
-	-	SWS_NvM_00803
-	-	SWS_NvM_00805
-	-	SWS_NvM_00806
-	-	SWS_NvM_00807
-	-	SWS_NvM_00808
-	-	SWS_NvM_00809
-	-	SWS_NvM_00810

-	-	SWS_NvM_00811
-	-	SWS_NvM_00812
-	-	SWS_NvM_00815
-	-	SWS_NvM_00818
-	-	SWS_NvM_00819
-	-	SWS_NvM_00820
-	-	SWS_NvM_00821
-	-	SWS_NvM_00822
-	-	SWS_NvM_00823
-	-	SWS_NvM_00824
-	-	SWS_NvM_00825
-	-	SWS_NvM_00826
-	-	SWS_NvM_00827
-	-	SWS_NvM_00828
-	-	SWS_NvM_00829
-	-	SWS_NvM_00830
-	-	SWS_NvM_00831
-	-	SWS_NvM_00832
-	-	SWS_NvM_00833
-	-	SWS_NvM_00834
-	-	SWS_NvM_00835
-	-	SWS_NvM_00837
-	-	SWS_NvM_00838
-	-	SWS_NvM_00839
-	-	SWS_NvM_00840
-	-	SWS_NvM_00841
-	-	SWS_NvM_00842
-	-	SWS_NvM_00843
-	-	SWS_NvM_00844
-	-	SWS_NvM_00845
-	-	SWS_NvM_00846
-	-	SWS_NvM_00847
-	-	SWS_NvM_00848
-	-	SWS_NvM_00864
-	-	SWS_NvM_00865
-	-	SWS_NvM_00866
-	-	SWS_NvM_00867
-	-	SWS_NvM_00868
-	-	SWS_NvM_00869

-	-	SWS_NvM_00870
-	-	SWS_NvM_00871
-	-	SWS_NvM_00872
-	-	SWS_NvM_00873
-	-	SWS_NvM_00874
-	-	SWS_NvM_00875
-	-	SWS_NvM_00876
-	-	SWS_NvM_00877
-	-	SWS_NvM_00878
-	-	SWS_NvM_00881
-	-	SWS_NvM_00882
-	-	SWS_NvM_00883
-	-	SWS_NvM_00884
-	-	SWS_NvM_00885
-	-	SWS_NvM_00886
-	-	SWS_NvM_00887
BSW00324	-	SWS_NvM_00744
BSW00420	-	SWS_NvM_00744
BSW00421	-	SWS_NvM_00465
BSW00431	-	SWS_NvM_00744
BSW00434	-	SWS_NvM_00744
BSW176	-	SWS_NvM_00454, SWS_NvM_00455, SWS_NvM_00460, SWS_NvM_00461, SWS_NvM_00540, SWS_NvM_00764, SWS_NvM_00793
SRS_BSW_00005	Modules of the $\hat{\mu}$ C Abstraction Layer (MCAL) may not have hard coded horizontal interfaces	SWS_NvM_00744
SRS_BSW_00006	The source code of software modules above the $\hat{\mu}$ C Abstraction Layer (MCAL) shall not be processor and compiler dependent.	SWS_NvM_00744
SRS_BSW_00007	All Basic SW Modules written in C language shall conform to the MISRA C 2004 Standard.	SWS_NvM_00744
SRS_BSW_00009	All Basic SW Modules shall be documented according to a common standard.	SWS_NvM_00744
SRS_BSW_00010	The memory consumption of all Basic SW Modules shall be documented for a defined configuration for all supported platforms.	SWS_NvM_00744
SRS_BSW_00101	The Basic Software Module shall be able to initialize variables and hardware in a separate initialization function	SWS_NvM_00399, SWS_NvM_00400

SRS_BSW_00160	Configuration files of AUTOSAR Basic SW module shall be readable for human beings	SWS_NvM_00744
SRS_BSW_00161	The AUTOSAR Basic Software shall provide a microcontroller abstraction layer which provides a standardized interface to higher software layers	SWS_NvM_00744
SRS_BSW_00162	The AUTOSAR Basic Software shall provide a hardware abstraction layer	SWS_NvM_00744
SRS_BSW_00164	The Implementation of interrupt service routines shall be done by the Operating System, complex drivers or modules	SWS_NvM_00744
SRS_BSW_00167	All AUTOSAR Basic Software Modules shall provide configuration rules and constraints to enable plausibility checks	SWS_NvM_00028
SRS_BSW_00168	SW components shall be tested by a function defined in a common API in the Basis-SW	SWS_NvM_00744
SRS_BSW_00170	The AUTOSAR SW Components shall provide information about their dependency from faults, signal qualities, driver demands	SWS_NvM_00744
SRS_BSW_00171	Optional functionality of a Basic-SW component that is not required in the ECU shall be configurable at pre-compile-time	SWS_NvM_00028
SRS_BSW_00172	The scheduling strategy that is built inside the Basic Software Modules shall be compatible with the strategy used in the system	SWS_NvM_00464
SRS_BSW_00302	All AUTOSAR Basic Software Modules shall only export information needed by other modules	SWS_NvM_00744
SRS_BSW_00304	All AUTOSAR Basic Software Modules shall use the following data types instead of native C data types	SWS_NvM_00744
SRS_BSW_00306	AUTOSAR Basic Software Modules shall be compiler and platform independent	SWS_NvM_00744
SRS_BSW_00307	Global variables naming convention	SWS_NvM_00744
SRS_BSW_00308	AUTOSAR Basic Software Modules shall not define global data in their header files, but in the C file	SWS_NvM_00744
SRS_BSW_00309	All AUTOSAR Basic Software Modules shall indicate all global data with read-only purposes by explicitly assigning the const keyword	SWS_NvM_00744
SRS_BSW_00312	Shared code shall be reentrant	SWS_NvM_00744
SRS_BSW_00314	All internal driver modules shall	SWS_NvM_00744

	separate the interrupt frame definition from the service routine	
SRS_BSW_00321	The version numbers of AUTOSAR Basic Software Modules shall be enumerated according specific rules	SWS_NvM_00744
SRS_BSW_00323	All AUTOSAR Basic Software Modules shall check passed API parameters for validity	SWS_NvM_00027
SRS_BSW_00325	The runtime of interrupt service routines and functions that are running in interrupt context shall be kept short	SWS_NvM_00744
SRS_BSW_00326	-	SWS_NvM_00744
SRS_BSW_00327	Error values naming convention	SWS_NvM_00023, SWS_NvM_00027
SRS_BSW_00328	All AUTOSAR Basic Software Modules shall avoid the duplication of code	SWS_NvM_00744
SRS_BSW_00330	It shall be allowed to use macros instead of functions where source code is used and runtime is critical	SWS_NvM_00744
SRS_BSW_00331	All Basic Software Modules shall strictly separate error and status information	SWS_NvM_00023, SWS_NvM_00027
SRS_BSW_00333	For each callback function it shall be specified if it is called from interrupt context or not	SWS_NvM_00467, SWS_NvM_00468, SWS_NvM_00469
SRS_BSW_00334	All Basic Software Modules shall provide an XML file that contains the meta data	SWS_NvM_00744
SRS_BSW_00335	Status values naming convention	SWS_NvM_00744
SRS_BSW_00336	Basic SW module shall be able to shutdown	SWS_NvM_00744
SRS_BSW_00337	Classification of development errors	SWS_NvM_00023
SRS_BSW_00341	Module documentation shall contains all needed informations	SWS_NvM_00744
SRS_BSW_00342	It shall be possible to create an AUTOSAR ECU out of modules provided as source code and modules provided as object code, even mixed	SWS_NvM_00744
SRS_BSW_00343	The unit of time for specification and configuration of Basic SW modules shall be preferably in physical time unit	SWS_NvM_00744
SRS_BSW_00344	BSW Modules shall support link-time configuration	SWS_NvM_00744
SRS_BSW_00347	A Naming separation of different instances of BSW drivers shall be in place	SWS_NvM_00744
SRS_BSW_00348	All AUTOSAR standard types and constants shall be placed and	SWS_NvM_00744

	organized in a standard type header file	
SRS_BSW_00353	All integer type definitions of target and compiler specific scope shall be placed and organized in a single type header	SWS_NvM_00744
SRS_BSW_00355	-	SWS_NvM_00744
SRS_BSW_00360	AUTOSAR Basic Software Modules callback functions are allowed to have parameters	SWS_NvM_00467, SWS_NvM_00468, SWS_NvM_00469
SRS_BSW_00361	All mappings of not standardized keywords of compiler specific scope shall be placed and organized in a compiler specific type and keyword header	SWS_NvM_00744
SRS_BSW_00371	The passing of function pointers as API parameter is forbidden for all AUTOSAR Basic Software Modules	SWS_NvM_00744
SRS_BSW_00373	The main processing function of each AUTOSAR Basic Software Module shall be named according the defined convention	SWS_NvM_00464
SRS_BSW_00375	Basic Software Modules shall report wake-up reasons	SWS_NvM_00744
SRS_BSW_00376	-	SWS_NvM_00464
SRS_BSW_00378	AUTOSAR shall provide a boolean type	SWS_NvM_00744
SRS_BSW_00381	The pre-compile time parameters shall be placed into a separate configuration header file	SWS_NvM_00028
SRS_BSW_00383	The Basic Software Module specifications shall specify which other configuration files from other modules they use at least in the description	SWS_NvM_00465, SWS_NvM_00466
SRS_BSW_00384	The Basic Software Module specifications shall specify at least in the description which other modules they require	SWS_NvM_00465, SWS_NvM_00466
SRS_BSW_00385	List possible error notifications	SWS_NvM_00023, SWS_NvM_00027
SRS_BSW_00386	The BSW shall specify the configuration for detecting an error	SWS_NvM_00023, SWS_NvM_00027
SRS_BSW_00388	Containers shall be used to group configuration parameters that are defined for the same object	SWS_NvM_00028
SRS_BSW_00389	Containers shall have names	SWS_NvM_00028
SRS_BSW_00390	Parameter content shall be unique within the module	SWS_NvM_00028
SRS_BSW_00391	-	SWS_NvM_00028
SRS_BSW_00392	Parameters shall have a type	SWS_NvM_00028

SRS_BSW_00393	Parameters shall have a range	SWS_NvM_00028
SRS_BSW_00394	The Basic Software Module specifications shall specify the scope of the configuration parameters	SWS_NvM_00028
SRS_BSW_00395	The Basic Software Module specifications shall list all configuration parameter dependencies	SWS_NvM_00028
SRS_BSW_00396	The Basic Software Module specifications shall specify the supported configuration classes for changing values and multiplicities for each parameter/container	SWS_NvM_00028
SRS_BSW_00397	The configuration parameters in pre-compile time are fixed before compilation starts	SWS_NvM_00028
SRS_BSW_00398	The link-time configuration is achieved on object code basis in the stage after compiling and before linking	SWS_NvM_00744
SRS_BSW_00399	Parameter-sets shall be located in a separate segment and shall be loaded after the code	SWS_NvM_00744
SRS_BSW_00400	Parameter shall be selected from multiple sets of parameters after code has been loaded and started	SWS_NvM_00744
SRS_BSW_00404	BSW Modules shall support post-build configuration	SWS_NvM_00744
SRS_BSW_00405	BSW Modules shall support multiple configuration sets	SWS_NvM_00744
SRS_BSW_00406	A static status variable denoting if a BSW module is initialized shall be initialized with value 0 before any APIs of the BSW module is called	SWS_NvM_00023, SWS_NvM_00027, SWS_NvM_00399, SWS_NvM_00400
SRS_BSW_00412	References to c-configuration parameters shall be placed into a separate h-file	SWS_NvM_00744
SRS_BSW_00414	Init functions shall have a pointer to a configuration structure as single parameter	SWS_NvM_00447
SRS_BSW_00415	Interfaces which are provided exclusively for one module shall be separated into a dedicated header file	SWS_NvM_00744
SRS_BSW_00416	The sequence of modules to be initialized shall be configurable	SWS_NvM_00744
SRS_BSW_00417	Software which is not part of the SW-C shall report error events only after the DEM is fully operational.	SWS_NvM_00744
SRS_BSW_00422	Pre-de-bouncing of error status information is done within the DEM	SWS_NvM_00744
SRS_BSW_00423	BSW modules with AUTOSAR	SWS_NvM_00744

	interfaces shall be describable with the means of the SW-C Template	
SRS_BSW_00425	The BSW module description template shall provide means to model the defined trigger conditions of schedulable objects	SWS_NvM_00464
SRS_BSW_00426	BSW Modules shall ensure data consistency of data which is shared between BSW modules	SWS_NvM_00744
SRS_BSW_00427	ISR functions shall be defined and documented in the BSW module description template	SWS_NvM_00744
SRS_BSW_00429	BSW modules shall be only allowed to use OS objects and/or related OS services	SWS_NvM_00332
SRS_BSW_00432	Modules should have separate main processing functions for read/receive and write/transmit data path	SWS_NvM_00744
SRS_BSW_00435	-	SWS_NvM_00077
SRS_BSW_00436	-	SWS_NvM_00077
SRS_BSW_00447	Standardizing Include file structure of BSW Modules Implementing Autosar Service	SWS_NvM_00755
SRS_BSW_00457	- Callback functions of Application software components shall be invoked by the Basis SW	SWS_NvM_00467, SWS_NvM_00468, SWS_NvM_00469, SWS_NvM_00539, SWS_NvM_00540
SRS_LIBS_08528	-	SWS_NvM_00137, SWS_NvM_00557
SRS_LIBS_08529	-	SWS_NvM_00137, SWS_NvM_00558
SRS_LIBS_08531	-	SWS_NvM_00137, SWS_NvM_00559
SRS_LIBS_08533	The NVRAM manager shall provide a service to check and load those NVRAM blocks, configured to have a permanent RAM data block to RAM	SWS_NvM_00454, SWS_NvM_00460, SWS_NvM_00540, SWS_NvM_00764
SRS_LIBS_08534	-	SWS_NvM_00137
SRS_LIBS_08535	The NVRAM manager shall provide a function, which triggers update of integrity information and saving of RAM data blocks to NV memory	SWS_NvM_00018, SWS_NvM_00253, SWS_NvM_00461
SRS_Mem_00011	The NVRAM manager shall be independent from its underlying memory hardware.	SWS_NvM_00157
SRS_Mem_00013	The NVRAM manager shall provide a mechanism to handle multiple, concurrent read / write requests	SWS_NvM_00162, SWS_NvM_00698, SWS_NvM_00699
SRS_Mem_00016	The NVRAM manager shall provide functionality to read out data associated with an NVRAM block from the non-volatile memory	SWS_NvM_00010, SWS_NvM_00051, SWS_NvM_00122, SWS_NvM_00195, SWS_NvM_00196, SWS_NvM_00454, SWS_NvM_00764, SWS_NvM_00765, SWS_NvM_00766
SRS_Mem_00017	The NVRAM manager shall provide	SWS_NvM_00051, SWS_NvM_00122,

	functionality to store data associated with an NVRAM block in the non-volatile memory	SWS_NvM_00410, SWS_NvM_00411, SWS_NvM_00455, SWS_NvM_00793, SWS_NvM_00794, SWS_NvM_00795
SRS_Mem_00018	The NVRAM manager shall provide functionality to restore an NVRAM block's associated data from ROM defaults	SWS_NvM_00012, SWS_NvM_00051, SWS_NvM_00122, SWS_NvM_00266, SWS_NvM_00267, SWS_NvM_00456, SWS_NvM_00813, SWS_NvM_00814, SWS_NvM_00816, SWS_NvM_00817
SRS_Mem_00020	The NVRAM manager shall provide functionality to read out the status of read/write operations	SWS_NvM_00015, SWS_NvM_00451
SRS_Mem_00027	The NVRAM manager shall provide an implicit way of accessing blocks in the NVRAM and in the shared memory (RAM).	SWS_NvM_00442
SRS_Mem_00030	The NVRAM manager shall implement mechanisms for consistency/integrity checks of data saved in NVRAM	SWS_NvM_00164
SRS_Mem_00034	Write accesses of the NVRAM manager to persistent memory shall be executed quasi-parallel to normal operation of the ECU	SWS_NvM_00162
SRS_Mem_00041	Each application shall be enabled to declare the memory requirements at configuration time	SWS_NvM_00051, SWS_NvM_00122
SRS_Mem_00125	For each block a notification shall be configurable	SWS_NvM_00463
SRS_Mem_00127	The NVRAM manager shall allow enabling/disabling a write protection for each NVRAM block individually	SWS_NvM_00016, SWS_NvM_00450
SRS_Mem_00129	The NVRAM manager shall repair data in blocks of management type 'NVRAM redundant'	SWS_NvM_00165, SWS_NvM_00582
SRS_Mem_00135	The NVRAM manager shall have an unique configuration identifier	SWS_NvM_00034
SRS_Mem_00136	The NVRAM manager shall provide functionality for determining updates of data associated with an NVRAM Block during runtime	SWS_NvM_00849, SWS_NvM_00850, SWS_NvM_00851, SWS_NvM_00852, SWS_NvM_00853, SWS_NvM_00854
SRS_Mem_00137	The NVRAM manager shall provide a service for auto-validating NVRAM blocks	SWS_NvM_00855, SWS_NvM_00856, SWS_NvM_00857, SWS_NvM_00858, SWS_NvM_00859, SWS_NvM_00860, SWS_NvM_00861, SWS_NvM_00862, SWS_NvM_00863
SRS_Mem_08000	The NVRAM manager shall be able to access multiple non-volatile memory devices	SWS_NvM_00051, SWS_NvM_00123, SWS_NvM_00442
SRS_Mem_08007	The NVRAM manager shall provide a service for the selection of valid dataset NV blocks	SWS_NvM_00448
SRS_Mem_08009	The NVRAM Manager shall allow a	SWS_NvM_00325, SWS_NvM_00326,

	static configuration of a default write protection (on/off) for each NVRAM block	SWS_NvM_00577
SRS_Mem_08010	The NVRAM manager shall copy the ROM default data to the data area of the corresponding RAM block if it can not read data from NV into RAM	SWS_NvM_00171, SWS_NvM_00172
SRS_Mem_08011	The NVRAM manager shall provide a service to invalidate a block of data in the non-volatile memory	SWS_NvM_00421, SWS_NvM_00459
SRS_Mem_08014	The NVRAM manager shall allow a non-continuous RAM block allocation in the global RAM area	SWS_NvM_00051, SWS_NvM_00122, SWS_NvM_00442
SRS_Mem_08015	Some of the NV Blocks in the NVRAM shall never be erased nor be replaced with the default ROM data after first initialization	SWS_NvM_00397
SRS_Mem_08540	The NVRAM manager shall provide a function for aborting the shutdown process	SWS_NvM_00019, SWS_NvM_00458
SRS_Mem_08541	The NVRAM manager shall guarantee that an accepted write request will be processed	SWS_NvM_00208, SWS_NvM_00384, SWS_NvM_00472, SWS_NvM_00798
SRS_Mem_08542	The NVRAM manager shall provide a prioritization for job processing order	SWS_NvM_00032, SWS_NvM_00378, SWS_NvM_00564
SRS_Mem_08544	The NVRAM manager shall provide a service to erase the NV block(s) associated with an NVRAM block	SWS_NvM_00415, SWS_NvM_00457
SRS_Mem_08545	The NVRAM Manager shall provide a service for marking the permanent RAM data block of an NVRAM block valid	SWS_NvM_00241, SWS_NvM_00405, SWS_NvM_00453
SRS_Mem_08546	It shall be possible to protect permanent RAM data blocks against data loss due to reset	SWS_NvM_00240, SWS_NvM_00548
SRS_Mem_08547	The NVRAM Manager shall be able to distinguish between explicitly invalidated and inconsistent data	SWS_NvM_00132, SWS_NvM_00165, SWS_NvM_00174, SWS_NvM_00571
SRS_Mem_08548	The NVRAM Manager shall request default data from the application	SWS_NvM_00700
SRS_Mem_08549	The NVRAM manager shall provide functionality to automatically initialize RAM data blocks after a software update	SWS_NvM_00171
SRS_Mem_08550	The NVRAM Manager shall provide a service for marking permanent RAM data blocks as modified/unmodified	SWS_NvM_00344, SWS_NvM_00345, SWS_NvM_00696
SRS_Mem_08554	The NVRAM manager shall retry read and write operations on NVRAM blocks if they have not succeeded up to a configurable number of times	SWS_NvM_00213, SWS_NvM_00526, SWS_NvM_00527, SWS_NvM_00529, SWS_NvM_00581, SWS_NvM_00804

SRS_Mem_08555	The NVRAM manager shall provide mechanisms for static verification of the block identifier when reading an NVRAM block	SWS_NvM_00523, SWS_NvM_00524, SWS_NvM_00593
SRS_Mem_08556	The NVRAM manager shall provide a mechanism for verification of the written block data by again reading and comparing it	SWS_NvM_00527, SWS_NvM_00528, SWS_NvM_00529
SRS_Mem_08558	The NVRAM manager shall provide a mechanism to remove all unprocessed requests associated with a NVRAM block	SWS_NvM_00458
SRS_Mem_08560	Each NVRAM block shall be configurable for shared access	SWS_NvM_00535, SWS_NvM_00536
SWS_BSW_00047	Implement index based API services	SWS_NvM_00447
SWS_BSW_00216	Name convention for type of the parameter passed to initialization functions	SWS_NvM_00880

7 Functional specification

7.1 Basic architecture guidelines

7.1.1 Layer structure

The figure below shows the communication interaction of module NvM.




Figure 4: NVRAM Manager interactions overview

7.1.2 Addressing scheme for the memory hardware abstraction

[SWS_NvM_00051] [The Memory Abstraction Interface, the underlying Flash EEPROM Emulation and EEPROM Abstraction Layer provide the NvM module with a virtual linear 32bit address space which is composed of a 16bit block number and a 16bit block address offset.] (SRS_Mem_00041, SRS_Mem_08000, SRS_Mem_08014, SRS_Mem_00016, SRS_Mem_00017, SRS_Mem_00018)

Hint: According to [SWS_NvM_00051], the NvM module allows for a (theoretical) maximum of 65536 logical blocks, each logical block having a (theoretical) maximum size of 64 Kbytes.

[SWS_NvM_00122] [The NvM module shall further subdivide the 16bit Fee/Ea block number into the following parts:

- NV block base number (NVM_NV_BLOCK_BASE_NUMBER) with a bit width of (16 -NVM_DATASET_SELECTION_BITS)
 - Data index with a bit width of (NVM_DATASET_SELECTION_BITS)
-] (SRS_Mem_00041, SRS_Mem_08014, SRS_Mem_00016, SRS_Mem_00017, SRS_Mem_00018)

[SWS_NvM_00343] [Handling/addressing of redundant NVRAM blocks shall be done towards the memory hardware abstraction in the same way like for dataset NVRAM blocks, i.e. the redundant NV blocks shall be managed by usage of the configuration parameter NvMDatasetSelectionBits.] ()

[SWS_NvM_00123] [The NV block base number (NVM_NV_BLOCK_BASE_NUMBER) shall be located in the most significant bits of the Fee/Ea block number.] (SRS_Mem_08000)

[SWS_NvM_00442] [The configuration tool shall configure the block identifiers.] (SRS_Mem_08000, SRS_Mem_00027, SRS_Mem_08014)

[SWS_NvM_00443] [The NvM module shall not modify the configured block identifiers.] ()

7.1.2.1 Examples

To clarify the previously described addressing scheme which is used for NVRAM manager ↔ memory hardware abstraction interaction, the following examples shall help to understand the correlations between the configuration parameters NvMNvBlockBaseNumber, NvMDatasetSelectionBits on NVRAM manager side and EA_BLOCK_NUMBER / FEE_BLOCK_NUMBER on memory hardware abstraction side [[ECUC NvM 00061](#)].

For the given examples A and B a simple formula is used:

$$\text{FEE/EA_BLOCK_NUMBER} = (\text{NvMNvBlockBaseNumber} \ll \text{NvMDatasetSelectionBits}) + \text{DataIndex}.$$

Example A:

The configuration parameter NvMDatasetSelectionBits is configured to be 2. This leads to the result that 14 bits are available as range for the configuration parameter NvMNvBlockBaseNumber.

- Range of NvMNvBlockBaseNumber: 0x1..0x3FFE
- Range of data index: 0x0..0x3(=2^NvMDatasetSelectionBits-1)
- Range of FEE_BLOCK_NUMBER/EA_BLOCK_NUMBER: 0x4..0xFFFFB

With this configuration the FEE/EA_BLOCK_NUMBER computes using the formula mentioned before should look like in the examples below:

For a native NVRAM block with NvMNvBlockBaseNumber = 2:

- NV block is accessed with FEE/EA_BLOCK_NUMBER = 8

For a redundant NVRAM block with NvMNvBlockBaseNumber = 3:

- 1st NV block with data index 0 is accessed with FEE/EA_BLOCK_NUMBER = 12
- 2nd NV block with data index 1 is accessed with FEE/EA_BLOCK_NUMBER = 13

For a dataset NVRAM block with NvMNvBlockBaseNumber = 4, NvMNvBlockNum = 3:

- NV block #0 with data index 0 is accessed with FEE/EA_BLOCK_NUMBER = 16
- NV block #1 with data index 1 is accessed with FEE/EA_BLOCK_NUMBER = 17
- NV block #2 with data index 2 is accessed with FEE/EA_BLOCK_NUMBER = 18

Example B:

The configuration parameter NvMDataSetSelectionBits is configured to be 4. This leads to the result that 12 bits are available as range for the configuration parameter NvMNvBlockBaseNumber.

- Range of NvMNvBlockBaseNumber: 0x1..0xFFE
- Range of data index: 0x0..0xF(=2^NvMDataSetSelectionBits-1)
- Range of FEE/EA Block Number: 0x10..0xFFEF

7.1.3 Basic storage objects

7.1.3.1 NV block

[SWS_NvM_00125] [The NV block is a basic storage object and represents a memory area consisting of NV user data and (optionally) a CRC value and (optionally) a NV block header.




Figure 5: NV Block layout

Note: This figure does not show the physical memory layout of an NV block. Only the logical clustering is shown.] ()

7.1.3.2 RAM block

[SWS_NvM_00126] [The RAM block is a basic storage object and represents an area in RAM consisting of user data and (optionally) a CRC value and (optionally) a NV block header.] ()

[SWS_NvM_00127] [Restrictions on CRC usage on RAM blocks. CRC is only available if the corresponding NV block(s) also have a CRC. CRC has to be of the same type as that of the corresponding NV block(s). [\[ECUC_NvM_00061\]](#).] ()

[SWS_NvM_00129] [The user data area of a RAM block can reside in a different RAM address location (global data section) than the state of the RAM block.] ()

[SWS_NvM_00130] [The data area of a RAM block shall be accessible from NVRAM Manager and from the application side (data passing from/to the corresponding NV block).] ()




Figure 6: RAM Block layout

Note: This figure does not show the physical memory layout of a RAM block. Only the logical clustering is shown.

As the NvM module doesn't support alignment, this could be managed by configuration, i.e. the block length could be enlarged by adding padding to meet alignment requirements.] ()

[SWS_NvM_00373] [The RAM block data shall contain the permanently or temporarily assigned user data.] ()

[SWS_NvM_00370] [In case of permanently assigned user data, the address of the RAM block data is known during configuration time.] ()

[SWS_NvM_00372] [In case of temporarily assigned user data, the address of the RAM block data is not known during configuration time and will be passed to the NvM module during runtime.] ()

[SWS_NvM_00088] [It shall be possible to allocate each RAM block without address constraints in the global RAM area. The whole number of configured RAM blocks needs not be located in a continuous address space.] ()

7.1.3.3 ROM block

[SWS_NvM_00020] [The ROM block is a basic storage object, resides in the ROM (FLASH) and is used to provide default data in case of an empty or damaged NV block.




Figure 7: ROM block layout

] ()

7.1.3.4 Administrative block

[SWS_NvM_00134] [The Administrative block shall be located in RAM and shall contain a block index which is used in association with Dataset NV blocks. Additionally, attribute/error/status information of the corresponding NVRAM block shall be contained.] ()

[SWS_NvM_00128] [The NvM module shall use state information of the permanent RAM block or of the RAM mirror in the NvM module in case of explicit synchronization (invalid/valid) to determine the validity of the permanent RAM block user data.] ()

[SWS_NvM_00132] [The RAM block state "invalid" indicates that the data area of the respective RAM block is invalid. The RAM block state "valid" indicates that the data area of the respective RAM block is valid.] (SRS_Mem_08547)

[SWS_NvM_00133] [The value of "invalid" shall be represented by all other values except "valid".] ()

[SWS_NvM_00135] [The Administrative block shall be invisible for the application and is used exclusively by the NvM module for security and administrative purposes of the RAM block and the NVRAM block itself.] ()

[SWS_NvM_00054] [The NvM module shall use an attribute field to manage the NV block write protection in order to protect/unprotect a NV block data field.] ()

[SWS_NvM_00136] [The NvM module shall use an error/status field to manage the error/status value of the last request [\[SWS_NvM_00083\]](#).] ()

7.1.3.5 NV Block Header

[SWS_NvM_00522] [The NV Block header shall be included first in the NV Block, if the mechanism Static Block ID is enabled.




Figure 8: NV block layout with Static Block ID enabled

] ()

7.1.4 Block management types

7.1.4.1 Block management types overview

[SWS_NvM_00137] [The following types of NVRAM storage shall be supported by the NvM module implementation:

- NVM_BLOCK_NATIVE
- NVM_BLOCK_REDUNDANT
- NVM_BLOCK_DATASET] (SRS_LIBS_08534, SRS_LIBS_08528, SRS_LIBS_08529, SRS_LIBS_08531)

[SWS_NvM_00557] [NVM_BLOCK_NATIVE type of NVRAM storage shall consist of the following basic storage objects:

- NV Blocks: 1
- RAM Blocks: 1
- ROM Blocks: 0..1
- Administrative Blocks:1] (SRS_LIBS_08528)

[SWS_NvM_00558] [NVM_BLOCK_REDUNDANT type of NVRAM storage shall consist of the following basic storage objects:

- NV Blocks: 2
- RAM Blocks: 1
- ROM Blocks: 0..1
- Administrative Blocks:1] (SRS_LIBS_08529)

[SWS_NvM_00559] [NVM_BLOCK_DATASET type of NVRAM storage shall consist of the following basic storage objects:

- NV Blocks: 1..(m<256)*
- RAM Blocks: 1
- ROM Blocks: 0..n
- Administrative Blocks:1

* The number of possible datasets depends on the configuration parameter NvMDatasetSelectionBits.] (SRS_LIBS_08531)

7.1.4.2 NVRAM block structure

[SWS_NvM_00138] [The NVRAM block shall consist of the mandatory basic storage objects NV block, RAM block and Administrative block.] ()

[SWS_NvM_00139] [The basic storage object ROM block is optional.] ()

[SWS_NvM_00140] [The composition of any NVRAM block is fixed during configuration by the corresponding NVRAM block descriptor.] ()

[SWS_NvM_00141] [All address offsets are given relatively to the start addresses of RAM or ROM in the NVRAM block descriptor. The start address is assumed to be zero.

Hint: A device specific base address or offset will be added by the respective device driver if needed.] ()

For details of the NVRAM block descriptor see chapter 7.1.4.3.

7.1.4.3 NVRAM block descriptor table

[SWS_NvM_00069] [A single NVRAM block to deal with will be selected via the NvM module API by providing a subsequently assigned Block ID.] ()

[SWS_NvM_00143] [All structures related to the NVRAM block descriptor table and their addresses in ROM (FLASH) have to be generated during configuration of the NvM module.] ()

7.1.4.4 Native NVRAM block

The Native NVRAM block is the simplest block management type. It allows storage to/retrieval from NV memory with a minimum of overhead.

[SWS_NvM_00000] [The Native NVRAM block consists of a single NV block, RAM block and Administrative block.] ()

7.1.4.5 Redundant NVRAM block

In addition to the Native NVRAM block, the Redundant NVRAM block provides enhanced fault tolerance, reliability and availability. It increases resistance against data corruption.

[SWS_NvM_00001] [The Redundant NVRAM block consists of two NV blocks, a RAM block and an Administrative block.

The following figure reflects the internal structure of a redundant NV block:




Figure 9: Redundant NVRAM Block layout

Note: This figure does not show the physical NV memory layout of a redundant NVRAM block. Only the logical clustering is shown.] ()

[SWS_NvM_00531] [In case one NV Block associated with a Redundant NVRAM block is deemed invalid (e.g. during read), an attempt shall be made to recover the NV Block using data from the incorrupt NV Block.] ()

[SWS_NvM_00546] [In case the recovery fails then this shall be reported to the DEM using the code `NVM_E_LOSS_OF_REDUNDANCY`.]

Note: “Recovery” denotes the re-establishment of redundancy. This usually means writing the recovered data back to the NV Block.] ()

7.1.4.6 Dataset NVRAM block

The Dataset NVRAM block is an array of equally sized data blocks (NV/ROM). The application can at one time access exactly one of these elements.

[SWS_NvM_00006] [The Dataset NVRAM block consists of multiple NV user data, (optionally) CRC areas, (optional) NV block headers, a RAM block and an Administrative block.] ()

[SWS_NvM_00144] [The index position of the dataset is noticed via a separated field in the corresponding Administrative block.] ()

[SWS_NvM_00374] [The NvM module shall be able to read all assigned NV blocks.] ()

[SWS_NvM_00375] [The NvM module shall only be able to write to all assigned NV blocks if (and only if) write protection is disabled.] ()

[SWS_NvM_00146] [If the basic storage object ROM block is selected as optional part, the index range which normally selects a dataset is extended to the ROM to make it possible to select a ROM block instead of a NV block. The index covers all NV/ROM blocks which may build up the NVRAM Dataset block.] ()

[SWS_NvM_00376] [The NvM module shall be able to only read optional ROM blocks (default datasets).] ()

[SWS_NvM_00377] [The NvM module shall treat a write to a ROM block like a write to a protected NV block.] ()

[SWS_NvM_00444] [The total number of configured datasets (NV+ROM blocks) must be in the range of 1..255.] ()

[SWS_NvM_00445] [In case of optional ROM blocks, data areas with an index from 0 up to NvMNvBlockNum - 1 represent the NV blocks with their CRC in the NV memory. Data areas with an index from NvMNvBlockNum up to NvMNvBlockNum + NvMRomBlockNum - 1 represent the ROM blocks.




Figure 10: Dataset NVRAM block layout

Note: This figure does not show the physical NV memory layout of a Dataset NVRAM block. Only the logical clustering is shown.] ()

7.1.4.7 NVRAM Manager API configuration classes

[SWS_NvM_00149] [To have the possibility to adapt the NvM module to limited hardware resources, three different API configuration classes shall be defined:

- API configuration class 3: All specified API calls are available. A maximum of functionality is supported.
- API configuration class 2: An intermediate set of API calls is available.
- API configuration class 1: Especially for matching systems with very limited hardware resources this API configuration class offers only a minimum set of API calls which are required in any case.] ()

[SWS_NvM_00560] [API configuration class 3 shall consist of the following API:

Type 1:

- NvM_SetDataIndex(...)
- NvM_GetDataIndex(...)
- NvM_SetBlockProtection(...)
- NvM_GetErrorStatus(...)
- NvM_SetRamBlockStatus(...)
- NvM_SetBlockLockStatus

Type 2:

- NvM_ReadBlock(...)
- NvM_WriteBlock(...)
- NvM_RestoreBlockDefaults(...)
- NvM_EraseNvBlock(...)
- NvM_InvalidateNvBlock(...)
- NvM_CancelJobs(...)
- NvM_ReadPRAMBlock(...)
- NvM_WritePRAMBlock(...)
- NvM_RestorePRAMBlockDefaults(...)

Type 3:

- NvM_ReadAll(...)
- NvM_WriteAll(...)
- NvM_CancelWriteAll(...)
- NvM_ValidateAll(...)

Type 4:

- NvM_Init(...) | ()

[SWS_NvM_00561] [API configuration class 2 shall consist of the following API:

Type 1:

- NvM_SetDataIndex(...)
- NvM_GetDataIndex(...)
- NvM_GetErrorStatus(...)
- NvM_SetRamBlockStatus(...)
- NvM_SetBlockLockStatus

Type 2:

- NvM_ReadBlock(...)
- NvM_WriteBlock(...)
- NvM_RestoreBlockDefaults(...)
- NvM_CancelJobs(...)
- NvM_ReadPRAMBlock(...)
- NvM_WritePRAMBlock(...)
- NvM_RestorePRAMBlockDefaults(...)

Type 3:

- NvM_ReadAll(...)
- NvM_WriteAll(...)
- NvM_CancelWriteAll(...)
- NvM_ValidatedAll(...)

Type 4:

- NvM_Init(...)] ()

[SWS_NvM_00562] [API configuration class 1 shall consist of the following API:

Type 1:

- NvM_GetErrorStatus(...)
- NvM_SetRamBlockStatus(...)
- NvM_SetBlockLockStatus

Type 2:

- --

Type 3:

- NvM_ReadAll(...)
- NvM_WriteAll(...)
- NvM_CancelWriteAll(...)

Type 4:

- NvM_Init(...)

Note: For API configuration class 1 no queues are needed, no immediate data can be written. Furthermore the API call NvM_SetRamBlockStatus is only available if configured by NvMSetRamBlockStatusApi.] ()

[SWS_NvM_00365] [Within API configuration class 1, the block management type NVM_BLOCK_DATASET is not supported.] ()

For information regarding the definition of Type 1...4 refer to chapter 8.1.5.

[SWS_NvM_00150] [The NvM module shall only contain that code that is needed to handle the configured block types.] ()

7.1.5 Scan order / priority scheme

[SWS_NvM_00032] [The NvM module shall support a priority based job processing.] (SRS_Mem_08542)

[SWS_NvM_00564] [By configuration parameter NvMJobPrioritization [\[SWS_NvM_00028\]](#) priority based job processing shall be enabled/disabled.] (SRS_Mem_08542)

[SWS_NvM_00378] [In case of priority based job processing order, the NvM module shall use two queues, one for immediate write jobs (crash data) another for all other jobs (including immediate read/erase jobs).] (SRS_Mem_08542)

[SWS_NvM_00379] [If priority based job processing is disabled via configuration, the NvM module shall not support immediate write jobs. In this case, the NvM module processes all jobs in FCFS order.] ()

[SWS_NvM_00380] [The job queue length for multi block requests originating from the NvM_ReadAll and NvM_WriteAll shall be one (only one job is queued).] ()

[SWS_NvM_00381] [The NvM module shall not interrupt jobs originating from the NvM_ReadAll request by other requests.] ()

Note: The only exception to the rule given in [[SWS_NvM_00381](#), [SWS_NvM_00567](#)] is a write job with immediate priority which shall preempt the running read / write job [[SWS_NvM_00182](#)]. The preempted job shall subsequently be resumed / restarted by the NvM module.

[SWS_NvM_00567] [The NvM module shall not interrupt jobs originating from the NvM_WriteAll request by other requests.] ()

[SWS_NvM_00568] [The NvM module shall rather queue read jobs that are requested during an ongoing NvM_ReadAll request and executed them subsequently.] ()

[SWS_NvM_00569] [The NvM module shall rather queue write jobs that are requested during an ongoing NvM_WriteAll request and executed them subsequently.] ()

[SWS_NvM_00725] [The NvM module shall rather queue write jobs that are requested during an ongoing NvM_ReadAll request and executed them subsequently.] ()

[SWS_NvM_00726] [The NvM module shall rather queue read jobs that are requested during an ongoing NvM_WriteAll request and executed them subsequently.] ()

Note: The NvM_WriteAll request can be aborted by calling NvM_CancelWriteAll. In this case, the current block is processed completely but no further blocks are written [[SWS_NvM_00238](#)].

Hint: It shall be allowed to dequeue requests, if they became obsolete by completion of the regarding NVRAM block.

[SWS_NvM_00570] [The preempted job shall subsequently be resumed / restarted by the NvM module. This behavior shall apply for single block requests as well as for multi block requests.] ()

7.2 General behavior

7.2.1 Functional requirements

[SWS_NvM_00383] [For each asynchronous request, a notification of the caller after completion of the job shall be a configurable option.] ()

[SWS_NvM_00384] [The NvM module shall provide a callback interface [SWS_NvM_00113](#).

Hint: The NvM module's environment shall access the non-volatile memory via the NvM module only. It shall not be allowed for any module (except for the NvM module) to access the non-volatile memory directly.] (SRS_Mem_08541)

[SWS_NvM_00038] [The NvM module only provides an implicit way of accessing blocks in the NVRAM and in the shared memory (RAM). This means, the NvM module copies one or more blocks from NVRAM to the RAM and the other way round.] ()

[SWS_NvM_00692] [The application accesses the RAM data directly, with respect to given restrictions (e.g. synchronization).] ()

[SWS_NvM_00385] [The NvM module shall queue all asynchronous “single block” read/write/control requests if the block with its specific ID is not already queued or currently in progress (multitasking restrictions).] ()

[SWS_NvM_00386] [The NvM module shall accept multiple asynchronous “single block” requests as long as no queue overflow occurs.] ()

[SWS_NvM_00155] [The highest priority request shall be fetched from the queues by the NvM module and processed in a serialized order.] ()

[SWS_NvM_00040] [The NvM module shall implement implicit mechanisms for consistency / integrity checks of data saved in NV memory [\[SWS_NvM_00165\]](#).] ()

Depending on implementation of the memory stack, callback routines provided and/or invoked by the NvM module may be called in interrupt context.

Hint: The NvM module providing routines called in interrupt context has therefore to make sure that their runtime is reasonably short.

[SWS_NvM_00085] [If there is no default ROM data available at configuration time or no callback defined by NvMInitBlockCallback then the application shall be responsible for providing the default initialization data.

In this case, the application has to use `NvM_GetErrorStatus()` to be able to distinguish [\[ECUC_NvM_00061\]](#) between first initialization and corrupted data [\[SWS_NvM_00083\]](#).] ()

[SWS_NvM_00387] [During processing of `NvM_ReadAll`, the NvM module shall be able to detect corrupted RAM data by performing a checksum calculation. [\[ECUC_NvM_00476\]](#).] ()

[SWS_NvM_00226] [During processing of `NvM_ReadAll`, the NvM module shall be able to detect invalid RAM data by testing the validity of a data within the administrative block [\[ECUC_NvM_00476\]](#).] ()

[SWS_NvM_00388] [During startup phase and normal operation of `NvM_ReadAll` and if the NvM module has detected an unrecoverable error within the NV block, the NvM module shall copy default data (if configured) to the corresponding RAM block.] ()

[SWS_NvM_00332] [To make use of the OS services, the NvM module shall only use the BSW scheduler instead of directly making use of OS objects and/or related OS services.] (SRS_BSW_00429)

7.2.2 Design notes

7.2.2.1 NVRAM manager startup

[SWS_NvM_00693] [`NvM_Init` shall be invoked by the ECU state manager exclusively.] ()

[SWS_NvM_00091] [Due to strong constraints concerning the ECU startup time, the `NvM_Init` request shall not contain the initialization of the configured NVRAM blocks.] ()

[SWS_NvM_00157] [The `NvM_Init` request shall not be responsible to trigger the initialization of underlying drivers and memory hardware abstraction. This shall also be handled by the ECU state manager.] (SRS_Mem_00011)

[SWS_NvM_00158] [The initialization of the RAM data blocks shall be done by another request, namely `NvM_ReadAll`.] ()

`NvM_ReadAll` shall be called exclusively by the ECU state manager if EcuM Fixed is used or by integration code if EcuM Flex is used.

[SWS_NvM_00694] [Software components which use the NvM module shall be responsible for checking global error/status information resulting from the NvM module startup. The ECU state manager shall use polling by using NvM_GetErrorStatus [[SWS_NvM_00015](#)] (reserved block ID 0) or callback notification (configurable option NvM_MultiBlockCallback [[SWS_NvM_00028](#)]) to derive global error/status information resulting from startup. If polling is used, the end of the NVRAM startup procedure shall be detected by the global error/status NVM_REQ_OK or NVM_REQ_NOT_OK (during startup NVM_REQ_PENDING) [[SWS_NvM_00083](#)]. If callbacks are chosen for notification, software components shall be notified automatically if an assigned NVRAM block has been processed [[SWS_NvM_00281](#)].

Note 1: If callbacks are configured for each NVRAM block which is processed within NvM_ReadAll, they can be used by the RTE to start e.g. SW-Cs at an early point of time.

Note 2: To ensure that the DEM is fully operational at an early point of time, i.e. its NV data is restored to RAM, DEM related NVRAM blocks should be configured to have a low ID to be processed first within NvM_ReadAll.] ()

[SWS_NvM_00160] [The NvM module shall not store the currently used Dataset index automatically in a persistent way. Software components shall check the specific error/status of all blocks they are responsible for by using NvM_GetErrorStatus [[SWS_NvM_00015](#)] with specific block IDs to determine the validity of the corresponding RAM blocks.] ()

[SWS_NvM_00695] [For all blocks of the block management type “NVRAM Dataset” [[SWS_NvM_00006](#)] the software component shall be responsible to set the proper index position by NvM_SetDataIndex [[SWS_NvM_00014](#)]. E.g. the current index position can be stored/maintained by the software component in a unique NVRAM block. To get the current index position of a “Dataset Block”, the software component shall use the NvM_GetDataIndex [[SWS_NvM_00021](#)] API call.] ()

7.2.2.2 NVRAM manager shutdown

[SWS_NvM_00092] [The basic shutdown procedure shall be done by the request NvM_WriteAll [[SWS_NvM_00018](#)].

Hint: NvM_WriteAll shall be invoked by the ECU state manager.] ()

7.2.2.3 (Quasi) parallel write access to the NvM module

[SWS_NvM_00162] [The NvM module shall receive the requests via an asynchronous interface using a queuing mechanism. The NvM module shall process all requests serially depending on their priority.] (SRS_Mem_00013, SRS_Mem_00034)

7.2.2.4 NVRAM block consistency check

[SWS_NvM_00164] [The NvM module shall provide implicit techniques to check the data consistency of NVRAM blocks [ECUC_NvM_00476], [\[SWS_NvM_00040\]](#).] (SRS_Mem_08547, SRS_Mem_00030)

[SWS_NvM_00571] [The data consistency check of a NVRAM block shall be done by CRC recalculations of its corresponding NV block(s).] (SRS_Mem_08547)

[SWS_NvM_00165] [The implicit way of a data consistency check shall be provided by configurable options of the internal functions. The implicit consistency check shall be configurable for each NVRAM block and depends on the configurable parameters `NvMBlockUseCrc` and `NvMCalcRamBlockCrc` [\[ECUC_NvM_00061\]](#).] (SRS_Mem_08547, SRS_Mem_00129)

[SWS_NvM_00724] [`NvMBlockUseCrc` should be enabled for NVRAM blocks where `NvMWriteBlockOnce = TRUE`. `NvMBlockWriteProt` should be disabled for NVRAM blocks where `NvMWriteBlockOnce = TRUE`, to enable the user to write data to the NVRAM block in case of CRC check is failed.] ()

[SWS_NvM_00544] [Depending on the configurable parameters `NvMBlockUseCrc` and `NvMCalcRamBlockCrc`, NvM module shall allocate memory for the largest CRC used.

Hint: NvM users must not know anything about CRC memory (e.g. size, location) for their data in a RAM block.] ()

7.2.2.5 Error recovery

[SWS_NvM_00047] [The NvM module shall provide techniques for error recovery. The error recovery depends on the NVRAM block management type [\[SWS_NvM_00001\]](#).] ()

[SWS_NvM_00389] [The NvM module shall provide error recovery on read for every kind of NVRAM block management type by loading of default values.] ()

[SWS_NvM_00390] [The NvM module shall provide error recovery on read for NVRAM blocks of block management type `NVM_BLOCK_REDUNDANT` by loading the RAM block with default values.] ()

[SWS_NvM_00168] [The NvM module shall provide error recovery on write by performing write retries regardless of the NVRAM block management type.] ()

[SWS_NvM_00169] [The NvM module shall provide read error recovery on startup for all NVRAM blocks with configured RAM block CRC in case of RAM block revalidation failure.] ()

7.2.2.6 Recovery of a RAM block with ROM data

[SWS_NvM_00171] [The NvM module shall provide implicit and explicit recovery techniques to restore ROM data to its corresponding RAM block in case of unrecoverable data inconsistency of a NV block [\[SWS_NvM_00387\]](#), [\[SWS_NvM_00226\]](#), [\[SWS_NvM_00388\]](#).] (SRS_Mem_08549, SRS_Mem_08010)

7.2.2.7 Implicit recovery of a RAM block with ROM default data

[SWS_NvM_00172] [The data content of the corresponding NV block shall remain unmodified during the implicit recovery.] (SRS_Mem_08010)

[SWS_NvM_00572] [The implicit recovery shall not be provided during startup (part of NvM_ReadAll) and NvM_ReadBlock or NvM_ReadPRAMBlock for each NVRAM block when no ROM block is configured (by the parameter NvMRomBlockDataAddress or NvMInitBlockCallback).] ()

[SWS_NvM_00573] [The implicit recovery shall not be provided during startup (part of NvM_ReadAll) and NvM_ReadBlock or NvM_ReadPRAMBlock for each NVRAM block for the following conditions:

- The ROM block is configured (by the parameter NvMRomBlockDataAddress or the parameter NvMInitBlockCallback).
- The permanent RAM block or the content of the RAM mirror in the NvM module (in case of explicit synchronization) state is valid and CRC (data) is consistent.] ()

[SWS_NvM_00574] [The implicit recovery shall not be provided during startup (part of NvM_ReadAll) and NvM_ReadBlock or NvM_ReadPRAMBlock for each NVRAM block for the following conditions:

- The ROM block is configured (by the parameter NvMRomBlockDataAddress or the parameter NvMInitBlockCallback).
- The permanent RAM block or the content of the RAM mirror in the NvM module (in case of explicit synchronization) state is invalid and CRC (data) is inconsistent.
- Read attempt from NV success.] ()

[SWS_NvM_00575] [The implicit recovery shall be provided during startup (part of NvM_ReadAll) and NvM_ReadBlock or NvM_ReadPRAMBlock for each NVRAM block for the following conditions:

- The ROM block is configured (by the parameter NvMRomBlockDataAddress or the parameter NvMInitBlockCallback).
- The permanent RAM block state or the content of the RAM mirror in the NvM module (in case of explicit synchronization) is invalid and CRC (data) is inconsistent.
- Read attempt from NV fails.] ()

7.2.2.8 Explicit recovery of a RAM block with ROM default data

[SWS_NvM_00391] [For explicit recovery with ROM block data the NvM module shall provide functions NvM_RestoreBlockDefaults and NvM_RestorePRAMBlockDefaults [\[SWS_NvM_00012\]](#) to restore ROM data to its corresponding RAM block.] ()

[SWS_NvM_00392] [The function NvM_RestoreBlockDefaults and NvM_RestorePRAMBlockDefaults shall remain unmodified the data content of the corresponding NV block.

Hint: The function NvM_RestoreBlockDefaults or NvM_RestorePRAMBlockDefaults shall be used by the application to restore ROM data to the corresponding RAM block every time it is needed.] ()

7.2.2.9 Detection of an incomplete write operation to a NV block

[SWS_NvM_00174] [The detection of an incomplete write operation to a NV block is out of scope of the NvM module. This is handled and detected by the memory hardware abstraction. The NvM module expects to get information from the memory hardware abstraction if a referenced NV block is invalid or inconsistent and cannot be read when requested.

SW-Cs may use NvM_InvalidateNvBlock to prevent lower layers from delivering old data.] (SRS_Mem_08547)

7.2.2.10 Termination of a single block request

[SWS_NvM_00175] [All asynchronous requests provided by the NvM module (except for NvM_CancelWriteAll) shall indicate their result in the designated error/status field of the corresponding Administrative block [\[SWS_NvM_00000\]](#).] ()

[SWS_NvM_00176] [The optional configuration parameter NvMSingleBlockCallback configures the notification via callback on the termination of an asynchronous block request (except for NvM_CancelWriteAll) [\[ECUC_NvM_00061\]](#).

Note: In communication with application SW-C, the NvMSingleBlockCallback shall be mapped to the Rte_call_<p>_<o> API.] ()

7.2.2.11 Termination of a multi block request

[SWS_NvM_00393] [The NvM module shall use a separate variable to store the result of an asynchronous multi block request (NvM_ReadAll, NvM_WriteAll including NvM_CancelWriteAll, NvM_ValidateAll).] ()

[SWS_NvM_00394] [The function NvM_GetErrorStatus [\[SWS_NvM_00015\]](#) shall return the most recent error/status information of an asynchronous multi block request (including NvM_CancelWriteAll) [\[SWS_NvM_00083\]](#) in conjunction with a reserved block ID value of 0.] ()

[SWS_NvM_00395] [The result of a multi block request shall represent only a common error/status information.] ()

[SWS_NvM_00396] [The multi block requests provided by the NvM module shall indicate their detailed error/status information in the designated error/status field of each affected Administrative block.] ()

[SWS_NvM_00179] [The optional configuration parameter NvMMultiBlockCallback configures the notification via callback on the termination of an asynchronous multi block request [\[SWS_NvM_00028\]](#).] ()

7.2.2.12 General handling of asynchronous requests/ job processing

[SWS_NvM_00180] [Every time when CRC calculation is processed within a request, the NvM module shall calculate the CRC in multiple steps if the referenced NVRAM block length exceeds the number of bytes configured by the parameter NvMCrcNumOfBytes.] ()

[SWS_NvM_00351] [For CRC calculation, the NvM module shall use initial values which are published by the CRC module.] ()

[SWS_NvM_00181] [Multiple concurrent single block requests shall be queueable.] ()

[SWS_NvM_00182] [The NvM module shall interrupt asynchronous request/job processing in favor of jobs with immediate priority (crash data).] ()

[SWS_NvM_00184] [If the invocation of an asynchronous function on the NvM module leads to a job queue overflow, the function shall return with E_NOT_OK.] ()

[SWS_NvM_00185] [On successful enqueueing a request, the NvM module shall set the request result of the corresponding NVRAM block to `NVM_REQ_PENDING`.] ()

[SWS_NvM_00270] [If the NvM module has successfully processed a job, it shall return `NVM_REQ_OK` as job result.] ()

7.2.2.13 NVRAM block write protection

The NvM module shall offer different kinds of write protection which shall be configurable. Every kind of write protection is only related to the NV part of NVRAM block, i.e. the RAM block data can be modified but not be written to NV memory.

[SWS_NvM_00325] [Enabling/Disabling of the write protection is allowed using `NvM_SetBlockProtection` function when the `NvMWriteBlockOnce` is `FALSE` regardless of the value (True/False) configured for `NvMBlockWriteProt`.] (SRS_Mem_08009)

[SWS_NvM_00577] [Enabling/Disabling of the write protection is not allowed using `NvM_SetBlockProtection` function when the `NvMWriteBlockOnce` is `TRUE` regardless of the value (True/False) configured for `NvMBlockWriteProt`.] (SRS_Mem_08009)

[SWS_NvM_00326] [For all NVRAM blocks configured with `NvMBlockWriteProt = TRUE`, the NvM module shall enable a default write protection.] (SRS_Mem_08009)

[SWS_NvM_00578] [The NvM module's environment can explicitly disable the write protection using the `NvM_SetBlockProtection` function.] ()

[SWS_NvM_00397] [For NVRAM blocks configured with `NvMWriteBlockOnce == TRUE` [NVM072], the NvM module shall only write once to the associated NV memory, i.e in case of a blank NV device.] (SRS_Mem_08015)

[SWS_NvM_00398] [For NVRAM blocks configured with `NvMWriteBlockOnce == TRUE`, the NvM module shall not allow disabling the write protection explicitly using the `NvM_SetBlockProtection` function.[SWS_NvM_00450]] ()

7.2.2.14 Validation and modification of RAM block data

This chapter shall give summarized information regarding the internal handling of NVRAM Manager status bits. Depending on different API calls, the influence on the status of RAM blocks shall be described in addition to the specification items located in chapter 8.1.3. The following figures depict the state transitions of RAM blocks.




Figure 11: RAM Block States

Since entering and preserving a state can be done based on multiple conditions and placing them all in the above figure would make it difficult to understand, more detailed explanations are provided in the following subchapters. The **INVALID / CHANGED** state is not detailed as it can never be reached (as mentioned in the figure above).

After the Initialization the RAM Block is in state **INVALID/UNCHANGED** until it is updated via **NvM_ReadAll**, which causes a transition to state **VALID/UNCHANGED**. In this state **WriteAll** is not allowed. This state is left, if the **NvM_SetRamBlockStatus** is invoked. If there occurs a CRC error the RAM Block changes to state **INVALID** again, which than can be left via the implicit or explicit error recovery mechanisms. After error recovery the block is in state **VALID/CHANGED** as the content of the RAM differs from the NVRAM content.

[SWS_NvM_00344] [If the API for modifying the RAM block status has been configured out (via `NvMSetRamBlockStatusApi` or

NvMBlockUseSetRamBlockStatus) the NvM module shall treat a RAM block or the RAM mirror in the NvM module (in case of explicit synchronization) as valid and modified when writing to it, i.e. during NvM_WriteAll, the NvM module shall write each permanent RAM block to NV memory.] (SRS_Mem_08550)

[SWS_NvM_00345] [If the API for modifying the RAM block status has been configured out (via NvMSetRamBlockStatusApi or NvMBlockUseSetRamBlockStatus) the NvM module shall treat a RAM block as invalid when reading it, i.e. during NvM_ReadAll, the NvM module shall copy each NVRAM block to RAM if configured accordingly.] (SRS_Mem_08550)

[SWS_NvM_00696] [In case of an unsuccessful block read attempt, it is the responsibility of the application to provide valid data before the next write attempt.] (SRS_Mem_08550)

[SWS_NvM_00472] [In case a RAM block is successfully copied to NV memory the RAM block state shall be set to "valid/unmodified" afterwards.] (SRS_Mem_08541)

7.2.2.14.1 The VALID / UNCHANGED state

This state implies that the contents of the RAM Block are either identical to the contents of the corresponding NV Block or - if the application has accessed the RAM Block - a potential change was not yet indicated. For a DATASET block these conditions apply to the RAM contents of the instance that was last processed. Also, the last block operation was successful and the block was not invalidated by request.

To enter the VALID / UNCHANGED state, at least of the following must occur:

1. NvM_ReadAll() read successfully the block
2. NvM_ReadBlock finished successfully for the block
3. NvM_WriteBlock finished successfully for the block
4. NvM_WriteAll() wrote successfully the block

The VALID / UNCHANGED state is preserved while:

- the last read or write for a BlockID was successful (no error and no retrieval of default data)

AND

- the application has not indicated a potential change of RAM block since last read or write

7.2.2.14.2 The VALID / CHANGED state

This state implies that the contents of the RAM Block potentially differ from the contents of the corresponding NV Block. For a DATASET block this condition applies to the RAM contents of the instance that was last processed. Also, the last operation for the block was successful and the block was not invalidated by request. The block owner can signal a potential RAM contents changed for the block causing the block state to become VALID / CHANGED.

To enter the VALID / CHANGED state, at least one of the following must occur:

1. NvM_SetRamBlockStatus called with TRUE for the block
2. NvM_WriteBlock is called for the block
3. NvM_WriteAll will also process the block
4. NvM_ReadBlock called for the block gives default data
5. NvM_RestoreBlockDefaults called for the block finishes successfully
6. NvM_ReadAll gives default data when processing the block
7. NvM_ValidateAll processed successfully the block

The VALID / CHANGED state is preserved while:

- a block owner has indicated a potential change of RAM block

OR

- default data was retrieved (implicitly or explicitly) for the block upon last read

7.2.2.14.3 The INVALID / UNCHANGED state

This state implies that the NV Block is invalid. For a DATASET block this means that the NV Block contents are invalid for the last instance that was processed.

To enter the INVALID / UNCHANGED state, at least one of the following must occur:

1. NvM_SetRamBlockStatus called with FALSE for the block
2. NvM_ReadBlock indicates invalidation by user request for the block
3. NvM_ReadBlock indicates corrupted data (if CRC configured) for the block
4. NvM_ReadBlock indicates wrong StaticID (if configured) for the block
5. NvM_WriteBlock finished non-successfully for the block
6. NvM_WriteAll non-successful write for the block
7. NvM_InvalidateNvBlock finished successfully for the block
8. NvM_EraseNvBlock finished successfully for the block

The INVALID / UNCHANGED state is preserved while:

- the block state is unknown at the time (early init, until ReadAll or first operation requested for a given block)

OR

- the block was detected as corrupted or with wrong StaticID

OR

- the last successful operation on the block was an invalidation

OR

- the current read failed and no default data
- OR
- the last successful operation on the block was an erase

7.2.2.15 Communication and implicit synchronization between application and NVRAM manager

To minimize locking/unlocking overhead or the use of other synchronization methods, the communication between applications and the NvM module must follow a strict sequence of steps which is described below. This ensures a reliable communication between applications and the NvM module and avoids data corruption in RAM blocks and a proper synchronization is guaranteed.

This access model assumes that two parties are involved in communication with a RAM block: The application and the NvM module.

[SWS_NvM_00697] [If several applications are using the same RAM block it is not the job of the NvM module to ensure the data integrity of the RAM block. In this case, the applications have to synchronize their accesses to the RAM block and have to guarantee that no unsuitable accesses to the RAM block take place during NVRAM operations (details see below).

Especially if several applications are sharing a NVRAM block by using (different) temporary RAM blocks, synchronization between applications becomes more complex and this is not handled by the NvM module, too. In case of using callbacks as notification method, it could happen that e.g. an application gets a notification although the request has not been initiated by this application.

All applications have to adhere to the following rules.] ()

7.2.2.15.1 Write requests (NvM_WriteBlock or NvM_WritePRAMBlock)

[SWS_NvM_00698] [Applications have to adhere to the following rules during write request for implicit synchronization between application and NVRAM manager:

1. The application fills a RAM block with the data that has to be written by the NvM module
2. The application issues the NvM_WriteBlock or NvM_WritePRAMBlock request which transfers control to the NvM module.
3. From now on the application must not modify the RAM block until success or failure of the request is signaled or derived via polling. In the meantime the contents of the RAM block may be read.
4. An application can use polling to get the status of the request or can be informed via a callback function asynchronously.
5. After completion of the NvM module operation, the RAM block is reusable for modifications.] (SRS_Mem_00013)

7.2.2.15.2 Read requests (NvM_ReadBlock or NvM_ReadPRAMBlock)

[SWS_NvM_00699] [Applications have to adhere to the following rules during read request for implicit synchronization between application and NVRAM manager:

1. The application provides a RAM block that has to be filled with NVRAM data from the NvM module's side.
2. The application issues the NvM_ReadBlock request which transfers control to the NvM module.
3. From now on the application must not read or write to the RAM block until success or failure of the request is signaled or derived via polling.
4. An application can use polling to get the status of the request or can be informed via a callback function.
5. After completion of the NvM module operation, the RAM block is available with new data for use by the application.] (SRS_Mem_00013)

7.2.2.15.3 Restore default requests (NvM_RestoreBlockDefaults and NvM_RestorePRAMBlockDefaults)

[SWS_NvM_00700] [Applications have to adhere to the following rules during restore default requests for implicit synchronization between application and NVRAM manager:

1. The application provides a RAM block, which has to be filled with ROM data from the NvM modules side.
2. The application issues the NvM_RestoreBlockDefaults or NvM_RestorePRAMBlockDefaults request which transfers control to the NvM module.
3. From now on the application must not read or write to the RAM block until success or failure of the request is signaled or derived via polling.
4. An application can use polling to get the status of the request or can be informed via a callback function.
5. After completion of the NvM module operation, the RAM block is available with the ROM data for use by the application.] (SRS_Mem_08548)

7.2.2.15.4 Multi block read requests (NvM_ReadAll)

This request may be triggered only by the ECU state manager if EcuM Fixed is used or by integration code if EcuM Flex is used at system startup.

This request fills all configured permanent RAM blocks with necessary data for startup.

If the request fails or the request is handled only partially successful, the NVRAM-Manager signals this condition to the DEM and returns an error to the ECU state manager. The DEM and the ECU state manager have to decide about further measures that have to be taken. These steps are beyond the scope of the NvM module and are handled in the specifications of DEM and ECU state manager.

[SWS_NvM_00701] [Applications have to adhere to the following rules during multi block read requests for implicit synchronization between application and NVRAM manager:

The ECU state manager issues the `NvM_ReadAll`.

1. The ECU state manager can use polling to get the status of the request or can be informed via a callback function.
2. During `NvM_ReadAll`, a single block callback (if configured) will be invoked after having completely processed a NVRAM block. These callbacks enable the RTE to start each SW-C individually.] ()

7.2.2.15.5 Multi block write requests (`NvM_WriteAll`)

This request must only be triggered by the ECU state manager at shutdown of the system. This request writes the contents of all modified permanent RAM blocks to NV memory. By calling this request only during ECU shutdown, the ECU state manager can ensure that no SW component is able to modify data in the RAM blocks until the end of the operation. These measures are beyond the scope of the NvM module and are handled in the specifications of the ECU state manager.

[SWS_NvM_00702] [Applications have to adhere to the following rules during multi block write requests for implicit synchronization between application and NVRAM manager:

1. The ECU state manager issues the `NvM_WriteAll` request which transfers control to the NvM module.
2. The ECU state manager can use polling to get the status of the request or can be informed via a callback function.] ()

7.2.2.15.6 Cancel Operation (`NvM_CancelWriteAll`)

This request cancels a pending `NvM_WriteAll` request. This is an asynchronous request and can be called to terminate a pending `NvM_WriteAll` request.

[SWS_NvM_00703] [`NvM_CancelWriteAll` request shall only be used by the ECU state manager.] ()

7.2.2.15.7 Modification of administrative blocks

For administrative purposes an administrative block is part of each configured NVRAM block (ref. to ch. 7.1.3.4).

[SWS_NvM_00704] [If there is a pending single-block operation for a NVRAM block, the application is not allowed to call any operation that modifies the administrative block, like `NvM_SetDataIndex`, `NvM_SetBlockProtection`, `NvM_SetRamBlockStatus`, until the pending job has finished.] ()

7.2.2.16 Normal and extended runtime preparation of NVRAM blocks

This subchapter is supposed to provide a short summary of normal and extended runtime preparation of NVRAM blocks. The detailed behavior regarding the handling of NVRAM blocks during start-up is specified in chapter 8.1.3.3.1.

Depending on the two configuration parameters `NvMDynamicConfiguration` and `NvMResistantToChangedSw` the NVRAM Manager shall behave in different ways during start-up, i.e. while processing the request `NvM_ReadAll()`.

If `NvMDynamicConfiguration` is set to `FALSE`, the NVRAM Manager shall ignore the stored configuration ID (see [SWS NvM_00034](#)) and continue with the normal runtime preparation of NVRAM blocks. In this case the RAM block shall be checked for its validity. If the RAM block content is detected to be invalid the NV block shall be checked for its validity. A NV block which is detected to be valid shall be copied to its assigned RAM block. If an invalid NV Block is detected default data shall be loaded.

If `NvMDynamicConfiguration` is set to `TRUE` and a configuration ID mismatch is detected, the extended runtime preparation shall be performed for those NVRAM blocks which are configured with `NvMResistantToChangedSw(FALSE)`. In this case default data shall be loaded independent of the validity of an assigned RAM or NV block.

7.2.2.17 Communication and explicit synchronization between application and NVRAM manager

In contrast to the implicit synchronization between the application and the NvM module (see section 7.2.2.15) an optional (i.e. configurable) explicit synchronization mechanism is available. It is realized by a RAM mirror in the NvM module. The data is transferred by the application in both directions via callback routines, called by the NvM module.

Here is a short analysis of this mechanism:

- The advantage is that applications can control their data in a better way. They are responsible for copying consistent data to and from the NvM module's RAM mirror, so they know the point in time. The RAM block is never in an inconsistent state due to concurrent accesses.
- The drawbacks are the additional RAM which needs to have the same size as the largest NVRAM block that uses this mechanism and the necessity of an additional copy between two RAM locations for every operation.

This mechanism especially enables the sharing of NVRAM blocks by different applications, if there is a module that synchronizes these applications and is the owner of the NVRAM block from the NvM module's perspective.

[SWS_NvM_00511] [For every NVRAM block there shall be the possibility to configure the usage of an explicit synchronization mechanism by the parameter `NvMBlockUseSyncMechanism`.] ()

[SWS_NvM_00512] [The NvM module must not allocate a RAM mirror if no block is configured to use the explicit synchronization mechanism.] ()

[SWS_NvM_00513] [The NvM module shall allocate only one RAM mirror if at least one block is configured to use the explicit synchronization mechanism. This RAM mirror must not exceed the size of the longest NVRAM block configured to use the explicit synchronization mechanism.] ()

[SWS_NvM_00514] [The NvM module shall use the internal mirror as buffer for all operations that read and write the RAM block of those NVRAM blocks with NvMBlockUseSyncMechanism == TRUE. The buffer must not be used for the other NVRAM blocks.] ()

[SWS_NvM_00515] [The NvM module shall call the routine NvMWriteRamBlockToNvM in order to copy the data from the RAM block to the mirror for all NVRAM blocks with NvMBlockUseSyncMechanism == TRUE. This routine must not be used for the other NVRAM blocks.] ()

[SWS_NvM_00516] [The NvM module shall call the routine NvMReadRamBlockFromNvM in order to copy the data from the mirror to the RAM block for all NVRAM blocks with NvMBlockUseSyncMechanism == TRUE. This routine must not be used for the other NVRAM blocks.] ()

[SWS_NvM_00517] [During a single block request if the routines NvMReadRamBlockFromNvM return E_NOT_OK, then the NvM module shall retry the routine call NvMRepeatMirrorOperations times. Thereafter the single block read job shall set the block specific job result to NVM_REQ_NOT_OK and shall report NVM_E_REQ_FAILED to the DEM.] ()

[SWS_NvM_00839] [In the case the NvMReadRamBlockFromNvM routine returns E_NOT_OK, the NvM module shall retry the routine call in the next call of the NvM_MainFunction.] ()

[SWS_NvM_00579] [During a single block request if the routines NvMWriteRamBlockToNvM return E_NOT_OK, then the NvM module shall retry the routine call NvMRepeatMirrorOperations times. Thereafter the single block write job shall set the block specific job result to NVM_REQ_NOT_OK and shall report NVM_E_REQ_FAILED to the DEM.] ()

[SWS_NvM_00840] [In the case the NvMWriteRamBlockToNvM routine returns E_NOT_OK, the NvM module shall retry the routine call in the next call of the NvM_MainFunction.] ()

[SWS_NvM_00837] [During a multi block request(NvM_WriteAll) if the routines NvMWriteRamBlockToNvM return E_NOT_OK, then the NvM module shall retry the routine call NvMRepeatMirrorOperations times. Thereafter the job of the function NvM_WriteAll shall set the block specific job result to NVM_REQ_NOT_OK and shall report NVM_E_REQ_FAILED to the DEM.] ()

[SWS_NvM_00838] [During a multi block request(NvM_ReadAll) if the routines NvMReadRamBlockFromNvM return E_NOT_OK, then the NvM module shall retry the routine call NvMRepeatMirrorOperations times. Thereafter the job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_NOT_OK and shall report NVM_E_REQ_FAILED to the DEM.] ()

The following two sections clarify the differences when using the explicit synchronization mechanism, compare to 7.2.2.15.1 and 7.2.2.15.2.

7.2.2.17.1 Write requests (NvM_WriteBlock or NvM_WritePRAMBlock)

[SWS_NvM_00705] [Applications have to adhere to the following rules during write request for explicit synchronization between application and NVRAM manager:

1. The application fills a RAM block with the data that has to be written by the NvM module.
2. The application issues the NvM_WriteBlock or NvM_WritePRAMBlock request.
3. The application might modify the RAM block until the routine NvMWriteRamBlockToNvM is called by the NvM module.
4. If the routine NvMWriteRamBlockToNvM is called by the NvM module, then the application has to provide a consistent copy of the RAM block to the destination requested by the NvM module. The application can use the return value E_NOT_OK in order to signal that data was not consistent. The NvM module will accept this NvMRepeatMirrorOperations times and then postpones the request and continues with its next request.
5. Continuation only if data was copied to the NvM module:
6. From now on the application can read and write the RAM block again.
7. An application can use polling to get the status of the request or can be informed via a callback routine asynchronously.

Note: The application may combine several write requests to different positions in one RAM block, if NvM_WriteBlock or NvM_WritePRAMBlock was requested, but not yet processed by the NvM module. The request was not processed, if the callback routine NvMWriteRamBlockToNvM was not called.] ()

7.2.2.17.2 Read requests (NvM_ReadBlock or NvM_ReadPRAMBlock)

[SWS_NvM_00706] [Applications have to adhere to the following rules during read request for explicit synchronization between application and NVRAM manager:

1. The application provides a RAM block that has to be filled with NVRAM data from the NvM module's side.
2. The application issues the NvM_ReadBlock or NvM_ReadPRAMBlock request.
3. The application might modify the RAM block until the routine NvMReadRamBlockFromNvM is called by the NvM module.
4. If the routine NvMReadRamBlockFromNvM is called by the NvM module, then the application copy the data from the destination given by the NvM module to the RAM block. The application can use the return value E_NOT_OK in order

to signal that data was not copied. The NvM module will accept this NvMRepeatMirrorOperations times and then postpones the request and continues with its next request.

5. Continuation only if data was copied from the NvM module:

6. Now the application finds the NV block values in the RAM block.

7. The application can use polling to get the status of the request or can be informed via a callback routine.

Note: The application may combine several read requests to different positions in one NV block, if NvM_ReadBlock or NvM_ReadPRAMBlock was requested, but not yet processed by the NvM module. The request was not processed, if the callback routine NvMReadRamBlockFromNvM was not called.

Note: NvM_RestoreBlockDefaults and NvM_RestorePRAMBlockDefaults works similarly to NvM_ReadBlock.] ()

7.2.2.17.3 Multi block read requests (NvM_ReadAll)

This request may be triggered only by the ECU state manager at system startup. This request fills all configured permanent RAM blocks with necessary data for startup.

If the request fails or the request is handled only partially successful, the NVRAM-Manager signals this condition to the DEM and returns an error to the ECU state manager. The DEM and the ECU state manager have to decide about further measures that have to be taken. These steps are beyond the scope of the NvM module and are handled in the specifications of DEM and ECU state manager.

Normal operation:

1. The ECU state manager issues the NvM_ReadAll.
2. The ECU state manager can use polling to get the status of the request or can be informed via a callback function.
3. During NvM_ReadAll job, if a synchronization callback (NvM_ReadRamBlockFromNvm) is configured for a block it will be called by the NvM module. In this callback the application shall copy the data from the destination given by the NvM module to the RAM block. The application can use the return value E_NOT_OK in order to signal that data was not copied. The NvM module will accept this NvMRepeatMirrorOperations times and then report the read operation as failed.
4. Now the application finds the NV block values in the RAM block if the read operation was successful.
5. During NvM_ReadAll, a single block callback (if configured) will be invoked after having completely processed a NVRAM block. These callbacks enable the RTE to start each SW-C individually.

7.2.2.17.4 Multi block write requests (NvM_WriteAll)

This request must only be triggered by the ECU state manager at shutdown of the system. This request writes the contents of all modified permanent RAM blocks to NV memory. By calling this request only during ECU shutdown, the ECU state manager can ensure that no SW component is able to modify data in the RAM blocks until the end of the operation. These measures are beyond the scope of the NvM module and are handled in the specifications of the ECU state manager.

Normal operation:

1. The ECU state manager issues the `NvM_WriteAll` request which transfers control to the NvM module.
2. During `NvM_WriteAll` job, if a synchronization callback (`NvM_WriteRamBlockToNvM`) is configured for a block it will be called by the NvM module. In this callback the application has to provide a consistent copy of the RAM block to the destination requested by the NvM module. The application can use the return value `E_NOT_OK` in order to signal that data was not consistent. The NvM module will accept this `NvMRepeatMirrorOperations` times and then report the write operation as failed.
3. Now the application can read and write the RAM block again.
4. The ECU state manager can use polling to get the status of the request or can be informed via a callback function.

7.2.2.18 Static Block ID Check

Note: NVRAM Manager stores the NV Block Header including the Static Block ID in the NV Block each time the block is written to NV memory. When a block is read, its Static Block ID is compared to the requested block ID. This permits to detect hardware failures which cause a wrong block to be read.

[SWS_NvM_00523] [The NVRAM Manager shall store the Static Block ID field of the Block Header each time the block is written to NV memory.] (SRS_Mem_08555)

[SWS_NvM_00524] [The NVRAM Manager shall check the Block Header each time the block is read from NV memory.] (SRS_Mem_08555)

[SWS_NvM_00525] [If the Static Block ID check fails then the failure `NVM_E_WRONG_BLOCK_ID` is reported to DEM.] ()

[SWS_NvM_00580] [If the Static Block ID check fails then the read error recovery is initiated.

Hint: A check shall be made during configuration to ensure that all Static Block IDs are unique.] ()

7.2.2.19 Read Retry

[SWS_NvM_00526] [If the NVRAM manager detects a failure during a read operation from NV memory, a CRC error then one or more additional read attempts shall be made, as configured by NVM_MAX_NUM_OF_READ_RETRIES, before continuing to read the redundant NV Block.] (SRS_Mem_08554)

[SWS_NvM_00581] [If the NVRAM manager detects a failure during a read operation from NV memory, a CRC error then one or more additional read attempts shall be made, as configured by NVM_MAX_NUM_OF_READ_RETRIES, before continuing to read the ROM Block.] (SRS_Mem_08554)

[SWS_NvM_00582] [If the NVRAM manager detects a failure during a read operation from NV memory, a Static Block ID check then one or more additional read attempts shall be made, as configured by NVM_MAX_NUM_OF_READ_RETRIES, before continuing to read the redundant NV Block.] (SRS_Mem_00129)

[SWS_NvM_00583] [If the NVRAM manager detects a failure during a read operation from NV memory, a Static Block ID check then one or more additional read attempts shall be made, as configured by NVM_MAX_NUM_OF_READ_RETRIES, before continuing to read the ROM Block.] ()

7.2.2.20 Write Verification

When a RAM Block is written to NV memory the NV block shall be immediately read back and compared with the original content in RAM Block if the behaviour is enabled by NVM_WRITE_VERIFICATION.

[SWS_NvM_00527] [Comparison between original content in RAM Block and the block read back shall be performed in steps so that the number of bytes read and compared is not greater than as specified by the configuration parameter NVM_WRITE_VERIFICATION_DATA_SIZE.] (SRS_Mem_08554, SRS_Mem_08556)

[SWS_NvM_00528] [If the original content in RAM Block is not the same as read back then the production code error NVM_E_VERIFY_FAILED shall be reported to DEM.] (SRS_Mem_08556)

[SWS_NvM_00529] [If the original content in RAM Block is not the same as read back then write retries shall be performed as specified in this document.] (SRS_Mem_08554, SRS_Mem_08556)

[SWS_NvM_00530] [If the read back operation fails then no read retries shall be performed.] ()

7.2.2.21 Comparing NV data in NvM

In order to avoid unnecessary write operations in NV memory, if the NV data of a specific RAM Block was not updated during runtime, the NvM module offers a CRC based compare mechanism which can be applied while processing a write job.

[SWS_NvM_00849] [The NvM module shall provide an option to skip writing of unchanged data by implementing a CRC based compare mechanism.] (SRS_Mem_00136)

Note: In general, there is a risk that some changed content of an RAM Block leads to the same CRC as the initial content so that an update might be lost if this option is used. Therefore this option should be used only for blocks where this risk can be tolerated.

[SWS_NvM_00850] [For every NVRAM Block there shall be the possibility to configure the usage of the CRC based compare mechanism by the parameter NvMBlockUseCRCCompMechanism.] (SRS_Mem_00136)

[SWS_NvM_00851] [The NvM module shall provide the CRC based compare functionality only for NVRAM blocks with the parameters NvMCalcRamBlockCrc and NvMBlockUseCrc set to true.] (SRS_Mem_00136)

7.2.2.22 NvM and BswM interaction

[SWS_NvM_00745] [If BswMMultiBlockJobStatusInformation is true the NVM shall inform the BSWM about the current state of a multi block job via BswM_NvM_CurrentJobMode and the configured multi job callback should not be called.] ()

[SWS_NvM_00746] [If BswMBlockStatusInformation is true, the NVM shall inform the BSWM about the current state of the block via BswM_NvM_CurrentBlockMode.] ()

7.2.2.23 NvM behaviour in case of Block locked

The `NvM_SetBlockLockStatus` API service shall only be usable by BSW Components, it is not published as Service in the SWC-Description. Thus it will not be accessible via RTE.

[SWS_NvM_00751] [If the API was called with parameter `Locked` as `TRUE`, the NVM shall guarantee that The NV contents associated to the NVRAM block identified by `BlockId`, will not be modified by any request. The Block shall be skipped during `NvM_WriteAll`, other requests, that are `NvM_WriteBlock`, `NvM_WritePRAMBlock`, `NvM_InvalidateNvBlock`, `NvM_EraseNvBlock`, shall be rejected.] ()

[SWS_NvM_00752] [If the API was called with parameter `Locked` as `TRUE`, the NVM shall guarantee that at next start-up, during processing of `NvM_ReadBlock` or `NvM_ReadPRAMBlock`, this NVRAM block shall be loaded from NV memory.] ()

[SWS_NvM_00753] [If the `Locked` parameter got the value `FALSE`, the NVM shall guarantee normal processing of this NVRAM block as specified by AUTOSAR.] ()

[SWS_NvM_00754] [The setting made using this service shall not be changeable by `NvM_SetRamBlockStatus`, nor by `NvM_SetBlockProtection`.] ()

7.2.2.23.1 Use Case

Save new Data for an NVRAM block via diagnostic services into NV memory. These data shall be made available to the SW-C(s) with next ECU start-up, i.e. they shall neither be overwritten by a request originating from an SW-C, nor be overwritten with permanent RAM block's data during shut-down (`NvM_WriteAll`).

7.2.2.23.2 Usage (by DCM):

1. DCM requests `NvM_SetBlockLockStatus(<BlockId>, FALSE)`, in order to re-enable writing to this block. (It might be locked by executing this procedure before).
2. DCM requests `NvM_WriteBlock(<blockId>, <DataBuffer>)`
3. DCM polls for completion of write request (using `NvM_GetErrorStatus()`)
4. On success (`NVM_REQ_OK`), the DCM issues `NvM_SetBlockLockStatus(<BlockId>, TRUE)`.

7.3 Development Errors

[SWS_NvM_00023]	[The	Development	errors
- <code>NVM_E_PARAM_BLOCK_ID</code>	(<code>0x0A</code>)		
- <code>NVM_E_PARAM_BLOCK_TYPE</code>	(<code>0x0B</code>)		
- <code>NVM_E_PARAM_BLOCK_DATA_IDX</code>	(<code>0x0C</code>)		

- NVM_E_PARAM_ADDRESS (0x0D)
- NVM_E_PARAM_DATA (0x0E)
- NVM_E_PARAM_POINTER (0x0F)
- NVM_E_BLOCK_WITHOUT_DEFAULTS (0x11)

shall be detectable by the NvM module when API requests are called with wrong parameters, depending on whether the build version mode is development mode.] (SRS_BSW_00385, SRS_BSW_00386, SRS_BSW_00406, SRS_BSW_00337, SRS_BSW_00327, SRS_BSW_00331)

[SWS_NvM_00586] [The Development error NVM_E_NOT_INITIALIZED (0x14) shall be detectable by the NvM module when NVRAM manager is still not initialized, depending on whether the build version mode is development mode.] ()

[SWS_NvM_00587] [The Development error NVM_E_BLOCK_PENDING (0x15) shall be detectable by the NvM module when API read/write/control request failed because a block with the same ID is already listed or currently in progress, depending on whether the build version mode is development mode.] ()

[SWS_NvM_00590] [The development error NVM_E_BLOCK_CONFIG (0x18) shall be detectable by the NvM module when the service is not possible with this block configuration, depending on whether the build version mode is development mode.] ()

[SWS_NvM_00747] [The development error NVM_E_BLOCK_LOCKED (0x19) shall be detectable by the NvM module when API write request failed for this block because RAM block is locked, depending on whether the build version mode is development mode.] ()

[SWS_NvM_00887] [The NVM_E_BLOCK_WITHOUT_DEFAULTS (0x11) development error shall be detectable by the NvM module when either the NvM_RestoreBlockDeafults or NvM_RestorePRAMBlockDefaults is called for a valid block ID that has no default data and no NvMInitBlockCallback configured for it.] ()

7.4 Production Errors

7.4.1 NVM_E_HARDWARE

[SWS_NvM_00835][

Error Name:	NVM_E_HARDWARE	
Short Description:	Reading from or writing to non volatile memory failed	
Long Description:	If read job (multi job or single job read) fails either because the MemIf reports MEMIF_JOB_FAILED, MEMIF_BLOCK_INCONSISTENT or a CRC mismatch occurs or if a write/invalidate/erase job fails because the MemIf reports MEMIF_JOB_FAILED, NvM shall report NVM_E_HARDWARE to the DEM.	
Detection Criteria:	Fail	MemIf reports MEMIF_JOB_FAILED, MEMIF_BLOCK_INCONSISTENT or a CRC mismatch occurs during read / write / invalidate / erase operation.
	Pass	Read / write / invalidate / erase is successfull.

		(MemIf does not report MEMIF_JOB_FAILED , MEMIF_BLOCK_INCONSISTENT and no CRC mismatch occurs)
Secondary Parameters:	The condition under which the FAIL and/or PASS detection is active: Every time a read / write / invalidate / erase is requested for the block NvM shall report if the condition of the block changed.	
Time Required:	Not applicabale. (there is no timeout monitoring in the NvM)	
Monitor Frequency	continous	

] ()

7.5 Extended Production Errors

<i>Type or error</i>	<i>Related error code</i>	<i>Value [hex]</i>
The processing of the read service detects an inconsistency	NVM_E_INTEGRITY_FAILED	Assigned by DEM
The processing of the service fails	NVM_E_REQ_FAILED	Assigned by DEM
The Static Block ID check during read failed	NVM_E_WRONG_BLOCK_ID	Assigned by DEM
The write verification failed	NVM_E_VERIFY_FAILED	Assigned by DEM
There is a loss of redundancy for a block of redundant type	NVM_E_LOSS_OF_REDUNDANCY	Assigned by DEM
The NVRAM Manager's job queue overflow occurs	NVM_E_QUEUE_OVERFLOW	Assigned by DEM
There is a write attempt to a NVRAM block with write protection	NVM_E_WRITE_PROTECTED	Assigned by DEM

[SWS_NvM_00591] [The extended production error NVM_E_INTEGRITY_FAILED (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when API request integrity failed, depending on whether the build version mode is in production mode.] ()

[SWS_NvM_00592] [The extended production error NVM_E_REQ_FAILED (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when API request failed, depending on whether the build version mode is in production mode.] ()

[SWS_NvM_00593] [The extended production error NVM_E_WRONG_BLOCK_ID (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when Static Block ID check failed, depending on whether the build version mode is in production mode.] (SRS_Mem_08555)

[SWS_NvM_00594] [The extended production error NVM_E_VERIFY_FAILED (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when write Verification failed, depending on whether the build version mode is in production mode.] ()

[SWS_NvM_00595] [The extended production error NVM_E_LOSS_OF_REDUNDANCY (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when loss of redundancy, depending on whether the build version mode is in production mode.] ()

[SWS_NvM_00722] [The extended production error NVM_E_QUEUE_OVERFLOW (value assigned by DEM, see container NvmDemEventParameterRefs) shall be detectable by the NvM module when an NVRAM Managers job queue overflow occurs.] ()

[SWS_NvM_00723] [The extended production error NVM_E_WRITE_PROTECTED (value assigned by DEM) shall be detectable by the NvM module when a write attempt to a NVRAM block with write protection occurs.] ()

[SWS_NvM_00871] [Each time a request is made to the NvM, the job of that request, if encountering an error situation, shall report the corresponding production error.]()

7.5.1 NVM_E_INTEGRITY_FAILED

Error Name:	NVM_E_INTEGRITY_FAILED	
Short Description:	Processin of the read service detects an inconsistency.	
Long Description:	If the read for a block detects that the data and/or CRC are corrupted based on the CRC check performed after the read was finished successfully (JobEndNotification from underlying memory module). This only applies for blocks configured with CRC.	
Detection Criteria:	Fail	See SWS_NvM_00864
	Pass	See SWS_NvM_00872
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: CRC checking is performed each time a block with CRC is read successfully by the underlying memory module and it will indicate failure or pass.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00864] [Fail condition: NVM_E_INTEGRITY_FAILED is reported by the NvM module if the processing of a read request will detect, via the CRC checking, corruption of the data and/or CRC of the block that was subject to the read operation.]()

[SWS_NvM_00872] [Pass condition: when requirement SWS_NvM_00864 does not apply, meaning the data of the block is not corrupted in terms of CRC checking.]()

7.5.2 NVM_E_REQ_FAILED

Error Name:	NVM_E_REQ_FAILED	
Short Description:	Processin of the read service failed at a lower layer in the MemStack architecture, including all retries.	
Long Description:	If the underlying layer reports JobErrorNotification, indicating that the request failed, either after it was accepted by the underlying memory module or because the module refused the request. This is done after all retries also failed.	
Detection Criteria:	Fail	See SWS_NvM_00865
	Pass	See: SWS_NvM_00873
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: check is performed to see if the job was accepted or not and, if accepted, to see if it finished successfully or not.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00865] [Fail condition: NVM_E_REQ_FAILED is reported by the NvM module if a user request is either rejected and the number of configured retries expired or if it was accepted and then failed, while being processed by the underlying memory stack module.]()

[SWS_NvM_00873] [Pass condition: when requirement SWS_NvM_00865 does not apply, meaning that the user request was accepted by the undelying layer, either from the first attempt or from one of the retries, and that it finished successfully, from the point of view of the underlying layer (job result is MEMIF_JOB_OK).]()

7.5.3 NVM_E_WRONG_BLOCK_ID

Error Name:	NVM_E_WRONG_BLOCK_ID	
Short Description:	Static block ID check, during read, indicates failure.	
Long Description:	If the read was successfully finished by the underlying memory module but the Static ID check failed (meaning the block ID that was read is not the same as the block ID for which the read was requested).	
Detection Criteria:	Fail	See SWS_NvM_00866
	Pass	See SWS_NvM_00874
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: check is performed each time the reading of a block is finished successfully by the underlying memory module, if the block is configured to have the Static ID checking performed for it.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00866] [Fail condition: NVM_E_WRONG_BLOCK_ID is reported by the NvM module if, after the block data is successfully read from the non-volatile memory, the Static ID that was retrieved is not the same as the current one, for the block the read was requested for.]()

[SWS_NvM_00874] [Pass condition: when requirement SWS_NvM_00866 does not apply, meaning that the block ID that was read from the non-volatile memory is the same as the block ID for which the read was requested.]()

7.5.4 NVM_E_VERIFY_FAILED

Error Name:	NVM_E_VERIFY_FAILED	
Short Description:	The write verification failed.	
Long Description:	If, after a successfully finished write, the verification for the written data fails.	
Detection Criteria:	Fail	See SWS_NvM_00867
	Pass	See SWS_NvM_00875
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: a check is performed each time a block that is configured to have write verification performed on it, has a write operation successfully finished.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00867] [Fail condition: NVM_E_VERIFY_FAILED is reported by the NvM module if, after a successful write, the write verification indicates failure and the configured number of retries has expired.]()

[SWS_NvM_00875] [Pass condition: when requirement SWS_NvM_00867 does not apply, meaning that the write verification indicates success, the latest for the last retry attempt.]()

7.5.5 NVM_E_LOSS_OF_REDUNDANCY

Error Name:	NVM_E_LOSS_OF_REDUNDANCY	
Short Description:	A redundant block has lost the redundancy.	
Long Description:	A redundant block has the same contents written in two different block instances – hence the redundancy. If the contents are different, if the first instance becomes corrupted or if the first instance cannot be read then NvM will report this fault.	
Detection Criteria:	Fail	See SWS_NvM_00868
	Pass	See SWS_NvM_00876
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: checks are performed whenever a reading is requested for a redundant block.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00868] [Fail condition: NVM_E_LOSS_OF_REDUNDANCY is reported by the NvM module if the reading performed over a REDUNDANT block indicates the block has lost its redundancy.]()

Note: The loss of redundancy is detected if the reading of the first instance of the block fails and the reading of the second instance of the block is finished successfully.

[SWS_NvM_00876] [Pass condition: when requirement SWS_NvM_00868 does not apply, meaning that the NvM did not detect the loss of redundancy for a REDUNDANT block.]()

7.5.6 NVM_E_QUEUE_OVERFLOW

Error Name:	NVM_E_QUEUE_OVERFLOW	
Short Description:	More requests were passed to NvM than the maximum that can be stored in the queue.	
Long Description:	NvM, when accepting a request, queues it. The actual processing of the request is not synchronous to the request being made. Therefore, if the number of requests made to NvM exceeds the size of the queue and none of the ones in the queue finishes, NvM will not have any more space where to store the requests. In this case it will report the fault to Dem.	
Detection Criteria:	Fail	See SWS_NvM_00869
	Pass	See SWS_NvM_00877
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: check is performed each time a job is requested from the NvM.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00869] [Fail condition: NVM_E_QUEUE_OVERFLOW is reported by the NvM module if a request is made that cannot be stored in the NvM queue (be it standard or immediate) as all configured queue positions of the related queue are already containing user requests.]()

[SWS_NvM_00877] [Pass condition: when requirement SWS_NvM_00869 does not apply, meaning that the related NvM queue (standard or immediate) is not full an can store the request being made.]()

7.5.7 NVM_E_WRITE_PROTECTED

Error Name:	NVM_E_WRITE_PROTECTED	
Short Description:	A write is requested for a write protected block.	
Long Description:	If a block has the write protection active (either configured or set by explicit request) and a write request is made for the block, NvM will detect this and report the fault to Dem.	
Detection Criteria:	Fail	See: SWS_NvM_00870
	Pass	See: SWS_NvM_00878
Secondary Parameters:	The condition under which the FAIL or PASS detection is active: check is performed for each write request.	
Time Required:	Not applicable. There is no timeout monitoring or constraint for NvM.	
Monitor Frequency	continuous	

[SWS_NvM_00870] [The production error NVM_E_WRITE_PROTECTED is reported by NvM if a write request is made for a block that has the write protection active.]()

[SWS_NvM_00878] [Pass condition: when requirement SWS_NvM_00870 does not apply, meaning that the write request is not made for a block with the write protection active.]()

7.6 Error detection

[SWS_NvM_00027] [If development error detection is enabled for NvM module, the function NvM_SetDataIndex shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] (SRS_BSW_00323, SRS_BSW_00385, SRS_BSW_00386, SRS_BSW_00406, SRS_BSW_00327, SRS_BSW_00331)

[SWS_NvM_00598] [If development error detection is enabled for NvM module, the function NvM_SetDataIndex shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00599] [If development error detection is enabled for NvM module, the function NvM_SetDataIndex shall report the DET error NVM_E_PARAM_BLOCK_DATA_IDX when DataIndex parameter exceeds the total number of configured datasets **[SWS_NvM_00444, [SWS_NvM_00445.] ()**

[SWS_NvM_00601] [If development error detection is enabled for NvM module, the function NvM_SetDataIndex shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00602] [If development error detection is enabled for NvM module, the function NvM_GetDataIndex shall report the DET error NVM_E_NOT_INITIALIZED when NVM not yet initialized.] ()

[SWS_NvM_00604] [If development error detection is enabled for NvM module, the function NvM_GetDataIndex shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00605] [If development error detection is enabled for NvM module, the function NvM_GetDataIndex shall report the DET error NVM_E_PARAM_DATA when a NULL pointer is passed via the parameter DataIndexPtr.] ()

[SWS_NvM_00606] [If development error detection is enabled for NvM module, the function NvM_SetBlockProtection shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00607] [If development error detection is enabled for NvM module, the function NvM_SetBlockProtection shall report the DET error

NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00608] [If development error detection is enabled for NvM module, the function NvM_SetBlockProtection shall report the DET error NVM_E_BLOCK_CONFIG when the NVRAM block is configured with NvMWriteBlockOnce = TRUE.] ()

[SWS_NvM_00609] [If development error detection is enabled for NvM module, the function NvM_SetBlockProtection shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00759] [If development error detection is enabled for NvM module, the function NvM_SetBlockProtection shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00610] [If development error detection is enabled for NvM module, the function NvM_GetErrorStatus shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00611] [If development error detection is enabled for NvM module, the function NvM_GetErrorStatus shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00612] [If development error detection is enabled for NvM module, the function NvM_GetErrorStatus shall report the DET error NVM_E_PARAM_DATA when a NULL pointer is passed via the parameter RequestResultPtr.] ()

[SWS_NvM_00613] [If development error detection is enabled for NvM module, the function NvM_GetVersionInfo shall report the DET error NVM_E_PARAM_POINTER when a NULL pointer is passed via the parameter versioninfo.] ()

[SWS_NvM_00614] [If development error detection is enabled for NvM module, the function NvM_ReadBlock shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00615] [If development error detection is enabled for NvM module, the function NvM_ReadBlock shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00616] [If development error detection is enabled for NvM module, the function NvM_ReadBlock shall report the DET error NVM_E_PARAM_ADDRESS when no permanent RAM block and no explicit synchronization is configured and a NULL pointer is passed via the parameter NvM_DstPtr.] ()

[SWS_NvM_00618] [If development error detection is enabled for NvM module, the function NvM_ReadBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00823] [If development error detection is enabled for NvM module, the function NvM_ReadPRAMBlock shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00824] [If development error detection is enabled for NvM module, the function NvM_ReadPRAMBlock shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00825] [If development error detection is enabled for NvM module, the function NvM_ReadPRAMBlock shall report the DET error NVM_E_PARAM_ADDRESS when no permanent RAM block and no explicit synchronization is configured and a NULL pointer is passed via the parameter NvM_DstPtr.] ()

[SWS_NvM_00826] [If development error detection is enabled for NvM module, the function NvM_ReadPRAMBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00619] [If development error detection is enabled for NvM module, the function NvM_WriteBlock shall report the DET error NVM_E_NOT_INITIALIZED when NVM not yet initialized.] ()

[SWS_NvM_00620] [If development error detection is enabled for NvM module, the function NvM_WriteBlock shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00622] [If development error detection is enabled for NvM module, the function NvM_WriteBlock shall report the DET error NVM_E_PARAM_ADDRESS when no permanent RAM block and no explicit synchronization is configured and a NULL pointer is passed via the parameter NvM_SrcPtr.] ()

[SWS_NvM_00624] [If development error detection is enabled for NvM module, the function NvM_WriteBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00748] [If development error detection is enabled for NvM module, the function NvM_WritePRAMBlock shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00827] [If development error detection is enabled for NvM module, the function NvM_WritePRAMBlock shall report the DET error NVM_E_NOT_INITIALIZED when NVM not yet initialized.] ()

[SWS_NvM_00828] [If development error detection is enabled for NvM module, the function NvM_WritePRAMBlock shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00829] [If development error detection is enabled for NvM module, the function NvM_WritePRAMBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00830] [If development error detection is enabled for NvM module, the function NvM_WritePRAMBlock shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00625] [If development error detection is enabled for NvM module, the function NvM_RestoreBlockDefaults shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00626] [If development error detection is enabled for NvM module, the function NvM_RestoreBlockDefaults shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00628] [If development error detection is enabled for NvM module, the function NvM_RestoreBlockDefaults shall report the DET error NVM_E_BLOCK_CONFIG when Default data is not available/configured for the referenced NVRAM block.] ()

[SWS_NvM_00629] [If development error detection is enabled for NvM module, the function NvM_RestoreBlockDefaults shall report the DET error NVM_E_PARAM_ADDRESS when no permanent RAM block and no explicit synchronization is configured and a NULL pointer is passed via the parameter NvM_DstPtr.] ()

[SWS_NvM_00630] [If development error detection is enabled for NvM module, the function NvM_RestoreBlockDefaults shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00831] [If development error detection is enabled for NvM module, the function NvM_RestorePRAMBlockDefaults shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00832] [If development error detection is enabled for NvM module, the function NvM_RestorePRAMBlockDefaults shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00833] [If development error detection is enabled for NvM module, the function NvM_RestorePRAMBlockDefaults shall report the DET error NVM_E_BLOCK_CONFIG when Default data is not available/configured for the referenced NVRAM block.] ()

[SWS_NvM_00834] [If development error detection is enabled for NvM module, the function NvM_RestorePRAMBlockDefaults shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00631] [If development error detection is enabled for NvM module, the function NvM_EraseNvBlock shall report the DET error NVM_E_NOT_INITIALIZED when the NVM is not yet initialized.] ()

[SWS_NvM_00632] [If development error detection is enabled for NvM module, the function NvM_EraseNvBlock shall report the DET error NVM_E_BLOCK_PENDING when the NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00635] [If development error detection is enabled for NvM module, the function NvM_EraseNvBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00636] [If development error detection is enabled for NvM module, the function NvM_EraseNvBlock shall report the DET error NVM_E_BLOCK_CONFIG when the NVRAM block has not immediate priority.] ()

[SWS_NvM_00757] [If development error detection is enabled for NvM module, the function NvM_EraseNvBlock shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00637] [If development error detection is enabled for NvM module, the function NvM_CancelWriteAll shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00638] [If development error detection is enabled for NvM module, the function NvM_InvalidateNvBlock shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00639] [If development error detection is enabled for NvM module, the function NvM_InvalidateNvBlock shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00642] [If development error detection is enabled for NvM module, the function NvM_InvalidateNvBlock shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00756] [If development error detection is enabled for NvM module, the function NvM_InvalidateNvBlock shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00643] [If development error detection is enabled for NvM module, the function NvM_SetRamBlockStatus shall report the DET error NVM_E_NOT_INITIALIZED when NVM not yet initialized.] ()

[SWS_NvM_00644] [If development error detection is enabled for NvM module, the function NvM_SetRamBlockStatus shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00645] [If development error detection is enabled for NvM module, the function NvM_SetRamBlockStatus shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00758] [If development error detection is enabled for NvM module, the function NvM_SetRamBlockStatus shall report the DET error NVM_E_BLOCK_LOCKED when the block is locked.] ()

[SWS_NvM_00646] [If development error detection is enabled for NvM module, the function NvM_ReadAll shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00647] [If development error detection is enabled for NvM module, the function NvM_WriteAll shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00648] [If development error detection is enabled for NvM module, the function NvM_CancelJobs shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00649] [If development error detection is enabled for NvM module, the function NvM_CancelJobs shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00728] [If development error detection is enabled for NvM module, the function NvM_SetBlockLockStatus shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] ()

[SWS_NvM_00729] [If development error detection is enabled for NvM module, the function NvM_SetBlockLockStatus shall report the DET error NVM_E_BLOCK_PENDING when NVRAM block identifier is already queued or currently in progress.] ()

[SWS_NvM_00730] [If development error detection is enabled for NvM module, the function NvM_SetBlockLockStatus shall report the DET error NVM_E_BLOCK_CONFIG when the NVRAM block is configured with NvMWriteBlockOnce = TRUE.] ()

[SWS_NvM_00731] [If development error detection is enabled for NvM module, the function NvM_SetBlockLockStatus shall report the DET error NVM_E_PARAM_BLOCK_ID when the passed BlockID is out of range.] ()

[SWS_NvM_00863] [If development error detection is enabled for NvM module, the function NvM_ValidateAll shall report the DET error NVM_E_NOT_INITIALIZED when NVM is not yet initialized.] (SRS_Mem_00137)

7.7 Debugging

[SWS_NvM_00510] {OBSOLETE} [The internal state “INIT DONE” shall be available for debugging.] ()

8 API specification

8.1 API

8.1.1 Imported types

In this chapter all types included from the following files are listed:

[SWS_NvM_00446] [

<i>Module</i>	<i>Imported Type</i>
Dem	Dem_EventIdType
	Dem_EventStatusType
MemIf	MemIf_JobResultType
	MemIf_ModeType
	MemIf_StatusType
Std_Types	Std_ReturnType
	Std_VersionInfoType

] ()

8.1.2 Type definitions

8.1.2.1 NvM_RequestResultType

[SWS_NvM_00083] [The type NvM_RequestResultType is an asynchronous request result, which will be returned by the API service NvM_GetErrorStatus

[\[SWS_NvM_00015\]](#).] ()

[SWS_NvM_00470][

Name:	NvM_RequestResultType		
Type:	uint8		
Range:	NVM_REQ_OK	0x00	0x00: The last asynchronous request has been finished successfully. This shall be the default value after reset. This status shall have the value 0.
	NVM_REQ_NOT_OK	0x01	0x01: The last asynchronous read/write/control request has been finished unsuccessfully.
	NVM_REQ_PENDING	0x02	0x02: An asynchronous read/write/control request is currently pending.
	NVM_REQ_INTEGRITY_FAILED	0x03	0x03: The result of the last asynchronous request NvM_ReadBlock or NvM_ReadAll is a data integrity failure.

			Note: In case of NvM_ReadBlock the content of the RAM block has changed but has become invalid. The application is responsible to renew and validate the RAM block content.
	NVM_REQ_BLOCK_SKIPPED	0x04	0x04: The referenced block was skipped during execution of NvM_ReadAll or NvM_WriteAll, e.g. Dataset NVRAM blocks (NvM_ReadAll) or NVRAM blocks without a permanently configured RAM block.
	NVM_REQ_NV_INVALIDATED	0x05	0x05: The referenced NV block is invalidated.
	NVM_REQ_CANCELED	0x06	0x06: The multi block request NvM_WriteAll was canceled by calling NvM_CancelWriteAll. Or Any single block job request (NvM_ReadBlock, NvM_WriteBlock, NvM_EraseNvBlock, NvM_InvalidateNvBlock and NvM_RestoreBlockDefaults) was canceled by calling NvM_CancelJobs.
	NVM_REQ_REDUNDANCY_FAILED	0x07	0x07: The required redundancy of the referenced NV block is lost. (obsolete)
	NVM_REQ_RESTORED_FROM_ROM	0x08	0x08: The referenced NV block had the default values copied to the RAM image.
Description:	This is an asynchronous request result returned by the API service NvM_GetErrorStatus. The availability of an asynchronous request result can be additionally signaled via a callback function.		

] ()

8.1.2.2 NvM_BlockIdType

[SWS_NvM_00471] [

Name:	NvM_BlockIdType		
Type:	uint16		
Range:	0..2 ¹⁶ -1	--	--
Description:	Identification of a NVRAM block via a unique block identifier. Reserved NVRAM block IDs: 0 -> to derive multi block request results via NvM_GetErrorStatus 1 -> redundant NVRAM block which holds the configuration ID		

] ()

[SWS_NvM_00475] [The NVRAM block IDs shall be in a sequential order, i.e. the NVRAM manager does not need to be capable of handling non-sequential NVRAM block IDs.] ()

Example: If 50 NvM block have to be configured then their IDs are expected to be configured from 2 until 51 because block ID 0 and 1 are reserved for NvM internal use. So the sequential order will start with the ID 0 and increase one by one until 51, however only the blocks with IDs from 2 to 51 can and will be configured.

8.1.2.3 NvM_ConfigType

[SWS_NvM_00880][

Name:	NvM_ConfigType	
Type:	Structure	
Range:	implementation specific	--
Description:	Configuration data structure of the NvM module.	

] (SWS_BSW_00216)

Since this type is used for compliance purposes only (meaning that NvM_Init will now have a pointer to this type as parameter, based on SWS_BSW_00047) it will be left to the developer to chose how to implement it, considering it has no use for the NvM module in any way.

8.1.3 Function definitions

8.1.3.1 Synchronous requests

8.1.3.1.1 NvM_Init

[SWS_NvM_00447] [

Service name:	NvM_Init		
Syntax:	void	const	NvM_ConfigType* NvM_Init(ConfigPtr)
Service ID[hex]:	0x00		
Sync/Async:	Synchronous		
Reentrancy:	Non Reentrant		
Parameters (in):	ConfigPtr	Pointer to the selected configuration set.	
Parameters (inout):	None		
Parameters (out):	None		
Return value:	None		
Description:	Service for resetting all internal variables.		

] (SRS_BSW_00414, SWS_BSW_00047)

[SWS_NvM_00881] [The Configuration pointer ConfigPtr shall always have a NULL_PTR value.] ()

The Configuration pointer ConfigPtr is currently not used and shall therefore be set to a NULL_PTR value when calling the NvM_Init API.

[SWS_NvM_00399] [The function NvM_Init shall reset all internal variables, e.g. the queues, request flags, state machines, to their initial values. It shall signal “INIT DONE” internally, e.g. to enable job processing and queue management.] (SRS_BSW_00101, SRS_BSW_00406)

[SWS_NvM_00400] [The function NvM_Init shall not modify the permanent RAM block contents or call explicit synchronization callback, as this shall be done on NvM_ReadAll.] (SRS_BSW_00101, SRS_BSW_00406)

[SWS_NvM_00192] [The function NvM_Init shall set the dataset index of all NVRAM blocks of type NVM_BLOCK_DATASET to zero.] ()

[SWS_NvM_00193] [The function NvM_Init shall not initialize other modules (it is assumed that the underlying layers are already initialized).] ()

The function NvM_Init is affected by the common [\[SWS_NvM_00028\]](#) and published configuration parameter.

Hint: The time consuming NVRAM block initialization and setup according to the block descriptor [\[ECUC_NvM_00061\]](#) shall be done by the NvM_ReadAll request.

8.1.3.1.2 NvM_SetDataIndex

[SWS_NvM_00448] [

Service name:	NvM_SetDataIndex	
Syntax:	Std_ReturnType	NvM_SetDataIndex(BlockId, DataIndex)
Service ID[hex]:	0x01	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
	DataIndex	Index position (association) of a NV/ROM block.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The index position was set successfully. E_NOT_OK: An error occurred.
Description:	Service for setting the DataIndex of a dataset NVRAM block.	

] (SRS_Mem_08007)

[SWS_NvM_00014] [The function NvM_SetDataIndex shall set the index to access a certain dataset of a NVRAM block (with/without ROM blocks).] ()

[SWS_NvM_00263] [The function NvM_SetDataIndex shall leave the content of the corresponding RAM block unmodified.] ()

[SWS_NvM_00264] [For blocks with block management different from NVM_BLOCK_DATASET, NvM_SetDataIndex shall return without any effect in production mode. Further, E_NOT_OK shall be returned.] ()

[SWS_NvM_00707] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_SetDataIndex.] ()

Hint: NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor needed [NVM062].

8.1.3.1.3 NvM_GetDataIndex

[SWS_NvM_00449] [

Service name:	NvM_GetDataIndex		
Syntax:	Std_ReturnType	NvM_BlockIdType uint8*	NvM_GetDataIndex(BlockId, DataIndexPtr)
Service ID[hex]:	0x02		
Sync/Async:	Synchronous		
Reentrancy:	Reentrant		
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.	
Parameters (inout):	None		
Parameters (out):	DataIndexPtr	Pointer to where to store the current dataset index (0..255)	
Return value:	Std_ReturnType	E_OK: The index position has been retrieved successfully. E_NOT_OK: An error occurred.	
Description:	Service for getting the currently set DataIndex of a dataset NVRAM block		

] ()

[SWS_NvM_00021] [The function NvM_GetDataIndex shall get the current index (association) of a dataset NVRAM block (with/without ROM blocks).] ()

[SWS_NvM_00265] [For blocks with block management different from NVM_BLOCK_DATASET, NvM_GetDataIndex shall set the index pointed by DataIndexPtr to zero. Further, E_NOT_OK shall be returned.] ()

[SWS_NvM_00708] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_GetDataIndex.

Hint: NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor needed [\[NVM062\]](#).] ()

8.1.3.1.4 NvM_SetBlockProtection

[SWS_NvM_00450] [

Service name:	NvM_SetBlockProtection	
Syntax:	Std_ReturnType NvM_SetBlockProtection(NvM_BlockIdType BlockId, boolean ProtectionEnabled)	
Service ID[hex]:	0x03	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
	ProtectionEnabled	TRUE: Write protection shall be enabled FALSE: Write protection shall be disabled
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The block was enabled/disabled as requested E_NOT_OK: An error occurred.
Description:	Service for setting/resetting the write protection for a NV block.	

] (SRS_Mem_00127)

[SWS_NvM_00016] [The function NvM_SetBlockProtection shall set/reset the write protection for the corresponding NV block by setting the write protection attribute in the administrative part of the corresponding NVRAM block.] (SRS_Mem_00127)

[SWS_NvM_00709] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_SetBlockProtection.

Hint: NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor needed [NVM062].] ()

8.1.3.1.5 NvM_GetErrorStatus

[SWS_NvM_00451]

Service name:	NvM_GetErrorStatus	
Syntax:	Std_ReturnType NvM_GetErrorStatus(NvM_BlockIdType BlockId, NvM_RequestResultType* RequestResultPtr)	
Service ID[hex]:	0x04	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	RequestResultPtr	Pointer to where to store the request result. See NvM_RequestResultType .
Return value:	Std_ReturnType	E_OK: The block dependent error/status information was read successfully. E_NOT_OK: An error occurred.
Description:	Service to read the block dependent error/status information.	

] (SRS_Mem_00020)

[SWS_NvM_00015] [The function NvM_GetErrorStatus shall read the block dependent error/status information in the administrative part of a NVRAM block. The status/error information of a NVRAM block shall be set by a former or current asynchronous request.] (SRS_Mem_00020)

[SWS_NvM_00710] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_GetErrorStatus.] ()

NVRAM common block configuration parameters [[SWS NvM 00028](#)], block management types [[ECUC NvM 00061](#)] and one configured NVRAM block descriptor are needed in the configuration with respect to the function NvM_GetErrorStatus [NVM062].

8.1.3.1.6 NvM_GetVersionInfo

[SWS_NvM_00452] [

Service name:	NvM_GetVersionInfo	
Syntax:	void	NvM_GetVersionInfo(Std_VersionInfoType* versioninfo)
Service ID[hex]:	0x0f	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	versioninfo	Pointer to where to store the version information of this module.
Return value:	None	
Description:	Service to get the version information of the NvM module.	

] ()

8.1.3.1.7 NvM_SetRamBlockStatus

[SWS_NvM_00453] [

Service name:	NvM_SetRamBlockStatus	
Syntax:	Std_ReturnType	NvM_SetRamBlockStatus(NvM_BlockIdType BlockId, boolean BlockChanged)
Service ID[hex]:	0x05	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
	BlockChanged	TRUE: Validate the RAM block and mark block as changed. FALSE: Invalidate the RAM block and mark block as unchanged.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The status of the RAM-Block was changed as requested. E_NOT_OK: An error occurred.
Description:	Service for setting the RAM block status of an NVRAM block.	

] (SRS_Mem_08545)

[SWS_NvM_00240] [The function NvM_SetRamBlockStatus shall only work on NVRAM blocks with a permanently configured RAM block that have NvMBlockUseSetRamBlockStatus enabled and shall have no effect to other NVRAM blocks..] (SRS_Mem_08546)

[SWS_NvM_00241] [The function `NvM_SetRamBlockStatus` shall assume that a changed permanent RAM block or the content of the RAM mirror in the NvM module (in case of explicit synchronization) is valid (basic assumption).] (SRS_Mem_08545)

[SWS_NvM_00405] [When the “BlockChanged” parameter passed to the function `NvM_SetRamBlockStatus` is FALSE the corresponding RAM block is either invalid or unchanged (or both).] (SRS_Mem_08545)

[SWS_NvM_00406] [When the “BlockChanged” parameter passed to the function `NvM_SetRamBlockStatus` is TRUE, the corresponding permanent RAM block or the content of the RAM mirror in the NvM module (in case of explicit synchronization) is valid and changed.] ()

[SWS_NvM_00121] [The function `NvM_SetRamBlockStatus` shall request the recalculation of CRC in the background, i.e. the CRC recalculation shall be processed by the `NvM_MainFunction`, if the given “BlockChanged” parameter is TRUE and CRC calculation in RAM is configured (i.e. `NvMCalcRamBlockCrc == TRUE`).] ()

Hint:

In some cases, a permanent RAM block cannot be validated neither by a reload of its NV data, nor by a load of its ROM data during the execution of a `NvM_ReadAll` command (startup). The application is responsible to fill in proper data to the RAM block and to validate the block via the function `NvM_SetRamBlockStatus` before this RAM block can be written to its corresponding NV block by `NvM_WriteAll`.

It is expected that the function `NvM_SetRamBlockStatus` will be called frequently for NVRAM blocks which are configured to be protected in RAM via CRC. Otherwise this function only needs to be called once to mark a block as “changed” and to be processed during `NvM_WriteAll`.

[SWS_NvM_00711] [The NvM module’s environment shall have initialized the NvM module before it calls the function `NvM_SetRamBlockStatus`.] ()

[SWS_NvM_00408] [The NvM module shall provide the function `NvM_SetRamBlockStatus` only if it is configured via `NvMSetRamBlockStatusApi` [\[SWS_NvM_00028\]](#).] ()

NVRAM common configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor are needed in the configuration with respect to the function `NvM_SetRamBlockStatus` [NVM062].

8.1.3.1.8 NvM_SetBlockLockStatus

[SWS_NvM_00548] [

Service name:	NvM_SetBlockLockStatus	
Syntax:	void NvM_SetBlockLockStatus(NvM_BlockIdType BlockId, boolean BlockLocked)	
Service ID[hex]:	0x13	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
	BlockLocked	TRUE: Mark the RAM.block as locked FALSE: Mark the RAM.block as unlocked
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Service for setting the lock status of a permanent RAM block or of the explicit synchronization of a NVRAM block.	

] (SRS_Mem_08546)

[SWS_NvM_00732] [The function NvM_BlockLockStatus shall only work on NVRAM blocks with a permanently configured RAM block or on NVRAM blocks configured to support explicit synchronization and shall have no effect to other NVRAM blocks. Hint: This function is to be used mainly by DCM, but it can also be used by complex device drivers. The function is not included in the ServicePort interface.] ()

8.1.3.1.9 NvM_CancelJobs

[SWS_NvM_00535] [

Service name:	NvM_CancelJobs	
Syntax:	Std_ReturnType NvM_CancelJobs(NvM_BlockIdType BlockId)	
Service ID[hex]:	0x10	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: The job was successfully removed from queue. E_NOT_OK: The job could not be found in the queue.
Description:	Service to cancel all jobs pending for a NV block.	

] (SRS_Mem_08560)

[SWS_NvM_00536] [The function NvM_CancelJobs shall cancel all jobs pending in the queue for the specified NV Block. If requested the result type for the canceled blocks is NVM_REQ_CANCELED.] (SRS_Mem_08560)

[SWS_NvM_00537] [A currently processed job shall continue even after the call of NvM_CancelJobs.] ()

[SWS_NvM_00225] [The job of the function NvM_CancelJobs shall set block specific job result for specified NVRAM block to NVM_REQ_CANCELED in advance if the request is accepted.

Hint: The intent is just to empty the queue during the cleanup phase in case of termination or restart of a partition, to avoid later end of job notification.] ()

8.1.3.2 Asynchronous single block requests

8.1.3.2.1 NvM_ReadBlock

[SWS_NvM_00454] [

Service name:	NvM_ReadBlock	
Syntax:	Std_ReturnType	NvM_ReadBlock(BlockId, NvM_DstPtr)
Service ID[hex]:	0x06	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	NvM_DstPtr	Pointer to the RAM data block.
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted
Description:	Service to copy the data of the NV block to its corresponding RAM block.	

] (SRS_LIBS_08533, BSW176, SRS_Mem_00016)

[SWS_NvM_00010] [The job of the function NvM_ReadBlock shall copy the data of the NV block to the corresponding RAM block.] (SRS_Mem_00016)

[SWS_NvM_00195] [The function NvM_ReadBlock shall take over the given parameters, queue the read request in the job queue and return.] (SRS_Mem_00016)

[SWS_NvM_00196] [If the function is provided with a valid RAM block address, it is used. If a NULL pointer is provided and if a permanent block or an NvMBlockUseSyncMechanism is specified the permanent block of the APIs shall be used. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted.] (SRS_Mem_00016)

[SWS_NvM_00278] [The job of the function NvM_ReadBlock shall provide the possibility to copy NV data to a temporary RAM block although the NVRAM block is configured with a permanent RAM block or explicit synchronization callbacks. In this case, the parameter NvM_DstPtr must be unequal to the NULL pointer. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted.] ()

[SWS_NvM_00198] [The function NvM_ReadBlock shall invalidate a permanent RAM block immediately when the block is successfully enqueued or the job processing starts, i.e. copying data from NV memory or ROM to RAM. If the block has a synchronization callback (NvM_ReadRamBlockFromNvm) configured the invalidation will be done just before NvMReadRamBlockFromNvm is called.] ()

[SWS_NvM_00199] [The job of the function NvM_ReadBlock shall initiate a read attempt on the second NV block if the passed BlockId references a NVRAM block of type NVM_BLOCK_REDUNDANT and the read attempts on the first NV block fail.] ()

[SWS_NvM_00340] [In case of NVRAM block management type NVM_BLOCK_DATASET, the job of the function NvM_ReadBlock shall copy only that NV block to the corresponding RAM block which is selected via the data index in the administrative block.] ()

[SWS_NvM_00355] [The job of the function NvM_ReadBlock shall not copy the NV block to the corresponding RAM block if the NVRAM block management type is NVM_BLOCK_DATASET and the NV block selected by the dataset index is invalidate.] ()

[SWS_NvM_00651] [The job of the function NvM_ReadBlock shall not copy the NV block to the corresponding RAM block if the NVRAM block management type is NVM_BLOCK_DATASET and the NV block selected by the dataset index is inconsistent.] ()

[SWS_NvM_00354] [The job of the function NvM_ReadBlock shall copy the ROM block to RAM and set the job result to NVM_REQ_OK if the NVRAM block management type is NVM_BLOCK_DATASET and the dataset index points at a ROM block.] ()

[SWS_NvM_00200] [The job of the function NvM_ReadBlock shall set the RAM block to valid and assume it to be unchanged after a successful copy process of the NV block to RAM.] ()

[SWS_NvM_00366] [The job of the function NvM_ReadBlock shall set the RAM block to valid and assume it to be changed if the default values are copied to the RAM successfully.] ()

[SWS_NvM_00206] [The job of the function NvM_ReadBlock shall set the job result to NVM_REQ_OK if the NV block was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00341] [The job of the function NvM_ReadBlock shall set the request result to NVM_REQ_NV_INVALIDATED if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00652] [The job of the function NvM_ReadBlock shall report no error to the DEM if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00358] [The job of the function NvM_ReadBlock shall set the request result to NVM_REQ_INTEGRITY_FAILED if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

[SWS_NvM_00653] [The job of the function NvM_ReadBlock shall report NVM_E_INTEGRITY_FAILED to the DEM if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

Note: After the production of an ECU / a car, on the production line all blocks shall have been written with valid data (may be default data) and all diagnostic events (errors) shall have been deleted. If the process does not allow to write all NV blocks during production than the NvM will report diagnostic events (errors) because of blocks that were never written and reported as MEMIF_BLOCK_INCONSISTENT by MemIf.

[SWS_NvM_00359] [The job of the function NvM_ReadBlock shall set the request result to NVM_REQ_NOT_OK if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00654] [The job of the function NvM_ReadBlock shall report NVM_E_REQ_FAILED to the DEM if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00279] [The job of the function NvM_ReadBlock shall set the job result to NVM_REQ_OK if the block management type of the given NVRAM block is NVM_BLOCK_REDUNDANT and one of the NV blocks was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00655] [The job of the function NvM_ReadBlock shall report no error to the DEM if the block management type of the given NVRAM block is NVM_BLOCK_REDUNDANT and one of the NV blocks was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00316] [The job of the function NvM_ReadBlock shall mark every NVRAM block that has been configured with NVM_WRITE_BLOCK_ONCE (TRUE) that is not detected by underlying SW as being invalidated, shall be marked as write protected.] ()

[SWS_NvM_00317] [The job of the function NvM_ReadBlock shall invalidate a NVRAM block of management type redundant if both NV blocks have been invalidated.] ()

[SWS_NvM_00201] [The job of the function NvM_ReadBlock shall request a CRC recalculation over the RAM block data after the copy process [\[SWS_NvM_00180\]](#) if the NV block is configured with CRC, i.e. if NvMCalRamBlockCrC == TRUE for the NV block.] ()

[SWS_NvM_00202] [The job of the function NvM_ReadBlock shall load the default values according to processing of NvM_RestoreBlockDefaults (also set the job result to NVM_REQ_RESTORED_FROM_ROM) if the recalculated CRC is not equal to the CRC stored in NV memory.] ()

[SWS_NvM_00658] [NvM_ReadBlock: If there are no default values available, the RAM blocks shall remain invalid.] ()

[SWS_NvM_00657] [The job of the function NvM_ReadBlock shall load the default values according to processing of NvM_RestoreBlockDefaults (also set the job result to NVM_REQ_RESTORED_FROM_ROM) if the read request passed to the underlying layer fails (MemIf reports MEMIF_JOB_FAILED or MEMIF_BLOCK_INCONSISTENT) and if the default values are available.] ()

[SWS_NvM_00203] [The job of the function NvM_ReadBlock shall report NVM_E_INTEGRITY_FAILED to the DEM if a CRC mismatch occurs.] ()

[SWS_NvM_00204] [The job of the function NvM_ReadBlock shall set the job result NVM_REQ_INTEGRITY_FAILED if a CRC mismatch occurs.] ()

[SWS_NvM_00712] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_ReadBlock.] ()

Hint: NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor are needed for configuration with respect to the function NvM_ReadBlock [NVM062].

8.1.3.2.2 NvM_WriteBlock

[SWS_NvM_00455] [

Service name:	NvM_WriteBlock		
Syntax:	Std_ReturnType	NvM_BlockIdType	NvM_WriteBlock(
	const	void*	BlockId,
			NvM_SrcPtr
)		
Service ID[hex]:	0x07		
Sync/Async:	Asynchronous		
Reentrancy:	Reentrant		
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.	
	NvM_SrcPtr	Pointer to the RAM data block.	
Parameters (inout):	None		
Parameters (out):	None		
Return value:	Std_ReturnType	E_OK: request has been accepted	
		E_NOT_OK: request has not been accepted	
Description:	Service to copy the data of the RAM block to its corresponding NV block.		

] (BSW176, SRS_Mem_00017)

[SWS_NvM_00410] [The job of the function NvM_WriteBlock shall copy the data of the RAM block to its corresponding NV block.] (SRS_Mem_00017)

[SWS_NvM_00411] [The function NvM_WriteBlock shall test the write protection attribute of the NV block in the administrative part of the corresponding RAM block. In case of failure an NVM_E_WRITE_PROTECTED / (during production) error shall be reported.] (SRS_Mem_00017)

[SWS_NvM_00217] [The function NvM_WriteBlock shall return with E_NOT_OK, if a write protected NVRAM block is referenced by the passed BlockId parameter.] ()

[SWS_NvM_00749] [The function NvM_WriteBlock shall return with E_NOT_OK, if a locked NVRAM block is referenced by the passed BlockId parameter. and a DET error (see Section 7.6) shall be emitted.] ()

[SWS_NvM_00208] [The function NvM_WriteBlock shall take over the given parameters, queue the write request in the job queue and return.] (SRS_Mem_08541)

[SWS_NvM_00209] [The function NvM_WriteBlock shall check the NVRAM block protection when the request is enqueued but not again before the request is executed.] ()

[SWS_NvM_00300] [The function NvM_WriteBlock shall cancel a pending job immediately in a destructive way if the passed BlockId references a NVRAM block configured to have immediate priority. The immediate job shall be the next active job to be processed.] ()

[SWS_NvM_00210] [If the function is provided with a valid RAM block address, it is used. If a NULL pointer is provided and if a permanent block or an NvMBlockUseSyncMechanism is specified the permanent block of the APIs shall be used. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted...] ()

[SWS_NvM_00280] [The job of the function NvM_WriteBlock shall provide the possibility to copy a temporary RAM block to a NV block although the NVRAM block is configured with a permanent RAM block or explicit synchronization callbacks. In this case, the parameter NvM_SrcPtr must be unequal to a NULL pointer. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted] ()

[SWS_NvM_00212] [The job of the function NvM_WriteBlock shall request a CRC recalculation before the RAM block will be copied to NV memory if the NV block is configured with CRC [\[SWS_NvM_00180\]](#).] ()

[SWS_NvM_00852] [The job of the function NvM_WriteBlock shall skip writing and consider the job as successfully finished if the NvMBlockUseCRCCompMechanism attribute of the NVRAM Block is set to true and the RAM block CRC calculated by the write job is equal to the CRC calculated during the last successful read or write job. This mechanism shall not be applied to blocks for which a loss of redundancy has been detected.] (SRS_Mem_00136)

[SWS_NvM_00338] [The job of the function NvM_WriteBlock shall copy the RAM block to the corresponding NV block which is selected via the data index in the administrative block if the NVRAM block management type of the given NVRAM block is NVM_BLOCK_DATASET.] ()

[SWS_NvM_00303] [The job of the function NvM_WriteBlock shall assume a referenced permanent RAM block or the RAM mirror in the NvM module in case of explicit synchronization to be valid when the request is passed to the NvM module. If the permanent RAM block is still in an invalid state, the function NvM_WriteBlock shall validate it automatically before copying the RAM block contents to NV memory or after calling explicit synchronization callback (NvM_WriteRamBlockToNvm).] ()

[SWS_NvM_00213] [The job of the function NvM_WriteBlock shall check the number of write retries using a write retry counter to avoid infinite loops. Each negative result reported by the memory interface shall be followed by an increment of the retry counter. In case of a retry counter overrun, the job of the function NvM_WriteBlock shall set the job result to NVM_REQ_NOT_OK.] (SRS_Mem_08554)

[SWS_NvM_00659] [The job of the function NvM_WriteBlock shall check the number of write retries using a write retry counter to avoid infinite loops. Each negative result reported by the memory interface shall be followed by an increment of the retry counter. In case of a retry counter overrun, the job of the function NvM_WriteBlock shall report NVM_E_REQ_FAILED to the DEM.] ()

[SWS_NvM_00216] [The configuration parameter NVM_MAX_NUM_OF_WRITE_RETRIES [\[SWS_NvM_00028\]](#) shall prescribe the

maximum number of write retries for the job of the function `NvM_WriteBlock` when RAM block data cannot be written successfully to the corresponding NV block.] ()

[SWS_NvM_00760] [The job of the function `NvM_WriteBlock` shall copy the data content of the RAM block to both corresponding NV blocks if the NVRAM block management type of the processed NVRAM block is `NVM_BLOCK_REDUNDANT`.] ()

[SWS_NvM_00761] [If the processed NVRAM block is of type `NVM_BLOCK_REDUNDANT` the job of the function `NvM_WriteBlock` shall start to copy the data of the RAM block to NV block which has not been read during the jobs started by `NvM_ReadBlock`, `NvM_ReadPRAMBlock` or `NvM_ReadAll` then continue to copy the other NV block.] ()

[SWS_NvM_00284] [The job of the function `NvM_WriteBlock` shall set `NVM_REQ_OK` as job result if the passed `BlockId` references a NVRAM block of type `NVM_BLOCK_REDUNDANT` and at least one of the NV blocks have been written successfully.] ()

[SWS_NvM_00328] [The job of the function `NvM_WriteBlock` shall set the write protection flag in the administrative block immediately if the NVRAM block is configured with `NvMWriteBlockOnce == TRUE` and the data has been written successfully to the NV block.] ()

[SWS_NvM_00713] [The NvM module's environment shall have initialized the NvM module before it calls the function `NvM_WriteBlock`.] ()

Hint:

To avoid the situation that in case of redundant NVRAM blocks two different NV blocks are containing different but valid data at the same time, each client of the function `NvM_WriteBlock` may call `NvM_InvalidateNvBlock` in advance.

NVRAM common block configuration parameters [[SWS_NvM_00028](#)], block management types [[ECUC_NvM_00061](#)] and one configured NVRAM block descriptor are needed in the configuration with respect to the function `NvM_WriteBlock` [NVM062].

[SWS_NvM_00547] [The job of the function `NvM_WriteBlock` with Block ID 1 shall write the compiled NVRAM configuration ID to the stored NVRAM configuration ID (block 1).] ()

Hint: If a pristine ECU is flashed for the first time, such a call invoked by will ensure that after a power-off without a proper shutdown, everything is as expected at the next start-up. Otherwise, the new configuration ID would not be stored in NV RAM and all ROM defaultd would be used.

A macro scan be used to indicate this usage.

8.1.3.2.3 NvM_RestoreBlockDefaults

[SWS_NvM_00456] [

Service name:	NvM_RestoreBlockDefaults		
Syntax:	Std_ReturnType	NvM_BlockIdType	NvM_RestoreBlockDefaults(BlockId, NvM_DestPtr)
Service ID[hex]:	0x08		
Sync/Async:	Asynchronous		
Reentrancy:	Non Reentrant		
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.	
Parameters (inout):	None		
Parameters (out):	NvM_DestPtr	Pointer to the RAM data block.	
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted	
Description:	Service to restore the default data to its corresponding RAM block.		

] (SRS_Mem_00018)

[SWS_NvM_00012] [The job of the function NvM_RestoreBlockDefaults shall restore the default data to its corresponding RAM block.] (SRS_Mem_00018)

[SWS_NvM_00224] [The function NvM_RestoreBlockDefaults shall take over the given parameters, queue the request in the job queue and return.] ()

[SWS_NvM_00267] [The job of the function NvM_RestoreBlockDefaults shall load the default data from a ROM block if a ROM block is configured.] (SRS_Mem_00018)

[SWS_NvM_00266] [The NvM module's environment shall call the function NvM_RestoreBlockDefaults to obtain the default data if no ROM block is configured for a NVRAM block and an application callback routine is configured via the parameter NvMInitBlockCallback.] (SRS_Mem_00018)

[SWS_NvM_00353] [The function NvM_RestoreBlockDefaults shall return with E_NOT_OK if the block management type of the given NVRAM block is NVM_BLOCK_DATASET, at least one ROM block is configured and the data index points at a NV block.] ()

[SWS_NvM_00435] [If the function is provided with a valid RAM block address, it is used. If a NULL pointer is provided and if a permanent block or an NvMBlockUseSyncMechanism is specified the permanent block of the APIs shall be used. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted.] ()

[SWS_NvM_00436] [The NvM module's environment shall pass a pointer unequal to NULL via the parameter NvM_DstPtr to the function NvM_RestoreBlockDefaults in order to copy ROM data to a temporary RAM block although the NVRAM block is configured with a permanent RAM block or explicit synchronization callbacks. Otherwise a DET-Parameter error (see Section 7.6) shall be emitted] ()

[SWS_NvM_00227] [The job of the function NvM_RestoreBlockDefaults shall invalidate a RAM block before copying default data to the RAM if a permanent RAM block is requested or before explicit synchronization callback (NvMReadRamBlockFromNvM) is called.] ()

[SWS_NvM_00228] [The job of the function NvM_RestoreBlockDefaults shall validate and assume a RAM block to be changed if the requested RAM block is permanent or after explicit synchronization callback (NvMReadRamBlockFromNvM) that is called returns E_OK and the copy process of the default data to RAM was successful.] ()

[SWS_NvM_00229] [The job of the function NvM_RestoreBlockDefaults shall request a recalculation of CRC from a RAM block after the copy process/validation if a CRC is configured for this RAM block.] ()

[SWS_NvM_00714] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_RestoreBlockDefaults.] ()

Hint: For the block management type NVM_BLOCK_DATASET, the application has to ensure that a valid dataset index is selected (pointing to ROM data).
NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor are needed in the configuration with respect to the function NvM_RestoreBlockDefaults [NVM062].

[SWS_NvM_00883] [If the block has no ROM default data and no NvMInitBlockCallback configured for it then the function NvM_RestoreBlockDefaults shall leave the block status unchanged and return E_NOT_OK as result.] ()

[SWS_NvM_00885] [If the block has no default data, it has no InitBlockCallbackFunction configured and the development error detection is enabled then the NvM_RestoreBlockDefaults API shall report the error NVM_E_BLOCK_WITHOUT_DEFAULTS error to the Det module.] ()

8.1.3.2.4 NvM_EraseNvBlock

[SWS_NvM_00457] [

Service name:	NvM_EraseNvBlock		
Syntax:	Std_ReturnType	NvM_BlockIdType	NvM_EraseNvBlock(BlockId)
Service ID[hex]:	0x09		
Sync/Async:	Asynchronous		
Reentrancy:	Reentrant		
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.	
Parameters (inout):	None		
Parameters (out):	None		
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted	
Description:	Service to erase a NV block.		

] (SRS_Mem_08544)

[SWS_NvM_00415] [The job of the function NvM_EraseNvBlock shall erase a NV block.] (SRS_Mem_08544)

[SWS_NvM_00231] [The function NvM_EraseNvBlock shall take over the given parameters, queue the request and return.] ()

[SWS_NvM_00418] [The function NvM_EraseNvBlock shall queue the request to erase in case of disabled write protection.] ()

[SWS_NvM_00416] [The job of the function NvM_EraseNvBlock shall leave the content of the RAM block unmodified.] ()

[SWS_NvM_00417] [The function NvM_EraseNvBlock shall test the write protection attribute of the NV block in the corresponding Administrative block. In case of failure an NVM_E_WRITE_PROTECTED / (during production) error shall be reported.] ()

[SWS_NvM_00262] [The function NvM_EraseNvBlock shall return with E_NOT_OK if a write protected NV block is referenced.] ()

[SWS_NvM_00661] [The function NvM_EraseNvBlock shall return with E_NOT_OK if a ROM block of a dataset NVRAM block is referenced.] ()

[SWS_NvM_00230] [The function NvM_EraseNvBlock shall check the write protection attribute of a NVRAM block only before the job is put to the job queue. In

case of failure an NVM_E_WRITE_PROTECTED / (during production) error shall be reported.] ()

[SWS_NvM_00662] [NvM_EraseNvBlock: The NvM module shall not re-check the write protection before fetching the job from the job queue.] ()

[SWS_NvM_00269] [If the referenced NVRAM block is of type NVM_BLOCK_REDUNDANT, the function NvM_EraseNvBlock shall only succeed when both NV blocks have been erased.] ()

[SWS_NvM_00271] [The job of the function NvM_EraseNvBlock shall set the job result to NVM_REQ_NOT_OK if the processing of the service fails.] ()

[SWS_NvM_00663] [The job of the function NvM_EraseNvBlock shall report NVM_E_REQ_FAILED to the DEM if the processing of the service fails.] ()

[SWS_NvM_00357] [The function NvM_EraseNvBlock shall return with E_NOT_OK, when development error detection is enabled and the referenced NVRAM block is configured with standard priority.] ()

[SWS_NvM_00715] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_EraseNvBlock.] ()
NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor are needed in the configuration with respect to the function NvM_EraseNvBlock [NVM062].

8.1.3.2.5 NvM_CancelWriteAll

[SWS_NvM_00458] [

Service name:	NvM_CancelWriteAll	
Syntax:	void	NvM_CancelWriteAll(void
Service ID[hex]:	0x0a	
Sync/Async:	Asynchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Service to cancel a running NvM_WriteAll request.	

] (SRS_Mem_08558, SRS_Mem_08540)

[SWS_NvM_00019] [The function NvM_CancelWriteAll shall cancel a running NvM_WriteAll request. It shall terminate the NvM_WriteAll request in a way that the data consistency during processing of a single NVRAM block is not compromised] (SRS_Mem_08540)

[SWS_NvM_00232] [The function NvM_CancelWriteAll shall signal the request to the NvM module and return.] ()

[SWS_NvM_00233] [The function NvM_CancelWriteAll shall be without any effect if no NvM_WriteAll request is pending.] ()

[SWS_NvM_00234] [The function NvM_CancelWriteAll shall treat multiple requests to cancel a running NvM_WriteAll request as one request, i.e. subsequent requests will be ignored.] ()

[SWS_NvM_00235] [The request result of the function NvM_CancelWriteAll shall be implicitly given by the result of the NvM_WriteAll request to be canceled.] ()

[SWS_NvM_00255] [The function NvM_CancelWriteAll shall ignore an already pending NvM_CancelWriteAll request.] ()

[SWS_NvM_00236] [The function NvM_CancelWriteAll shall only modify the error/status attribute field of the pending blocks to NVM_REQ_CANCELED and for the currently written block after the processing of a single NVRAM block is finished to NVM_REQ_OK or NVM_REQ_NOT_OK depending on the success of the write operation.] ()

[SWS_NvM_00716] [The NvM module's environment shall have initialized the NvM module before it calls the function function NvM_CancelWriteAll.] ()

[SWS_NvM_00420] [The function NvM_CancelWriteAll shall signal the NvM module and shall not be queued, i.e. there can be only one pending request of this type.] ()

8.1.3.2.6 NvM_InvalidateNvBlock

[SWS_NvM_00459] [

Service name:	NvM_InvalidateNvBlock	
Syntax:	Std_ReturnType	NvM_InvalidateNvBlock(NvM_BlockIdType BlockId)
Service ID[hex]:	0x0b	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted
Description:	Service to invalidate a NV block.	

] (SRS_Mem_08011)

[SWS_NvM_00421] [The job of the function NvM_InvalidateNvBlock shall invalidate a NV block.] (SRS_Mem_08011)

[SWS_NvM_00422] [The job of the function NvM_InvalidateNvBlock shall leave the RAM block unmodified.] ()

[SWS_NvM_00423] [The function NvM_InvalidateNvBlock shall check the write protection attribute of the NV block in the administrative part of the corresponding RAM block. In case of failure an NVM_E_WRITE_PROTECTED / (during production) error shall be reported.] ()

[SWS_NvM_00424] [The function NvM_InvalidateNvBlock shall queue the request if the write protection of the corresponding NV block is disabled.] ()

[SWS_NvM_00239] [The function NvM_InvalidateNvBlock shall take over the given parameters, queue the request and return.] ()

[SWS_NvM_00272] [The function NvM_InvalidateNvBlock shall return with E_NOT_OK if a write protected NV block is referenced by the BlockId parameter.] ()

[SWS_NvM_00664] [The function NvM_InvalidateNvBlock shall return with E_NOT_OK if a ROM block of a dataset NVRAM block is referenced by the BlockId parameter.] ()

[SWS_NvM_00273] [The function `NvM_InvalidateNvBlock` shall check the write protection attribute of a NVRAM block only before the job is put to the job queue. In case of failure an `NVM_E_WRITE_PROTECTED` / (during production) error shall be reported.] ()

[SWS_NvM_00665] [The NvM module shall not recheck write protection before fetching the job from the job queue.] ()

[SWS_NvM_00274] [If the referenced NVRAM block is of type `NVM_BLOCK_REDUNDANT`, the function `NvM_InvalidateNvBlock` shall only set the request result `NvM_RequestResultType` to `NVM_REQ_OK` when both NV blocks have been invalidated.] ()

[SWS_NvM_00275] [The function `NvM_InvalidateNvBlock` shall set the job result to `NVM_REQ_NOT_OK` if the processing of this service fails.] ()

[SWS_NvM_00666] [The function `NvM_InvalidateNvBlock` shall report `NVM_E_REQ_FAILED` to the DEM if the processing of this service fails.] ()

[SWS_NvM_00717] [The NvM module's environment shall have initialized the NvM module before it calls the function `NvM_InvalidateNvBlock`.] ()

NVRAM common block configuration parameters [\[SWS_NvM_00028\]](#), block management types [\[ECUC_NvM_00061\]](#) and one configured NVRAM block descriptor are needed in the configuration with respect to the function `NvM_InvalidateBlock` [NVM062].

8.1.3.2.7 NvM_ReadPRAMBlock

[SWS_NvM_00764] [

Service name:	NvM_ReadPRAMBlock	
Syntax:	Std_ReturnType NvM_ReadPRAMBlock(NvM_BlockIdType BlockId)	
Service ID[hex]:	0x16	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted
Description:	Service to copy the data of the NV block to its corresponding permanent RAM block.	

] (SRS_LIBS_08533, BSW176, SRS_Mem_00016)

[SWS_NvM_00765] [The job of the function NvM_ReadPRAMBlock shall copy the data of the NV block to the permanent RAM block.] (SRS_Mem_00016)

[SWS_NvM_00766] [The function NvM_ReadPRAMBlock shall take over the given parameters, queue the read request in the job queue and return.] (SRS_Mem_00016)

[SWS_NvM_00767] [The function NvM_ReadPRAMBlock shall invalidate a permanent RAM block immediately when the block is successfully enqueued or the job processing starts, i.e. copying data from NV memory or ROM to RAM. If the block has a synchronization callback (NvM_ReadRamBlockFromNvm) configured the invalidation will be done just before NvMReadRamBlockFromNvM is called.] ()

[SWS_NvM_00768] [The job of the function NvM_ReadPRAMBlock shall initiate a read attempt on the second NV block if the passed BlockId references a NVRAM block of type NVM_BLOCK_REDUNDANT and the read attempts on the first NV block fail.] ()

[SWS_NvM_00769] [In case of NVRAM block management type NVM_BLOCK_DATASET, the job of the function NvM_ReadPRAMBlock shall copy only that NV block to the corresponding RAM block which is selected via the data index in the administrative block.] ()

[SWS_NvM_00770] [The job of the function NvM_ReadPRAMBlock shall not copy the NV block to the corresponding RAM block if the NVRAM block management type

is NVM_BLOCK_DATASET and the NV block selected by the dataset index is invalidate.] ()

[SWS_NvM_00771] [The job of the function NvM_ReadPRAMBlock shall not copy the NV block to the corresponding RAM block if the NVRAM block management type is NVM_BLOCK_DATASET and the NV block selected by the dataset index is inconsistent.] ()

[SWS_NvM_00772] [The job of the function NvM_ReadPRAMBlock shall copy the ROM block to RAM and set the job result to NVM_REQ_OK if the NVRAM block management type is NVM_BLOCK_DATASET and the dataset index points at a ROM block.] ()

[SWS_NvM_00773] [The job of the function NvM_ReadPRAMBlock shall set the RAM block to valid and assume it to be unchanged after a successful copy process of the NV block to RAM.] ()

[SWS_NvM_00774] [The job of the function NvM_ReadPRAMBlock shall set the RAM block to valid and assume it to be changed if the default values are copied to the RAM successfully.] ()

[SWS_NvM_00775] [The job of the function NvM_ReadPRAMBlock shall set the job result to NVM_REQ_OK if the NV block was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00776] [The job of the function NvM_ReadPRAMBlock shall set the request result to NVM_REQ_NV_INVALIDATED if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00777] [The job of the function NvM_ReadPRAMBlock shall report no error to the DEM if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00778] [The job of the function NvM_ReadPRAMBlock shall set the request result to NVM_REQ_INTEGRITY_FAILED if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

[SWS_NvM_00779] [The job of the function NvM_ReadPRAMBlock shall report NVM_E_INTEGRITY_FAILED to the DEM if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

[SWS_NvM_00780] [The job of the function NvM_ReadPRAMBlock shall set the request result to NVM_REQ_NOT_OK if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00781] [The job of the function NvM_ReadPRAMBlock shall report NVM_E_REQ_FAILED to the DEM if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00782] [The job of the function NvM_ReadPRAMBlock shall set the job result to NVM_REQ_OK if the block management type of the given NVRAM block is NVM_BLOCK_REDUNDANT and one of the NV blocks was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00783] [The job of the function NvM_ReadPRAMBlock shall report no error to the DEM if the block management type of the given NVRAM block is NVM_BLOCK_REDUNDANT and one of the NV blocks was copied successfully from NV memory to RAM.] ()

[SWS_NvM_00784] [The job of the function NvM_ReadPRAMBlock shall mark every NVRAM block that has been configured with NVM_WRITE_BLOCK_ONCE (TRUE) that is not detected by underlying SW as being invalidated, shall be marked as write protected.] ()

[SWS_NvM_00785] [The job of the function NvM_ReadPRAMBlock shall invalidate a NVRAM block of management type redundant if both NV blocks have been invalidated.] ()

[SWS_NvM_00786] [The job of the function NvM_ReadPRAMBlock shall request a CRC recalculation over the RAM block data after the copy process [\[SWS_NvM_00180\]](#) if the NV block is configured with CRC, i.e. if NvMCalRamBlockCrC == TRUE for the NV block.] ()

[SWS_NvM_00787] [The job of the function NvM_ReadPRAMBlock shall load the default values according to processing of NvM_RestorePRAMBlockDefaults if the recalculated CRC is not equal to the CRC stored in NV memory.] ()

[SWS_NvM_00788] [NvM_ReadPRAMBlock: If there are no default values available, the RAM blocks shall remain invalid.] ()

[SWS_NvM_00789] [The job of the function NvM_ReadPRAMBlock shall load the default values according to processing of NvM_RestorePRAMBlockDefaults if the read request passed to the underlying layer fails.] ()

[SWS_NvM_00790] [The job of the function NvM_ReadPRAMBlock shall report NVM_E_INTEGRITY_FAILED to the DEM if a CRC mismatch occurs.] ()

[SWS_NvM_00791] [The job of the function NvM_ReadPRAMBlock shall set the job result NVM_REQ_INTEGRITY_FAILED if a CRC mismatch occurs.] ()

[SWS_NvM_00792] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_ReadPRAMBlock.] ()

Hint: NVRAM common block configuration parameters [\[SWS NvM 00028\]](#), block management types [\[ECUC NvM 00061\]](#) and one configured NVRAM block descriptor are needed for configuration with respected to the function NvM_ReadPRAMBlock [NVM062].

[SWS_NvM_00882] [The job of the function NvM_ReadPRAMBlock shall load the default values according to processing of NvM_RestorePRAMBlockDefaults (also set the job result to NVM_REQ_RESTORED_FROM_ROM) if the read request passed to the underlying layer fails (MemIf reports MEMIF_JOB_FAILED or MEMIF_BLOCK_INCONSISTENT) and if the default values are available.] ()

8.1.3.2.8 NvM_WritePRAMBlock

[SWS_NvM_00793] [

Service name:	NvM_WritePRAMBlock		
Syntax:	Std_ReturnType	NvM_WritePRAMBlock(BlockId
		NvM_BlockIdType)
Service ID[hex]:	0x17		
Sync/Async:	Asynchronous		
Reentrancy:	Reentrant		
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.	
Parameters (inout):	None		
Parameters (out):	None		
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted	
Description:	Service to copy the data of the RAM block to its corresponding permanent RAM block.		

] (BSW176, SRS_Mem_00017)

[SWS_NvM_00794] [The job of the function NvM_WritePRAMBlock shall copy the data of the permanent RAM block to its corresponding NV block.] (SRS_Mem_00017)

[SWS_NvM_00795] [The function NvM_WritePRAMBlock shall test the write protection attribute of the NV block in the administrative part of the corresponding RAM block. In case of failure an NVM_E_WRITE_PROTECTED / (during production) error shall be reported.] (SRS_Mem_00017)

[SWS_NvM_00796] [The function NvM_WritePRAMBlock shall return with E_NOT_OK, if a write protected NVRAM block is referenced by the passed BlockId parameter.] ()

[SWS_NvM_00797] [The function NvM_WritePRAMBlock shall return with E_NOT_OK, if a locked NVRAM block is referenced by the passed BlockId parameter. and a DET error (see Section 7.6) shall be emitted.] ()

[SWS_NvM_00798] [The function NvM_WritePRAMBlock shall take over the given parameters, queue the write request in the job queue and return.] (SRS_Mem_08541)

[SWS_NvM_00799] [The function NvM_WritePRAMBlock shall check the NVRAM block protection when the request is enqueued but not again before the request is executed.] ()

[SWS_NvM_00800] [The function NvM_WritePRAMBlock shall cancel a pending job immediately in a destructive way if the passed BlockId references a NVRAM block configured to have immediate priority. The immediate job shall be the next active job to be processed.] ()

[SWS_NvM_00801] [The job of the function NvM_WritePRAMBlock shall request a CRC recalculation before the RAM block will be copied to NV memory if the NV block is configured with CRC [\[SWS_NvM_00180\]](#).] ()

[SWS_NvM_00853] [The job of the function NvM_WritePRAMBlock shall skip writing and consider the job as successfully finished if the NvMBlockUseCRCCompMechanism attribute of the NVRAM Block is set to true and the RAM block CRC calculated by the write job is equal to the CRC calculated during the last successful read or write job. This mechanism shall not be applied to blocks for which a loss of redundancy has been detected.] (SRS_Mem_00136)

[SWS_NvM_00802] [The job of the function NvM_WritePRAMBlock shall copy the RAM block to the corresponding NV block which is selected via the data index in the administrative block if the NVRAM block management type of the given NVRAM block is NVM_BLOCK_DATASET.] ()

[SWS_NvM_00803] [The job of the function NvM_WritePRAMBlock shall assume a referenced permanent RAM block or the RAM mirror in the NvM module in case of explicit synchronization to be valid when the request is passed to the NvM module. If the permanent RAM block is still in an invalid state, the function NvM_WritePRAMBlock shall validate it automatically before copying the RAM block contents to NV memory or after calling explicit synchronization callback (NvM_WriteRamBlockToNvm).] ()

[SWS_NvM_00804] [The job of the function NvM_WritePRAMBlock shall check the number of write retries using a write retry counter to avoid infinite loops. Each negative result reported by the memory interface shall be followed by an increment of the retry counter. In case of a retry counter overrun, the job of the function NvM_WritePRAMBlock shall set the job result to NVM_REQ_NOT_OK.] (SRS_Mem_08554)

[SWS_NvM_00805] [The job of the function NvM_WritePRAMBlock shall check the number of write retries using a write retry counter to avoid infinite loops. Each negative result reported by the memory interface shall be followed by an increment of the retry counter. In case of a retry counter overrun, the job of the function NvM_WritePRAMBlock shall report NVM_E_REQ_FAILED to the DEM.] ()

[SWS_NvM_00806] [The configuration parameter NVM_MAX_NUM_OF_WRITE_RETRIES [\[SWS_NvM_00028\]](#) shall prescribe the maximum number of write retries for the job of the function NvM_WritePRAMBlock

when RAM block data cannot be written successfully to the corresponding NV block.
] ()

[SWS_NvM_00807] [The job of the function NvM_WritePRAMBlock shall copy the data content of the RAM block to both corresponding NV blocks if the NVRAM block management type of the processed NVRAM block is NVM_BLOCK_REDUNDANT.]
()

[SWS_NvM_00808] [If the processed NVRAM block is of type NVM_BLOCK_REDUNDANT the job of the function NvM_WritePRAMBlock shall start to copy the data of the RAM block to NV block which has not been read during the jobs started by NvM_ReadBlock, NvM_ReadPRAMBlock or NvM_ReadAll then continue to copy the other NV block.] ()

[SWS_NvM_00809] [The job of the function NvM_WritePRAMBlock shall set NVM_REQ_OK as job result if the passed BlockId references a NVRAM block of type NVM_BLOCK_REDUNDANT and at least one of the NV blocks have been written successfully.] ()

[SWS_NvM_00810] [The job of the function NvM_WritePRAMBlock shall set the write protection flag in the administrative block immediately if the NVRAM block is configured with NvMWriteBlockOnce == TRUE and the data has been written successfully to the NV block.] ()

[SWS_NvM_00811] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_WritePRAMBlock.] ()

Hint:

To avoid the situation that in case of redundant NVRAM blocks two different NV blocks are containing different but valid data at the same time, each client of the function NvM_WritePRAMBlock may call NvM_InvalidateNvBlock in advance.

NVRAM common block configuration parameters [[SWS_NvM_00028](#)], block management types [[ECUC_NvM_00061](#)] and one configured NVRAM block descriptor are needed in the configuration with respect to the function NvM_WritePRAMBlock [NVM062].

[SWS_NvM_00812] [The job of the function NvM_WritePRAMBlock with Block ID 1 shall write the compiled NVRAM configuration ID to the stored NVRAM configuration ID (block 1).] ()

Hint: If a pristine ECU is flashed for the first time, such a call invoked by will ensure that after a power-off without a proper shutdown, everything is as expected at the next start-up. Otherwise, the new configuration ID would not be stored in NV RAM and all ROM defaultd would be used.

A macro scan be used to indicate this usage.

8.1.3.2.9 NvM_RestorePRAMBlockDefaults

[SWS_NvM_00813] [

Service name:	NvM_RestorePRAMBlockDefaults	
Syntax:	Std_ReturnType NvM_RestorePRAMBlockDefaults(NvM_BlockIdType BlockId)	
Service ID[hex]:	0x18	
Sync/Async:	Asynchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	BlockId	The block identifier uniquely identifies one NVRAM block descriptor. A NVRAM block descriptor contains all needed information about a single NVRAM block.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: request has been accepted E_NOT_OK: request has not been accepted
Description:	Service to restore the default data to its corresponding permanent RAM block.	

] (SRS_Mem_00018)

[SWS_NvM_00814] [The job of the function NvM_RestorePRAMBlockDefaults shall restore the default data to its corresponding permanent RAM block.] (SRS_Mem_00018)

[SWS_NvM_00815] [The function NvM_RestorePRAMBlockDefaults shall take over the given parameters, queue the request in the job queue and return.] ()

[SWS_NvM_00816] [The job of the function NvM_RestorePRAMBlockDefaults shall load the default data from a ROM block if a ROM block is configured.] (SRS_Mem_00018)

[SWS_NvM_00817] [The NvM module's environment shall call the function NvM_RestorePRAMBlockDefaults to obtain the default data if no ROM block is configured for a NVRAM block and an application callback routine is configured via the parameter NvMInitBlockCallback.] (SRS_Mem_00018)

[SWS_NvM_00818] [The function NvM_RestorePRAMBlockDefaults shall return with E_NOT_OK if the block management type of the given NVRAM block is NVM_BLOCK_DATASET, at least one ROM block is configured and the data index points at a NV block.] ()

[SWS_NvM_00819] [The job of the function NvM_RestorePRAMBlockDefaults shall invalidate a RAM block before copying default data to the permanent RAM block or before explicit synchronization callback (NvMReadRamBlockFromNvM) is called.] ()

[SWS_NvM_00820] [The job of the function NvM_RestorePRAMBlockDefaults shall validate and assume a RAM block to be changed if the requested RAM block is

permanent or after explicit synchronization callback (NvMReadRamBlockFromNvM) that is called returns E_OK and the copy process of the default data to RAM was successful.] ()

[SWS_NvM_00821] [The job of the function NvM_RestorePRAMBlockDefaults shall request a recalculation of CRC from a RAM block after the copy process/validation if a CRC is configured for this RAM block.] ()

[SWS_NvM_00822] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_RestorePRAMBlockDefaults.] ()

Hint: For the block management type NVM_BLOCK_DATASET, the application has to ensure that a valid dataset index is selected (pointing to ROM data).

NVRAM common block configuration parameters [[SWS_NvM_00028](#)], block management types [[ECUC_NvM_00061](#)] and one configured NVRAM block descriptor are needed in the configuration with respect to the function NvM_RestorePRAMBlockDefaults [NVM062].

[SWS_NvM_00884] [If the block has no ROM default data and no NvMInitBlockCallback configured for it then the function NvM_RestorePRAMBlockDefaults shall leave the block status unchanged and return E_NOT_OK as result.] ()

[SWS_NvM_00886] [If the block has no default data, it has no InitBlockCallbackFunction configured and the development error detection is enabled then the NvM_RestorePRAMBlockDefaults API shall report the error NVM_E_BLOCK_WITHOUT_DEFAULTS error to the Det module.] ()

8.1.3.3 Asynchronous multi block requests

8.1.3.3.1 NvM_ReadAll

[SWS_NvM_00460] [

Service name:	NvM_ReadAll	
Syntax:	void	NvM_ReadAll(void
Service ID[hex]:	0x0c	
Sync/Async:	Asynchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Initiates a multi block read request.	

] (SRS_LIBS_08533, BSW176)

[SWS_NvM_00356] [The multi block service NvM_ReadAll shall provide two distinct functionalities.

- Initialize the management data for all NVRAM blocks (see [SWS_NvM_00304](#) ff)
- Copy data to the permanent RAM blocks or call explicit synchronization callback(NvM_ReadRamBlockFromNvm) for those NVRAM blocks which are configured accordingly.

Note: The two functionalities can be implemented in one loop.] ()

[SWS_NvM_00243] [The function NvM_ReadAll shall signal the request to the NvM module and return. The NVRAM Manager shall defer the processing of the requested ReadAll until all single block job queues are empty.] ()

[SWS_NvM_00304] [The job of the function NvM_ReadAll shall set each proceeding block specific job result for NVRAM blocks in advance.] ()

[SWS_NvM_00667] [The job of the function NvM_ReadAll shall set the multi block job result to NVM_REQ_PENDING in advance.] ()

[SWS_NvM_00244] [The job of the function NvM_ReadAll shall iterate over all user NVRAM blocks, i.e. except for reserved Block Ids 0 (multi block request result) and 1 (NV configuration ID), beginning with the lowest Block Id.] ()

[SWS_NvM_00245] [Blocks of management type NVM_BLOCK_DATASET shall not be loaded automatically upon start-up. Thus the selection of blocks, which belong to

block management type NVM_BLOCK_DATASET, shall not be possible for the service NvM_ReadAll.] ()

[SWS_NvM_00362] [The NvM module shall initiate the recalculation of the RAM CRC for every NVRAM block with a valid permanent RAM block or explicit synchronization callback configured and `NvmCalcRamBlockCrc == TRUE` during the processing of `NvM_ReadAll`.] ()

[SWS_NvM_00364] [The job of the function `NvM_ReadAll` shall treat the data for every recalculated RAM CRC which matches the stored RAM CRC as valid and set the block specific request result to `NVM_REQ_OK`.

Note: This mechanism enables the NVRAM Manager to avoid overwriting of maybe still valid RAM data with outdated NV data.] ()

[SWS_NvM_00363] [The job of the function `NvM_ReadAll` shall load default values in case the blocks are marked as invalid or if the recalculated CRC does not match.] ()

[SWS_NvM_00246] [The job of the function `NvM_ReadAll` shall validate the configuration ID by comparing the stored NVRAM configuration ID vs. the compiled NVRAM configuration ID.] ()

[SWS_NvM_00669] [`NvM_ReadAll`: The NVRAM block with the block ID 1 (redundant type with CRC) shall be reserved to contain the stored NVRAM configuration ID.] ()

[SWS_NvM_00247] [The job of the function `NvM_ReadAll` shall process the normal runtime preparation for all configured NVRAM blocks in case of configuration ID match.] ()

[SWS_NvM_00670] [The job of the function `NvM_ReadAll` shall set the error/status information field of the corresponding NVRAM block's administrative block to `NVM_REQ_OK` in case of configuration ID match.] ()

[SWS_NvM_00305] [The job of the function `NvM_ReadAll` shall report the extended production error `NVM_E_REQ_FAILED` to the DEM if the configuration ID cannot be read because of an error detected by one of the subsequent SW layers.] ()

[SWS_NvM_00671] [The job of the function `NvM_ReadAll` shall set the error status field of the reserved NVRAM block to `NVM_REQ_INTEGRITY_FAILED` if the configuration ID cannot be read because of an error detected by one of the subsequent SW layers. The NvM module shall behave in the same way as if a configuration ID mismatch was detected.] ()

[SWS_NvM_00307] [The job of the function NvM_ReadAll shall set the error/status information field of the reserved NVRAM block with ID 1 to NVM_REQ_NOT_OK in the case of configuration ID mismatch.] ()

[SWS_NvM_00306] [In case the NvM module can not read the configuration ID because the corresponding NV blocks are empty or invalidated, the job of the function NvM_ReadAll shall not report an extended production error or a production error to the DEM.] ()

[SWS_NvM_00672] [In case the NvM module can not read the configuration ID because the corresponding NV blocks are empty or invalidated, the job of the function NvM_ReadAll shall set the error/status information field in this NVRAM block's administrative block to NVM_REQ_NV_INVALIDATED.] ()

[SWS_NvM_00673] [NvM_ReadAll: In case the NvM module can not read the configuration ID because the corresponding NV blocks are empty or invalidated, NVM module shall update the configuration ID from the RAM block assigned to the reserved NVRAM block with ID 1 according to the new (compiled) configuration ID. The NvM module shall behave the same way as if the configuration ID matched.] ()

[SWS_NvM_00248] [The job of the function NvM_ReadAll shall ignore a configuration ID mismatch and behave normal if NvMDynamicConfiguration == FALSE [\[SWS_NvM_00028\]](#).] ()

[SWS_NvM_00249] [The job of the function NvM_ReadAll shall process an extended runtime preparation for all blocks which are configured with NvMResistantToChangedSw == FALSE and NvMDynamicConfiguration == TRUE and configuration ID mismatch occurs.] ()

[SWS_NvM_00674] [The job of the function NvM_ReadAll shall process the normal runtime preparation of all NVRAM blocks when they are configured with NvMResistantToChangedSw == TRUE and NvMDynamicConfiguration == TRUE and if a configuration ID mismatch occurs.] ()

[SWS_NvM_00314] [The job of the function NvM_ReadAll shall mark every NVRAM block that has been configured with NVM_WRITE_BLOCK_ONCE (TRUE) and that is not detected by underlying SW as being invalidated, shall be marked as write protected. This write protection cannot be cleared by NvM_SetBlockProtection.] ()

[SWS_NvM_00315] [The job of the function NvM_ReadAll shall only invalidate a NVRAM block of management type NVM_BLOCK_REDUNDANT if both NV blocks have been invalidated.] ()

[SWS_NvM_00718] [The NvM module's environment shall use the multi block request NvM_ReadAll to load and validate the content of configured permanent RAM or to do the explicit synchronization for configured blocks during start-up [\[SWS_NvM_00091\]](#).] ()

[SWS_NvM_00118] [The job of the function NvM_ReadAll shall process only the permanent RAM blocks or call explicit synchronization callback (NvM_ReadRamBlockFromNvm) for blocks which are configured with NvmSelectBlockForReadall == TRUE.] ()

[SWS_NvM_00287] [The job of the function NvM_ReadAll shall set the job result to NVM_REQ_BLOCK_SKIPPED for each NVRAM block configured to be processed by the job of the function NvM_ReadAll (NvMSelectBlockForReadAll is checked) and which has not been read during processing of the NvM_ReadAll job.] ()

[SWS_NvM_00426] [If configured by NvMDrvModeSwitch, the job of the function NvM_ReadAll shall switch the mode of each memory device to "fast-mode" before starting to iterate over all user NVRAM blocks.] ()

[SWS_NvM_00427] [If configured by NvMDrvModeSwitch, the job of the function NvM_ReadAll shall switch the mode of each memory device to "slow-mode" after having processed all user NVRAM blocks.] ()

[SWS_NvM_00308] [The job of the function NvM_ReadAll shall load the ROM default data to the corresponding RAM blocks and set the error/status field in the administrative block to NVM_REQ_OK when processing the extended runtime preparation.] ()

[SWS_NvM_00309] [When executing the extended runtime preparation, the job of the function NvM_ReadAll shall treat the affected NVRAM blocks as invalid or blank in order to allow rewriting of blocks configured with NVM_BLOCK_WRITE_ONCE == TRUE.] ()

[SWS_NvM_00310] [The job of the function NvM_ReadAll shall update the configuration ID from the RAM block assigned to the reserved NVRAM block with ID 1 according to the new (compiled) configuration ID, mark the NVRAM block to be written during NvM_WriteAll and request a CRC recalculation if a configuration ID mismatch occurs and if the NVRAM block is configured with NvMDynamicConfiguration == TRUE.] ()

[SWS_NvM_00311] [The NvM module shall allow applications to send any request for the reserved NVRAM Block ID 1 if (and only if) NvMDynamicConfiguration is set to TRUE, including NvM_WriteBlock and NvM_WritePRAMBlock.] ()

[SWS_NvM_00312] [The NvM module shall not send a request for invalidation of the reserved configuration ID NVRAM block to the underlying layer, unless requested so by the application. This shall ensure that the NvM module's environment can rely on this block to be only invalidated at the first start-up of the ECU or if desired by the application.] ()

[SWS_NvM_00313] [In case of a Configuration ID match, the job of the function NvM_ReadAll shall not automatically write to the Configuration ID block stored in the reserved NVRAM block 1.] ()

[SWS_NvM_00288] [The job of the function NvM_ReadAll shall initiate a read attempt on the second NV block for each NVRAM block of type NVM_BLOCK_REDUNDANT [\[SWS_NvM_00118\]](#), where the read attempt of the first block fails (see also [SWS_NvM_00531](#)).] ()

[SWS_NvM_00290] [The job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_OK if the job has successfully copied the corresponding NV block from NV memory to RAM.] ()

[SWS_NvM_00342] [The job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_NV_INVALIDATED if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00676] [The job of the function NvM_ReadAll shall report no error to the DEM if the MemIf reports MEMIF_BLOCK_INVALID.] ()

[SWS_NvM_00360] [The job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_INTEGRITY_FAILED if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

[SWS_NvM_00677] [The job of the function NvM_ReadAll shall report NVM_E_INTEGRITY_FAILED to the DEM if the MemIf reports MEMIF_BLOCK_INCONSISTENT.] ()

Note: After the production of an ECU / a car, on the production line all blocks shall have been written with valid data (may be default data) and all diagnostic events (errors) shall have been deleted. If the process does not allow to write all NV blocks during production than the NvM will report diagnostic events (errors) because of blocks that were never written and reported as MEMIF_BLOCK_INCONSISTENT by MemIf.

[SWS_NvM_00361] [The job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_NOT_OK if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00678] [The job of the function NvM_ReadAll shall report NVM_E_REQ_FAILED to the DEM, if the MemIf reports MEMIF_JOB_FAILED.] ()

[SWS_NvM_00291] [The job of the function NvM_ReadAll shall set the block specific job result to NVM_REQ_OK if the corresponding block management type is NVM_BLOCK_REDUNDANT and the function has successfully copied one of the NV blocks from NV memory to RAM.] ()

[SWS_NvM_00292] [The job of the function NvM_ReadAll shall request a CRC recalculation over the RAM block data after the copy process [SWS_NvM_00180](#) if the NV block is configured with CRC, , i.e. if NvMCalRamBlockCrC == TRUE for the NV block.] ()

[SWS_NvM_00293] [The job of the function NvM_ReadAll shall load the default values to the RAM blocks according to the processing of NvM_RestoreBlockDefaults (also set the corresponding job result to NVM_REQ_RESTORED_FROM_ROM) if the recalculated CRC is not equal to the CRC stored in NV memory and if the default values are available.] ()

[SWS_NvM_00679] [The job of the function NvM_ReadAll shall load the default values to the RAM blocks according to the processing of NvM_RestoreBlockDefaults (also set the job result to NVM_REQ_RESTORED_FROM_ROM) if the read request passed to the underlying layer fails (MemIf reports MEMIF_JOB_FAILED or MEMIF_BLOCK_INCONSISTENT) and if the default values are available.] ()

[SWS_NvM_00680] [NvM_ReadAll: If the read request passed to the underlying layer fails and there are no default values available, the job shall leave the RAM blocks invalid.] ()

[SWS_NvM_00294] [The job of the function NvM_ReadAll shall report NVM_E_INTEGRITY_FAILED to the DEM if a CRC mismatch occurs.] ()

[SWS_NvM_00295] [The job of the function NvM_ReadAll shall set a block specific job result to NVM_REQ_INTEGRITY_FAILED if a CRC mismatch occurs.] ()

[SWS_NvM_00302] [The job of the function NvM_ReadAll shall report NVM_E_REQ_FAILED to the DEM if the referenced NVRAM Block is not configured with CRC and the corresponding job process has failed.] ()

[SWS_NvM_00301] [The job of the function NvM_ReadAll shall set the multi block job result to NVM_REQ_NOT_OK if the job fails with the processing of at least one NVRAM block.] ()

[SWS_NvM_00281] [If configured by NvMSingleBlockCallback, the job of the function NvM_ReadAll shall call the single block callback after having completely processed a NVRAM block.] ()

Note: The idea behind using the single block callbacks also for multi-block requests is to speed up the software initialization process:

- A single-block callback issued from a multi-block request (e.g. NvM_ReadAll) will result in an RTE event.
- If the RTE is initialized after or during the asynchronous multi-block request (e.g. NvM_ReadAll), all or some of these RTE events will get lost because they are overwritten during the RTE initialization (see SWS_Rte_2536).
- After its initialization, the RTE can use the "surviving" RTE events to start software components even before the complete multi-block request (e.g. NvM_ReadAll) has been finished.
- For those RTE events that got lost during the initialization: the RTE will start those software components and the software components either query the status of the NV block they want to access or request that NV block to be read. This is exactly the same behavior if the single-block callbacks would not be used in multi-block requests.

[SWS_NvM_00251] [The job of the function NvM_ReadAll shall mark a NVRAM block as "valid/unmodified" if NV data has been successfully loaded to the RAM Block.] ()

[SWS_NvM_00367] [The job of the function NvM_ReadAll shall set a RAM block to valid and assume it to be changed if the job has successfully copied default values to the corresponding RAM.] ()

[SWS_NvM_00719] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_ReadAll.] ()

The DEM shall already be able to accept error notifications.

NVRAM common block configuration parameters [[SWS_NvM_00028](#)], block management types [[ECUC_NvM_00061](#)] and all configured NVRAM block descriptors are needed in the configuration with respect to the function NvM_ReadAll [NVM062], [[SWS_NvM_00069](#)].

8.1.3.3.2 NvM_WriteAll

[SWS_NvM_00461] [

Service name:	NvM_WriteAll	
Syntax:	void	NvM_WriteAll(void
Service ID[hex]:	0x0d	
Sync/Async:	Asynchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Initiates a multi block write request.	

] (BSW176, SRS_LIBS_08535)

[SWS_NvM_00018] [The job of the function `NvM_WriteAll` shall synchronize the contents of permanent RAM blocks to their corresponding NV blocks or call explicit synchronization callback (`NvM_WriteRamBlockToNvm`) on shutdown.] (SRS_LIBS_08535)

[SWS_NvM_00733] [If NVRAM block ID 1 (which holds the configuration ID of the memory layout) is marked as "to be written during `NvM_WriteAll`", the job of the function `NvM_WriteAll` shall write this block in a final step (last write operation) to prevent memory layout mismatch in case of a power loss failure during write operation.] ()

[SWS_NvM_00254] [The function `NvM_WriteAll` shall signal the request to the NvM module and return. The NVRAM Manager shall defer the processing of the requested WriteAll until all single block job queues are empty.] ()

[SWS_NvM_00549] [The job of the function `NvM_WriteAll` shall set each proceeding block specific job result for NVRAM blocks and the multi block job result to `NVM_REQ_PENDING` in advance.] ()

[SWS_NvM_00252] [The job of the function `NvM_WriteAll` shall process only the permanent RAM blocks or call explicit synchronization callback (`NvM_WriteRamBlockToNvm`) for all blocks for which the corresponding NVRAM block parameter `NvMSelectBlockForWriteAll` is configured to true.] ()

[SWS_NvM_00430] [If configured by `NvMDrvModeSwitch`, the job of the function `NvM_WriteAll` shall set the mode of each memory device to "fast-mode" before starting to iterate over all non-reserved NVRAM blocks.] ()

[SWS_NvM_00431] [If configured by NvMDrvModeSwitch, the job of the function NvM_WriteAll shall set the mode of each memory device to “slow-mode” after having processed all non-reserved NVRAM blocks.] ()

[SWS_NvM_00681] [If configured by NvMDrvModeSwitch, the job of the function NvM_WriteAll shall set the mode of each memory device to “slow-mode” after the function NvM_CancelWriteAll has canceled the job.] ()

[SWS_NvM_00432] [The job of the function NvM_WriteAll shall check the write-protection for each RAM block in advance.] ()

[SWS_NvM_00682] [The job of the function NvM_WriteAll shall check the “valid/modified” state for each RAM block in advance.] ()

[SWS_NvM_00433] [The job of the function NvM_WriteAll shall only write the content of a RAM block to its corresponding NV block for non write-protected NVRAM blocks.] ()

[SWS_NvM_00474] [The job of the function NvM_WriteAll shall correct the redundant data (if configured) if the redundancy has been lost. In this case the job of the function NvM_WriteAll shall ignore write protection for this block in order to be able to repair it.] ()

Note: If NvM implementation detects loss of redundancy during read operation the user (application) should ensure that redundant block is read (e.g. during NvM_ReadAll by configuring the block to be read during NvM_ReadAll). If the block is not read then the NVM will not be able to correct the redundant block's data.

[SWS_NvM_00434] [The job of the function NvM_WriteAll shall skip every write-protected NVRAM block without error notification.] ()

[SWS_NvM_00750] [The job of the function NvM_WriteAll shall skip every locked NVRAM block without error notification.] ()

[SWS_NvM_00854] [The job of the function NvM_WriteAll shall skip an NVRAM block if the NvMBlockUseCRCCompMechanism attribute is set to true and the RAM block CRC calculated by the write job is equal to the CRC calculated during the last successful read or write job. This mechanism shall not be applied to blocks for which a loss of redundancy has been detected.] (SRS_Mem_00136)

[SWS_NvM_00298] [The job of the function NvM_WriteAll shall set the job result to NVM_REQ_BLOCK_SKIPPED for each NVRAM block configured to be processed by the job of the function NvM_WriteAll (NvMSelectBlockForWriteAll is checked) and which has not been written during processing of the NvM_WriteAll job.] ()

[SWS_NvM_00339] [In case of NVRAM block management type NVM_BLOCK_DATASET, the job of the function NvM_WriteAll shall copy only the RAM block to the corresponding NV block which is selected via the data index in the administrative block.] ()

[SWS_NvM_00253] [The job of the function NvM_WriteAll shall request a CRC recalculation and renew the CRC from a NVRAM block before writing the data if a CRC is configured for this NVRAM block.] (SRS_LIBS_08535)

[SWS_NvM_00296] [The job of the function NvM_WriteAll shall check the number of write retries by a write retry counter to avoid infinite loops. Each unsuccessful result reported by the MemIf module shall be followed by an increment of the retry counter.] ()

[SWS_NvM_00683] [The job of the function NvM_WriteAll shall set the block specific job result to NVM_REQ_NOT_OK if the write retry counter becomes greater than the configured NVM_MAX_NUM_OF_WRITE_RETRIES.] ()

[SWS_NvM_00684] [The job of the function NvM_WriteAll shall report NVM_E_REQ_FAILED to the DEM if the write retry counter becomes greater than the configured NVM_MAX_NUM_OF_WRITE_RETRIES.] ()

[SWS_NvM_00762] [The job of the function NvM_WriteAll shall copy the data content of the RAM block to both corresponding NV blocks if the NVRAM block management type of the processed NVRAM block is NVM_BLOCK_REDUNDANT.] ()

[SWS_NvM_00763] [If the processed NVRAM block is of type NVM_BLOCK_REDUNDANT the job of the function NvM_WriteAll shall start to copy the data of the RAM block to NV block which has not been read during the jobs started by NvM_ReadBlock, NvM_ReadPRAMBlock or NvM_ReadAll then continue to copy the other NV block.] ()

[SWS_NvM_00337] [The job of the function NvM_WriteAll shall set the single block job result to NVM_REQ_OK if the processed NVRAM block is of type NVM_BLOCK_REDUNDANT and at least one of the NV blocks has been written successfully.] ()

[SWS_NvM_00238] [The job of the function NvM_WriteAll shall complete the job in a non-destructive way for the NVRAM block currently being processed if a cancellation of NvM_WriteAll is signaled by a call of NvM_CancelWriteAll.] ()

[SWS_NvM_00237] [The NvM module shall set the multi block request result to NVM_REQ_CANCELED in case of cancellation of NvM_WriteAll.] ()

[SWS_NvM_00685] [NvM_WriteAll: The NvM module shall anyway report the error code condition, due to a failed NVRAM block write, to the DEM.] ()

[SWS_NvM_00318] [The job of the function NvM_WriteAll shall set the multi block request result to NVM_REQ_NOT_OK if processing of one or even more NVRAM blocks fails.] ()

[SWS_NvM_00329] [If the job of the function NvM_WriteAll has successfully written data to NV memory for a NVRAM block configured with NvMWriteBlockOnce == TRUE, the job shall immediately set the corresponding write protection flag in the administrative block.] ()

[SWS_NvM_00720] [The NvM module's environment shall have initialized the NvM module before it calls the function NvM_WriteAll.] ()

No other multiblock request shall be pending when the NvM module's environment calls the function NvM_WriteAll.

Note: To avoid the situation that in case of redundant NVRAM blocks two different NV blocks are containing different but valid data at the same time, each client of the NvM_WriteAll service may call NvM_InvalidateNvBlock in advance.

NVRAM common block configuration parameters [\[SWS NvM 00028\]](#), block management types [\[ECUC NvM 00061\]](#) and all configured NVRAM block descriptors are needed in the configuration with respect to the NvM_WriteAll function [NVM062], [\[SWS NvM 00069\]](#).

8.1.3.3.3 NvM_ValidateAll

[SWS_NvM_00855] [

Service name:	NvM_ValidateAll
Syntax:	void NvM_ValidateAll(void)
Service ID[hex]:	0x19
Sync/Async:	Asynchronous
Reentrancy:	Non Reentrant
Parameters (in):	None
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	Initiates a multi block validation request.

] (SRS_Mem_00137)

[SWS_NvM_00856] [If auto validation is configured for an NVRAM Block (NvMBlockUseAutoValidation == TRUE) and the RAM Block status is not INVALID the function NvM_ValidateAll shall set the RAM Block status to “VALID / CHANGED”.] (SRS_Mem_00137)

[SWS_NvM_00857] [For blocks which meet the conditions of SWS_NvM_00856 and in addition have CRC calculation in RAM configured the function NvM_ValidateAll shall request the recalculation of CRC in the background, i.e. the CRC recalculation shall be processed by the NvM_MainFunction.] (SRS_Mem_00137)

Note: In case that EcuM fixed is used the function NvM_ValidateAll can be accessed via a configured callout.

[SWS_NvM_00858] [The function NvM_ValidateAll shall signal the request to the NvM module and return. The NVRAM Manager shall defer the processing of the requested NvM_ValidateAll function until all single block job queues are empty.] (SRS_Mem_00137)

[SWS_NvM_00859] [The NvM module’s environment shall have initialized the NvM module before it calls the function NvM_ValidateAll.] (SRS_Mem_00137)

[SWS_NvM_00860] [The job of the function NvM_ValidateAll shall process only the permanent RAM blocks or call explicit synchronization callback (NvM_WriteRamBlockToNvm) for all blocks for which the corresponding NVRAM Block parameter NvMBlockUseAutoValidation is configured to true.] (SRS_Mem_00137)

[SWS_NvM_00861] [The job of the function NvM_ValidateAll shall set each proceeding block specific job result for NVRAM blocks and the multi block job result to NVM_REQ_PENDING in advance.] (SRS_Mem_00137)

[SWS_NvM_00862] [The job of the function NvM_ValidateAll shall set the block specific job result to NVM_REQ_OK if the RAM block was successfully validated.] (SRS_Mem_00137)

8.1.3.4 Callback notification of the NvM module

[SWS_NvM_00438] [The NvM module shall provide callback functions to be used by the underlying memory abstraction (EEPROM abstraction / FLASH EEPROM Emulation) to signal end of job state with or without error.

Note: The file NvM_Cbk.h is to be included by the underlying memory driver layers.]
()

8.1.3.4.1 NVRAM Manager job end notification without error

[SWS_NvM_00462] [

Service name:	NvM_JobEndNotification
Syntax:	void NvM_JobEndNotification(void)
Service ID[hex]:	0x11
Sync/Async:	Synchronous
Reentrancy:	Non Reentrant
Parameters (in):	None
Parameters (inout):	None
Parameters (out):	None
Return value:	None
Description:	Function to be used by the underlying memory abstraction to signal end of job without error.

] ()

[SWS_NvM_00111] [The callback function NvM_JobEndNotification is used by the underlying memory abstraction to signal end of job without error.

Note: Successful job end notification of the memory abstraction:

- Read finished & OK
- Write finished & OK
- Erase finished & OK

This routine might be called in interrupt context, depending on the calling function. All memory abstraction modules should be configured to use the same mode (callback/polling).] ()

[SWS_NvM_00440] [The NvM module shall only provide the callback function NvM_JobEndNotification if polling mode is disabled via NvMPollingMode.

The function NvM_JobEndNotification is affected by the common [\[SWS_NvM_00028\]](#) configuration parameters.] ()

8.1.3.4.2 NVRAM Manager job end notification with error

[SWS_NvM_00463] [

Service name:	NvM_JobErrorNotification	
Syntax:	void	NvM_JobErrorNotification(void
Service ID[hex]:	0x12	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Function to be used by the underlying memory abstraction to signal end of job with error.	

] (SRS_Mem_00125)

[SWS_NvM_00112] [The callback function NvM_JobErrorNotification is to be used by the underlying memory abstraction to signal end of job with error.

Note: Unsuccessful job end notification of the memory abstraction:

- Read aborted or failed
- Write aborted or failed
- Erase aborted or failed

This routine might be called in interrupt context, depending on the calling function. All memory abstraction modules should be configured to use the same mode (callback/polling).] ()

[SWS_NvM_00441] [The NvM module shall only provide the callback function NvM_JobErrorNotification if polling mode is disabled via NvMPollingMode.

The function NvM_JoberrorNotification is affected by the common

[\[SWS_NvM_00028\]](#) configuration parameters.] ()

8.1.3.5 Scheduled functions

These functions are directly called by the Basic Software Scheduler. The following functions shall have no return value and no parameter. All functions shall be non reentrant.

[SWS_NvM_00464] [

Service name:	NvM_MainFunction	
Syntax:	void	NvM_MainFunction(void
Service ID[hex]:	0x0e	
Description:	Service for performing the processing of the NvM jobs.	

] (SRS_BSW_00425, SRS_BSW_00373, SRS_BSW_00376, SRS_BSW_00172)

[SWS_NvM_00256] [The function NvM_MainFunction shall perform the processing of the NvM module jobs.] ()

[SWS_NvM_00333] [The function NvM_MainFunction shall perform the CRC recalculation if requested for a NVRAM block in addition to [SWS_NvM_00256](#).] ()

[SWS_NvM_00334] [The NvM module shall only start writing of a block (i.e. hand over the job to the lower layers) after CRC calculation for this block has been finished.] ()

[SWS_NvM_00257] [The NvM module shall only do/start job processing, queue management and CRC recalculation if the NvM_Init function has internally set an "INIT DONE" signal.] ()

[SWS_NvM_00258] [The function NvM_MainFunction shall restart a destructively canceled request caused by an immediate priority request after the NvM module has processed the immediate priority request [[SWS_NvM_00182](#)].] ()

[SWS_NvM_00259] [The function NvM_MainFunction shall supervise the immediate priority queue (if configured) regarding the existence of immediate priority requests.] ()

[SWS_NvM_00346] [If polling mode is enabled, the function NvM_MainFunction shall check the status of the requested job sent to the lower layer.] ()

[SWS_NvM_00347] [If callback routines are configured, the function NvM_MainFunction shall call callback routines to the upper layer after completion of an asynchronous service.] ()

[SWS_NvM_00350] [In case of processing an NvM_WriteAll multi block request, the function NvM_MainFunction shall not call callback routines to the upper layer as long

as the service MemIf_GetStatus returns MEMIF_BUSY_INTERNAL for the reserved device ID MEMIF_BROADCAST_ID [7]. For this purpose (status is MEMIF_BUSY_INTERNAL), the function NvM_MainFunction shall cyclically poll the status of the Memory Hardware Abstraction independent of being configured for polling or callback mode.] ()

[SWS_NvM_00349] [The function NvM_MainFunction shall return immediately if no further job processing is possible.] ()

[SWS_NvM_00721] [NVRAM blocks with immediate priority are not expected to be configured to have a CRC.] ()

8.1.4 Expected Interfaces

In this chapter, all interfaces required by other modules are listed.

8.1.4.1 Mandatory Interfaces

The following table defines all interfaces which are required to fulfill the core functionality of the module.

[SWS_NvM_00465] [

<i>API function</i>	<i>Description</i>
EcuM_CB_NfyNvMJobEnd	Used to notify about the end of NVRAM jobs initiated by EcuM. The callback must be callable from normal and interrupt execution contexts.
MemIf_Cancel	Invokes the "Cancel" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_EraseImmediateBlock	Invokes the "EraseImmediateBlock" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_GetJobResult	Invokes the "GetJobResult" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_GetStatus	Invokes the "GetStatus" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_InvalidateBlock	Invokes the "InvalidateBlock" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_Read	Invokes the "Read" function of the underlying memory abstraction module selected by the parameter DeviceIndex.
MemIf_Write	Invokes the "Write" function of the underlying memory abstraction module selected by the parameter DeviceIndex.

] (SRS_BSW_00383, SRS_BSW_00384, BSW00421)

8.1.4.2 Optional Interfaces

The following table defines all interfaces which are required to fulfill an optional functionality of the module.

[SWS_NvM_00466] [

<i>API function</i>	<i>Description</i>
Crc_CalculateCRC16	This service makes a CRC16 calculation on Crc_Length data bytes.
Crc_CalculateCRC32	This service makes a CRC32 calculation on Crc_Length data bytes.
Crc_CalculateCRC8	This service makes a CRC8 calculation on Crc_Length data bytes, with SAE J1850 parameters
Dem_ReportErrorStatus	Queues the reported events from the BSW modules (API is only used by BSW modules). The interface has an asynchronous behavior, because the processing of the event is done within the Dem main function. OBD Events Suppression shall be ignored for this computation.
Det_ReportError	Service to report development errors.
MemIf_SetMode	Invokes the "SetMode" functions of all underlying memory abstraction modules.

] (SRS_BSW_00383, SRS_BSW_00384)

8.1.4.3 Configurable interfaces

In this chapter, all interfaces are listed for which the target function can be configured. The target function is usually a callback function. The names of these interfaces are not fixed because they are configurable.

[SWS_NvM_00113] [The notification of a caller via an asynchronous callback routine (NvMSingleBlockCallback) shall be optionally configurable for all NV blocks (see ECUC_NvM_00061).] ()

[SWS_NvM_00740] [If a callback is configured for a NVRAM block, every asynchronous block request to the block itself shall be terminated with an invocation of the callback routine.] ()

[SWS_NvM_00741] [The ID identifying the NVRAM service, shall be passed to the callback routine.] ()

[SWS_NvM_00742] [If no callback is configured for a NVRAM block, there shall be no asynchronous notification of the caller in case of an asynchronous block request.] ()

[SWS_NvM_00260] [A common callback entry (NvMMultiBlockCallback) which is not bound to any NVRAM block shall be optionally configurable for all asynchronous multi block requests (including NvM_CancelWriteAll).] ()

[SWS_NvM_00686] [The ID identifying the NVRAM service shall be passed to the common callback routine (NvMMultiBlockCallback).] ()

8.1.4.3.1 Single block job end notification

[SWS_NvM_00467] [

Service name:	NvM_SingleBlockCallbackFunction	
Syntax:	Std_ReturnType NvM_SingleBlockCallbackFunction(uint8 ServiceId, NvM_RequestResultType JobResult)	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	ServiceId	Unique Service ID of NVRAM manager service.
	JobResult	Covers the job result of the previous processed single block job.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: callback function has been processed successfully any other: callback function has been processed unsuccessfully
Description:	Per block callback routine to notify the upper layer that an asynchronous single block request has been finished.	

] (SRS_BSW_00457 , SRS_BSW_00360 , SRS_BSW_00333)

Note: The following requirements are related to the above mentioned callback [SWS_NVM_00176](#), [SWS_NVM_00281](#), [SWS_NvM_00113](#) and [ECUC_NvM_00506](#).

Note: Please refer to NvMSingleBlockCallback in chapter 10. The Single block job end notification might be called in interrupt context only if there is no callback configured in NvM that belongs to a SW-C.

8.1.4.3.2 Multi block job end notification

[SWS_NvM_00468] [

Service name:	NvM_MultiBlockCallbackFunction	
Syntax:	void NvM_MultiBlockCallbackFunction(uint8 ServiceId, NvM_RequestResultType JobResult)	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	ServiceId	Unique Service ID of NVRAM manager service.
	JobResult	Covers the job result of the previous processed multi block job.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Common callback routine to notify the upper layer that an asynchronous multi block request has been finished.	

] (SRS_BSW_00457 , SRS_BSW_00360 , SRS_BSW_00333)

Note: The following requirements are related to the above mentioned callback [SWS_NVM_00179](#), [SWS_NVM_00260](#), [SWS_NVM_00686](#) and [ECUC_NvM_00500](#).

Note: Please refer to NvMMultiBlockCallback in chapter 10. The Multi block job end notification might be called in interrupt context, depending on the calling function.

8.1.4.3.3 Callback function for block initialization

[SWS_NvM_00469] [

Service name:	InitBlockCallbackFunction	
Syntax:	Std_ReturnType	InitBlockCallbackFunction(void)
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: callback function has been processed successfully any other: callback function has been processed unsuccessfully
Description:	Per block callback routine which shall be called by the NvM module when default data needs to be restored in RAM, even if a ROM block is configured. Note: Here the application should copy default data to a RAM block if a ROM block isn't configured and/or it could set some flags to know that default data was restored.	

] (SRS_BSW_00457 , SRS_BSW_00360 , SRS_BSW_00333)

Note: The following requirements are related to the above mentioned callback: [SWS_NVM_00085](#), [SWS_NVM_00266](#), [SWS_NvM_00817](#) and [ECUC_NvM_00116](#).

[SWS_NvM_00369] [If the Init block callback returns a value different than E_OK and the block has no default data configured then the job result shall be set to NVM_REQ_NOT_OK.

Note: The Init block callback is called either if a read request for a block failed in retrieving the data from the non-volatile memory or if explicit default data recovery is requested. Either way, NvM will attempt to retrieve the default data for the block and then call the init callback. If the block has no default data and the Init block callback does not indicate E_OK, the read/restore defaults operation has failed completely and the job result needs to reflect this.] ()

Note: Please refer to NvMInitBlockCallback in chapter 10. The init block callback function might be called in interrupt context only if there is no callback configured in NvM that belongs to a SW-C.

8.1.4.3.4 Callback function for RAM to NvM copy

[SWS_NvM_00539] [

Service name:	NvM_WriteRamBlockToNvm	
Syntax:	Std_ReturnType void* NvM_WriteRamBlockToNvm(NvMBuffer)	
Service ID[hex]:	--	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	None	
Parameters (inout):	None	
Parameters (out):	NvMBuffer	the address of the buffer where the data shall be written to
Return value:	Std_ReturnType	E_OK: callback function has been processed successfully any other: callback function has been processed unsuccessfully
Description:	Block specific callback routine which shall be called in order to let the application copy data from RAM block to NvM module's mirror.	

] (SRS_BSW_00457)

[SWS_NvM_00541] [The RAM to NvM copy callback shall be a function pointer.] ()
Note: Please refer to NvMWriteRamBlockToNvM in chapter 10.

8.1.4.3.5 Callback function for NvM to RAM copy

[SWS_NvM_00540] [

Service name:	NvM_ReadRamBlockFromNvm	
Syntax:	Std_ReturnType const void* NvM_ReadRamBlockFromNvm(NvMBuffer)	
Service ID[hex]:	--	
Sync/Async:	Synchronous	
Reentrancy:	Non Reentrant	
Parameters (in):	NvMBuffer	the address of the buffer where the data can be read from
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: callback function has been processed successfully any other: callback function has been processed unsuccessfully
Description:	Block specific callback routine which shall be called in order to let the application copy data from NvM module's mirror to RAM block.	

] (SRS_LIBS_08533, BSW176, SRS_BSW_00457)

[SWS_NvM_00542] [The NvM to RAM copy callback shall be a function pointer.] ()
Note: Please refer to NvMReadRamBlockFromNvM in chapter 10.

8.1.5 API Overview

Request Types	Characteristics of Request Types
Type 1: - NvM_SetDataIndex (...) - NvM_GetDataIndex (...) - NvM_SetBlockProtection (...) - NvM_GetErrorStatus(...) - NvM_SetRamBlockStatus(...)	- synchronous request - affects one RAM block - available for all SW-Cs
Type 2: - NvM_ReadBlock(...) - NvM_WriteBlock(...) - NvM_RestoreBlockDefaults(...) - NvM_EraseNvBlock(...) - NvM_InvalidateNvBlock(...) - NvM_CancelJobs(...) - NvM_ReadPRAMBlock(...) - NvM_WritePRAMBlock(...) - NvM_RestorePRAMBlockDefaults(...)	- asynchronous request (result via callback or polling) - affects one NVRAM block - handled by NVRAM manager task via request list - available for all SW-Cs
Type 3: - NvM_ReadAll(...) - NvM_WriteAll(...) - NvM_CancelWriteAll(...) - NvM_ValidateAll(...)	- asynchronous request (result via callback or polling) - affects all NVRAM blocks with permanent RAM data
Type 4: - NvM_Init(...)	- synchronous request - basic initialization - success signaled to the task via command interface inside the function itself

8.2 Service Interfaces

This chapter is an addition to the specification of the NvM module. Whereas the other parts of the specification define the behavior and the C-interfaces of the corresponding basic software module, this chapter formally specifies the corresponding AUTOSAR service in terms of the SWC template. The interfaces described here will be visible on the VFB and are used to generate the RTE between application software and the NvM module.

8.2.1 Client-Server-Interfaces

8.2.1.1 NvM_Admin

[SWS_NvM_00737] [

Name	NvMAdmin	
Comment	--	
IsService	true	
Variation	--	
Possible Errors	0	E_OK
	1	E_NOT_OK

Operations

SetBlockProtection		
Comments	Service for setting/resetting the write protection for a NV block.	
Variation	{ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3	
Parameters	ProtectionEnabled	
	Comment	--
	Type	boolean
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--

] ()

8.2.1.2 NvM_Mirror

[SWS_NvM_00738] [

Name	NvMMirror	
Comment	--	
IsService	true	
Variation	--	
Possible Errors	0	E_OK
	1	E_NOT_OK

Operations

ReadRamBlockFromNvM		
Comments	Block specific callback routine which shall be called in order to let the application copy data from NvM module's mirror to RAM block.	
Variation	--	
Parameters	SrcPtr	
	Comment	The parameter "SrcPtr" shall be typed by an ImplementationDataType of category DATA_REFERENCE with the pointer target void to pass an address (pointer) to the RAM Block.
	Type	ConstVoidPtr
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
WriteRamBlockToNvM		
Comments	Block specific callback routine which shall be called in order to let the application copy data from RAM block to NvM module's mirror.	
Variation	--	
Parameters	DstPtr	
	Comment	The parameter "DstPtr" shall be typed by an ImplementationDataType of category DATA_REFERENCE with the pointer target void to pass an address (pointer) to the RAM Block.
	Type	VoidPtr
	Variation	--
	Direction	IN

Possible Errors	E_OK	Operation successful
	E_NOT_OK	--

] ()

8.2.1.3 NvM_NotifyInitBlock

[SWS_NvM_00736] [

Name	NvMNotifyInitBlock	
Comment	Callback that is called by the NvM module when default data needs to be restored to the RAM image	
IsService	true	
Variation	--	
Possible Errors	0	E_OK

Operations

InitBlock		
Comments	This callback is called if the initialization of a block has completed.	
Variation	--	
Possible Errors	E_OK	Operation successful

] ()

8.2.1.4 NvM_NotifyJobFinished

[SWS_NvM_00735]

Name	NvMNotifyJobFinished	
Comment	Callback that is called when a job has finished	
IsService	true	
Variation	--	
Possible Errors	0	E_OK

Operations

JobFinished		
Comments	Callback that gets called if a job has finished	
Variation	--	
Parameters	ServiceId	
	Comment	--
	Type	uint8
	Variation	--
	Direction	IN
	JobResult	
	Comment	--
	Type	NvM_RequestResultType
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful

] ()

8.2.1.5 NvM_Service

[SWS_NvM_00734]

Name	NvMService	
Comment	--	
IsService	true	
Variation	--	
Possible Errors	0	E_OK

	1	E_NOT_OK
--	---	----------

Operations

EraseBlock		
Comments	Service to erase a NV block.	
Variation	{ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3	
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
GetDataIndex		
Comments	Service for getting the currently set DataIndex of a dataset NVRAM block	
Variation	<pre>(({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2) ({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)) && (count({ecuc(NvM/NvMBlockDescriptor/ NvMBlockManagementType)} == NVM_BLOCK_DATASET) > 0)</pre>	
Parameters	DataIndexPtr	
	Comment	--
	Type	uint8
	Variation	--
	Direction	OUT
Possible Errors	E_OK	Operation successful
	E_NOT_OK	An error occurred or the block is not of type DATASET
GetErrorStatus		
Comments	Service to read the block dependent error/status information.	
Variation	--	
Parameters	RequestResultPtr	
	Comment	--
	Type	NvM_RequestResultType
	Variation	--
	Direction	OUT
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--

InvalidateNvBlock		
Comments	Service to invalidate a NV block.	
Variation	{ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3	
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
ReadBlock		
Comments	Service to copy the data of the NV block to its corresponding RAM block.	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	
Parameters	DstPtr	
	Comment	The parameter "DstPtr" shall be typed by an ImplementationDataType of category DATA_REFERENCE with the pointer target void to pass an address (pointer) to the RAM Block.
	Type	VoidPtr
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
ReadPRAMBlock		
Comments	--	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
RestoreBlockDefaults		
Comments	Service to restore the default data to its corresponding RAM block.	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	

Parameters	DstPtr	
	Comment	The parameter "DstPtr" shall be typed by an ImplementationDataType of category DATA_REFERENCE with the pointer target void to pass an address (pointer) to the RAM Block.
	Type	VoidPtr
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
RestorePRAMBlockDefaults		
Comments	--	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
SetDataIndex		
Comments	Service for setting the DataIndex of a dataset NVRAM block.	
Variation	((({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2) ({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)) && (count({ecuc(NvM/NvMBlockDescriptor/NvMBlockManagementType)} == NVM_BLOCK_DATASET) > 0))	
Parameters	DataIndex	
	Comment	--
	Type	uint8
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	An error occurred or the block is not of type DATASET
SetRamBlockStatus		
Comments	Service for setting the RAM block status of an NVRAM block.	

Variation	{ecuc(NvM/NvMBlockDescriptor/NvMBlockUseSetRamBlockStatus)} == true	
Parameters	BlockChanged	
	Comment	--
	Type	boolean
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
WriteBlock		
Comments	Service to copy the data of the RAM block to its corresponding NV block.	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	
Parameters	SrcPtr	
	Comment	The parameter "SrcPtr" shall be typed by an ImplementationDataType of category DATA_REFERENCE with the pointer target void to pass an address (pointer) to the RAM Block.
	Type	ConstVoidPtr
	Variation	--
	Direction	IN
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--
WritePRAMBlock		
Comments	--	
Variation	({ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_2 {ecuc(NvM/NvMCommon/NvMApiConfigClass)} == NVM_API_CONFIG_CLASS_3)	
Possible Errors	E_OK	Operation successful
	E_NOT_OK	--

] ()

8.2.2 Implementation Data Types

8.2.2.1 ImplementationDataType NvM_RequestResultType

[SWS_NvM_00841]

Name	NvM_RequestResultType		
Kind	Type		
Derived from	uint8		
Description	This is an asynchronous request result returned by the API service NvM_GetErrorStatus. The availability of an asynchronous request result can be additionally signaled via a callback function.		
Range	NVM_REQ_OK	0x00	0x00: The last asynchronous request has been finished successfully. This shall be the default value after reset. This status shall have the value 0.
	NVM_REQ_NOT_OK	0x01	0x01: The last asynchronous read/write/control request has been finished unsuccessfully.
	NVM_REQ_PENDING	0x02	0x02: An asynchronous read/write/control request is currently pending.
	NVM_REQ_INTEGRITY_FAILED	0x03	0x03: The result of the last asynchronous request NvM_ReadBlock or NvM_ReadAll is a data integrity failure. Note: In case of NvM_ReadBlock the content of the RAM block has changed but has become invalid. The application is responsible to renew and validate the RAM block content.
	NVM_REQ_BLOCK_SKIPPED	0x04	0x04: The referenced block was skipped during execution of NvM_ReadAll or NvM_WriteAll, e.g. Dataset NVRAM blocks (NvM_ReadAll) or NVRAM blocks without a permanently configured RAM block.
	NVM_REQ_NV_INVALIDATED	0x05	0x05: The referenced NV block is invalidated.
	NVM_REQ_CANCELED	0x06	0x06: The multi block request

			NvM_WriteAll was canceled by calling NvM_CancelWriteAll. Or Any single block job request (NvM_ReadBlock, NvM_WriteBlock, NvM_EraseNvBlock, NvM_InvalidateNvBlock and NvM_RestoreBlockDefaults) was canceled by calling NvM_CancelJobs.
	NVM_REQ_REDUNDANCY_FAILED	0x07	0x07: The required redundancy of the referenced NV block is lost. (obsolete)
	NVM_REQ_RESTORED_FROM_ROM	0x08	0x08: The referenced NV block had the default values copied to the RAM image.
Variation	--		

] ()

8.2.2.2 ImplementationDataType NvM_BlockIdType

[SWS_NvM_00842]

Name	NvM_BlockIdType		
Kind	Type		
Derived from	uint16		
Description	<p>Identification of a NVRAM block via a unique block identifier.</p> <p>Reserved NVRAM block IDs: 0 -> to derive multi block request results via NvM_GetErrorStatus 1 -> redundant NVRAM block which holds the configuration ID</p>		
Range	0..2 ^(16- NvMDatasetSelectionBits) -1		--
Variation	--		

] ()

8.2.2.3 ImplementationDataType ConstVoidPtr

[SWS_NvM_00848]

Name	ConstVoidPtr		
Kind	Type		
ImplementationPolicy	const		
Derived from	void		
Description	--		
Variation	--		

] ()

8.2.3 Ports

8.2.3.1 NvM_PAdmin_{Block}

[SWS_NvM_00843]

Name	PAdmin_{Block}		
Kind	ProvidedPort	Interface	NvMAdmin
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.2 NvM_PM_{Block}

[SWS_NvM_00844]

Name	PM_{Block}		
Kind	RequiredPort	Interface	NvMMirror
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.3 NvM_PNIB_{Block}

[SWS_NvM_00845]

Name	PNIB_{Block}		
Kind	RequiredPort	Interface	NvMNotifyInitBlock
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.4 NvM_PNJF_{Block}

[SWS_NvM_00846]

Name	PNJF_{Block}		
Kind	RequiredPort	Interface	NvMNotifyJobFinished
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

8.2.3.5 NvM_PS_{Block}

[SWS_NvM_00847]

Name	PS_{Block}		
------	------------	--	--

Kind	ProvidedPort	Interface	NvMService
Description	--		
Variation	Block = {ecuc(NvM/NvMBlockDescriptor.SHORT-NAME)}		

] ()

9 Sequence Diagrams

9.1 Synchronous calls

9.1.1 NvM_Init




Figure 12: UML sequence diagram NvM_Init

9.1.2 NvM_SetDataIndex




Figure 13: UML sequence diagram NvM_SetDataIndex

9.1.3 NvM_GetDataIndex




Figure 14: UML sequence diagram NvM_GetDataIndex

9.1.4 NvM_SetBlockProtection




Figure 15: UML sequence diagram NvM_SetBlockProtection

9.1.5 NvM_GetErrorStatus




Figure 16: UML sequence diagram NvM_GetErrorStatus

9.1.6 NvM_GetVersionInfo




Figure 17: UML sequence diagram NvM_GetVersionInfo

9.2 Asynchronous calls

The following sequence diagrams concentrate on the interaction between the NvM module and SW-C's or the ECU state manager. For interaction regarding the Memory Interface please ref. to [5] or [6].

9.2.1 Asynchronous call with polling

The following diagram shows the function NvM_WriteBlock as an example of a request that is performed asynchronously. The sequence for all other asynchronous functions is the same, only the processed number of blocks and the block types may vary. The result of the asynchronous function is obtained by polling requests to the error/status information.




Figure 18: UML sequence diagram for asynchronous call with polling

9.2.2 Asynchronous call with callback

The following diagram shows the function NvM_WriteBlock as an example of a request that is performed asynchronously. The sequence for all other asynchronous functions is the same, only the processed number of blocks and the block types may vary. The result of the asynchronous function is obtained after an asynchronous notification (callback) by requesting the error/status information.




Figure 19: UML sequence diagram for asynchronous call with callback

9.2.3 Cancellation of a Multi Block Request

The following diagram shows the effect of a cancel operation applied to a running NvM_WriteAll multi block request. The running NvM_WriteAll function completes the actual NVRAM block and stops further writes.




Figure 20: UML sequence diagram for cancellation of asynchronous call

10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals. It also specifies a template (table) you shall use for the parameter specification.

Chapter 10.2 specifies the structure (containers) and the parameters of the module NvM.

Chapter 10.2.8 specifies published information of the module NvM.

10.1 How to read this chapter

For details refer to the chapter 10.1 “Introduction to configuration specification” in *SWS_BSWGeneral*.

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe chapter 7.2 and chapter 8.

10.2.1 Variants

[SWS_NvM_00727] [The NVM module shall support the configuration variants VARIANT-PRE-COMPILE and VARIANT-LINK-TIME.

The VARIANT-PRE-COMPILE is designed for all parameters to be fixed at compile time.

The VARIANT-LINK-TIME is designed for the use cases where parameters are fixed at link-time. This variant is particularly useful for integrators not in possession of the NvM source code.] ()

10.2.2 NvM

SWS Item	ECUC_NvM_00539 :
Module Name	NvM
Module Description	Configuration of the NvM (NvRam Manager) module.
Post-Build Variant Support	false

Included Containers		
Container Name	Multiplicity	Scope / Dependency
NvMBlockDescriptor	1..65536	Container for a management structure to configure the composition of a given NVRAM Block Management Type. Its multiplicity describes the number of configured NVRAM blocks, one block is required to be configured. The NVRAM block descriptors are condensed in the NVRAM block descriptor table.
NvMCommon	1	Container for common configuration options.
NvmDemEventParameterRefs	0..1	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus

		API in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in the container and can be extended by vendor specific error references.
--	--	---

10.2.3 NvMCommon

SWS Item	ECUC_NvM_00028 :	
Container Name	NvMCommon	
Description	Container for common configuration options.	
Configuration Parameters		

SWS Item	ECUC_NvM_00491 :		
Name	NvMApiConfigClass		
Description	Preprocessor switch to enable some API calls which are related to NVM API configuration classes.		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	NVM_API_CONFIG_CLASS_1	All API calls belonging to configuration class 1 are available.	
	NVM_API_CONFIG_CLASS_2	All API calls belonging to configuration class 2 are available.	
	NVM_API_CONFIG_CLASS_3	All API calls belonging to configuration class 3 are available.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope Dependency	/scope: local		

SWS Item	ECUC_NvM_00550 :		
Name	NvMBswMMultiBlockJobStatusInformation		
Description	This parameter specifies whether BswM is informed about the current status of the multiblock job. True: call BswM_NvM_CurrentJobMode if ReadAll and WriteAll are started, finished, canceled False: do not inform BswM at all		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	true		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00492 :	
Name	NvMCompiledConfigId	
Description	Configuration ID regarding the NV memory layout. This configuration ID shall be published as e.g. a SW-C shall have the possibility to write it to NV memory.	
Multiplicity	1	
Type	EcucIntegerParamDef	
Range	0 .. 65535	

Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00493 :		
Name	NvMCrcNumOfBytes		
Description	If CRC is configured for at least one NVRAM block, this parameter defines the maximum number of bytes which shall be processed within one cycle of job processing.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00494 :		
Name	NvMDatasetSelectionBits		
Description	<p>Defines the number of least significant bits which shall be used to address a certain dataset of a NVRAM block within the interface to the memory hardware abstraction.</p> <p>0..8: Number of bits which are used for dataset or redundant block addressing.</p> <p>0: No dataset or redundant NVRAM blocks are configured at all, no selection bits required.</p> <p>1: In case of redundant NVRAM blocks are configured, but no dataset NVRAM blocks.</p>		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 8		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local dependency: MemHwA, NVM_NVRAM_BLOCK_IDENTIFIER, NVM_BLOCK_MANAGEMENT_TYPE		

SWS Item	ECUC_NvM_00495 :		
Name	NvMDevErrorDetect		
Description	<p>Switches the Default Error Tracer (Det) detection and notification ON or OFF.</p> <ul style="list-style-type: none"> true: enabled (ON). false: disabled (OFF). 		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		

Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00496 :		
Name	NvMDrvModeSwitch		
Description	Preprocessor switch to enable switching memory drivers to fast mode during performing NvM_ReadAll and NvM_WriteAll true: Fast mode enabled. false: Fast mode disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00497 :		
Name	NvMDynamicConfiguration		
Description	Preprocessor switch to enable the dynamic configuration management handling by the NvM_ReadAll request. true: Dynamic configuration management handling enabled. false: Dynamic configuration management handling disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00498 :		
Name	NvMJobPrioritization		
Description	Preprocessor switch to enable job prioritization handling true: Job prioritization handling enabled. false: Job prioritization handling disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00555 :		
Name	NvMMainFunctionPeriod		
Description	The period between successive calls to the main function in seconds.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	1E-7 .. INF		
Default value	--		
Post-Build Variant Value	false		

Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00500 :		
Name	NvMMultiBlockCallback		
Description	Entry address of the common callback routine which shall be invoked on termination of each asynchronous multi block request		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Multiplicity	Variant	false	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00501 :		
Name	NvMPollingMode		
Description	Preprocessor switch to enable/disable the polling mode in the NVRAM Manager and at the same time disable/enable the callback functions useable by lower layers true: Polling mode enabled, callback function usage disabled. false: Polling mode disabled, callback function usage enabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00518 :		
Name	NvMRepeatMirrorOperations		
Description	Defines the number of retries to let the application copy data to or from the NvM module's mirror before postponing the current job.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 7		
Default value	0		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00502 :		
Name	NvMSetRamBlockStatusApi		
Description	Preprocessor switch to enable the API NvM_SetRamBlockStatus. true: API NvM_SetRamBlockStatus enabled. false: API NvM_SetRamBlockStatus disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00503 :		
Name	NvMSizeImmediateJobQueue		
Description	Defines the number of queue entries for the immediate priority job queue. If NVM_JOB_PRIORITIZATION is switched OFF this parameter shall be out of scope.		
Multiplicity	0..1		
Type	EcucIntegerParamDef		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		local
	dependency: NVM_JOB_PRIORITIZATION		

SWS Item	ECUC_NvM_00504 :		
Name	NvMSizeStandardJobQueue		
Description	Defines the number of queue entries for the standard job queue.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00505 :		
Name	NvMVersionInfoApi		
Description	Pre-processor switch to enable / disable the API to read out the modules version information [NVM285], [NVM286]. true: Version info API enabled. false: Version info API disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		

Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: local		

No Included Containers

[SWS_NvM_00028] [The following tables specify parameters that shall be definable in the module's configuration file (NvM_Cfg.h).] (SRS_BSW_00167, SRS_BSW_00381, SRS_BSW_00388, SRS_BSW_00389, SRS_BSW_00390, SRS_BSW_00391, SRS_BSW_00392, SRS_BSW_00393, SRS_BSW_00394, SRS_BSW_00395, SRS_BSW_00396, SRS_BSW_00397, SRS_BSW_00171)

10.2.4 NvMBlockDescriptor

SWS Item	ECUC_NvM_00061 :		
Container Name	NvMBlockDescriptor		
Description	Container for a management structure to configure the composition of a given NVRAM Block Management Type. Its multiplicity describes the number of configured NVRAM blocks, one block is required to be configured. The NVRAM block descriptors are condensed in the NVRAM block descriptor table.		
Configuration Parameters			

SWS Item	ECUC_NvM_00476 :		
Name	NvMBlockCrcType		
Description	Defines CRC data width for the NVRAM block. Default: NVM_CRC16, i.e. CRC16 will be used if NVM_BLOCK_USE_CRC==true		
Multiplicity	0..1		
Type	EcucEnumerationParamDef		
Range	NVM_CRC16	(Default) CRC16 will be used if NVM_BLOCK_USE_CRC==true.	
	NVM_CRC32	CRC32 is selected for this NVRAM block if NVM_BLOCK_USE_CRC==true.	
	NVM_CRC8	CRC8 is selected for this NVRAM block if NVM_BLOCK_USE_CRC==true.	
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope Dependency	scope: local dependency: NVM_BLOCK_USE_CRC, NVM_CALC_RAM_BLOCK_CRC		

SWS Item	ECUC_NvM_00554 :		
Name	NvMBlockHeaderInclude		
Description	Defines the header file where the owner of the NVRAM block has the declarations of the permanent RAM data block, ROM data block (if		

	configured) and the callback function prototype for each configured callback. If no permanent RAM block, ROM block or callback functions are configured then this configuration parameter shall be ignored.		
Multiplicity	0..1		
Type	EcucStringParamDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00477 :		
Name	NvMBlockJobPriority		
Description	Defines the job priority for a NVRAM block (0 = Immediate priority).		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 255		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00062 :		
Name	NvMBlockManagementType		
Description	Defines the block management type for the NVRAM block.[NVM137]		
Multiplicity	1		
Type	EcucEnumerationParamDef		
Range	NVM_BLOCK_DATASET	NVRAM block is configured to be of dataset type.	
	NVM_BLOCK_NATIVE	NVRAM block is configured to be of native type.	
	NVM_BLOCK_REDUNDANT	NVRAM block is configured to be of redundant type.	
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope Dependency	scope: local		

SWS Item	ECUC_NvM_00557 :		
Name	NvMBlockUseAutoValidation		
Description	Defines whether the RAM Block shall be auto validated during shutdown phase.		

	true: if auto validation mechanism is used, false: otherwise		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00556 :		
Name	NvMBlockUseCRCCompMechanism		
Description	Defines whether the CRC of the RAM Block shall be compared during a write job with the CRC which was calculated during the last successful read or write job. true: if compare mechanism is used, false: otherwise		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00036 :		
Name	NvMBlockUseCrc		
Description	Defines CRC usage for the NVRAM block, i.e. memory space for CRC is reserved in RAM and NV memory. true: CRC will be used for this NVRAM block. false: CRC will not be used for this NVRAM block.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00552 :		
Name	NvMBlockUseSetRamBlockStatus		
Description	Defines if NvMSetRamBlockStatusApi shall be used for this block or not. Note: If NvMSetRamBlockStatusApi is disabled this configuration parameter shall be ignored. true: calling of NvMSetRamBlockStatus for this RAM block shall set the status of the RAM block. false: calling of NvMSetRamBlockStatus for this RAM block shall be ignored.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	

Scope / Dependency	scope: local
---------------------------	--------------

SWS Item	ECUC_NvM_00519 :		
Name	NvMBlockUseSyncMechanism		
Description	Defines whether an explicit synchronization mechanism with a RAM mirror and callback routines for transferring data to and from NvM module's RAM mirror is used for NV block. true if synchronization mechanism is used, false otherwise.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00033 :		
Name	NvMBlockWriteProt		
Description	Defines an initial write protection of the NV block true: Initial block write protection is enabled. false: Initial block write protection is disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00551 :		
Name	NvMBswMBlockStatusInformation		
Description	This parameter specifies whether BswM is informed about the current status of the specified block. True: Call BswM_NvM_CurrentBlockMode on changes False: Don't inform BswM at all		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00119 :		
Name	NvMCalcRamBlockCrc		
Description	Defines CRC (re)calculation for the permanent RAM block or NVRAM blocks which are configured to use explicit synchronization mechanism. true: CRC will be (re)calculated for this permanent RAM block. false: CRC will not be (re)calculated for this permanent RAM block.		
Multiplicity	0..1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		

Multiplicity			
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: dependency: NVM_BLOCK_USE_CRC		local

SWS Item	ECUC_NvM_00116 :		
Name	NvMInitBlockCallback		
Description	Entry address of a block specific callback routine which shall be called if no ROM data is available for initialization of the NVRAM block. If not configured, no specific callback routine shall be called for initialization of the NVRAM block with default data.		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00533 :		
Name	NvMMaxNumOfReadRetries		
Description	Defines the maximum number of read retries.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 7		
Default value	0		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00499 :		
Name	NvMMaxNumOfWriteRetries		
Description	Defines the maximum number of write retries for a NVRAM block with [ECUC_NvM_00061]. Regardless of configuration a consistency check (and maybe write retries) are always forced for each block which is processed by the request NvM_WriteAll and NvM_WriteBlock.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 7		

Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00478 :		
Name	NvMNvBlockBaseNumber		
Description	<p>Configuration parameter to perform the link between the NVM_NVRAM_BLOCK_IDENTIFIER used by the SW-Cs and the FEE_BLOCK_NUMBER expected by the memory abstraction modules. The parameter value equals the FEE_BLOCK_NUMBER or EA_BLOCK_NUMBER shifted to the right by NvMDataSetSelectionBits bits. (ref. to chapter 7.1.2.1).</p> <p>Calculation Formula: value = TargetBlockReference.[Ea/Fee]BlockConfiguration.[Ea/Fee]BlockNumber >> NvMDataSetSelectionBits</p>		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 65534		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		local
	dependency: FEE_BLOCK_NUMBER, EA_BLOCK_NUMBER		

SWS Item	ECUC_NvM_00479 :		
Name	NvMNvBlockLength		
Description	<p>Defines the NV block data length in bytes.</p> <p>Note: The implementer can add the attribute 'withAuto' to the parameter definition which indicates that the length can be calculated by the generator automatically (e.g. by using the sizeof operator). When 'withAuto' is set to 'true' for this parameter definition the 'isAutoValue' can be set to 'true'. If 'isAutoValue' is set to 'true' the actual value will not be considered during ECU Configuration but will be (re-)calculated by the code generator and stored in the value attribute afterwards.</p>		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00480 :		
Name	NvMNvBlockNum		
Description	<p>Defines the number of multiple NV blocks in a contiguous area according to the given block management type.</p> <p>1-255 For NVRAM blocks to be configured of block management type NVM_BLOCK_DATASET. The actual range is limited according to SWS_NvM_00444.</p> <p>1 For NVRAM blocks to be configured of block management type</p>		

	NVM_BLOCK_NATIVE 2 For NVRAM blocks to be configured of block management type NVM_BLOCK_REDUNDANT		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 255		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: dependency: NVM_BLOCK_MANAGEMENT_TYPE		local

SWS Item	ECUC_NvM_00481 :		
Name	NvMNvramBlockIdentifier		
Description	Identification of a NVRAM block via a unique block identifier. Implementation Type: NvM_BlockIdType. min = 1 max = 2^(16- NVM_DATASET_SELECTION_BITS)-1 Reserved NVRAM block IDs: 0 -> to derive multi block request results via NvM_GetErrorStatus 1 -> redundant NVRAM block which holds the configuration ID (generation tool should check that this block is correctly configured from type,CRC and size point of view)		
Multiplicity	1		
Type	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: dependency: NVM_DATASET_SELECTION_BITS		local

SWS Item	ECUC_NvM_00035 :		
Name	NvMNvramDeviceId		
Description	Defines the NVRAM device ID where the NVRAM block is located. Calculation Formula: value = TargetBlockReference.[Ea/Fee]BlockConfiguration.[Ea/Fee]DeviceIndex		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 1		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: dependency: EA_DEVICE_INDEX, FEE_DEVICE_INDEX		local

SWS Item	ECUC_NvM_00482 :		
Name	NvMRamBlockDataAddress		
Description	Defines the start address of the RAM block data. If this is not configured, no permanent RAM data block is available for the selected block management type.		
Multiplicity	0..1		
Type	EcucStringParamDef		

Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC NvM_00521 :		
Name	NvMReadRamBlockFromNvCallback		
Description	Entry address of a block specific callback routine which shall be called in order to let the application copy data from the NvM module's mirror to RAM block. Implementation type: Std_ReturnType E_OK: copy was successful E_NOT_OK: copy was not successful, callback routine to be called again		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC NvM_00483 :		
Name	NvMResistantToChangedSw		
Description	Defines whether a NVRAM block shall be treated resistant to configuration changes or not. If there is no default data available at configuration time then the application shall be responsible for providing the default initialization data. In this case the application has to use NvM_GetErrorStatus() to be able to distinguish between first initialization and corrupted data. true: NVRAM block is resistant to changed software. false: NVRAM block is not resistant to changed software.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME

	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00484 :		
Name	NvMRomBlockDataAddress		
Description	Defines the start address of the ROM block data. If not configured, no ROM block is available for the selected block management type.		
Multiplicity	0..1		
Type	EcucStringParamDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Multiplicity	Variant	false	
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00485 :		
Name	NvMRomBlockNum		
Description	Defines the number of multiple ROM blocks in a contiguous area according to the given block management type. 0-254 For NVRAM blocks to be configured of block management type NVM_BLOCK_DATASET. The actual range is limited according to SWS_NvM_00444. 0-1 For NVRAM blocks to be configured of block management type NVM_BLOCK_NATIVE 0-1 For NVRAM blocks to be configured of block management type NVM_BLOCK_REDUNDANT		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	0 .. 254		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope:		local
	dependency:	NVM_BLOCK_MANAGEMENT_TYPE,	
	NVM_NV_BLOCK_NUM		

SWS Item	ECUC_NvM_00117 :		
Name	NvMSelectBlockForReadAll		
Description	Defines whether a NVRAM block shall be processed during NvM_ReadAll or not. This configuration parameter has only influence on those NVRAM blocks which are configured to have a permanent RAM block or which are configured to use explicit synchronization mechanism. true: NVRAM block shall be processed by NvM_ReadAll false: NVRAM block shall not be processed by NvM_ReadAll		
Multiplicity	0..1		

Type	EcucBooleanParamDef		
Default value	--		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: dependency: NVM_RAM_BLOCK_DATA_ADDRESS		local

SWS Item	ECUC_NvM_00549 :		
Name	NvMSelectBlockForWriteAll		
Description	Defines whether a NVRAM block shall be processed during NvM_WriteAll or not. This configuration parameter has only influence on those NVRAM blocks which are configured to have a permanent RAM block or which are configured to use explicit synchronization mechanism. true: NVRAM block shall be processed by NvM_WriteAll false: NVRAM block shall not be processed by NvM_WriteAll		
Multiplicity	0..1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: dependency: NVM_RAM_BLOCK_DATA_ADDRESS		local

SWS Item	ECUC_NvM_00506 :		
Name	NvMSingleBlockCallback		
Description	Entry address of the block specific callback routine which shall be invoked on termination of each asynchronous single block request [NVM113].		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	

Scope / Dependency	scope: local		
SWS Item	ECUC_NvM_00532 :		
Name	NvMStaticBlockIDCheck		
Description	Defines if the Static Block ID check is enabled. false: Static Block ID check is disabled. true: Static Block ID check is enabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		
SWS Item	ECUC_NvM_00072 :		
Name	NvMWriteBlockOnce		
Description	Defines write protection after first write. The NVRAM manager sets the write protection bit after the NV block was written the first time. This means that some of the NV blocks in the NVRAM should never be erased nor be replaced with the default ROM data after first initialization. [NVM276]. true: Defines write protection after first write is enabled. false: Defines write protection after first write is disabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		
SWS Item	ECUC_NvM_00520 :		
Name	NvMWriteRamBlockToNvCallback		
Description	Entry address of a block specific callback routine which shall be called in order to let the application copy data from RAM block to NvM module's mirror. Implementation type: Std_ReturnType E_OK: copy was successful E_NOT_OK: copy was not successful, callback routine to be called again		
Multiplicity	0..1		
Type	EcucFunctionNameDef		
Default value	--		
maxLength	--		
minLength	--		
regularExpression	--		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	

Scope / Dependency	scope: local		
SWS Item	ECUC_NvM_00534 :		
Name	NvMWriteVerification		
Description	Defines if Write Verification is enabled. false: Write verification is disabled. true: Write Verification is enabled.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	false		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

SWS Item	ECUC_NvM_00538 :		
Name	NvMWriteVerificationDataSize		
Description	Defines the number of bytes to compare in each step when comparing the content of a RAM Block and a block read back.		
Multiplicity	1		
Type	EcucIntegerParamDef		
Range	1 .. 65535		
Default value	--		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
NvMTargetBlockReference	1	This parameter is just a container for the parameters for EA and FEE

10.2.5 NvMTargetBlockReference

SWS Item	ECUC_NvM_00486 :
Choice container Name	NvMTargetBlockReference
Description	This parameter is just a container for the parameters for EA and FEE

Container Choices		
Container Name	Multiplicity	Scope / Dependency
NvMEaRef	0..1	EEPROM Abstraction
NvMFeeRef	0..1	Flash EEPROM Emulation

10.2.6 NvMEaRef

SWS Item	ECUC_NvM_00487 :
Container Name	NvMEaRef
Description	EEPROM Abstraction
Configuration Parameters	

SWS Item	ECUC_NvM_00488 :		
Name	NvMNameOfEaBlock		
Description	reference to EaBlock		
Multiplicity	1		
Type	Symbolic name reference to [EaBlockConfiguration]		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

No Included Containers

10.2.7 NvMFeeRef

SWS Item	ECUC_NvM_00489 :		
Container Name	NvMFeeRef		
Description	Flash EEPROM Emulation		
Configuration Parameters			

SWS Item	ECUC_NvM_00490 :		
Name	NvMNameOfFeeBlock		
Description	reference to FeeBlock		
Multiplicity	1		
Type	Symbolic name reference to [FeeBlockConfiguration]		
Post-Build Variant Value	false		
Value Configuration Class	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	--	
Scope / Dependency	scope: local		

No Included Containers

10.2.8 NvmDemEventParameterRefs

SWS Item	ECUC_NvM_00541 :		
Container Name	NvmDemEventParameterRefs		
Description	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_ReportErrorStatus API in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId value. The standardized errors are provided in the container and can be extended by vendor specific error references.		
Configuration Parameters			

SWS Item	ECUC_NvM_00553 :		
Name	NVM_E_HARDWARE		
Description	Reference to the DemEventParameter which shall be issued when the hardware error has occurred.		
Multiplicity	0..1		

Type	Symbolic name reference to [DemEventParameter]		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00542 :		
Name	NVM_E_INTEGRITY_FAILED		
Description	Reference to the DemEventParameter which shall be issued when the error "API request integrity failed" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00546 :		
Name	NVM_E_LOSS_OF_REDUNDANCY		
Description	Reference to the DemEventParameter which shall be issued when the error "loss of redundancy" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00547 :		
Name	NVM_E_QUEUE_OVERFLOW		
Description	Reference to the DemEventParameter which shall be issued when the error "NVRAM Managers job queue overflow" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Multiplicity Variant	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants

Class	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00543 :		
Name	NVM_E_REQ_FAILED		
Description	Reference to the DemEventParameter which shall be issued when the error "API request failed" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00545 :		
Name	NVM_E_VERIFY_FAILED		
Description	Reference to the DemEventParameter which shall be issued when the error "Write Verification failed" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: ECU		

SWS Item	ECUC_NvM_00548 :		
Name	NVM_E_WRITE_PROTECTED		
Description	Reference to the DemEventParameter which shall be issued when the error "write attempt to NVRAM block with write protection" has occurred.		
Multiplicity	0..1		
Type	Symbolic name reference to [DemEventParameter]		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	

Scope / Dependency		scope: ECU	
SWS Item		ECUC_NvM_00544 :	
Name		NVM_E_WRONG_BLOCK_ID	
Description		Reference to the DemEventParameter which shall be issued when the error "Static Block ID check failed" has occurred.	
Multiplicity		0..1	
Type		Symbolic name reference to [DemEventParameter]	
Post-Build Multiplicity		false	
Post-Build Variant Value		false	
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency		scope: ECU	
No Included Containers			

10.3 Common configuration options

[SWS_NvM_00030] [By use of configuration techniques, each application shall be enabled to declare the memory requirements at configuration time. This information shall be useable to assign memory areas and to generate the appropriate interfaces. Wrong memory assignments and conflicts in requirements (sufficient memory not available) shall be detected at configuration time.] ()

[SWS_NvM_00034] [The NVRAM memory layout configuration shall have a unique ID. The NvM module shall have a configuration identifier that is a unique property of the memory layout configuration. The ID can be either statically assigned to the configuration or it can be calculated from the configuration properties. This should be supported by a configuration tool. The ID must be changed if the block configuration changes, i.e. if a block is added or removed, or if its size or type is changed. The ID shall be stored together with the data and shall be used in addition to the data checksum to determine the consistency of the NVRAM contents.] (SRS_Mem_00135)

[SWS_NvM_00073] [The comparison between the stored configuration ID and the compiled configuration ID shall be done as the first step within the function NvM_ReadAll during startup.] ()

[SWS_NvM_00688] [In case of a detected configuration ID mismatch, the behavior of the NvM module shall be defined by a configurable option.] ()

[SWS_NvM_00052] [Provide information about used memory resources. The NvM module configuration shall provide information on how many resources of RAM, ROM and NVRAM are used. The configuration tool shall be responsible to provide detailed information about all reserved resources. The format of this information shall be commonly used (e.g. MAP file format).] ()

10.4 Published parameters

For details refer to the chapter 10.3 “Published Information” in SWS_BSWGeneral.

11 Not applicable requirements

[SWS_NvM_00744] [These requirements are not applicable to this specification.]
(SRS_BSW_00344, SRS_BSW_00404, SRS_BSW_00405, SRS_BSW_00170,
SRS_BSW_00412, SRS_BSW_00398, SRS_BSW_00399, SRS_BSW_00400,
SRS_BSW_00416, SRS_BSW_00168, SRS_BSW_00423, SRS_BSW_00426,
SRS_BSW_00427, BSW00431, SRS_BSW_00432, BSW00434, SRS_BSW_00375,
SRS_BSW_00422, BSW00420, SRS_BSW_00417, SRS_BSW_00336,
SRS_BSW_00161, SRS_BSW_00162, BSW00324, SRS_BSW_00005,
SRS_BSW_00415, SRS_BSW_00164, SRS_BSW_00325, SRS_BSW_00326,
SRS_BSW_00342, SRS_BSW_00343, SRS_BSW_00160, SRS_BSW_00007,
SRS_BSW_00347, SRS_BSW_00307, SRS_BSW_00335, SRS_BSW_00314,
SRS_BSW_00348, SRS_BSW_00353, SRS_BSW_00361, SRS_BSW_00302,
SRS_BSW_00328, SRS_BSW_00312, SRS_BSW_00006, SRS_BSW_00304,
SRS_BSW_00355, SRS_BSW_00378, SRS_BSW_00306, SRS_BSW_00308,
SRS_BSW_00309, SRS_BSW_00371, SRS_BSW_00330, SRS_BSW_00009,
SRS_BSW_00010, SRS_BSW_00321, SRS_BSW_00341, SRS_BSW_00334)