

<b>Document Title</b>	Guide to Mode Management
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	440

<b>Document Status</b>	Final
<b>Part of AUTOSAR Standard</b>	Classic Platform
<b>Part of Standard Release</b>	4.3.1

<b>Document Change History</b>			
<b>Date</b>	<b>Release</b>	<b>Changed by</b>	<b>Description</b>
2017-12-08	4.3.1	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Clarified rules of initialization</li> <li>• Minor corrections / clarifications / editorial changes; For details please refer to the ChangeDocumentation</li> </ul>
2016-11-30	4.3.0	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Explanation of multicore BswM interaction</li> <li>• Minor corrections / clarifications / editorial changes; For details please refer to the ChangeDocumentation</li> </ul>
2015-07-31	4.2.2	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Description of wakeup handling on multiple cores</li> <li>• Description of inter-partition mode communication</li> </ul>
2014-10-31	4.2.1	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Incorporation of Concept "EcuMFixedMC"</li> <li>• Clarified LIN Schedule Table Switching</li> </ul>
2014-03-31	4.1.3	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Clarified Wakeup Handling</li> <li>• Extended diagnostic related mode management</li> <li>• Fixed inconsistencies with BswM</li> </ul>
2013-10-31	4.1.2	AUTOSAR Release Management	<ul style="list-style-type: none"> <li>• Added section about Pretended Networking</li> </ul>

2013-03-15	4.1.1	AUTOSAR Release Management	<ul style="list-style-type: none"><li>• Changes regarding J1939 Network Management</li><li>• Introduction of J1939 Diagnostic Mode Management</li></ul>
2011-12-22	4.0.3	AUTOSAR Release Management	<ul style="list-style-type: none"><li>• Initial release</li></ul>



## Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## Table of Contents

1	Introduction	8
1.1	Further Work	8
2	Overall mechanisms and concepts	9
2.1	Declaration of modes	9
2.2	Mode managers and mode users	11
2.3	Modes in the RTE	11
2.4	Modes in the Basic Software Scheduler	12
2.5	Communication of modes	12
2.5.1	Mode switch	13
2.5.2	Mode request	14
2.5.3	Conformance of mode switches and mode requests	14
2.5.4	Mode proxies	14
2.5.5	Mode communication on multi core ECUs	15
3	Configuration of the Basic Software Modemanager	18
3.1	Process how to configure and integrate a BswM	18
3.2	Semantics of BswM Configuration: Interfaces and behavioral aspects	19
3.2.1	Interface of the BswM	19
3.2.1.1	Mode Requests	19
3.2.1.2	Available Actions	20
3.2.2	Definition of the interface in pseudo code	21
3.2.2.1	Mode switch and mode request interfaces	21
3.2.2.2	ModeRequestPorts defined by the standardized interface of the BswM	23
3.2.2.3	Configurable ModeRequestPorts	30
3.2.2.4	Configurable ModeSwitchPorts	31
3.2.3	Configuration of the BswM behavior	32
3.3	ECU state management	33
3.3.1	ECU Mode Handling	34
3.3.1.1	Startup	34
3.3.1.2	Running	35
3.3.1.3	Shutdown and Sleep	35
3.3.2	Startup	36
3.3.3	Run	37
3.3.4	Shutdown	38
3.3.5	Sleep	39
3.3.6	Wakeup	39
3.3.7	Reset of partitions	39
3.4	Communication Management	40
3.4.1	Startup and Shutdown	41
3.4.2	I-PDU Group Switching	41
3.4.3	J1939 Networkmanagement	45
3.4.4	J1939 diagnostic mode management	47

3.4.5	Pretended Networking . . . . .	47
3.4.5.1	Activation of Pretended Networking . . . . .	47
3.4.5.2	Deactivation of Pretended Networking . . . . .	48
3.4.6	LIN Schedule Table Switch . . . . .	49
3.5	Diagnostics . . . . .	50
3.5.1	Diagnostic Session Control . . . . .	51
3.5.2	ECU Reset . . . . .	51
3.5.3	Rapid Power Shutdown . . . . .	53
3.5.4	Communication Control diagnostic service . . . . .	54
3.5.5	Control DTC Setting . . . . .	57
3.5.6	Roe Status . . . . .	58
3.6	BswM to BswM interaction on multicore ECUs . . . . .	58
3.7	Inter-partition Actions . . . . .	59
3.8	Inter-partition Requests/Indications . . . . .	59
4	Backward Compatibility . . . . .	61
4.1	Example for BswM Configuration . . . . .	63
4.1.1	Startup . . . . .	63
4.1.2	Shutdown . . . . .	64
4.1.3	Wakeup . . . . .	66
5	Acronyms and abbreviations . . . . .	67
5.1	Technical Terms . . . . .	67

## Bibliography

- [1] Specification of ECU State Manager with fixed state machine  
AUTOSAR\_SWS\_ECUStateManagerFixed
- [2] Software Component Template  
AUTOSAR\_TPS\_SoftwareComponentTemplate
- [3] Meta Model  
AUTOSAR\_MMOD\_MetaModel
- [4] Basic Software Module Description Template  
AUTOSAR\_TPS\_BSWModuleDescriptionTemplate
- [5] Specification of Basic Software Mode Manager  
AUTOSAR\_SWS\_BSWModeManager
- [6] Specification of Diagnostic Communication Manager  
AUTOSAR\_SWS\_DiagnosticCommunicationManager
- [7] Glossary  
AUTOSAR\_TR\_Glossary

# 1 Introduction

This document is a general introduction to AUTOSAR mode management for the Release 4.0.3 onwards. Its main purpose is to give users as well as developers of AUTOSAR an detailed overview of the different aspects of AUTOSAR mode management based on examples, which are explained in context. The code listings in this document together form the configuration of a sample ECU.

Chapter 2 explains the basic mode management concepts e.g. modes in general, how mode switches are implemented, roles of mode managers and mode users etc. It secondly gives an introduction to Application Mode management and the dependencies to Basic Software Mode management, which are closely related.

The `Basic Software Modemanager` is the central mode management module in AUTOSAR R4.0. It is configurable to a high degree. How this configuration can be achieved is the topic of chapter 3.

Chapter 4 than deals with migration strategies from fixed ECU Management as it was used in AUTOSAR R3.1<sup>1</sup> to the new approach of ECU management of AUTOSAR 4.0

## 1.1 Further Work

Due to complexity and broad scope of this topic there are still some uses cases which are not yet described here in full detail. These issues will be enhanced in further releases.

- ECUs as Gateways
- Communication management for FlexRay
- Communication management for Ethernet
- Communication management for Lin (including schedule table switching)
- DCM Routing path groups
- BSWM configuration for multicore ECUs

---

<sup>1</sup>and in R4.0 with the ECU Statemanager with fixed state machine[1]



## 2 Overall mechanisms and concepts

This chapter gives an overview of the concept of modes and a short definition of states in AUTOSAR. Definitions of the terms mode and state can be found in chapter 5.1 A mode can be seen as the current state of an ECU<sup>1</sup> wide, global variable, which is maintained by the RTE respectively the Schedule Manager. The possible assignments of a mode are defined in `ModeDeclarationGroups`, which are defined in the AUTOSAR Software Component Template [2]. Modes can be used for different purposes. First of all modes are used to synchronize Software Components and Basic Software Modules. Via modes specified triggers can be enabled and disabled, and consequently the activation of `ExecutableEntitys` can be prevented. Also `ExecutableEntitys` can be triggered explicitly during a Mode Switch. On the other hand mode switches can explicitly trigger executable entities during transition from one mode to another. For example the RTE can activate an `OnEntry ExecutableEntity` to initialize a certain resource before entering a specific mode. In this mode the triggers of this `ExecutableEntity` are activated. If the mode is left the `OnExit ExecutableEntity` is called, which could execute some cleanup code and the triggers would be deactivated.


### 2.1 Declaration of modes

The Software Component Template [2] defines a generic mechanism for describing modes in AUTOSAR. Modes are defined via `ModeDeclarations`. A `ModeDeclaration` represents a possible assignment of the current state of a global variable. E.g in ECU state management there may exist the `ModeDeclarations` `STARTUP`, `RUN`, `POST_RUN`, `SLEEP`.

A `ModeDeclarationGroup` groups several `ModeDeclarations` in a similar way as an enumeration groups literals. In the given example this could be the `ModeDeclarationGroup` `ECUMODE`. For each `ModeDeclarationGroup` an `InitialMode` has to be defined, which is assigned to the variable at startup. Figure 2.1 shows an excerpt of the AUTOSAR Metamodel [3] with the relationships of `ModeDeclarations`, `ModeDeclarationGroups` and `ExecutableEntitys`.

---

<sup>1</sup>In R4.0 this is limited to a single partition



**Figure 2.1: Excerpt of Metamodel regarding Modes**


## 2.2 Mode managers and mode users

In mode management there are two parties involved: *Mode managers* and *mode users*. Responsible for switching modes are *Mode managers*, which are the only instances able to change the value of the global variable. A mode manager is either a Software Component, which provides a `ModeRequestPort` or a *Basic Software Module*, which either provides also a `ModeRequestPort` in its Software Component Description or a `ModeDeclarationGroup` in its Basic Software Module Description. Mode users are informed of Mode switches via well-defined mechanisms and have the possibility to read the currently active mode at any time. If a Mode user wants to change into a different mode it can request a Mode switch from the corresponding Mode manager.

## 2.3 Modes in the RTE

The AUTOSAR Runtime Environment implements the concept of modes. For this purposes it creates for each `ModeDeclarationGroupPrototype` of an Atomic Software Component a so called `ModeMachineInstance`. A `ModeMachineInstance` is a state machine whose states are defined by the `ModeDeclarations` of the respective `ModeDeclarationGroup`.

Figure 2.2 depicts the interaction of `ModeDeclarationGroupPrototypes` Mode managers and Mode users. Note that the mode switch ports of the mode users are not directly connected to the corresponding `Ports` of the mode managers but instead are connected to the mode machine instances of the RTE. This is important to understand the mechanism of mode switching inside the RTE.



**Figure 2.2: The RTE instantiates for each `ModeDeclarationGroupPrototype` a `ModemachinInstance`**

Previous versions of the Basic Software Modules especially the ECU state manager module have differentiated between ECU states and ECU modes. ECU modes were longer lasting operational ECU states that were visible to applications i.e. starting up, shutting down, going to sleep and waking up. The ECU Manager states were generally continuous sequences of ECU Manager module operations terminated by waiting until external conditions were fulfilled. Startup1, for example, contained all BSW initialization before the OS was started and terminated when the OS returned control to the ECU Manager module. With flexible ECU management the ECU state machine is implemented as general modes under the control of the BSW Mode Manager module. To overcome this terminology problem states are used only internally and are not visible to the application. For interaction with the application the basic software has to use modes.

## 2.4 Modes in the Basic Software Scheduler

The Basic Software Scheduler provides for Basic Software Modules a similar mechanism for mode communication as the RTE provides it for Software Components. If a Basic Software Module provides a ModeDeclarationGroupPrototype as providedModeGroup in its Basic Software Module Description the Basic Software Scheduler instantiates a ModeMachineInstance. Consequently for this Basic Software Module a SchM\protect\T1\textunderscore Switch API is provided, which enables this module to initiate a Mode switch. Mode users have to reference the ModeDeclarationGroupPrototype as requiredModeGroup and will get a SchM\protect\T1\textunderscore Mode API to read the mode, which is currently active. Mode requests between Basic Software Modules can be communicated directly via function calls, as Basic Software Modules.

Another possibility for a Basic Software Module acting as a Mode user to get informed about mode switches, is to register a BSW Module Entry, which is triggered by a Mode Switch Event (see also [4]).

## 2.5 Communication of modes


The Software Component Template differs the following distinctive types of mode communication between Mode managers and Mode users.

- **Mode Switch:** A Mode Switch is the communication of a current mode transition from one mode to another. Mode Switches are always initiated by Mode Managers.
- **Mode Request:** A Mode Request is the request of a mode user to the Mode Manager to enter a certain mode. Note that it is not guaranteed that the Mode Manager will enter this mode. Moreover he has to arbitrate all requests from the Mode Users and decide which mode he will enter.

Furthermore, the concept of `Mode Proxies` and information about communication of modes on multi core ECUs is given.

### 2.5.1 Mode switch

As every other communication between Software Components or between Software Components and Basic Software Modules, Modes are communicated via `PortPrototypes`. Each `PortPrototype` has to be typed by a `PortInterface`. In case of mode communication there exist so called mode switch interfaces, which are `PortInterfaces`. These are shown in Figure 2.3. Each `ModeSwitchInterface` has exactly one `ModeDeclarationGroupPrototype` which consists of multiple `ModeDeclarations`. Any `ModeDeclaration` represents one mode of the `ModeDeclarationGroup`. One of these is defined as the initial mode.



**Figure 2.3: mode switch interface**

These `Mode switches` are necessary because `Software Components` need to be capable of reacting to state changes initiated by a `ModeManager`. Depending on the configuration there are two mechanisms available how a `Software Component` can react on a mode change.

1. A `ModeSwitchEvent` can trigger a `OnExtry`, `OnTransition` or `OnEntry-Runnable`.
2. An `RTEEvent` can be disabled in a certain mode and consequently prevent the execution of accordant `ExecutableEntities`.

## 2.5.2 Mode request

Mode requests are distributed on the way from the mode requester (Mode Arbitration SWC or a generic SWC) to the `mode manager`. The `mode managers` on each ECU then have to decide and initiate the local mode switch. Thus the arbitration result is communicated only locally on each ECU using RTE mode switch mechanism.

For `mode requests`, the communication of modes works slightly differently as for `mode switches`: without `ModeDeclarationGroups`.

The request of modes is done via standard `SenderReceiverInterfaces`. Contrarily to `ModeSwitchInterfaces` the requested mode is not given by a `ModeDeclarationGroup` but by a `VariableDataPrototype` that has to contain an enumeration. This enumeration consists of a set which contains the modes that can be requested.

Mode requests can be distributed in the whole system. For application and vehicle modes, the requests of the mode requester have to be distributed to all affected ECUs. This implies a 1:n-connection between the mode requester and the mode Managers. In AUTOSAR this is only possible with Sender-Receiver Communication. The mode manager only requires the information about the requested mode and not the mode switch from the mode requester. The `mode manager` has one Sender-Receiver port for each mode requester. To actually transmit the signal, COM shall use a periodic signal with signal timeout notification to RTE. The `mode manager` will use the data element outdated event to release a mode request.

## 2.5.3 Conformance of mode switches and mode requests

As stated above, the `ModeSwitchInterfaces` work with `ModeDeclarationGroups` whereas `mode request interfaces` takes parameters via `VariableDataPrototypes` containing enumerations.

The configuration utility is in duty to ensure with respect to consistency the equivalence of represented data in both representations. That means that the elements of the enumeration must precisely match the elements of the `ModeDeclarationGroup`. Or formulated another way: All modes available in one of the interfaces must also be available in the other one.

## 2.5.4 Mode proxies

Currently AUTOSAR has a constraint that only local software components are allowed to communicate with `ServiceComponents`. So it is not possible that a `SoftwareComponent` can request modes from a remote e.g Basic Software Mode Manager. To overcome this limitation so called `ServiceProxyComponentType` were introduced in AUTOSAR Release 4.0. Figure 2.4 depicts this concept.

For the application software and the RTE a `ServiceProxySoftwareComponentType` behaves like a "normal" `AtomicSwComponentType`, but it is actually a proxy for an AUTOSAR Service. This means that on the one side it has to communicate over service ports with the ECU-local `ServiceSwComponentType` it represents. On the other side it has to offer the corresponding `PortPrototypes` to the `ApplicationSwComponentTypes`. In the meta-model, the `ServiceProxySwComponentType` does not differ from an `ApplicationSwComponentType` except by its class. It is up to the implementer to meet the restrictions imposed by the semantics as a proxy. The main difference between a `ServiceProxySwComponentType` and an `ApplicationSwComponentType` is on system level: A prototype of a `ServiceProxySwComponentType` can be mapped to several ECUs even if it appears only once in the VFB system, because such a prototype is required on each ECU, where it has to address a local `ServiceSwComponentType`. As a result of this, a `ServiceProxySwComponentType` can only receive but not send signals over the network. (see also [2]).





Figure 2.4: Communication via `ServiceProxySwComponents`

### 2.5.5 Mode communication on multi core ECUs

The RTE is able to synchronize `ModeMachineInstances` over different partitions of an ECU. This enables configurations where one `ModeDeclarationGroupPrototype` of a provide port is connected to `ModeDeclarationGroupPrototypes` of require ports from more than one partition. Consequently the `ModeUsers` of a `ModeDeclarationGroupPrototype` can be distributed on several partitions.



**Figure 2.5: Example configuration**

According to [SWS\_Rte\_02665] a ModeMachineInstance executes a sequence of 10 steps during a mode transition:

1. Activation of mode disablings
2. Wait until ExecutableEntities which are impacted by ModeDisablingDependencies of the next mode are terminated
3. Execution of OnExit ExecutableEntities
4. Wait until all OnExit ExecutableEntities are terminated
5. Execution of OnTransition ExecutableEntities
6. Wait until all OnTransition ExecutableEntities are terminated
7. Execution of OnEntry ExecutableEntities
8. Wait until all OnEntry ExecutableEntities are terminated
9. Deactivation of mode disabling of the previous and activation of the mode disabling of the current mode
10. Triggering of ModeSwitchAckEvents

The steps 1 to 9 can be executed in parallel on each CPU core, respectively for the mode users distributed on the corresponding core. Step 10 is only executed if the other steps have been finished for the whole ModeMachineInstance. Nevertheless some application-specific use cases might require a higher degree of synchronization w. r. t. steps 1 to 9, e. g. the execution of all OnExit ExecutableEntities before the OnTransition ExecutableEntities. For this reason the RTE offers the opportunity to configure synchronization points (see [ECUC\_Rte\_09127], [ECUC\_Rte\_09128] and [ECUC\_Rte\_09129] for further details).

ModeMachineInstances which has mode users on different partitions cannot be reinitialized to default mode in case of a partition restart. This would interfere with other still running partitions. Therefore the only applicable strategy to handle the restart of



the partition is `modeManagerErrorBehavior.errorReactionPolicy` set to `lastMode`, which specifies that the mode users keep their last known mode.

### 3 Configuration of the Basic Software Modemanager

The BSW Mode Manager is the module that implements the part of the Vehicle Mode Management and Application Mode Management concept that resides in the BSW. Its responsibility is to arbitrate mode requests from application layer Software Components or other Basic Software Modules based on rules, and perform actions based on the arbitration result.

From an functional point view the BswM is responsible to put the Basic Software in a state so that the Basic Software can run properly and meet the functional requirements.

The configuration of the BswM is very project- and ECU- specific. Therefore it can not be standardized by AUTOSAR. Nevertheless it is expected that a BswM implementation behaves in specific situations in a certain way . This chapter starts with an introduction on the general concept of the BswM, which is more or less a execution environment for rules described by the user. Afterwards typical scenarios in the lifecycle of an ECU are described and examples are given how the BswM could be configured.

#### 3.1 Process how to configure and integrate a BswM

The configuration and integration of a BswM into an ECU project consists of the same steps as for other Basic Software Modules. Nevertheless it is described for a better understanding of the next steps. In general the following actions have to be taken:

1. Create a ECUC configuration of the module. For the BswM this configuration contains:
  - (a) the necessary `ModeRequestSources`,
  - (b) the provided `ModeSwitchPorts`,
  - (c) a description of the `Rules` and `ActionLists`.
2. The configuration is used as input for the module generator, which creates
  - (a) a `SoftwareComponentDescription` of the AUTOSAR Interface,
  - (b) the implementation of the module<sup>1</sup>.
3. The last step is to integrate the Module into the ECU by connecting the ports of the `Software Components` with the corresponding ports of the BswM.

---

<sup>1</sup>This documents assumes that the Implementation of the BswM is generated to a large extend.

## 3.2 Semantics of BswM Configuration: Interfaces and behavioral aspects

In general the BswM can be seen as a state machine, which is defined by its interface and a behavioral description. The input actions of this state machine are mode requests. Each mode request is described in the ECU configuration of the BswM as a `BswMModeRequestSource`. These mode requests can be of different types (C-API calls, mode requests via RTE, mode notifications via RTE, etc.) but internally they are treated in the same way.

If a mode is requested the internal mirror of this `BswMModeRequestSource` is updated and depending on the configuration a rule evaluation is triggered, which results in the execution of predefined action lists. Action lists group Actions. Typically an action is a triggering of a mode switch in the RTE or Schedule Manager, but there are also predefined actions which change the status of some Basic Software Module.

### 3.2.1 Interface of the BswM

The interface is defined by the `BswMModeRequestSource` and the `BswMAction-ListItem` containers.

#### 3.2.1.1 Mode Requests

`BswMModeRequestSource` is a `ChoiceContainer`, which can be of the following kinds:

1. C-APIs, which are defined in the specification of the BswM. `BasicSoftware-Modules` can directly call C-APIs from the BswM, who will translate them internally into a `ModeRequest`. For example a call to the API

```
BswM_CanSM_CurrentState(  
    NetworkHandleType Network,  
    CanSM_BswMCurrentStateType CurrentState  
)
```

is to be mapped to different `ModeRequestPorts` depending on the parameter `Network`, which identifies the channel on which the event occurred. The parameter `CurrentState` then contains the mode which is requested. The mode requests, which are defined by the standardized interface of the BswM are described in more detailed in [3.2.2.2](#)

2. `RPorts` typed by a `SenderReceiverInterface`. `BswMSwcModeRequest`: For each container of this type the BswM has to create a corresponding `RPort` in its Service Component Description.
3. `RPorts` typed by a `ModeSwitchInterface`. `BswMSwcModeNotification`: For each container of this type the BswM has to create a corresponding `RPort` in

its Service Component Description. As it is typed by a `ModeSwitchInterface` the BswM acts as a mode user of this `ModeMachineInstance` and is informed if the mode manager performs an `rte_switch`.

4. `RequiredModeDeclarationGroupPrototypeS BswMBswModeNotification`: For each container of this type the BswM has to create a corresponding `RequiredModeDeclarationGroupPrototype` in the role `required-ModeDeclarationGroup` in its Basic Software Module Description. In this case the BswM also acts as a mode user, but the `ModeMachineInstance` is maintained by the Schedule Manager. The BswM therefore gets informed if the mode manager e.g. another Basic Software Module performs a `SchM_Switch` call.

### 3.2.1.2 Available Actions

`BswMActionListItems` can be of the following kinds:

1. C-APIs from other BswM Modules, which are called directly during the execution of an `ActionList`.
  - `BswMComMAllowCom`
  - `BswMComMModeLimitation`
  - `BswMComMModeSwitch`
  - `BswMDeadlineMonitoringControl`
  - `BswMEcuMGoDown`
  - `BswMEcuMSelectShutdownTarget`
  - `BswMEcuMStateSwitch`
  - `BswMJ1939Rm`
  - `BswMLinScheduleSwitch`
  - `BswMNMControl`
  - `BswMPduGroupSwitch`
  - `BswMPduRouterControl`
  - `BswMRteSwitch`
  - `BswMSchMSwitch`
  - `BswMSwitchIPduMode`
  - `BswMTriggerIPduSend`
  - `BswMUserCallout`

2. `PPorts` typed by a `ModeSwitchInterface: SwitchPort` For each container of this type the BswM has to create a corresponding `PPort` in its Service Component Description if it is referenced by a `RteSwitch` action.
3. `ProvidedModeDeclarationGroupPrototypes SwitchPort`: For each container of this type the BswM has to create a corresponding `ProvidedModeDeclarationGroupPrototype` in the role `providedModeGroup` in its Basic Software Module Description if the `SwitchPort` is referenced by a `SchMSwitch` action. In this case the BswM also acts as a mode manager, but the `ModeMachineInstance` is maintained by the Schedule Manager.

### 3.2.2 Definition of the interface in pseudo code

The following paragraphs define the interface of the BswM in pseudo code.

#### 3.2.2.1 Mode switch and mode request interfaces

An example of the BswM configuration of `ModeSwitchInterfaces` is shown in Listing 3.1. There is a `ModeDeclarationGroup` and a `ModeSwitchInterface` created. The `ModeSwitchInterface` uses the defined `ModeDeclarationGroup` as prototype where `exampleModes` is the short name of the `ModeSwitchInterface`.

**Listing 3.1: Mode switch interface for the overall mode of a ECU**

```
modeGroup MDG_ApplicationModes {
    APP_ACTIVE,
    APP_STARTING,
    APP_INACTIVE
}

interface modeSwitch MSIF_ApplicationModes {
    mode MDG_ApplicationModes appMode
}
```

A configuration of a mode request interface that corresponds to the `ModeSwitchInterface` of Listing 3.1 is shown as example in Listing 3.2. Out of this BswM configuration an `Arxml` description will be created which includes the mode declarations and interfaces. An excerpt of that `arxml` is shown in 3.3.

**Listing 3.2: Declaration of a mode request interface**

```
enum ENUM_ApplicationModes{
    ModeA,
    ModeB,
    ModeC
}

interface senderReceiver exampleModeRequestPort {
    data ENUM_ApplicationsModes exampleModeRequest
}
```

**Listing 3.3: Excerpt of the mode request interface's ARXML description**

```

<SENDER-RECEIVER-INTERFACE>
  <SHORT-NAME>exampleModeRequestPort</SHORT-NAME>
  <IS-SERVICE>>false</IS-SERVICE>
  <DATA-ELEMENTS>
    <VARIABLE-DATA-PROTOTYPE>
      <SHORT-NAME>exampleModeRequest</SHORT-NAME>
      ...
      <TYPE-TREF DEST="APPLICATION-PRIMITIVE-DATA-TYPE">ENUM_ApplicationModes
        </TYPE-TREF>
    </VARIABLE-DATA-PROTOTYPE>
  </DATA-ELEMENTS>
</SENDER-RECEIVER-INTERFACE>

...

<APPLICATION-PRIMITIVE-DATA-TYPE>
  <SHORT-NAME>ENUM_ApplicationModes</SHORT-NAME>
  <CATEGORY>VALUE</CATEGORY>
  <SW-DATA-DEF-PROPS>
    <SW-DATA-DEF-PROPS-VARIANTS>
      <SW-DATA-DEF-PROPS-CONDITIONAL>
        <COMPU-METHOD-REF DEST="COMPU-METHOD">ENUM_ApplicationModes_def</
          COMPU-METHOD-REF>
      </SW-DATA-DEF-PROPS-CONDITIONAL>
    </SW-DATA-DEF-PROPS-VARIANTS>
  </SW-DATA-DEF-PROPS>
</APPLICATION-PRIMITIVE-DATA-TYPE>

...

<COMPU-METHOD>
  <SHORT-NAME>ENUM_ApplicationModes_def</SHORT-NAME>
  <CATEGORY>TEXTTABLE</CATEGORY>
  <COMPU-INTERNAL-TO-PHYS>
    <COMPU-SCALES>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">0</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">0</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeA</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">1</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">1</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeB</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
      <COMPU-SCALE>
        <LOWER-LIMIT INTERVAL-TYPE="CLOSED">2</LOWER-LIMIT>
        <UPPER-LIMIT INTERVAL-TYPE="CLOSED">2</UPPER-LIMIT>
        <COMPU-CONST>
          <VT>ModeC</VT>
        </COMPU-CONST>
      </COMPU-SCALE>
    </COMPU-SCALES>
  </COMPU-INTERNAL-TO-PHYS>
</COMPU-METHOD>

```

```

    </COMPU-CONST>
    </COMPU-SCALE>
  </COMPU-SCALES>
  </COMPU-INTERNAL-TO-PHYS>
</COMPU-METHOD>

```

Every mode request to the BswM has to be mapped to an restricted set of values, which allows the integrator the define the arbitration rules.

The ECU modes can be set by BswM using the `EcuM_SetState` API.

**Purpose:** Via this interface BswM sets the current state of the EcuM.

**Signature:** `EcuM_SetState(EcuM_StateType State)`

**Modes:**

```

modeGroup EcuM_StateType {
    ECUM_STATE_STARTUP,
    ECUM_STATE_APP_RUN,
    ECUM_STATE_APP_POST_RUN,
    ECUM_STATE_SHUTDOWN,
    ECUM_STATE_SLEEP
}

```

### 3.2.2.2 ModeRequestPorts defined by the standardized interface of the BswM

In the BswM configuration, the mode request sources have to be defined. The following ModeRequestPorts are implicitly defined by API of the BswM. This subsection summarizes the port interface.

The following ModeDeclarationGroups are defined in the particular SWS documents of the AUTOSAR specification as C-Enums. Nevertheless they are referenced here in form of BswM configurations which act as a base for the rest of this document. Refer to the definition of C-Enums in the SWS documents for the definition of modes.

#### 3.2.2.2.1 BswMComMIndication

**Purpose:** Function called by ComM to indicate its current state.

**Signature:**

```

void BswM_ComM_CurrentMode(
    NetworkHandleType Network,
    ComM_ModeType RequestedMode
)

```

**Modes:**

```

modeGroup ComM_ModeType

```

**Example:**

```

request ComMIndication ComM_Mode_Channell {
    processing IMMEDIATE
    initialValue COMM_NO_COM_NO_PENDING_REQUEST
    source MyComM.ComMChannell
}

```

**Note:** This ModeRequestSource has to be created once for each ComM-Channel identified by the Network parameter.

### 3.2.2.2.2 BswMComMPncRequest

**Purpose:** Function called by ComM to indicate the current state of a partial network.

**Signature:**

```
void BswM_ComM_CurrentPNCMode(
    PNCHandleType PNC,
    ComM_PncModeType CurrentPncMode
)
```

**Modes:** modeGroup ComM\_PncModeType

**Example:**

```
request ComMPncRequest PNC1 {
    processing IMMEDIATE
    initialValue PNC_NO_COMMUNICATION
    source MyComM.ComMPnc1
}
request ComMPncRequest PNC2 {
    processing IMMEDIATE
    initialValue PNC_NO_COMMUNICATION
    source MyComM.ComMPnc2
}
request ComMPncRequest PNC3 {
    processing IMMEDIATE
    initialValue PNC_NO_COMMUNICATION
    source MyComM.ComMPnc3
}
```

**Note:** This ModeRequestSource has to be created once for each partial network.

### 3.2.2.2.3 BswMDcmComModeRequest

**Purpose:** Function called by DCM to indicate the current state of CommunicationControl.

**Signature:**

```
void BswM_Dcm_CommunicationMode_CurrentState(
    NetworkHandleType Network,
    Dcm_CommunicationModeType RequestedMode
)
```

**Modes:** modeGroup Dcm\_CommunicationModeType

**Example:**

```
request DcmComModeRequest
    BswM_Dcm_CommunicationMode_CurrentState {
    processing IMMEDIATE
    initialValue DCM_ENABLE_RX_TX_NORM
    network "network1"
```



}

### 3.2.2.2.4 BswMCanSMIndication

**Purpose:** Function called by CanSM to indicate its current state.

**Signature:**

```
void BswM_CanSM_CurrentState(
    NetworkHandleType Network,
    CanSM_BswMCurrentStateType CurrentState
)
```

**Modes:** modeGroup CanSM\_BswMCurrentStateType

**Example:**

```
request CanSMIndication CanSM_Can1 {
    processing IMMEDIATE
    initialValue CANSM_BSWM_NO_COMMUNICATION
    source MyComM.CanNet1
}

request CanSMIndication CanSM_Can2 {
    processing IMMEDIATE
    initialValue CANSM_BSWM_NO_COMMUNICATION
    source MyComM.CanNet2
}
```

**Note:** This ModeRequestSource has to be created once for each CAN channel.

### 3.2.2.2.5 BswMEthSMIndication

**Purpose:** Function called by EthSM to indicate its current state.

**Signature:**

```
void BswM_EthSM_CurrentState(
    NetworkHandleType Network,
    EthSM_NetworkModeStateType CurrentState
)
```

**Modes:** modeGroup EthSM\_NetworkModeStateType

**Example:**

```
request EthSMIndication EthSM_Network1 {
    processing IMMEDIATE
    initialValue ETHSM_NO_COMMUNICATION
    source MyComM.EthSmNetwork
}
```

**Note:** This ModeRequestSource has to be created once for each ethernet channel.

### 3.2.2.2.6 BswMFrSMIndication

**Purpose:** Function called by FrSM to indicate its current state.

**Signature:**

```
void BswM_FrSM_CurrentState(
    NetworkHandleType Network,
    FrSM_BswM_StateType CurrentState
)
```

**Modes:** modeGroup FrSM\_BswM\_StateType

**Example:**

```
request FrSMIndication FrSM_BswM_StateType {
    processing IMMEDIATE
    initialValue FRSM_BSWM_READY
    source MyComM.EthSmNetwork
}
```

**Note:** This ModeRequestSource has to be created once for each FlexRay cluster.

### 3.2.2.2.7 BswMLinSMIndication

**Purpose:** Function called by LinSM to indicate its current state.

**Signature:**

```
void BswM_LinSM_CurrentState(
    NetworkHandleType Network,
    LinSM_ModeType CurrentState
)
```

**Modes:** modeGroup LinSM\_ModeType

**Example:**

```
request LinSMIndication LinSM_CurrentState {
    processing IMMEDIATE
    initialValue LINSM_NO_COM
    source MyComM.LinSMChannel
}
```

**Note:** This ModeRequestSource has to be created once for each Lin channel.

### 3.2.2.2.8 BswMEcuMRequestedState

**Purpose:** Via this interface EcuM requests a state from BswM based on the result of the RUN Request Protocol.

**Signature:**

```
BswM_EcuM_RequestState(
    EcuM_StateType State,
    EcuM_RunStatusType CurrentStatus)
```

**Modes:** modeGroup EcuM\_StateType {  
ECUM\_STATE\_APP\_RUN,

```

        ECUM_STATE_APP_POST_RUN
    }

```

**Parameter:**

```

EcuM_RunStatusType {
    ECUM_RUNSTATUS_UNKNOWN,
    ECUM_RUNSTATUS_REQUESTED,
    ECUM_RUNSTATUS_RELEASED
}

```

### 3.2.2.2.9 BswMEcuMCurrentState

**Signature:** `BswM_EcuM_CurrentState(EcuM_StateType CurrentState)`

### 3.2.2.2.10 BswMEcuMIndication

**Purpose:** Function called by the ECUM with fixed state machine to indicate its current state.

**Signature:**

```

void BswM_EcuM_CurrentState(
    EcuM_StateType CurrentState
)

```

**Modes:** `modeGroup EcuM_StateType`

**Example:**

```

request EcuMIndication EcuM_State {
    processing IMMEDIATE
    initialValue ECUM_STATE_STARTUP
}

```

### 3.2.2.2.11 BswMEcuMWakeupSource

**Purpose:** Function called by the ECUM to indicate the current state of the wakeup sources.

**Signature:**

```

void BswM_EcuM_CurrentWakeup(
    EcuM_WakeupSourceType source,
    EcuM_WakeupStatusType state
)

```

**Modes:** `modeGroup EcuM_WakeupStatusType`

**Example:**

```

request EcuMWakeupSource EcuM_WakeupSource {
    processing IMMEDIATE
    initialValue ECUM_WKSTATUS_NONE
    source MyEcuM.EcuMWakeupSource1
}

```

**Note:** This ModeRequestSource has to be created once for each Wakeup source.

### 3.2.2.2.12 BswMLinScheduleIndication

**Purpose:** Function called by LinSM to indicate the currently active schedule table for a specific LIN channel.

**Signature:**

```
void BswM_LinSM_CurrentSchedule (
    NetworkHandleType Network,
    LinIf_SchHandleType CurrentSchedule
)
```

**Modes:** The reported modes depend on the configured schedules in the Lin Statemanager.

**Example:**

```
request LinScheduleIndication LinSM1_CurrentSchedule {
    processing IMMEDIATE
    initialValue TBD
    source MyLinSM.LinSMChannel
}
```

### 3.2.2.2.13 BswMLinTpModeRequest

**Purpose:** Function called by LinTP to request a mode for the corresponding LIN channel. The LinTp\_Mode mainly correlates to the LIN schedule table that should be used.

**Signature:**

```
void BswM_LinTp_RequestMode (
    NetworkHandleType Network,
    LinTp_Mode LinTpRequestedMode
)
```

**Modes:** modeGroup LinTp\_Mode

**Example:**

```
request LinTpModeRequest LinTp_Mode {
    processing IMMEDIATE
    initialValue LINTP_APPLICATIVE_SCHEDULE
    source MyLinIF.config0.LinIFChannel
}
```

### 3.2.2.2.14 BswMNvMJobModeIndication

**Purpose:** Indicates the current status of the multiblock job. The job is identified via BswMNvmService, e.g. 0x0c for NvmReadAll, 0x0d for NvmWriteAll.

**Signature:**

```
void BswM_NvM_CurrentJobMode (
    uint8 ServiceId,
    NvM_RequestResultType CurrentJobMode
)
```

**Modes:** modeGroup NvM\_RequestResultType

**Example:**

```

request NvMJobModeIndication NvMWriteAllJobMode {
    service WriteAll
    initialValue NVM_BLK_NOT_OK
    processing IMMEDIATE
}

request NvMJobModeIndication NvMReadAllJobMode {
    service ReadAll
    initialValue NVM_BLK_NOT_OK
    processing IMMEDIATE
}

```

### 3.2.2.2.15 BswMNvMRequest

**Purpose:** Via this Mode Request Source the NvM indicates the current status of the specified block.

**Signature:**

```

void BswM_NvM_CurrentBlockMode (
    NvM_BlockIdType Block,
    NvM_RequestResultType CurrentBlockMode
)

```

**Modes:** modeGroup NvM\_RequestResultType

### 3.2.2.2.16 BswMJ1939NmIndication

**Signature:**

```

void BswM_J1939Nm_StateChangeNotification (
    NetworkHandleType nmNetworkHandle,
    uint8 Node,
    Nm_StateType nmCurrentState
)

```

**Modes:** modeGroup Nm\_StateType

**Example:**

```

request BswMJ1939NmIndication J1939NmState {
    network "Channell"
    node "Node1"
    initialValue NM_STATE_UNINIT
    processing IMMEDIATE
}

```

**Note:** This ModeRequestSource has to be configured for each channel managed by J1939 network management. This type of Mode Request Source is currently not supported by ARText.

### 3.2.2.2.17 BswMWdgMRequestPartitionReset

**Signature:** `void BswM_WdgM_RequestPartitionReset ( ApplicationType Application )`

**Modes:** `modeGroup WdgM_PartitionResetType`

**Example:**

```
request WdgMRequestPartitionReset WdgM_RequestResetPart1 {
  processing IMMEDIATE
  initialValue WDGM_PARTITION_RESET_NOTREQUESTED
  source MyEcuC.eCucPartition
}
```

**Note:** This ModeRequestSource has to be created once for each partition for which a reset can be requested by the Watchdog Manager module.

### 3.2.2.2.18 BswMJ1939DcmBroadcastStatus

**Signature:** `void BswM_J1939DcmBroadcastStatus ( uint16 networkMask )`

**Modes:** `modeGroup J1939DcmBroadcastStatusType`

**Example:**

```
request BswMJ1939DcmBroadcastStatus
J1939BroadcastStatusChannel1 {
  processing IMMEDIATE
  initialValue NETWORK_DISABLED
  source MyComM.CanNet1
}
```

**Note:** This is a notification of the desired broadcast status per network, triggered via DM13.

### 3.2.2.3 Configurable ModeRequestPorts

Besides the interface, which is defined by the standardized interface of the BswM, additional mode request ports can be defined via the configuration parameters.

E.g it is necessary for the interaction with applications, that an application software component at least notifies the BswM about it's current state. This can be achieved by definition of a ModeRequestPort as shown in Listing 3.4. The BswM will than create a corresponding RPort typed by a SenderReceiverInterface.

#### Listing 3.4: Application ModeRequestPort

```
request SwcModeRequest ApplModeRequest {
  source MSIF_ApplicationModes.appMode
```

```

processing IMMEDIATE
initialValue ModeA
}

```

Note that the reference to a `ModeDeclarationGroupPrototype` can be misleading. The meaning is that the BswM creates a `SenderReceiverInterface` containing a `VariableDataPrototype`. The `SwDataDefProps` of this `VariableDataPrototype` refer to a `CompuMethod`, which defines an enumeration corresponding die to the referred `ModeDeclarationGroupPrototype`.

### Listing 3.5: Application ModeNotification

```

request SwcModeNotification ApplModeNotification {
    source MSIF_ApplicationModes.appMode
    processing IMMEDIATE
    initialValue ModeA
}

```

Listing 3.5 shows the declaration of a mode notification port. Note that in contrast to 3.4 the BswM will generate a `RPort` typed by a `ModeSwitchInterface` in this case. The BswM then gets informed via a `ModeSwitchNotification` if the mode manager initiates a mode switch.

### Listing 3.6: BasicSoftwareModeNotification

```

request BswModeNotification EcuMode {
    source MSIF_EcuMode.ecuMode
    processing IMMEDIATE
    initialValue ECU_STARTUP_ONE
}

```

Listing 3.6 shows the declaration of a mode notification port. If such a port is configured, the BswM configuration tool will create a `requiredModeGroup ModeDeclarationGroupPrototype`, so that the BswM gets informed of mode switches via the Schedule Manager, if the corresponding mode manager initiates a mode switch with a call to `SchM_Switch` API.

#### 3.2.2.4 Configurable ModeSwitchPorts

In the configuration of the BswM contains `BswMSwitchPorts`. These containers contain references to mode switch interfaces. If a `BswMSwitchPorts` is referenced by a `BswMSchMSwitch` action the module generator of the BswM shall create a `providedModeGroup ModeDeclarationGroupPrototype`. If a `BswMSwitchPorts` is referenced by a `BswMRteSwitch` action the module generator of the BswM shall create a `PPort` typed by the corresponding `ModeSwitchInterface`. 3.7 show an example for a `mode switch port`.

### Listing 3.7: Example for a configurable mode switch port

```

switchport EcuMode {
    modeSwitchinterface MSIF_EcuMode
}

```

### 3.2.3 Configuration of the BswM behavior

The behavior of the BswM is specified via rules and action lists. A rule is a logical expression, which combines the current values of `ModeRequestPorts`. The evaluation of each rule either results in the execution of its `true` or `false` action lists.

The `ModeControlContainer` contains these `ActionLists`. An `ActionList` can consist of a set of atomic actions, other “nested” `ActionLists` or it can reference (nested) rules which are then evaluated in the context of this `ActionList`.

The following example shows a simple rule, which activates the IPDU Groups of a dedicated CAN channel. According to this rule, the BswM has to provide a `ModeRequestPort` of type `CanSMIndication` named `Can1_Indication`. This is a `ModeRequest` from a basic software module in this case from the Can State manager. In code this `ModeRequestPorts` corresponds to the API `BswM_CanSM_CurrentState` as described in [SWS\_BswM\_00049] in [5]. The `source` parameter identifies the network to which this `ModeRequestSourcePort` belongs to. It's up to the configuration tool of the BswM to allocate the right parameters for the API corresponding to the referenced ECUC Container.

The value of the `ModeRequestSourcePort` initially is `CAN_SM_BswM_NO_COMMUNICATION`.

processing `immediate` means that every evaluation rule, which refers to this `ModeRequestSourcePort` shall immediately be processed. Every immediate mode request will trigger the evaluation of the referring rules. If this parameter would be deferred in case of a mode request, the evaluation of rules would be delayed until the next run of the main function of the BSWM. The BSWM does not support queued evaluation of deferred mode requests. As a result, deferred mode requests will have "last-is-best" semantics. Only the last mode request made before the execution of the BSWM'S main function will be used.

The following example shows an arbitration rule called `canIPDUActivation`. The overall content is rather self explanatory. The `initial` parameters specifies that the initial result of the rule evaluation is `false`.

#### Listing 3.8: Example for a rule

```
rule checkApp1Request initially false {
if ( App1ModeRequest == MDG_ApplicationModes.ModeA && EcuMode ==
    MDG_EcuMode.ECU_RUN) {
    actionlist checkApp1RequestTrueActions
}
}

actions checkApp1RequestTrueActions on condition {
    ComMAllowCom MyComM.CanNet1 true
    SchMSwitch EcuMode : ECU_RUN
}
```

At which point in time a rule is executed, after an event has occurred depends on the parameter `BswMActionListExecution`. Either it is executed every time the



rule is evaluated with the corresponding result, or only when the evaluation result has changed from the previous evaluation. This is called `triggered` respectively `conditional` execution.

Table 3.1 gives an overview in which situations an `ActionList` is executed or not. Triggered `ActionLists` are executed (triggered) if the result of the rule evaluation changes. Conditional `ActionLists` depend only on the current result (condition) of the evaluation independent if it has changed or not.

eval. result (old) -> (new)	true -> true	true -> false	false false	->	false -> true
TrueActionList	CONDITION	-	-		TRIGGERED/ CONDITION
FalseActionList	-	TRIGGERED/ CONDITION	CONDITION		-

**Table 3.1: Execution of Action Lists depending on parameter `BswMActionListExecution`**

### 3.3 ECU state management

During startup and shutdown the task of the BswM is to initialize all basic software modules in a similar way as it is done by the ECUM in older AUTOSAR releases. To achieve this the following `ModeDeclarationGroup` is defined, which indicates the overall state of the ECU to application software components and is used for internal rule arbitration.

The modes of this `ModeDeclarationGroup` are named similar to the states of the ECUM with fixed state machine. Nevertheless they have due to several reasons not exactly the same semantics.

#### Listing 3.9: ModeDeclarationGroup for overall ECU state management

```
modeGroup MDG_EcuMode {
    ECU_RUN,
    ECU_APP_RUN,
    ECU_APP_POST_RUN,
    ECU_GO_SLEEP,
    ECU_GO_OFF_ONE,
    ECU_SLEEP,
    ECU_GO_OFF_TWO,
    ECU_STARTUP_ONE,
    ECU_STARTUP_TWO,
    ECU_RESET_READY
}

interface modeSwitch MSIF_EcuMode {
    mode MDG_EcuMode ecuMode
}
```

The initial mode of this `ModeDeclarationGroup` is `ECU_STARTUP_ONE`.

### 3.3.1 ECU Mode Handling

ECU Mode Handling is introduced with AUTOSAR 4.2.1 in BSW modules ECU State Manager with flexible state machine and BSW Mode Manager. ECU State Manager provides a common interface to SW-Cs to request and release the Modes `RUN` and `POST_RUN`.

The ECU State Manager (EcuM) does not contain an own state machine. It shall receive state notifications from BswM and propagate these to the RTE.

The following API is provided for ECU Mode Handling:

**Purpose:** Via this interface EcuM notifies BswM about the current Mode of ECU Mode.

**Modes:**

```
modeGroup EcuM_StateType {
    ECUM_STATE_STARTUP,
    ECUM_STATE_APP_RUN,
    ECUM_STATE_APP_POST_RUN,
    ECUM_STATE_SHUTDOWN,
    ECUM_STATE_SLEEP
}
```

**EcuM\_CurrentState:** Set by EcuM using the interface `BswM_EcuM_CurrentState()`. This state is set by EcuM when the RTE has given its feedback.

**RUNRequested:** Set by EcuM using the interface `BswM_EcuM_RequestedState()` depending on the result of the RUN Request Protocol.

**POSTRUNRequested:** Set by EcuM using the interface `BswM_EcuM_RequestedState()` depending on the result of the RUN Request Protocol.

The following BswM rules show an example regarding the interaction between EcuM and BswM for ECU Mode Handling. Note that the following BswM rules are not sufficient for a complete system. Further BswM rules will be needed to cover NvM, Wakeup Handling and Diagnostics for example. See chapter 4 for a complete example.

#### 3.3.1.1 Startup

The Mode `STARTUP` is applied during startup of RTE. After all drivers are initialized, the `RUN` Mode is set:

```
rule SwitchToStartup initially false {
    if (EcuMode == ECUM_STARTUP) {
        actionlist SwitchToStartup
    }
}

actions SwitchToStartup on condition {
    custom "EcuM_DriverInitListTwo()"
}
```

```

custom "Rte_Start()"
custom "EcuM_DriverInitListThree()"
custom "ComM_CommunicationAllowed(TRUE)"
custom "EcuM_SetState(ECUM_STATE_APP_RUN)"
}

```

### 3.3.1.2 Running

When all EcuM users have released the RUN Mode, EcuM sets the RUNRequested Mode to RELEASED.

```

Rule SwitchToPostRun initially false {
  if (EcuM_CurrentState==RUN && RUNRequested == RELEASED) {
    actionlist SwitchToPostRun
  }
}

```

```

actions SwitchToPostRun on condition {
  custom "CommunicationAllowed(FALSE)"
  custom "EcuM_SetState(ECUM_STATE_APP_POST_RUN)"
}

```

SWCs can request RUN Mode during POST\_RUN. The following BswM rule switches back to RUN Mode in case at least one EcuM user has requested the RUN Mode.

```

rule SwitchBackToRunMode initially false {
  if (EcuM_CurrentState==POST_RUN && RUNRequested == REQUESTED &&
    POSTRUNRequested == RELEASED) {
    actionlist SwitchBackToRunMode
  }
}

```

```

actions SwitchBackToRunMode on condition {
  custom "ComM_CommunicationAllowed(TRUE)"
  custom "EcuM_SetState(ECUM_STATE_APP_RUN)"
}

```

### 3.3.1.3 Shutdown and Sleep

The BswM rules below illustrate only the switch to SLEEP Mode.

```

rule SwitchToShutdownMode initially false {
  if (EcuM_CurrentState==POST_RUN && RUNRequested == RELEASED &&
    POSTRUNRequested == RELEASED) {
    actionlist SwitchToShutdownMode
  }
}

```

```

actions SwitchToShutdownMode on condition {
  custom "EcuM_SetState(ECUM_STATE_SLEEP)"
}

```

Note that further BswM rules are needed for a complete running system.

### 3.3.2 Startup

The ECUM starts the operating system and afterwards its *post OS sequence* starts the Schedule Manager (`SchM_Start()`), initializes the BswM (`BswM_Init()`) and afterwards finishes the initialization of the SchM (`SchM_Init()` and `SchM_StartTiming()`). The BswM after its initialization has to take care, that all necessary init routines of the basic software modules are called and that the RTE is started (`FirstRte_Start()`, then `Rte_Init()` and at last `Rte_StartTiming()`).

In this scenario it is expected that the BswM has the following `providedModeGroup`. The purpose of this `modeGroup` is to track the current state/mode of the ECU similar to the states of the ECU State manager in previous AUTOSAR releases.

Rule `InitBlockII` specifies the initialization of basic drivers to access the NVRAM and initiates `NvM_ReadAll`. As the `EcuMode` source has the processing attribute set to `DEFERRED` this rule will be evaluated every time the main function of the BswM is called. After the first run it sets the `EcuMode` to `ECU_STARTUP_TWO` so that the action list will never be invoked again.

If the `NvM_ReadAll` job is finished the `NvM_ReadAllFinished` rule is triggered, which initiates the remaining initialization and switches the `EcuMode` to `ECU_RUN`.

#### Listing 3.10: Rules and ActionLists for Startup

```

rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE ) {
        actionlist InitBlockIIActions
    }
}

actions InitBlockIIActions on condition {
    custom "Spi_Init(null)"
    custom "Eep_Init(null)"
    custom "Fls_Init(null)"
    custom "NvM_Init(null)"
    SchMSwitch EcuMode : ECU_STARTUP_TWO
    custom "NvM_ReadAll()"
}

rule NvM_ReadAllFinished initially false {
    if ( NvM_ReadAllJobMode == NVM_REQ_OK && EcuMode == MDG_EcuMode.
        ECU_STARTUP_TWO ) {
        actionlist NvM_ReadAllFinishedActions
    }
}

actions NvM_ReadAllFinishedActions on condition {
    custom "Can_Init(null)"
    custom "CanIf_Init(null)"
    custom "CanSM_Init(null)"
    custom "CanTp_Init(null)"
    custom "Lin_Init(null)"
    custom "LinIf_Init(null)"
}
    
```

```

custom "LinSM_Init (null) "
custom "LinTp_Init (null) "
custom "Fr_Init (null) "
custom "FrIf_Init (null) "
custom "FrSM_Init (null) "
custom "FrTp_Init (null) "
custom "PduR_Init (null) "
custom "CANNM_Init (null) "
custom "FrNM_Init (null) "
custom "NmIf_Init (null) "
custom "IpduM_Init (null) "
custom "COM_Init (null) "
custom "DCM_Init (null) "
custom "ComM_Init (null) "
custom "DEM_Init (null) "
custom "StartRte () "
SchMSwitch EcuMode : ECU_RUN
}

```

In order to ensure that the RTE is properly initialized before runnables in service modules call RTE API functions, those runnables can be disabled by a mode disabling dependency deactivating the runnable in all modes except EcuM mode RUN. For server runnables - which cannot be disabled - the Rte will ignore incoming client server requests as long as it is not initialized.

When the RTE is started the runnables will be started. Now it is up to the application to keep the ECU running. To achieve this the BswM can for example provide a ModeRequestPort as depicted in example 3.4. For the further reading is expected, that the application software requests the mode APP1\_ACTIVE from the BswM. If this mode is requested the BswM shall not shutdown the ECU.

### Listing 3.11: Application runs, enable communication

```

rule checkApp1Request initially false {
if ( App1ModeRequest == MDG_ApplicationModes.ModeA && EcuMode ==
  MDG_EcuMode.ECU_RUN) {
  actionlist checkApp1RequestTrueActions
}
}

actions checkApp1RequestTrueActions on condition {
  ComMAllowCom MyComM.CanNet1 true
  SchMSwitch EcuMode : ECU_RUN
}

```

### 3.3.3 Run

As the BswM is a highly flexible module it depends to a high extend to the integrator, how it is determined if an ECU shall shut down or not. Many different variants are conceivable. This document proposes an approach, which is quite similar to the concept

of the ECUM in AUTOSAR R3.1. The general concept is, that a ECU keeps running as long as at least one application software component requests the run state.

The information if an application can be shut down in a certain mode has to be provided by the software component developer. Example 3.12 shows a simplified rule for an ECU with one software component. If switches its mode to `INACTIVE` the BswM initiates the shutdown sequence.

### Listing 3.12: Initiate shutdown, if no application wants to run any more

```
rule checkApplRequest initially false {
    if ( ApplModeRequest == MDG_ApplicationModes.APP_INACTIVE && EcuMode ==
        MDG_EcuMode.ECU_RUN) {
        actionlist checkApplRequestActions
    }
}

actions checkApplRequestActions on condition {
    ComMAllowCom ArMmExample.EcuC.MyComM.ComMChannel1 false
    SchMSwitch EcuMode : ECU_APP_POST_RUN
}
```

## 3.3.4 Shutdown

In state `ECU_APP_POST_RUN` the BswM waits until all channels report, that no requests are pending any more. The rule in listing 3.12 is triggered every time the mode of a ComM channel changes. If there are multiple ComM channels, they have to be combined to a single expression.

### Listing 3.13: Shutdown sequence

```
rule InitiateShutdown initially false {
    if ( ComM_Mode_Channel1 == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_APP_POST_RUN) {
        actionlist InitiateShutdownActions
    }
}

actions InitiateShutdownActions on condition {
    custom "Dem_Shutdown(null)"
    custom "Rte_Stop()"
    custom "ComM_DeInit()"
    SchMSwitch EcuMode : ECU_GO_OFF_ONE
    custom "NvM_WriteAll()"
}

rule NvMWriteAllFinished initially false {
    if ( NvMWriteAllJobMode == NVM_BLK_OK && EcuMode == MDG_EcuMode.
        ECU_GO_OFF_ONE) {
        actionlist NvMWriteAllFinishedTrueActions
    }
}
```

```
actions NvMWriteAllFinishedTrueActions on condition {
    custom "EcuM_SelectShutdownCause (ECUM_CAUSE_ECU_STATE) "
    custom "EcuM_GoDown (MODULE_ID) "
}
```

Note that in the configuration of the ECUM the module id of the BswM has to be added as a valid user to `EcuMFlexUserConfig`.

### 3.3.5 Sleep

Entering a sleep state is similar to the shutdown sequence [3.12](#) except that `EcuM_GoHalt` resp. `EcuM_GoPoll` is called instead of `EcuM_GoDown`.

### 3.3.6 Wakeup

Example [3.14](#) shows a rule which starts the ECU only, if a certain wakeup event, identified by `EcuM_WakeupSource` has occurred. Otherwise the ECU will be immediately shut down.

#### Listing 3.14: start sequence with wakeup check

```
rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE && EcuM_WakeupSource ==
        ECUM_WKSTATUS_VALIDATED) {
        actionlist InitBlockIITrueActions
    } else {
        actionlist InitBlockIIFalseActions
    }
}

actions InitBlockIITrueActions on condition {
    custom "Spi_Init (null) "
    custom "Eep_Init (null) "
    custom "Fls_Init (null) "
    custom "NvM_Init (null) "
    SchMSwitch EcuMode : ECU_STARTUP_TWO
    custom "NvM_ReadAll () "
}

actions InitBlockIIFalseActions on condition {
    custom "EcuM_GoDown (MODULE_ID) "
}
```

### 3.3.7 Reset of partitions

In the case that an error occurred in a particular partition and it has to be restarted, the BSW Modules which are partitioned to the partition have to be reinitialized. In order to determine the partition which has been restarted, the Mode Request Source `BswMPartitionRestarted` can be utilized.

**Listing 3.15: reset sequence of partition**

```

rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE ) {
        actionlist InitBlockIIActions
    }
}

actions InitBlockIIActions on condition {
    custom "Spi_Init (null) "
    custom "Eep_Init (null) "
    custom "Fls_Init (null) "
    custom "NvM_Init (null) "
    custom "EcuM_SetState (ECU_STARTUP_TWO) "
    custom "NvM_ReadAll () "
}

rule NvMReadAllFinished initially false {
    if ( NvMReadAllJobMode == NVM_REQ_OK
    && EcuMode == MDG_EcuMode.ECU_STARTUP_TWO
    && BSWM_BSW_MODE_REQUEST_API_CALLED (BswMPartitionRestarted) ) {
        actionlist NvMReadAllFinished4PartitionActions
    }
}

actions NvMReadAllFinished4PartitionActions on condition {
    // Initialize only the modules partitioned to the corresponding core, e.g
    .
    custom "Can_Init (null) "
    custom "CanIf_Init (null) "
    custom "CanSM_Init (null) "
    custom "CanTp_Init (null) "
    ...
}
    
```

## 3.4 Communication Management

Besides parts of the ECU state management, the BswM is also responsible for parts of the communication management. This section describes the functionality of the BswM, which is related to the Communication Stack of AUTOSAR. This covers but is not restricted to the following uses cases.

- Starting and stopping of IPDU Groups in general
- Partial Networking
- Diagnostic use cases which influence the communication of an ECU. e.g. it might be necessary to set the FlexRay State manager to passive mode via `FrSm_SetEcuPassive()` when requested by an application.

To fulfill the requested functionality the BswM has ModeRequestSources to

- the Communication Manager
- the bus state managers



- AUTOSAR COM

### 3.4.1 Startup and Shutdown

Besides the initialization of the communication stack the BswM can be configured to initialize further modules or execute custom actions depending on the ECU's needs. Due to the flexibility of the BswM it is also possible, that after a wake up event only a part of the communication stack is started.

Analogue to Startup, it is possible to configure additional actions to be executed on shutdown.

### 3.4.2 I-PDU Group Switching

For the I-PDU group switching it is expected that there exists for each channel a dedicated I-PDU group for outgoing and incoming I-PDUs in COM. AUTOSAR COM takes care that an I-PDU is active(started) if at least one I-PDU group containing this I-PDU is active.

To illustrate how the I-PDUs of an ECU can be managed the following scenario is created. The exemplary ECU shall have two CAN channels and three partial networks. The mode request ports for the channels are named `CanSM_Can1` and `CanSM_Can2`, the request sources for the partial networks are named `PNC1`, `PNC2` and `PNC3`.

I-PDUs of `PNC1` shall be communicated only over `Channel1`. I-PDUs of `PNC3` shall be communicated over `Channel1` and `Channel2`. I-PDUs of `PNC2` shall be communicated only over `Channel2`.

In case of an indication by a bus state manager the BswM shall check, which partial networks are requested.

#### Listing 3.16: Active wakeup on channel

```

rule activeWakeupChannel1 initially false {
  if ( CanSM_Can1 == CANSM_BSWM_FULLL_COMMUNICATION) {
    actionlist activeWakeupChannel1Actions
  }
}

actions activeWakeupChannel1Actions on condition {
  rule pnc1requested
  rule pnc2requested
  rule pnc3requested
}

rule activeWakeupChannel2 initially false {
  if ( CanSM_Can2 == CANSM_BSWM_FULLL_COMMUNICATION &&
    PNC2 != PNC_REQUESTED &&

```

```

PNC3 != PNC_REQUESTED
) {
    actionlist activeWakeupChannel2Actions
}
}

actions activeWakeupChannel2Actions on condition {
    rule pnc1requested
    rule pnc2requested
    rule pnc3requested
}

```

If a bus state manager reports that the bus is going silent the BswM stop the corresponding I-PDU groups. If the channel is part of a partial network the whole partial network has to be stopped.

### Listing 3.17: CanSM reports SILENT\_COMMUNICATION or NO\_COMMUNICATION

```

rule stopComChannel1 initially false {
    if ( CanSM_Can1 == CANSM_BSWM_SILENT_COMMUNICATION ||
        CanSM_Can1 == CANSM_BSWM_NO_COMMUNICATION
    ) {
        actionlist stopComChannel1Actions
    }
}

actions stopComChannel1Actions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1IPDUS, ArMmExample.EcuC.MyCom.
            PNC1IPDUS, ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
}

rule stopChannel2 initially false {
    if ( CanSM_Can2 == CANSM_BSWM_SILENT_COMMUNICATION ||
        CanSM_Can2 == CANSM_BSWM_NO_COMMUNICATION
    ) {
        actionlist stopChannel2Actions
    }
}

actions stopChannel2Actions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN2IPDUS, ArMmExample.EcuC.MyCom.
            PNC2IPDUS, ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
}

```

In case that a single partial network is going down the IPDU group representing this network has to be switched off.

### Listing 3.18: PNC reports NO\_COMMUNICATION

```

rule pnc1nocom initially false {

```

```

if ( PNC1 == PNC_NO_COMMUNICATION ) {
    actionlist pnc1nocomTrueActions
}

actions pnc1nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC1IPDUS
    }
}

rule pnc2nocom initially false {
    if ( PNC2 == PNC_NO_COMMUNICATION ) {
        actionlist pnc2nocomTrueActions
    }
}

actions pnc2nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC2IPDUS
    }
}

rule pnc3nocom initially false {
    if ( PNC3 == PNC_NO_COMMUNICATION ) {
        actionlist pnc3nocomActions
    }
}

actions pnc3nocomActions on condition {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
    DeadlineMonitoring {
        disable ArMmExample.EcuC.MyCom.PNC3IPDUS
    }
}

```

If a partial network is requested the IPDU group is turned on.

**Listing 3.19: PNC reports PNC\_REQUESTED or PNC\_READY\_SLEEP**

```

rule pnc1requested initially false {
    if ( PNC1 == PNC_REQUESTED ||
        PNC1 == PNC_READY_SLEEP ) {
        actionlist pnc1requestedActions
    }
}

```

```

}

actions pnc1requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC1IPDUS
  }
}

rule pnc2requested initially false {
  if ( PNC2 == PNC_REQUESTED ||
      PNC2 == PNC_READY_SLEEP ) {
    actionlist pnc2requestedActions
  }
}

actions pnc2requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC2IPDUS
  }
}

rule pnc3requested initially false {
  if ( PNC3 == PNC_REQUESTED ||
      PNC3 == PNC_READY_SLEEP ) {
    actionlist pnc3requestedActions
  }
}

actions pnc3requestedActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC3IPDUS
  }
}

```

In case of an indication that the partial network statemachine has switched to the prepare sleep state only the deadline monitoring of the corresponding IPDU groups shall be turned off but the IPDUs are still transmitted until the state `PNC_OFF` is reached.

### Listing 3.20: PNC reports `PNC_PREPARE_SLEEP`

```

rule pnc1preparesleep initially false {
  if (PNC1 == PNC_PREPARE_SLEEP)
  {
    actionlist pnc1preparesleepActions
  }
}

actions pnc1preparesleepActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.PNC1IPDUS
  }
  DeadlineMonitoring {
    disable ArMmExample.EcuC.MyCom.PNC1IPDUS
  }
}

```

```

}

rule pnc2preparesleep initially false {
  if (PNC2 == PNC_PREPARE_SLEEP )
  {
    actionlist pnc2preparesleepActions
  }
}

actions pnc2preparesleepActions on condition {
  PduGroupSwitch {init true
    enable ArMmExample.EcuC.MyCom.PNC2IPDUS
  }
  DeadlineMonitoring {
    disable ArMmExample.EcuC.MyCom.PNC2IPDUS
  }
}

rule pnc3preparesleep initially false {
  if (PNC3 == PNC_PREPARE_SLEEP )
  {
    actionlist pnc3preparesleepActions
  }
}

actions pnc3preparesleepActions on condition {
  PduGroupSwitch {init true
    enable ArMmExample.EcuC.MyCom.PNC3IPDUS
  }
  DeadlineMonitoring {
    disable ArMmExample.EcuC.MyCom.PNC3IPDUS
  }
}

```

### 3.4.3 J1939 Networkmanagement

In contrast to current AUTOSAR network management, the task of J1939 network management is not to handle sleep and wake-up of ECUs, but to assign unique addresses to each node represented by an ECU.

This is achieved by sending the AddressClaimed (AC, 0x0EE00) parameter group at start-up, which announces the desired address. If another node claims the same address, and has higher priority, the node has to go silent after sending the CannotClaimAddress parameter group (AC with null address as SA), or try to use another address.

To support this use case the BswM is extended to accept state change indications from the J1939Nm via the API function `BswM_J1939Nm_StateChangeNotification()` (see also [3.2.2.2.16](#)).

Depending on the state indicated by the network management the BswM needs to switch ComIPduGroups of COM, PduRRoutingPathGroups of PduR, and general request handling of the J1939Rm.

The first two actions are realized via `BswMPduGroupSwitch-` and `BswMPduRouterControl` -actions. The J1939 Request Manager shall be switched using the `BswMJ1939Rm` action.

COM is expected to have IPDU groups containing all locally received and transmitted I-PDUs for each network. The PduR shall be configured in the same way, having `RoutingPathGroups` for all locally received and transmitted IPDUs for each channel, excluding the received I-PDU for the Request message forwarded to the J1939Rm.

The BswM must then be configured to switch on and off the aforementioned IPDU groups and `PduRRoutingPathGroups` depending on the reported NM states, as well as general request handling of the J1939 Request Manager. The following rule shows the actions of the BswM depending on the NM states. <sup>2</sup>

**Listing 3.21: Rule to implement network management according to J1939**

```

rule J1939_nm_normal_operation initially false {
  if ( J1939NmState == NM_STATE_NORMAL_OPERATION ) {
    actionlist J1939NormalOperationActions
  }
}

actions J1939NormalOperationActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.J1939IPDUS
  }
  PduRoute enable J1939_RoutingPath
  custom "J1939Rm_SetState(J1939RM_STATE_ONLINE) "
  custom "Xcp_SetTransmissionMode(CHANNEL1,XCP_TX_ON) "
}

rule J1939_nm_offline initially false {
  if ( J1939NmState != NM_STATE_NORMAL_OPERATION ) {
    actionlist J1939OfflineActions
  }
}

actions J1939OfflineActions on condition {
  PduGroupSwitch {
    disable ArMmExample.EcuC.MyCom.J1939IPDUS
  }
  PduRoute disable J1939_RoutingPath
  custom "_J1939Rm_SetState(J1939RM_STATE_OFFLINE) "
  custom "Xcp_SetTransmissionMode(CHANNEL1,XCP_TX_OFF) "
}

```

<sup>2</sup>It is recommended to use the `BswMJ1939Rm` action instead of the custom calls. The custom calls are only used in this listing as they are not supported in the current ARTtext version.

### 3.4.4 J1939 diagnostic mode management

In addition to address assignment the BswM has also to supervise the sending of broadcast messages in a J1939 environment. Each IPDU group represents the broadcast messages (J1939 PGs with PDU2 format PGN or PDU1 format PGN and broadcast destination address) of one network.

For this purpose it is also expected that COM contains one IPDU group for each channel, which contains the broadcast messages of this ECU.

#### Listing 3.22: Rule to implement broadcast management according to J1939

```
rule J1939_broadcast_management initially false {
  if ( BswMJ1939DcmBroadcastStatus == NETWORK_ENABLED) {
    actionlist J1939ActivateBroadcastActions
  } else {
    actionlist J1939DeactivateBroadcastActions
  }
}

actions J1939ActivateBroadcastActions on condition {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.J1939BroadcastIPDUS
  }
}

actions J1939DeactivateBroadcastActions on condition {
  PduGroupSwitch {
    disable ArMmExample.EcuC.MyCom.J1939BroadcastIPDUS
  }
}
```

### 3.4.5 Pretended Networking

When implementing the Pretended Networking concept, the BswM should be user-configured to support the mode management requirements. The following subchapters contain recommendations regarding the BswM configuration for Pretended Networking.

#### 3.4.5.1 Activation of Pretended Networking

For the configuration of the activation of Pretended Networking the following aspects have to be considered:

- The BswM should be configured to arbitrate the Mode Request. If there are different ICOM Mode Requests received during the same arbitration cycle of the BswM, the request with the lowest ICOM Configuration ID should be used.

- The BswM should be configured to request FULL\_COM in ComM in order to prevent ComM from deactivating the CAN transceiver when switching to Pretended Networking (transceiver stays in CANTRCV\_NORMAL).
- Pretended Networking needs to be supported by the BswM on a per channel basis. For this, the BswM should be configured with separate sets of Requests/Rules/Actions for each channel.
- BswM should switch to Pretended Networking if and only if all SWCs affected by activation of Pretended Networking have requested a switch to Pretended Networking by a ModeRequest for this channel.
- The configured rules in the BswM should only take action on valid requested ICOM Configuration IDs. Therefore the BSW configurator should setup rules and actions which only react to valid ICOM IDs, such as in the following pseudo code sample:

```
if(IcomConfigId == 0) doActionList1;
if(IcomConfigId == 1) doActionList2;
//ignore all other IcomConfigIds
```

- BswM should be configured to stop all I-PDU groups for a channel to be switched to Pretended Networking.
- BswM should be configured to request activation of Pretended Networking in <bus>SM by calling <bus>SM\_SetIcomConfiguration.
- BswM should be configured to handle a notification from <bus>SM (e.g. CanSm calls Bswm\_CanSm\_CurrentIcomConfiguration) if activation of Pretended Networking was successful. This can be performed by means of the ModeRequest-Source "BswMCanSMIcomIndication".
- The BswM should notify the affected SWCs when an ICOM configuration has been changed. In order to ensure this, the BswM should be configured to perform mode switch indications.
- Errors in case of failures in changing the ICOM configuration should be configured based on a sub state via a BswM action list. The error occurred can be accessed by evaluation of the BswMModeRequestSource "BswMCanSMIcomIndication".

### 3.4.5.2 Deactivation of Pretended Networking

For the configuration of the deactivation of Pretended Networking the following aspects have to be considered:

- The BswM should be configured to start the I-PDU groups assigned to a channel when Pretended Networking is deactivated for this channel.



- The BswM should be configured to call <bus>SM to deactivate Pretended Networking after the I-PDU groups have been started.
- The BswM should be configured to report an error to DEM in case a deactivation of Pretended Networking was not possible.
- The BswM should be configured to request new ICOM configurations from <bus>SM.
- The BswM should notify the affected SWCs when an ICOM configuration has been changed. In order to ensure this, the BswM should be configured to perform mode switch indications.
- Errors in case of failures in changing the ICOM configuration should be configured based on a sub state via a BswM action list. The error occurred can be accessed by evaluation of the BswMModeRequestSource "BswMCanSMIcomIndication".

### 3.4.6 LIN Schedule Table Switch

The BswM is able to switch the schedule tables LIN channels based on requests from Application SWCs.

The SWC requests a LIN schedule table from the BswM in form of an application mode. After the successful switch the BswM switches to the requested mode.

In the following, an example for this behavior is shown. At first, a `ModeDeclarationGroup` is needed which is used by the Application SWCs to request a certain schedule to which the LIN channel shall be switched.

```
modeGroup MDG_LinScheduleTables {
    Schedule1,
    Schedule2
}
```

An enumeration containing the same values is needed for the `SenderReceiverInterface` between BswM and SWC.

```
enum ENUM_LinScheduleTables {
    Schedule1,
    Schedule2
}
```

A `ModeSwitchInterface` is necessary to switch the application mode after the LIN schedule table was set.

```
interface modeSwitch LinScheduleMode {
    mode MDG_LinScheduleTables LinScheduleMode
}
```

Also a `SenderReceiverInterface` which uses the previously defined enumeration is needed. It can be used by the application SWC to request a mode that should lead to a LIN schedule table switch.

```
interface senderReceiver LinChannel1ScheduleTableRequestPort {
    data ENUM_LinScheduleTables LinScheduleMode
}
```

The following BswM rule switches the schedule table of a LIN channel when the application SWC request another application mode.

```
rule LinChannel1Schedule1Request initially false {
    if (LinChannel1ScheduleTableRequestPort == Schedule1)
    {
        LinScheduleSwitch(LinSchedule1)
    }
}
```

The following BswM rule switches the application mode to the mode which was previously requested by the application. It is triggered when the LinSM notifies the BswM that a LIN schedule table switch occurred.

```
rule LinChannel1Schedule1Switched initially false {
    if (LinSM_CurrentState == LinSchedule1)
    {
        RteSwitch(LinScheduleMode, Schedule1)
    }
}
```

And finally the corresponding rules for the LIN schedule table `LinSchedule2`:

```
rule LinChannel1Schedule2Request initially false {
    if (LinChannel1ScheduleTableRequestPort == Schedule2)
    {
        LinScheduleSwitch(LinSchedule2)
    }
}
rule LinChannel2Schedule1Switched initially false {
    if (LinSM_CurrentState == Schedule2)
    {
        RteSwitch(LinScheduleMode, LinSchedule2)
    }
}
```

### 3.5 Diagnostics

In AUTOSAR release 4.0.3 onwards the DCM is the overall mode manager for all diagnostic use cases. The BswM is responsible to change the state of the other basic software modules accordingly.

### 3.5.1 Diagnostic Session Control

For session control [SWS\_Dcm\_00777] in SWS\_DiagnosticCommunicationManager [6] defines the following `ModeDeclarationGroup` as `providedModeGroup`. Note: The mode names and values are derived from the Dcm configuration. This guide shows just an example.

#### Listing 3.23: ModeGroup for session control service of the DCM

```
modeGroup DcmDiagnosticSessionControl {
    DefaultSession,
    ProgrammingSession,
    ExtendedDiagnosticSession,
    SafetySystemDiagnosticSession,
    AllSessionLevel
}

interface modeSwitch MSIF_DcmDiagnosticSessionControl {
    mode DcmDiagnosticSessionControl diagnosticSessionControl
}
```

The DCM acting as a `mode manager` can inform other BSW modules about the current mode of the session control service and if needed set the basic software in the corresponding mode. Listing 3.24 shows the corresponding mode switch interface.

Note that the same interface can also be used to inform the application software about the current diagnostic session.

#### Listing 3.24: ModeRequestPort for session control service of the DCM

```
request BswModeNotification DiagnosticSessionControl {
    source MSIF_DcmDiagnosticSessionControl.diagnosticSessionControl
    processing IMMEDIATE
    initialValue DefaultSession
}
```

### 3.5.2 ECU Reset

In case of ECU Reset, the interaction between DCM and BswM is more complex. The Specification of the Diagnostic Communication Manager [6] specifies for this purpose the interface as described in listing 3.25. Via this interface the DCM signals the BswM to

1. prepare the ECU to execute a specific reset.
2. to explicitly execute this reset.

#### Listing 3.25: Mode switch interface for ECU reset diagnostic service

```
modeGroup DcmEcuReset{
    NONE,
    HARD,
    KEYONOFF,
```

```

SOFT,
JUMPTOBOOTLOADER,
JUMPTOSYSSUPPLIERBOOTLOADER ,
EXECUTE
}

interface modeSwitch MSIF_DcmEcuReset {
    mode DcmEcuReset ecureset
}

```

[SWS\_Dcm\_00373] states that on reception of a request for UDS Service with the sub functions other than enableRapidPowerShutDown (0x04) or disableRapidPowerShutDown (0x05), the DCM module shall switch the ModeDeclarationGroupPrototype DcmEcuReset to the received resetType. After the mode switch is requested the DCM triggers the start of the positive response message transmission.

According to [SWS\_Dcm\_00594] on the transmit confirmation (call to Dcm\_TpTxConfirmation) of the positive response, the DCM module shall trigger the mode switch of ModeDeclarationGroupPrototype DcmEcuReset to EXECUTE. By this final mode switch the DCM request the BswM to finally shutdown the ECU and to to perform the reset.

Listing 3.26 depicts how the different reset scenarios specified in the DCM can be configured in the DCM. Note that in the running example of this document the overall EcuMode is used to signal to the DCM that the ECU is ready to be reset. Depending on the diagnostic service the DCM shall wait for this acknowledgment or switch immediately to the EXECUTE mode, which will cause the BswM to invoke EcuM\_GoDown.

### Listing 3.26: Ruleset to implement different reset scenarios

```

rule DcmEcuResetHard initially false {
    if ( DcmEcuResetMode == DcmEcuReset.HARD) {
        actionlist DcmEcuResetHardActions
    }
}

actions DcmEcuResetHardActions on condition {
    custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_IO) "
    custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
    SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetKeyOnOff initially false {
    if ( DcmEcuResetMode == DcmEcuReset.KEYONOFF) {
        actionlist DcmEcuResetKeyOnOffActions
    }
}

actions DcmEcuResetKeyOnOffActions on condition {
    custom "EcuM_SelectShutdownTarget (ECU_RESET, ECUM_RESET_IO) "
    custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
    SchMSwitch EcuMode : ECU_RESET_READY
}

```

```

}
rule DcmEcuResetSoft initially false {
  if ( DcmEcuResetMode == DcmEcuReset.SOFT) {
    actionlist DcmEcuResetSoftActions
  }
}

actions DcmEcuResetSoftActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_MCU) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetBootLoader initially false {
  if ( DcmEcuResetMode == DcmEcuReset.JUMPTOBOOTLOADER) {
    actionlist DcmEcuResetBootLoaderActions
  }
}

actions DcmEcuResetBootLoaderActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_MCU) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  custom "EcuM_SelectBootTarget (ECUM_BOOT_TARGET_OEM_BOOTLOADER) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuResetSupplierBootloader initially false {
  if ( DcmEcuResetMode == DcmEcuReset.JUMPTOSYSSUPPLIERBOOTLOADER ) {
    actionlist DcmEcuResetSupplierBootloaderActions
  }
}

actions DcmEcuResetSupplierBootloaderActions on condition {
  custom "EcuM_SelectShutdownTarget (ECU_RESET, _ECUM_RESET_MCU) "
  custom "EcuM_SelectShutdownCause (ECUM_CAUSE_DCM) "
  custom "EcuM_SelectBootTarget (ECUM_BOOT_TARGET_SYS_BOOTLOADER) "
  SchMSwitch EcuMode : ECU_RESET_READY
}

rule DcmEcuReset initially false {
  if ( DcmEcuResetMode == DcmEcuReset.EXECUTE ) {
    actionlist DcmEcuResetActions
  }
}

actions DcmEcuResetActions on condition {
  custom "EcuM_GoDown (MODULE_ID) "
}

```

### 3.5.3 Rapid Power Shutdown

On reception of a request for UDS Service with the sub functions enableRapidPowerShutdown (0x04) or disableRapidPowerShutdown (0x05), the DCM module triggers the

mode switch of ModeDeclarationGroupPrototype DcmRapidPowerShutDown ENABLE\_RAPIDPOWERSHUTDOWN or DISABLE\_RAPIDPOWERSHUTDOWN.

In most use cases this information is interpreted by the application to reduce overrun times. Nevertheless it also can be provided to the BswM (listing 3.27) if different shutdown sequences shall be realized by the BswM.

**Listing 3.27: Mode switch interface for rapid power shutdown**

```
modeGroup DcmRapidPowerShutDown {
    ENABLE_RAPIDPOWERSHUTDOWN,
    DISABLE_RAPIDPOWERSHUTDOWN
}

interface modeSwitch MSIF_RapidPowerShutdown {
    mode DcmRapidPowerShutDown powerShutDown
}
```

### 3.5.4 Communication Control diagnostic service

If the DCM reports to the BswM that a specified communication control mode is entered, the BswM has to enable resp. disable the corresponding IPDU groups as shown in listing 3.28.

**Listing 3.28: Ruleset for diagnostic communication control**

```
rule communicationcontrol1 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NORM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_TX_NORM
    }
}

actions communicationcontrol_DCM_ENABLE_RX_TX_NORM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1IPDUS
    }
}
//-----
rule communicationcontrol2 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NORM )
    {
        actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM
    }
}

actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1RXIPDUS
        disable ArMmExample.EcuC.MyCom.CAN1TXIPDUS
    }
}
//-----
```

```

rule communicationcontrol3 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NORM )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM
  }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1TXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1RXIPDUS
  }
}
//-----

rule communicationcontrol5 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NORMAL )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_TX_NORMAL
  }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NORMAL on trigger {
  PduGroupSwitch {
    init true
    disable ArMmExample.EcuC.MyCom.CAN1IPDUS
  }
}
//-----

rule communicationcontrol6 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_TX_NM
  }
}
actions communicationcontrol_DCM_ENABLE_RX_TX_NM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1NMIPDUS
  }
}
//-----

rule communicationcontrol7 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NM
  }
}
actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS
  }
}

```

```

}
//-----

rule communicationcontrol8 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NM )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NM
  }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS
  }
}
//-----

rule communicationcontrol9 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NM )
  {
    actionlist communicationcontrol_DCM_DISABLE_RX_TX_NM
  }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NM on trigger {
  PduGroupSwitch {
    init true
    disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
      CAN1NMTXIPDUS
  }
}
//-----

rule communicationcontrol10 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_TX_NORM_NM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_TX_NORM_NM
  }
}
actions communicationcontrol_DCM_ENABLE_RX_TX_NORM_NM on trigger {
  PduGroupSwitch {
    init true
    enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
      CAN1NMTXIPDUS
  }
}
//-----

rule communicationcontrol11 initially false on condition {
  if (Dcm_Communication_Control_CAN1 == DCM_ENABLE_RX_DISABLE_TX_NORM_NM )
  {
    actionlist communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM_NM
  }
}
actions communicationcontrol_DCM_ENABLE_RX_DISABLE_TX_NORM_NM on trigger {
  PduGroupSwitch {

```



```

    init true
    enable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
        CAN1RXIPDUS
    disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
        CAN1TXIPDUS
}
}
//-----

rule communicationcontrol12 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_ENABLE_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_ENABLE_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        enable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1TXIPDUS
        disable ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1RXIPDUS
    }
}
//-----

rule communicationcontrol13 initially false on condition {
    if (Dcm_Communication_Control_CAN1 == DCM_DISABLE_RX_TX_NORM_NM )
    {
        actionlist communicationcontrol_DCM_DISABLE_RX_TX_NORM_NM
    }
}
actions communicationcontrol_DCM_DISABLE_RX_TX_NORM_NM on trigger {
    PduGroupSwitch {
        init true
        disable ArMmExample.EcuC.MyCom.CAN1NMTXIPDUS, ArMmExample.EcuC.MyCom.
            CAN1TXIPDUS, ArMmExample.EcuC.MyCom.CAN1NMRXIPDUS, ArMmExample.EcuC.
            MyCom.CAN1RXIPDUS
    }
}
//-----

```

### 3.5.5 Control DTC Setting

**Listing 3.29: Mode switch interface for Control of DTC setting**

```

modeGroup DcmControlDTCSetting {
    ENABLEDTCSETTING,
    DISABLEDTCSETTING
}

interface modeSwitch MSIF_DcmControlDtcSetting {
    mode DcmControlDTCSetting dtcSetting
}

```

### 3.5.6 Roe Status

The Dcm will switch the current status of the Roe per configured Roe Event via a mode switch of ModeDeclarationGroupPrototype `DcmResponseOnEvent_<RoeEventID>` switching the mode to `EVENT_STARTED`, `EVENT_STOPPED` and `EVENT_CLEARED`. The information is necessary mainly for applications that need to interact with the Dcm if the events shall be triggered from external.

#### Listing 3.30: Mode switch interface for Roe Status

```
ModeGroup DcmResponseOnEvent_<RoeEventID> {
    EVENT_STARTED,
    EVENT_STOPPED,
    EVENT_CLEARED
}

interface modeSwitch MSIF_DcmResponseOnEvent{
    mode DcmResponseOnEvent currentMode
}
```

## 3.6 BswM to BswM interaction on multicore ECUs

This chapter describes configuration and integration guidelines related to BswM usage in multi partition ECUs.

The BswM mainly interacts with the state managers of the functional clusters, e.g. with the ComM, and should therefore be locally available on the same partition in order to limit inter-core communication as much as possible.

Therefore, the BswM can be distributed over multiple partitions containing BSW modules. These independent BswMs have partition specific configuration sets. The synchronization of the different partition local BswM instances can be accomplished by normal mode-communication (mode request, mode switch) between BswM service components.

If a partition of the ECU contains BSW modules running inside the partition, the partition would also have a partition local BswM.

A partition local BswM is responsible for the complete initialization of the BSW Modules within its partition. As the initialization sequence largely depends on the distribution of the modules in different partitions, this has a big impact on the configuration of all partition local BswMs.

Each partition local BswM has the job of coordinating the initialization of the BSW modules which are running in its partition.

Each instance of the BswM will then take care of the correct initialization and deinitialization of the partition local BSW modules, so that the following scenarios can be realized:

**Startup up:** After startup of the OS, each EcuM will hand over control to the partition local BswM, which then takes care of the initialization of the other partition local BSW Modules. Afterwards, the partition local BswM signals the readiness of the partition to the other BswM instances running in other partitions. This signalling is done using normal mode-communication between the BswM service components.

**Shutdown:** The partition local BswM determines via its ModeRequestSources, whether it can be shut down or not. If this is the case, it signals its current state to the other BswM instances running in other partitions. This signalling is done using normal mode-communication between the BswM service components. The BswM placed inside the partition of the Master EcuM can then decide on this information whether it initiates a shutdown of the ECU.

**Deinitialization:** The BswM (on the partition where the Master EcuM is running inside) can signal the other BswMs that it wants to shutdown the ECU. This signalling is done using normal mode-communication between the BswM service components. The other BswMs can then deinitialize the modules running inside their partition in order to enable a clean shutdown.

**Restart of a partition:** If a partition is restarted, the local BswM signals to the other BswM instances that it is in a restart mode. This signalling is done using normal mode-communication between the BswM service components. Then, the other BswMs can determine if local applications need to be informed or potentially restarted, and how to synchronize them to the newly started partition.

### **3.7 Inter-partition Actions**

The BswM does not implement mechanisms to prevent the execution of actions which affect modules residing on another partition. The configurator of the BswM needs to be aware of this during the configuration of BswM actions. Generally, the BswM can safely execute actions which affect its own partition, but special consideration on the part of the configurator must be given when configuring a BswM action which affects another partition. When configuring a cross-partition action, care must be taken to ensure that the cross-partition action (in implementation, a function call to another partition) can be executed safely and without endangering system performance or stability. If necessary, the implementor of a function needs to state limitations with respect to its usage (e.g. 'not prepared to be called cross-partition with memory protection enabled'). Among other things, the following issues need to be considered on the part of the configurator of cross-partition actions: memory protection, stopping/restarting of partitions, and proper preparation of the callee's (i.e. the recipient of the action) partition.

### **3.8 Inter-partition Requests/Indications**

If the BswM is integrated in a multi-partition ECU, mode requests and/or mode indications could possibly be sent across partition boundaries to the BswM. In the case of


a mode request/indication which crosses a partition via the Rte (e.g. BswMSwcModeRequest), the configurator does not need to take special considerations regarding system stability or data consistency, the Rte handles the communication of this type of cross-partition mode request/indication. However, if the cross-partition mode request/indication comes directly from a BSW module (e.g. BswMComMIndication) or from a generic source (e.g. BswMGenericRequest), the configurator must take special considerations, for example:

1. When the configurator uses memory protection, memory sections which are involved in cross-partition mode requests/indications (e.g. BswM-internal status flags) need to be configured to allow such cross-partition access.
2. Cross-partition Mode requests/indications which are configured with IMMEDIATE processing may also trigger an immediately executed actionlist. The resultant actions will be executed in the context of the caller (e.g. a BSW module in another partition). For these IMMEDIATE cross-partition mode requests/indication, the same issues as in chapter "Inter-partition Actions" also need to be considered.

## 4 Backward Compatibility


This chapter describes a setup to reuse software components (legacy SWCs), which are designed to work with the “ECU State Manager (EcuM) with fixed state machine” [1]. This means that a setup based on EcuM with flexible state machines and the BswM is described which emulates the behavior of the EcuM with a fixed state machine.

An overview of the architectural solution is shown in Figure 4.1. To reuse software components (legacy SWCs), which are designed to work with the "ECU State Manager with fixed state machine" the option "ECU Mode Handling" has to be activated. A so called Compatibility SWC is not necessary to realize this behavior.



**Figure 4.1: Default States in EcuM Flex make it possible to reuse legacy SWCs**

Figure 4.2 depicts the behavioral aspects of the proposal. The small boxes represent the states of fixed EcuM. The green boxes mark the phases of the EcuM flexible. Application software will only notice changes during the UP phase.



**Figure 4.2: Mapping: Phases of fixed EcuM to flexible EcuM**

The result is that all states of the fixed EcuM in the UP phase have to be emulated using the BswM and the software component introduced for this scenario. This software component has to map modes reported by the BswM to modes defined in the interface of the EcuM with fixed statemachine.

## 4.1 Example for BswM Configuration

The system designer has to make sure that all pre- and post-conditions are met when setting a state of the ECU State Manager. As the EcuM shall remain flexible, there is no validation of the sequence the states are switched by BswM. When the sequence of states shall be compatible to the sequence of EcuMFixed, the system designer has to realize this behavior by BswM rules.

### 4.1.1 Startup

During startup phase the same BSW modules shall be initialized as the fixed EcuM does. This is implemented via BswM rules which are executed after initialization of EcuM and initialize these modules. The modules which are already initialized by flexible EcuM are omitted by BswM.

The changed BswM rules can be seen in Listing 4.1.

**Listing 4.1: BswM configuration for fixed EcuM compatible startup**

```

rule InitBlockII initially false {
    if ( EcuMode == MDG_EcuMode.ECU_STARTUP_ONE ) {
        actionlist InitBlockIITrueActions
    }
}

actions InitBlockIITrueActions on condition {
    custom "Port_Init(null)"
    custom "Dio_Init(null)"
    custom "Adc_Init(null)"
    custom "Spi_Init(null)"
    custom "Eep_Init(null)"
    custom "Fls_Init(null)"
    custom "NvM_Init(null)"
    custom "EcuM_SetState(ECU_STARTUP_TWO)"
    custom "NvM_ReadAll()"
}

rule NvMReadAllFinished initially false {
    if ( NvMReadAllJobMode != NVM_REQ_PENDING && EcuMode == MDG_EcuMode.
        ECU_STARTUP_TWO) {
        actionlist NvMReadAllFinishedTrueActions
    }
}

actions NvMReadAllFinishedTrueActions on condition {
    custom "CanTrcv_Init(null)"
    custom "Can_Init(null)"
    custom "CanIf_Init(null)"
    custom "CanSM_Init(null)"
    custom "CanTp_Init(null)"
    custom "Lin_Init(null)"
    custom "LinIf_Init(null)"
}

```

```

custom "LinSM_Init (null) "
custom "LinTp_Init (null) "
custom "FrTrcv_Init (null) "
custom "Fr_Init (null) "
custom "FrIf_Init (null) "
custom "FrSM_Init (null) "
custom "FrTp_Init (null) "
custom "PduR_Init (null) "
custom "CANNM_Init (null) "
custom "FrNM_Init (null) "
custom "NmIf_Init (null) "
custom "IpduM_Init (null) "
custom "COM_Init (null) "
custom "DCM_Init (null) "
custom "StartRte () "
custom "ComM_Init (null) "
custom "DEM_Init (null) "
custom "FIM_Init (null) "
custom "EcuM_SetState (ECU_RUN) "
}

```

#### 4.1.2 Shutdown

For that shutdown mechanism the BswM configuration of Listing 4.2 is responsible. The listed rules coordinate the post-run phase, deinitialize the modules and put the ECU into shut down or sleep. These rules execute the same callouts *EcuM\_On<Mode>()* as it would happen with a fixed EcuM.

**Listing 4.2: BswM configuration for fixed EcuM compatible shutdown**

```

rule checkEcuMCompatibilityModeRequest initially false {
  if ( EcuMode == MDG_EcuMode.ECU_APP_RUN) {
    actionlist checkEcuMCompatibilityModeRequestActions
  }
}

actions checkEcuMCompatibilityModeRequestActions on condition {
  ComMAllowCom MyComM.CanNet1 false
  custom "EcuM_SetState (ECU_APP_POST_RUN) "
}

rule GoBackToRun initially false {
  if ( EcuMode == MDG_EcuMode.ECU_APP_POST_RUN) {
    actionlist GoBackToRunActions
  }
}

actions GoBackToRunActions on condition {
  custom "EcuM_SetState (ECU_APP_RUN) "
}

rule PrepShutdown initially false {

```



```

if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
    MDG_EcuMode.ECU_APP_POST_RUN) {
    actionlist PrepShutdownActions
}
}

actions PrepShutdownActions on condition {
    custom "Dem_Shutdown(null)"
    custom "EcuM_SetState(ECU_GO_SLEEP)"
    custom "EcuM_SetState(ECU_GO_OFF_ONE)"
}

rule GoSleep initially false {
    if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_GO_SLEEP) {
        actionlist GoSleepActions
    }
}

actions GoSleepActions on condition {
    custom "EcuM_SetState(ECU_STARTUP_TWO)"
    custom "NvM_WriteAll()"
}

rule GoOff initially false {
    if ( ComM_Mode_Channell == COMM_NO_COM_REQUEST_PENDING && EcuMode ==
        MDG_EcuMode.ECU_GO_OFF_ONE) {
        actionlist GoOffActions
    }
}

actions GoOffActions on condition {
    custom "Rte_stop(null)"
    custom "ComM_DeInit(null)"
    custom "EcuM_SetState(ECU_GO_OFF_TWO)"
    custom "NvM_WriteAll()"
}

rule GoSleepNvMWriteAllFinished initially false {
    if ( NvMWriteAllJobMode != NVM_REQ_PENDING && EcuMode == MDG_EcuMode.
        ECU_SLEEP)
    {
        actionlist GoSleepNvMWriteAllFinishedActions
    }
}

actions GoSleepNvMWriteAllFinishedActions on condition {
    custom "EcuM_GoHalt()"
}

rule GoOff2 initially false {
    if ( NvMWriteAllJobMode == NVM_BLK_OK && EcuMode == MDG_EcuMode.
        ECU_GO_OFF_TWO) {
        actionlist GoOff2Actions
    }
}

```

```
}  
  
actions GoOff2Actions on condition {  
  custom "EcuM_GoDown () "  
}
```

### 4.1.3 Wakeup

The functionality for correct wakeup from sleep mode has to be fully configured in the BswM. But as it does not need any adjustments for backward compatibility, there are no modifications to be done.

## 5 Acronyms and abbreviations

### 5.1 Technical Terms

All technical terms used throughout this document – except the ones listed here – can be found in the official AUTOSAR glossary [7] or the Software Component Template Specification [2].

Term	Description
mode	A Mode is a certain set of states of the various state machines (not only of the ECU State Manager) that are running in the vehicle and are relevant to a particular entity, an application or the whole vehicle
state	States are internal to their respective BSW component and thus not visible to the application. So they are only used by the BSW's internal state machine. The States inside the ECU State Manager build the phases and therefore handle the modes.
phase	A logical or temporal assembly of ECU Manager's actions and events, e.g. STARTUP, UP, SHUTDOWN, SLEEP, etc. Phases can consist of Sub-Phases which are often called Sequences if they above all exist to group sequences of executed actions into logical units. Phases in this context are not the phases of the AUTOSAR Methodology.
mode switch port	The port for receiving (or sending) a mode switch notification. For this purpose, a mode switch port is typed by a <code>ModeSwitchInterface</code> .
mode request interface	A <code>AUTOSAR SenderReceiverInterfaces</code> , which carries the requested mode in a <code>VariableDataPrototype</code> .
mode user	An <code>AUTOSAR SW-C</code> or <code>AUTOSAR Basic Software Module</code> that depends on modes by <code>ModeDisablingDependency</code> , <code>SwcModeSwitchEvent</code> , <code>BswModeSwitchEvent</code> , or simply by reading the current state of a mode is called a <code>mode user</code> . A mode user is defined by having a <code>require mode switch port</code> or a <code>requiredModeGroup ModeDeclarationGroupPrototype</code> . See also section 2.
mode manager	Entering and leaving modes is initiated by a <code>mode manager</code> . A mode manager is defined by having a <code>provide mode switch port</code> or a <code>providedModeGroup ModeDeclarationGroupPrototype</code> . A mode manager might be either an <code>application mode manager</code> or a <code>Basic Software Module</code> that provides a service including mode switches, like the ECU State Manager. See also section 2.2.
application mode manager	An <code>application mode manager</code> is a <code>AUTOSAR software-component</code> that provides the service of switching modes. The modes of a <code>application mode manager</code> do not have to be standardized.
mode request	The communication of a mode request from the <code>mode user</code> to the <code>mode manager</code> using either the <code>SenderReceiverInterface</code> is called a <code>mode request</code> .

mode switch notification	The communication of a mode switch from the <a href="#">mode manager</a> to the <a href="#">mode user</a> using either the <code>ModeSwitchInterface</code> or <code>providedModeGroup</code> and <code>requiredModeGroup</code> <code>ModeDeclarationGroupPrototype</code> is called mode switch notification.
mode machine instance	The instances of mode machines or <code>ModeDeclarationGroups</code> are defined by the <code>ModeDeclarationGroupPrototypes</code> of the <a href="#">mode manager</a> Since a mode switch is not executed instantaneously, the RTE or Basic Software Scheduler has to maintain it's own states. For each <a href="#">mode managers</a> <code>ModeDeclarationGroupPrototype</code> , RTE or Basic Software Scheduler has one state machine. This state machine is called <a href="#">mode machine instance</a> . For all <a href="#">mode users</a> of the same <a href="#">mode managers</a> <code>ModeDeclarationGroupPrototype</code> RTE and Basic Software Scheduler uses the same mode machine instance. See also section <a href="#">2.2</a> .
common mode machine instance	A “common mode machine instance” is a special “mode machine instance” shared by BSW Modules and SW-Cs: The RTE Generator creates only one <a href="#">mode machine instance</a> if a <code>ModeDeclarationGroupPrototype</code> instantiated in a port of a software-component is synchronized <code>synchronizedModeGroup</code> of a
Mode Disabling Dependency	An <code>RTEEvent</code> and <code>BswEvent</code> that starts a <code>RunnableEntity</code> respectively a Basic Software Schedulable Entity can contain a <code>disabledMode</code> or <code>disabledInMode</code> association which references a <code>ModeDeclaration</code> . This association is called <code>ModeDisablingDependency</code> in this document.
mode disabling dependent ExecutableEntity	A mode disabling dependent <code>RunnableEntity</code> or a Basic Software Schedulable Entity is triggered by an <code>RTEEvent</code> respectively a <code>BswEvent</code> with a <code>ModeDisablingDependency</code> . RTE and Basic Software Scheduler prevent the start of those <code>RunnableEntity</code> or Basic Software Schedulable Entity by the <code>RTEEvent</code> / <code>BswEvent</code> , when the corresponding <a href="#">mode disabling</a> is active. See also section <a href="#">2.2</a> .
mode disabling	When a ‘mode disabling’ is active, RTE and Basic Software Scheduler disables the start of <a href="#">mode disabling dependent ExecutableEntities</a> . The ‘mode disabling’ is active during the mode that is referenced in the mode disabling dependency and during the transitions that enter and leave this mode. See also section <a href="#">2.2</a> .
OnEntry ExecutableEntity	A <code>RunnableEntity</code> or a Basic Software Schedulable Entity that is triggered by a <code>SwcModeSwitchEvent</code> respectively a <code>BswModeSwitchEvent</code> with <code>ModeActivationKind</code> ‘entry’ is triggered on entering the mode. It is called <code>OnEntry ExecutableEntity</code> . See also section <a href="#">2.2</a> .
OnExit ExecutableEntity	A <code>RunnableEntity</code> or a Basic Software Schedulable Entity that is triggered by a <code>SwcModeSwitchEvent</code> respectively a <code>BswModeSwitchEvent</code> with <code>ModeActivationKind</code> ‘exit’ is triggered on exiting the mode. It is called <code>OnExit ExecutableEntity</code> . See also section <a href="#">2.2</a> .

OnTransition ExecutableEntity	A RunnableEntity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchEvent respectively a BswModeSwitchEvent with ModeActivationKind 'transition' is triggered on a transition between the two specified modes. It is called OnTransition ExecutableEntity. See also section 2.2.
mode switch acknowledge ExecutableEntity	A RunnableEntity or a Basic Software Schedulable Entity that is triggered by a SwcModeSwitchedAckEvent respectively a BswModeSwitchedAckEvent connected to the mode manager's ModeDeclarationGroupPrototype. It is called mode switch acknowledge ExecutableEntity. See also section 2.2.
server runnable	A server that is triggered by an OperationInvokedEvent. It has a mixed behavior between a runnable and a function call. In certain situations, RTE can implement the client server communication as a simple function call.
runnable activation	The activation of a runnable is linked to the RTEEvent that leads to the execution of the runnable. It is defined as the incident that is referred to by the RTEEvent. E.g., for a timing event, the corresponding runnable is activated, when the timer expires, and for a data received event, the runnable is activated when the data is received by the RTE.
Basic Software Schedulable Entity activation	The activation of a Basic Software Schedulable Entity is defined as the activation of the task that contains the Basic Software Schedulable Entity and eventually includes setting a flag that tells the glue code in the task which Basic Software Schedulable Entity is to be executed.
Runnable start	A runnable is started by the calling the C-function that implements the runnable from within a started task.
Basic Software Schedulable Entity start	A Basic Software Schedulable Entity is started by the calling the C-function that implements the Basic Software Schedulable Entity from within a started task.
Trigger Source	A Trigger Source administrate the particular Trigger and informs the RTE or Basic Software Scheduler if the Trigger is raised. A Trigger Source has dedicated provide trigger ports or / and releasedTrigger Triggers to communicate to the Trigger Sinks.
Trigger Sink	A Trigger Sink relies on the activation of Runnable Entities or Basic Software Schedulable Entities if a particular Trigger is raised. A Trigger Sink has a dedicated require trigger ports or / and requiredTrigger Triggers to communicate to the Trigger Sources.
Trigger port	A PortPrototype which is typed by an TriggerInterface
triggered ExecutableEntity	A Runnable Entity or a Basic Software Schedulable Entity that is triggered at least by one ExternalTriggerOccurredEvent / BswExternalTriggerOccurredEvent or InternalTriggerOccurredEvent / BswInternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Runnable Triggering is implemented by RTE or Basic Software Scheduler as a direct function call of the triggered ExecutableEntity by the triggering ExecutableEntity.

triggered runnable	A Runnable Entity that is triggered at least by one ExternalTriggerOccurredEvent or InternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Runnable Triggering is implemented by RTE as a direct function call of the triggered runnable by the triggering runnable.
triggered Basic Software Schedulable Entity	A Basic Software Schedulable Entity that is triggered at least by one BswExternalTriggerOccurredEvent or BswInternalTriggerOccurredEvent. In particular cases, the Trigger Event Communication or the Inter Basic Software Schedulable Entity Triggering is implemented by Basic Software Scheduler as a direct function call of the triggered ExecutableEntity by the triggering ExecutableEntity.
execution-instance	An execution-instance of a ExecutableEntity is one instance or call context of an ExecutableEntity with respect to concurrent execution.
inter-ECU communication	The communication between ECUs, typically using COM is called <a href="#">inter-ECUcommunication</a> in this document.
inter-partition communication	The communication within one ECU but between different partitions, represented by different OS applications, is called <a href="#">inter-partition</a> communication in this document. It typically involves the use of OS mechanisms like IOC or trusted function calls. The partitions can be located on different cores or use different memory sections of the ECU.
intra-partition communication	The communication within one partition of one ECU is called <a href="#">intra-partition</a> communication. In this case, RTE can make use of internal buffers and queues for communication.
intra-ECU communication	The communication within one ECU is called <a href="#">intra-ECU</a> communication in this document. It is a super set of <a href="#">inter-partition</a> communication and <a href="#">intra-partition</a> communication.