

Document Title	Specification of Network Management
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	898

Document Status	published
Part of AUTOSAR Standard	Adaptive Platform
Part of Standard Release	R24-11

Document Change History			
Date	Release	Changed by	Description
2024-11-27	R24-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Added NetworkManagementPortInterface and PortPrototype • Reworked ara::com C++ API descriptions based on header files with generated API Tables • Editorial changes
2023-11-23	R23-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Replaced Network Management Service Interface with C++ API • Several quality improvements
2022-11-24	R22-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Added clarifications regarding Operational Modes • Several quality improvements
2021-11-25	R21-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Several quality improvements • Removed chapter 10
2020-11-30	R20-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Several quality improvements • Changed NetworkState DataType from bool to NetworkStateType



△

2019-11-28	R19-11	AUTOSAR Release Management	<ul style="list-style-type: none"> • Added Functional Cluster Lifecycle Chapter • Several quality improvements • Improved linking to Manifest • Changed Document Status from Final to published
2019-03-29	19-03	AUTOSAR Release Management	<ul style="list-style-type: none"> • Introduced Service Interface for interaction via SM • Introduced possibility to group PNCs/Channels/VLANs
2018-10-30	18-10	AUTOSAR Release Management	<ul style="list-style-type: none"> • Updated interaction with State Management • Removed APIs and Services (interaction is done via SM) • Temporary removed user data access to applications
2018-03-29	18-03	AUTOSAR Release Management	<ul style="list-style-type: none"> • Initial release

Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Contents

1	Introduction and functional overview	7
2	Acronyms and Abbreviations	8
3	Related documentation	9
3.1	Input documents & related standards and norms	9
3.2	Further applicable specification	9
4	Constraints and assumptions	10
4.1	Known Limitations	10
4.2	Applicability to car domains	10
5	Dependencies to other Functional Clusters	11
5.1	Provided Interfaces	11
5.2	Required Interfaces	12
5.3	Protocol layer dependencies	12
6	Requirements Tracing	13
7	Functional specification	15
7.1	Architectural Overview	15
7.2	Network Management Algorithm	17
7.3	NetworkControl	18
7.4	Operational Modes	21
7.4.1	Network Mode	22
7.4.1.1	Repeat Message State	23
7.4.1.2	Normal Operation State	24
7.4.1.3	Ready Sleep State	25
7.4.2	Prepare Bus-Sleep Mode	26
7.4.3	Bus-Sleep Mode	27
7.5	Message Format	28
7.5.1	Source Node Identifier	28
7.5.2	Control Bit Vector	28
7.5.3	User Data	29
7.6	Nm Transmission	30
7.6.1	Transmission Scheduling	30
7.7	Nm User Data Handling	31
7.8	Partial Networking	31
7.8.1	Partial Network State Machine	31
7.8.2	Rx Handling of NM messages	31
7.8.3	Tx Handling of NM messages	32
7.8.4	NM message Filter Algorithm	32
7.9	Functional Cluster Lifecycle	34
7.9.1	Startup	34
7.9.2	Shutdown	34

7.10	Reporting	34
7.10.1	Security Events	34
7.10.2	Log Messages	34
7.10.3	Violation Messages	35
7.10.4	Production Errors	36
8	API specification	37
8.1	Header: ara/nm/network_handle.h	38
8.1.1	Class: NetworkHandle	38
8.1.1.1	Public Member Types	38
8.1.1.1.1	Type Alias: NetworkStateChangeNotifier	38
8.1.1.1.2	Enumeration: NetworkStateType	39
8.1.1.2	Public Member Functions	39
8.1.1.2.1	Special Member Functions	39
8.1.1.2.1.1	Copy Constructor	39
8.1.1.2.1.2	Move Constructor	40
8.1.1.2.1.3	Copy Assignment Operator	40
8.1.1.2.1.4	Move Assignment Operator	41
8.1.1.2.1.5	Destructor	41
8.1.1.2.2	Constructors	42
8.1.1.2.2.1	NetworkHandle	42
8.1.1.2.3	Member Functions	42
8.1.1.2.3.1	GetNetworkRequestedState	42
8.1.1.2.3.2	GetNetworkState	43
8.1.1.2.3.3	RegisterNetworkRequestedState ChangeNotifier	44
8.1.1.2.3.4	RegisterNetworkRequestedState ChangeNotifier	44
8.1.1.2.3.5	RegisterNetworkStateChangeNotifier	45
8.1.1.2.3.6	RegisterNetworkStateChangeNotifier	46
8.1.1.2.3.7	SetNetworkRequestedState	46
8.1.1.2.3.8	UnregisterNetworkRequestedState ChangeNotifier	47
8.1.1.2.3.9	UnregisterNetworkStateChangeNotifier	48
8.2	Header: ara/nm/nm_error_domain.h	48
8.2.1	Non-Member Types	48
8.2.1.1	Enumeration: NmErrc	48
8.2.2	Non-Member Functions	49
8.2.2.1	Other	49
8.2.2.1.1	GetNmDomain	49
8.2.2.1.2	MakeErrorCode	49
8.2.3	Class: NmErrorDomain	50
8.2.3.1	Public Member Types	50
8.2.3.1.1	Type Alias: Errc	50
8.2.3.1.2	Type Alias: Exception	51
8.2.3.2	Public Member Functions	51

8.2.3.2.1	Special Member Functions	51
8.2.3.2.1.1	Default Constructor	51
8.2.3.2.2	Member Functions	52
8.2.3.2.2.1	Message	52
8.2.3.2.2.2	Name	52
8.2.3.2.2.3	ThrowAsException	53
8.2.4	Class: NmException	53
8.2.4.1	Public Member Functions	54
8.2.4.1.1	Constructors	54
8.2.4.1.1.1	NmException	54
9	Service Interfaces	55
10	Configuration	56
10.1	Default Values	56
10.2	Semantic Constraints	56
A	Mentioned Manifest Elements	57
B	Demands and constraints on Base Software (normative)	65
C	Platform Extension Interfaces (normative)	66
D	Not implemented requirements	67
E	History of Constraints and Specification Items	68
E.1	Constraint and Specification Item Changes between AUTOSAR Release R23-11 and R24-11	68
E.1.1	Added Specification Items in R24-11	68
E.1.2	Changed Specification Items in R24-11	68
E.1.3	Deleted Specification Items in R24-11	69
E.1.4	Added Constraints in R24-11	69
E.1.5	Changed Constraints in R24-11	69
E.1.6	Deleted Constraints in R24-11	69
E.2	Constraint and Specification Item Changes between AUTOSAR Release R22-11 and R23-11	70
E.2.1	Added Specification Items in R23-11	70
E.2.2	Changed Specification Items in R23-11	71
E.2.3	Deleted Specification Items in R23-11	71
E.3	Constraint and Specification Item Changes between AUTOSAR Release R21-11 and R22-11	72
E.3.1	Added Specification Items in R22-11	72
E.3.2	Changed Specification Items in R22-11	72
E.3.3	Deleted Specification Items in R22-11	72
E.3.4	Added Constraints in R22-11	72
E.3.5	Changed Constraints in R22-11	72
E.3.6	Deleted Constraints in R22-11	72

1 Introduction and functional overview

This specification describes the functionality, API and the configuration of the Network Management for the AUTOSAR Adaptive Platform.

Adaptive Network Management (NM) is intended to work independent of the communication stack used. Its main purpose is to coordinate the transition between normal operation and bus-sleep mode of the underlying networks (physical and partial networks).




Figure 1.1: Architecture overview with example applications

2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations that are only relevant within this specification. A general list of acronyms and abbreviations is available in [1].

Abbreviation / Acronym:	Description:
API	Application Programming Interface
CBV	Control Bit Vector
CM	Communication Management
CWU	Car Wakeup
EM	Execution Management
IP	Internet Protocol
MTU	Maximum Transmission Unit
NM	Network Management
NM Node	A node that supports network management. Please note that network node, node and NM node are used with the same meaning throughout the document.
PN	Partial Network
PNI	Partial Network Information
PNL	Partial Network Learning
UDP	User Datagram Protocol

Terms:	Description:
Bus communication	Communication on the physical medium
Logical Network	A network in which devices can be addressed independent from the actual network technology.
NM cluster	Set of NM nodes coordinated with the use of the NM algorithm.
NM message	Refers to the payload transmitted in a packet. It contains the NM User Data, Partial Network Information as well as the Control Bit Vector and the Source Node Identifier.
NM packet	Refers to an Ethernet Frame containing an IP as well as an UDP header in addition to a NM message. Please note that adaptive network management is currently only supported for Ethernet.
PN communication	Communication during partial network operation
Physical channel	A channel enabling communication using physical devices, such as I/O ports and cables.
Repeat Message Request Bit Indication	Repeat Message Bit set in the Control Bit Vector of a received NM message.
Internally Requested	At least one field NetworkRequestedState associated to that channel/network/PNC/VLAN is set to kFullCom.
Externally Requested	A Network Management Message associated to that channel/network/PNC/VLAN has been received. In case of PNC associated means the bit corresponding to this PNC had the value 1.
FULL_COM	Communication over the network is possible/allowed, the network is up.
NO_COM	Communication over the network is impossible/disabled, the network is down.

3 Related documentation

3.1 Input documents & related standards and norms

- [1] Glossary
AUTOSAR_FO_TR_Glossary
- [2] Specification of Adaptive Platform Core
AUTOSAR_AP_SWS_Core
- [3] Explanation of Adaptive Platform Software Architecture
AUTOSAR_AP_EXP_SWArchitecture
- [4] Specification of the AUTOSAR Network Management Protocol
AUTOSAR_FO_PRS_NetworkManagementProtocol
- [5] Requirements on AUTOSAR Network Management
AUTOSAR_FO_RS_NetworkManagement
- [6] General Requirements specific to Adaptive Platform
AUTOSAR_AP_RS_General
- [7] Specification of State Management
AUTOSAR_AP_SWS_StateManagement
- [8] Specification of Manifest
AUTOSAR_AP_TPS_ManifestSpecification

3.2 Further applicable specification

AUTOSAR provides a core specification [2] which is also applicable for this functional cluster. The chapter "General requirements for all Functional Clusters" of [2] shall be considered an additional and required specification for implementing this functional cluster.

4 Constraints and assumptions

4.1 Known Limitations

The Adaptive Network Management is actually only supporting UdpNM.

The Adaptive Network Management does not allow node detection (Repeat Message State) but only handles incoming requests.

The Adaptive Network Management cannot be configured as the master network coordinator.

The Adaptive Network Management does not support coordinated shutdown using the information in CBV.

The Adaptive Network Management does not support passive mode and passive start-up. Passive start-up would mean that a node has started (i.e. goes to Normal mode), but the network has been woken up by another node.

Modeling part for mapping the logical networks to the BitVector positions as defined in chapter 7.3 is not available in the manifest.

Update and access of User Data was removed as the service interface to Applications has been removed. State Management will control the network request/release and it must be clarified if user data changes/indications shall be done via State Management or directly by applications.

4.2 Applicability to car domains

AUTOSAR Adaptive Network Management can be used for all car domains.

5 Dependencies to other Functional Clusters

This chapter defines the dependencies of this functional cluster to other functional clusters. AUTOSAR decided not to standardize interfaces which are exclusively used between functional clusters to allow efficient implementations which might depend e.g., on the used operating system. The goal of this chapter is to provide an informative guideline for the interactions between functional clusters without specifying syntactical details. This ensures compatibility between documents specifying different functional clusters and supports parallel implementation of different functional clusters. Details of internal interfaces are up to the platform provider. Additional internal interfaces, parameters, and return values can be added. A detailed technical architecture documentation of the overall AUTOSAR Adaptive Platform is provided in [3].

Section 5.1 “[Provided Interfaces](#)” lists the interfaces provided by `Network Management` to other Functional Clusters. Section 5.2 “[Required Interfaces](#)” lists the interfaces required by `Network Management`.

5.1 Provided Interfaces

This section provides an overview of the public interfaces provided by this functional cluster towards other functional clusters.




Figure 5.1: Interfaces provided by Network Management to other Functional Clusters

Figure 5.1 shows the interfaces provided by `Network Management` to other functional clusters within the AUTOSAR Adaptive Platform. Table 5.1 lists the interfaces provided to other functional clusters within the AUTOSAR Adaptive Platform and provides a rationale.

Interface	Functional Cluster	Purpose
<code>NetworkHandle</code>	State Management	This interface shall be used to retrieve information about the network status of a <code>NetworkHandle</code> .

Table 5.1: Interfaces provided to other Functional Clusters

5.2 Required Interfaces

This section provides an overview of the public interfaces required by this functional cluster from other functional clusters.




Figure 5.2: Interfaces required by Network Management from other Functional Clusters

Figure 5.2 shows the interfaces required by Network Management from other functional clusters within the AUTOSAR Adaptive Platform. Table 5.2 lists the interfaces required from other functional clusters within the AUTOSAR Adaptive Platform and provides a rationale.

Functional Cluster	Interface	Purpose
Log and Trace	Logger	Network Management shall use this interface to log standardized messages.

Table 5.2: Interfaces required from other Functional Clusters

5.3 Protocol layer dependencies

The Adaptive Network Management is based on the protocol mentioned in PRS NetworkManagementProtocol [4].

Adaptive Network Management uses functionality of the underlying communication stack in order to send or receive NM messages on the physical networks.

6 Requirements Tracing

The following tables reference the requirements specified in RS Adaptive Network Management [5] and the AUTOSAR RS General [6], and links to the fulfillment of these. Please note that if column “Satisfied by” is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS_AP_00119]	Return values / application errors	[SWS_ANM_01105] [SWS_ANM_01106] [SWS_ANM_01107] [SWS_ANM_01109] [SWS_ANM_01110]
[RS_AP_00120]	Method and Function names	[SWS_ANM_01102] [SWS_ANM_01105] [SWS_ANM_01106] [SWS_ANM_01107] [SWS_ANM_01108] [SWS_ANM_01109] [SWS_ANM_01110]
[RS_AP_00121]	Parameter names	[SWS_ANM_01102] [SWS_ANM_01107] [SWS_ANM_01108] [SWS_ANM_01110]
[RS_AP_00122]	Type names	[SWS_ANM_01100] [SWS_ANM_01101] [SWS_ANM_01103] [SWS_ANM_01104] [SWS_ANM_01111]
[RS_AP_00125]	Enumerator and constant names	[SWS_ANM_01111]
[RS_AP_00127]	Usage of ara::core types	[SWS_ANM_01100] [SWS_ANM_01101] [SWS_ANM_01111]
[RS_AP_00135]	Avoidance of shared ownership	[SWS_ANM_01102] [SWS_ANM_01110]
[RS_AP_00140]	Usage of "final specifier"	[SWS_ANM_01101]
[RS_AP_00149]	Error handling for non-initialized Functional Cluster	[SWS_ANM_01111]
[RS_AP_00159]	usage of "noexcept" specifier	[SWS_ANM_01102] [SWS_ANM_01105] [SWS_ANM_01106] [SWS_ANM_01107] [SWS_ANM_01109] [SWS_ANM_01110]
[RS_Nm_00043]	Nm shall not prohibit bus traffic with Nm not being initialized	[SWS_ANM_00090]
[RS_Nm_00044]	The Nm shall be applicable to different types of communication systems which are in the scope of AUTOSAR and support a bus sleep mode.	[SWS_ANM_00005] [SWS_ANM_00006] [SWS_ANM_00007] [SWS_ANM_00008] [SWS_ANM_00009] [SWS_ANM_00012] [SWS_ANM_00013] [SWS_ANM_00016] [SWS_ANM_00017] [SWS_ANM_00021] [SWS_ANM_00044] [SWS_ANM_00046] [SWS_ANM_00047] [SWS_ANM_00062] [SWS_ANM_00070] [SWS_ANM_00092]
[RS_Nm_00045]	Nm shall provide services to coordinate shutdown of Nm-clusters independently of each other	[SWS_ANM_01009]
[RS_Nm_00047]	Nm shall provide a service to request to keep the bus awake and a service to cancel this request.	[SWS_ANM_00011] [SWS_ANM_00014] [SWS_ANM_00015] [SWS_ANM_00016] [SWS_ANM_00018] [SWS_ANM_00019] [SWS_ANM_00020] [SWS_ANM_00022] [SWS_ANM_00023] [SWS_ANM_00025] [SWS_ANM_00066] [SWS_ANM_00086] [SWS_ANM_00087] [SWS_ANM_00088]
[RS_Nm_00048]	Nm shall put the communication controller into sleep mode if there is no bus communication	[SWS_ANM_00024]





Requirement	Description	Satisfied by
[RS_Nm_00050]	The Nm shall provide the current state of Nm	[SWS_ANM_00063] [SWS_ANM_00083] [SWS_ANM_01000] [SWS_ANM_01001] [SWS_ANM_01002] [SWS_ANM_01003] [SWS_ANM_01004] [SWS_ANM_01005] [SWS_ANM_01006] [SWS_ANM_01007] [SWS_ANM_01008]
[RS_Nm_00051]	Nm shall inform application when Nm state changes occur.	[SWS_ANM_01007] [SWS_ANM_01008] [SWS_ANM_01010] [SWS_ANM_01011] [SWS_ANM_01012] [SWS_ANM_01013] [SWS_ANM_01014] [SWS_ANM_01015] [SWS_ANM_01020] [SWS_ANM_01358]
[RS_Nm_00054]	There shall be a deterministic time from the point where all nodes agree to go to bus sleep to the point where bus is switched off.	[SWS_ANM_00024]
[RS_Nm_00149]	The timing of Nm shall be configurable.	[SWS_ANM_00053] [SWS_ANM_00056]
[RS_Nm_00150]	Specific features of the Network Management shall be configurable	[SWS_ANM_00007] [SWS_ANM_00013] [SWS_ANM_00029] [SWS_ANM_00033] [SWS_ANM_00035] [SWS_ANM_00040] [SWS_ANM_00044] [SWS_ANM_00047] [SWS_ANM_00051] [SWS_ANM_00052] [SWS_ANM_00054] [SWS_ANM_00081] [SWS_ANM_00084] [SWS_ANM_00085] [SWS_ANM_00089] [SWS_ANM_00095]
[RS_Nm_00151]	The Network Management algorithm shall allow any node to integrate into an already running Nm cluster	[SWS_ANM_00037] [SWS_ANM_00038] [SWS_ANM_00071] [SWS_ANM_00091]
[RS_Nm_02505]	The Nm shall optionally set the local node identifier to the Nm-message	[SWS_ANM_00033] [SWS_ANM_00034]
[RS_Nm_02508]	Every node shall have a node identifier associated with it that is unique in the Nm-cluster.	[SWS_ANM_00034]
[RS_Nm_02513]	Nm shall provide functionality which enables upper layers to control the sleep mode.	[SWS_ANM_01009]
[RS_Nm_02519]	The Nm Control Bit Vector shall contain a PNI (Partial Network Information) bit.	[SWS_ANM_00051] [SWS_ANM_00052] [SWS_ANM_00054] [SWS_ANM_00055] [SWS_ANM_00067]
[RS_Nm_02527]	Nm shall implement a filter algorithm dropping all Nm messages that are not relevant for the ECU	[SWS_ANM_00067] [SWS_ANM_00081]
[RS_Nm_02528]	Nm shall provide a service which allows for instantaneous sending of Nm messages.	[SWS_ANM_00094]
[RS_Nm_02546]	UdpNm shall support Partial Networking on Ethernet	[SWS_ANM_00051] [SWS_ANM_00052] [SWS_ANM_00053] [SWS_ANM_00054] [SWS_ANM_00055] [SWS_ANM_00056]

Table 6.1: Requirements Tracing

7 Functional specification

The Adaptive Network Management offers services that allows to request and query the network states for logical network handles that can be mapped to physical or partial networks.

To do so, the following functionalities are provided:

1. Interfaces for requesting and releasing logical network handles
2. Support for partial networking

7.1 Architectural Overview

Figure 7.1 gives an overview of the Adaptive NM service.

The following figure shows an overview on the interaction between [7] and *Network Management* as well as an example mapping between logical networks, partial networks and physical networks.




Figure 7.1: Overview Of Network Management

7.2 Network Management Algorithm

The AUTOSAR Adaptive NM is based on decentralized direct network management strategy, which means that every network node performs activities self-sufficient depending only on the NM packets received and/or transmitted within the communication system.

The AUTOSAR Adaptive NM algorithm is based on periodic NM packets, which are received by all nodes in the cluster via multicast. Reception of NM packets indicates that sending nodes want to keep the NM-cluster awake. If any node is ready to go to sleep mode, it stops sending NM packets, but as long as NM packets from other nodes are received, it postpones transition to sleep mode. Finally, if a dedicated timer elapses because no NM packets are received anymore, every node initiates transition to the sleep mode.

If any node in the NM-cluster requires bus-communication, it can keep the NM-cluster awake by transmitting NM packets.

The main concept of the AUTOSAR Adaptive NM coordination algorithm as described in [4] can be summarized by the following key-behavior:

Every network node transmits periodic NM messages as long as it requires bus-communication; otherwise it does not transmit NM messages.

7.3 NetworkControl

Logical network handles are mapped to one or more partial or physical networks, while a partial network itself can be mapped to one or multiple physical networks. By using the logical network handle all assigned partial networks, VLANs and underlying physical channel(s) are controlled together.

With the introduction of the `State Management` functional cluster, `Network Management` no longer receives logical network requests from applications, instead they are controlled by the `State Management`. `State Management` can split the one or more applications in multiple functions that might require network communication. Applications (or part of) would then request different functions to be activated/deactivated from `State Management` and then `State Management` would in turn, depending on configuration, request/release different logical networks. `NM` checks then the requested state over all logical networks handles and will activate or deactivate the according physical networks.

[SWS_ANM_00063]

Upstream requirements: [RS_Nm_00050](#)

[Each port offered by `NM` shall enable control of one logical `NmNetworkHandle` which in turn can be mapped to partial networks or VLANs.]

Note: In the Manifest the untagged VLAN represents the physical ethernet channel.

[SWS_ANM_00066]

Upstream requirements: [RS_Nm_00047](#)

[Each logical `NmNetworkHandle` shall be mapped to partial networks(via `PncMappingIdent`) and/or VLANs (via `EthernetCommunicationConnector`). Configurations where a logical `NmNetworkHandle` maps the same VLAN directly and via partial network(s) shall not be possible.]

[SWS_ANM_00067]

Upstream requirements: [RS_Nm_02519](#), [RS_Nm_02527](#)

[If partial networking is used a mapping between partial network(s) and `EthernetCommunicationConnector` shall be configured in `PncMapping`.]

Note: One Partial Network can be mapped to several VLAN(s)

[SWS_ANM_00083]

Upstream requirements: RS_Nm_00050

[The return value of the `ara::nm::NetworkHandle::GetNetworkState` shall be `kFullCom`, if all PNCs, VLANs and/or physical channels associated to this instance of `NmNetworkHandle` are in `FULL_COM`. Otherwise the value shall be `kNoCom`.]

Note: The consequence of [SWS_ANM_00083] is, that a lowest wins strategy is applied.

[SWS_ANM_00084]

Upstream requirements: RS_Nm_00150

[If `ara::nm::NetworkHandle::SetNetworkRequestedState` is called with `kFullCom`, the Network Management shall consider each PNC, VLAN and/or physical channel associated with the instance of `NmNetworkHandle` as internally requested.]

Note: The consequence of [SWS_ANM_00084] is, that a highest wins strategy is applied, that means that if in any instance of `NmNetworkHandle` the network requested state is set to `FULL_COM` (via `ara::nm::NetworkHandle::SetNetworkRequestedState` is called with `kFullCom`), the target state of the associated PNC/VLAN/channel(s) is Network Mode, substate Normal Operation State.

[SWS_ANM_00085]

Upstream requirements: RS_Nm_00150

[Network Management shall bring (or keep) all networks/physical channels to `FULL_COM` that are either internally requested or externally requested.]

[SWS_ANM_00086]

Upstream requirements: RS_Nm_00047

[A PNC shall be considered in `FULL_COM`, if all physical channels, to which it is mapped, are in `FULL_COM` and the PNC is internally or externally requested. This includes a call of the registered change notification via `ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier` or via `ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier` using an execution context executor. If the notification is registered via `ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier` using an execution context executor, the call shall be done in the context of the passed `executor`.]

[SWS_ANM_00087] Handling of external wake-up

Upstream requirements: RS_Nm_00047

[Upon detection of of an external wake-up, `FULL_COM` shall be the target state for the corresponding channel(s). If Network Management is configured for that channel,

the target state shall be `Network Mode`, with the default initial sub state `Repeat Message`.]

Note: Its up to the Platform Implementation how an external wakeup event is detected.

[SWS_ANM_00088] Default target state after start-up

Upstream requirements: [RS_Nm_00047](#)

[The default target state after start up for channels for which no external wake-up has been detected shall be [NO_COM](#).]

7.4 Operational Modes

This chapter describes the operational modes of the AUTOSAR Adaptive NM.

[SWS_ANM_00062]

Upstream requirements: [RS_Nm_00044](#)

[NM shall realize the behavior of the state machine mentioned in the figure described below for every physical channel separately.]

Note: The state machine in Figure 7.2 is applied to physical channels. In case of partial networking, the Nm module should additionally take care of relevant PNs.

The Network Management contains three operational modes:

- Network Mode, see [7.4.1](#)
- Prepare Bus-Sleep Mode, see [7.4.2](#)
- Bus-Sleep Mode, see [7.4.3](#)

These modes will not be visible to the Adaptive Application as it is.

When the NM is in Network mode it implies that the network is requested or active. And the logical network information bit will be set to 1.

When the NM is in Prepare Bus-Sleep or Bus-Sleep Mode, It implies that the network is released or inactive. And the logical network information bit will be set to 0.

The following figure shows the state diagram. Mode change related transitions are denoted in green and error handling related transmissions in red.




Figure 7.2: State Chart Diagram

7.4.1 Network Mode

[SWS_ANM_00005]

Upstream requirements: [RS_Nm_00044](#)

[The Network Mode shall consist of three internal states:

- Repeat Message State
- Normal Operation State
- Ready Sleep State

]

For more information check the following chapters:

- Repeat Message State, see [7.4.1.1](#)
- Normal Operation State, see [7.4.1.2](#)

- Ready Sleep State, see [7.4.1.3](#)

[SWS_ANM_00006]

Upstream requirements: [RS_Nm_00044](#)

[When the Network Mode is entered from Bus-Sleep Mode or Prepare Bus-Sleep Mode, by default, the Repeat Message State shall be entered.]

[SWS_ANM_00007]

Upstream requirements: [RS_Nm_00044](#), [RS_Nm_00150](#)

[When the Network Mode is entered, the NM-Timeout Timer shall be started with the value [nmNetworkTimeout](#).]

[SWS_ANM_00008]

Upstream requirements: [RS_Nm_00044](#)

[Upon successful reception of a NM message in Network Mode, the NM-Timeout Timer shall be restarted with the value [nmNetworkTimeout](#).]

[SWS_ANM_00009]

Upstream requirements: [RS_Nm_00044](#)

[Upon successful transmission of a NM message in Network Mode, the NM-Timeout Timer shall be restarted with the value [nmNetworkTimeout](#).]

7.4.1.1 Repeat Message State

The Repeat Message State ensures, that any transition from Bus-Sleep or Prepare Bus-Sleep to the Network Mode becomes visible for the other nodes on the network. Additionally, it ensures that any node stays active for a minimum amount of time.

[SWS_ANM_00011]

Upstream requirements: [RS_Nm_00047](#)

[When the Repeat Message State of Network Mode is entered from Bus-Sleep Mode, Prepare-Bus-Sleep Mode or from within Network Mode (Normal Operation State or Ready Sleep State) transmission of NM messages shall be (re-) started.]

[SWS_ANM_00012]

Upstream requirements: [RS_Nm_00044](#)

[When the NM-Timeout Timer expires in the Repeat Message State, the NM-Timeout Timer shall be restarted.]

[SWS_ANM_00013]

Upstream requirements: [RS_Nm_00044](#), [RS_Nm_00150](#)

[The NM shall stay in the Repeat Message State for a configurable amount of time determined by the [nmRepeatMessageTime](#); after that time the Repeat Message State shall be left.]

[SWS_ANM_00014]

Upstream requirements: [RS_Nm_00047](#)

[When Repeat Message State is left, the Normal Operation State shall be entered, if the network has been requested.]

[SWS_ANM_00015]

Upstream requirements: [RS_Nm_00047](#)

[When Repeat Message State is left, the Ready Sleep State shall be entered, if the network has been released.]

[SWS_ANM_00070]

Upstream requirements: [RS_Nm_00044](#)

[The Repeat Message State of Network Mode is entered from Bus-Sleep Mode or Prepare-Bus-Sleep Mode by default, when a network (channel/PNC/VLAN) is requested by calling [ara::nm::NetworkHandle::SetNetworkRequestedState](#) with the value [kFullCom](#) and the NM module shall transmit a NM message immediately.]

[SWS_ANM_00092] nmPnHandleMultipleNetworkRequests

Upstream requirements: [RS_Nm_00044](#)

[If in Ready Sleep State, Normal Operation State or Repeat Message State and [nmPnHandleMultipleNetworkRequests](#) is set to true and the requested state of the channel/VLAN or an associated PNC changes, Repeat Message State shall be (re-)entered.]

7.4.1.2 Normal Operation State

The Normal Operation State ensures that any node can keep the NM-cluster awake as long as the network functionality is required.

[SWS_ANM_00016]

Upstream requirements: [RS_Nm_00047](#), [RS_Nm_00044](#)

[When the Normal Operation State is entered from Ready Sleep State, transmission of NM messages shall be started immediately.]

[SWS_ANM_00017]

Upstream requirements: [RS_Nm_00044](#)

[When the NM-Timeout Timer expires in the Normal Operation State, the NM-Timeout Timer shall be restarted.]

[SWS_ANM_00018]

Upstream requirements: [RS_Nm_00047](#)

[When the network is released and the current state is Normal Operation State, the Normal Operation State shall be left and the Ready Sleep state shall be entered.]

[SWS_ANM_00019]

Upstream requirements: [RS_Nm_00047](#)

[If Repeat Message Request Bit (set in the CBV of the received NM message) is received in the Normal Operation State, the Normal Operation State shall be left and the Repeat Message State shall be entered.]

7.4.1.3 Ready Sleep State

The Ready Sleep State ensures that any node in the NM-cluster waits with the transition to the Prepare Bus-Sleep Mode as long as any other node keeps the NM-cluster awake.

[SWS_ANM_00020]

Upstream requirements: [RS_Nm_00047](#)

[When the Ready Sleep State is entered from Repeat Message State or Normal Operation State, transmission of NM messages shall be stopped.]

[SWS_ANM_00021]

Upstream requirements: [RS_Nm_00044](#)

[When the NM-Timeout Timer expires in the Ready Sleep State, the Ready Sleep State shall be left and the Prepare Bus-Sleep Mode shall be entered.]

[SWS_ANM_00022]

Upstream requirements: [RS_Nm_00047](#)

[When the network is requested (by calling `ara::nm::NetworkHandle::SetNetworkRequestedState` with `kFullCom`) and the current state is the Ready Sleep State, the Ready Sleep State shall be left and the Normal Operation State shall be entered.]

[SWS_ANM_00023]

Upstream requirements: [RS_Nm_00047](#)

[If Repeat Message Request Bit (set in the CBV of the received NM message) is received in the Ready Sleep State, the Ready Sleep State shall be left and the Repeat Message State shall be entered.]

Note: Handling of multiple transition conditions which might arise at the same time (e.g. NM-Timeout timer expires vs. network is requested) is considered to be implementation-specific.

7.4.2 Prepare Bus-Sleep Mode

The purpose of the Prepare Bus Sleep state is to ensure that all nodes have time to stop their network activity before the Bus Sleep state is entered. Bus activity is calmed down (i.e. queued messages are transmitted in order to empty all TX-buffers) and finally there is no activity on the bus in the Prepare Bus-Sleep Mode.

[SWS_ANM_00024]

Upstream requirements: [RS_Nm_00048](#), [RS_Nm_00054](#)

[The NM shall stay in the Prepare Bus-Sleep Mode for an amount of time determined by the `nmWaitBusSleepTime`; after that time, the Prepare Bus-Sleep Mode shall be left and the Bus-Sleep Mode shall be entered.]

[SWS_ANM_00025]

Upstream requirements: [RS_Nm_00047](#)

[Upon successful reception of a NM message in the Prepare Bus-Sleep Mode, the Prepare Bus-Sleep Mode shall be left and the Network Mode shall be entered; by default, the Repeat Message State is entered.]

Rationale: Other nodes in the cluster are still in Prepare Bus-Sleep Mode; in the exceptional situation described above, transition into the Bus-Sleep Mode shall be avoided and bus-communication shall be restored as fast as possible.

7.4.3 Bus-Sleep Mode

The purpose of the Bus-Sleep state is to reduce power consumption in the node, when no messages are to be exchanged. Transmission and reception capabilities can be switched off if supported by hardware.

If a configurable amount of time determined by `nmNetworkTimeout` + `nmWaitBusSleepTime` is identically configured for all nodes in the network management cluster, all nodes in the network management cluster that are coordinated with use of the AUTOSAR NM algorithm perform the transition into the Bus-Sleep Mode at approximately the same time.

[SWS_ANM_00029]

Upstream requirements: [RS_Nm_00150](#)

[In Bus-Sleep Mode the return value of the corresponding `ara::nm::NetworkHandle::GetNetworkState` are `kNoCom` (see also [\[SWS_ANM_00083\]](#)).]

Note: Reception of a message during bus sleep (if receiving capability is not switched off) is not explicitly handled in this specification as for example wake-up is considered project specific.

Note: In Bus-Sleep Mode, it is assumed that all nodes in a cluster are in this state. Typically, all nodes request the communication approximately at the same time by a common trigger, for instance a wake-up line.

7.5 Message Format

Message Layout is shown in [4].

Note: As mentioned in [4], the length of an NM packet shall not exceed the MTU (Maximum Transmission Unit) of the underlying physical transport layer.

7.5.1 Source Node Identifier

[SWS_ANM_00033]

Upstream requirements: RS_Nm_00150, RS_Nm_02505

[The location of the source node identifier shall be taken from `nmNidPosition`. If `nmNidPosition` is not set, NID shall not be contained in the Nm messages (see [PRS_Nm_00074]).]

[SWS_ANM_00034]

Upstream requirements: RS_Nm_02508, RS_Nm_02505

[The source node identifier shall be set with configurable Node-Id value `nmNodeId` unless the location of the source node identifier is set to Off (see [PRS_Nm_00013]).]

7.5.2 Control Bit Vector

The format (bit-layout) and definition of the CBV is described in [4].

[SWS_ANM_00035]

Upstream requirements: RS_Nm_00150

[The location of the Control Bit Vector shall be configurable using `nmCbvPosition`. If `nmCbvPosition` is not set, CBV shall not be contained in the Nm messages (see [PRS_Nm_00075]).]

[SWS_ANM_00037]

Upstream requirements: RS_Nm_00151

[Repeat Message Request Bit shall always be set to 0 in the transmitted NM message.]

[SWS_ANM_00038]

Upstream requirements: RS_Nm_00151

[Active Wakeup Bit shall always be set to 0 in the transmitted NM message.]

[SWS_ANM_00071]

Upstream requirements: [RS_Nm_00151](#)

[NM Coordinator Sleep Ready Bit shall always be set to 0 in the transmitted NM message.]

[SWS_ANM_00091]

Upstream requirements: [RS_Nm_00151](#)

[Partial Network Learning Bit (PNL) shall always be set to 0 in the transmitted NM message.]

7.5.3 User Data

[SWS_ANM_00040]

Upstream requirements: [RS_Nm_00150](#)

[If NM user data is configured (i.e. `nmUserDataLength` is existing with a value greater than 0) it shall be always included in the NM message (see [PRS_Nm_00158]).]

Note: the range (in bytes) that contains the user data in the received NM message is defined by `nmUserDataLength`.

Note: UserData does not include the PNI in case the Partial Networking is active. Received and Transmitted UserData does not overlap with the PNI.

[SWS_ANM_00095]

Upstream requirements: [RS_Nm_00150](#)

[If `nmUserDataLength` is existing with a value greater than 0 and no data is provided by the application then the Nm shall set the user data to 0 before sending the NM message.]

Note: Currently there is no standardized API to get/set user data.

7.6 Nm Transmission

7.6.1 Transmission Scheduling

Note: The periodic transmission mode is used in the "Repeat Message State" and "Normal Operation State".

[SWS_ANM_00044]

Upstream requirements: [RS_Nm_00044](#), [RS_Nm_00150](#)

[If the Repeat Message State is entered ([\[SWS_ANM_00070\]](#)), the transmission of NM message shall be delayed by `nmMsgCycleOffset` after entering the Repeat Message State.]

[SWS_ANM_00046]

Upstream requirements: [RS_Nm_00044](#)

[If transmission of NM messages has been started and the NM Message Cycle Timer expires, a NM message transmission shall be initiated.]

[SWS_ANM_00047]

Upstream requirements: [RS_Nm_00044](#), [RS_Nm_00150](#)

[If the NM Message Cycle Timer expires it shall be restarted with `nmMsgCycleTime`.]

[SWS_ANM_00094] Immediate Nm Transmissions

Upstream requirements: [RS_Nm_02528](#)

[Upon an active network request (by calling `ara::nm::NetworkHandle::SetNetworkRequestedState` with `kFullCom`) immediate Nm messages shall be sent according to [PRS_Nm_00334](#) using:

- `nmImmediateNmCycleTime` as `NmImmediateNmCycleTime` and
- `nmImmediateNmTransmissions` as `NmImmediateNmTransmissions`

]

7.7 Nm User Data Handling

Note: Although contained in the underlying Protocol Specification [4] currently no use case is seen for user data.

7.8 Partial Networking

7.8.1 Partial Network State Machine

The partial network state machine mentioned in Figure 7.2 is supposed to be implementation specific. Note: Although being implementation specific, the implemented behaviour shall conform to the Partial Networking requirements described in [4].

7.8.2 Rx Handling of NM messages

Note : Reception Handling of PNC bit vector as described in [4] is switched on/off by `NmCluster.nmPncParticipation`

[SWS_ANM_00051]

Upstream requirements: `RS_Nm_00150`, `RS_Nm_02519`, `RS_Nm_02546`

[If `nmPncParticipation` is TRUE and the PNI bit in the received NM message is 1, the NM shall consider this messages as relevant to update the internal states. Otherwise the message is ignored.]

[SWS_ANM_00052]

Upstream requirements: `RS_Nm_00150`, `RS_Nm_02519`, `RS_Nm_02546`

[If `nmPncParticipation` is set to TRUE and the PNI bit in the received NM message is 0, NM shall still process the user data information.]

[SWS_ANM_00053]

Upstream requirements: `RS_Nm_00149`, `RS_Nm_02546`

[The reset time value `PnResetTime` shall be configured by `pnResetTimer`.]

[SWS_ANM_00056]

Upstream requirements: `RS_Nm_00149`, `RS_Nm_02546`

[`pnResetTimer` shall be configured to a value greater than `nmMsgCycleTime`.]

7.8.3 Tx Handling of NM messages

[SWS_ANM_00054]

Upstream requirements: [RS_Nm_00150](#), [RS_Nm_02519](#), [RS_Nm_02546](#)

[[nmPncParticipation](#) shall enable/disable the reception and transmission of PN information.]

Note: The usage of the CBV is mandatory in case Partial Networking is used. This has to be ensured by configuration in the respective platform.

7.8.4 NM message Filter Algorithm

[SWS_ANM_00055]

Upstream requirements: [RS_Nm_02519](#), [RS_Nm_02546](#)

[The range (in bytes) that contains the Partial Network request information (PNC bit vector) in the received NM message shall be defined by PNC bit vector offset ([pncVectorOffset](#)) starting from byte 0 and PNC bit vector length ([pncVectorLength](#)).]

Example:

- PNC bit vector Offset = 3
- PNC bit vector Length = 2

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	Control Bit Vector (default)							
Byte 1	User data 0							
Byte 2	User data 1							
Byte 3	PNC bit vector 0							
Byte 4	PNC bit vector 1							

Table 7.1: NM message layout example

In the above example only Byte 3 and Byte 4 of the NM message contain Partial Network request information.

Note: Every bit of the PNC bit vector represents one Partial Network. If the bit is set to 1 the Partial Network is requested. If the bit is set to 0 there is no request for this Partial Network.

[SWS_ANM_00081]

Upstream requirements: [RS_Nm_00150](#), [RS_Nm_02527](#)

[The Nm shall filter out messages containing Partial Network request information if they do not contain at least one bit set to 1 that corresponds to a Partial Network that is configured in a NmNetworkHandle and allNmMessagesKeepAwake is FALSE.]

Note: When activated the Nm Message Filter Algorithm will filter out any Nm Message not containing at least one relevant Partial Network being requested (its Bit in the PN bit vector set to 1).

[SWS_ANM_00089] allNmMessagesKeepAwake

Upstream requirements: [RS_Nm_00150](#)

[If no relevant Partial Network is requested in the received NM Message and [allNmMessagesKeepAwake](#) is TRUE the Message shall not be filtered out from further Rx Indication handling.]

Note: This is required to enable the ECU to stay awake on any kind of NM Message.

7.9 Functional Cluster Lifecycle

This section defines behavior of this functional cluster during its life-cycle. Please note that there is a general behavior for `ara::core::Initialize` and `ara::core::Deinitialize` defined in [2] by [SWS_CORE_90021] and [SWS_CORE_90022].

7.9.1 Startup

No special startup handling needed for Network Management. The environment is expected to take care that Network Management is running and able to serve communication requests as soon as network communication is needed. If and how the Nm is actually start up in advance depends on platform constraints like e.g. fast (re-)start etc.

7.9.2 Shutdown

[SWS_ANM_00090] Communication Shutdown

Upstream requirements: [RS_Nm_00043](#)

[When a `SIGTERM` is received by NM, any active Network Requests via `ara::nm::NetworkHandle::SetNetworkRequestedState` shall be withdrawn and `ara::nm::NetworkHandle::GetNetworkState` shall return `kNoCom` until process termination.]

Note: The NetworkHardware might be shutdown afterwards. It is assumed that State-Management takes care that no shutdown is initiated while Network Communication is still needed and that active Network Requests during shutdown are an exceptional situation.

7.10 Reporting

7.10.1 Security Events

This functional cluster does not define any security events.

7.10.2 Log Messages

This functional cluster does not define any non-verbose log messages (i.e., modelled DLT messages).

7.10.3 Violation Messages

This section lists all violation messages (i.e., DLT messages logged for Violations according to [SWS_CORE_00021]) defined by this functional cluster.

Dlt-Message	InstanceSpecifierMappingIntegrityViolation		
Description	InstanceSpecifier either cannot be resolved in the model in the context of your executable, or it refers to a model element other than a PortPrototype. String format: "Violation detected in {processIdentifier} at {location}: Invalid InstanceSpecifer {instanceSpecifier} in a constructor of class: {className}"		
MessageId	0x80001ffc		
MessageType Info	DLT_LOG_FATAL		
Dlt-Argument	ArgumentDescription	ArgumentType	ArgumentUnit
processIdentifier	Identifier of the process that caused the violation.	uint8 [encoding UTF-8]	NoUnit
location	An implementation-defined identifier of the location where the violation was detected, for example {filename}:{linenumber}.	uint8 [encoding UTF-8]	NoUnit
instanceSpecifier	InstanceSpecifier used to try to create the object.	uint8 [encoding UTF-8]	NoUnit
className	Name of the class that was instantiated.	uint8 [encoding UTF-8]	NoUnit

Dlt-Message	PortInterfaceMappingViolation		
Description	The type of mapping does not match the expected type of PortInterface: {portInterfaceTypeName} referenced by a {mappingTypeName}. String format: "Violation detected in {processIdentifier} at {location}: Invalid InstanceSpecifer {instanceSpecifier} in a constructor of class: {className}"		
MessageId	0x80001ffb		
MessageType Info	DLT_LOG_FATAL		
Dlt-Argument	ArgumentDescription	ArgumentType	ArgumentUnit
processIdentifier	Identifier of the process that caused the violation.	uint8 [encoding UTF-8]	NoUnit
location	An implementation-defined identifier of the location where the violation was detected, for example {filename}:{linenumber}.	uint8 [encoding UTF-8]	NoUnit
instanceSpecifier	InstanceSpecifier used to try to create the object.	uint8 [encoding UTF-8]	NoUnit
className	Name of the class that was instantiated.	uint8 [encoding UTF-8]	NoUnit

Dlt-Message	ProcessMappingViolation		
Description	Matching InstanceRef exists, but no matching (modelled) Process found that matches the (runtime) process. String format: "Violation detected in {processIdentifier} at {location}: Invalid InstanceSpecifer {instanceSpecifier} in a constructor of class: {className}"		
MessageId	0x80001ffa		
MessageType Info	DLT_LOG_FATAL		
Dlt-Argument	ArgumentDescription	ArgumentType	ArgumentUnit
processIdentifier	Identifier of the process that caused the violation.	uint8 [encoding UTF-8]	NoUnit
location	An implementation-defined identifier of the location where the violation was detected, for example {filename}:{linenumber}.	uint8 [encoding UTF-8]	NoUnit
instanceSpecifier	InstanceSpecifier used to try to create the object.	uint8 [encoding UTF-8]	NoUnit
className	Name of the class that was instantiated.	uint8 [encoding UTF-8]	NoUnit

Dlt-Message	InstanceSpecifierAlreadyInUseViolation		
Description	Violation message that is sent in case a constructor in the ara framework was called with an Instance Specifier already in use in this process. String format: "Violation detected in {processIdentifier} at {location}: InstanceSpecifer {instanceSpecifier} in constructor of class {className} already in use in this process"		
MessageId	0x80001ff9		
MessageType Info	DLT_LOG_FATAL		
Dlt-Argument	ArgumentDescription	ArgumentType	ArgumentUnit
processIdentifier	Identifier of the process that caused the violation.	uint8 [encoding UTF-8]	NoUnit
location	An implementation-defined identifier of the location where the violation was detected, for example {filename}:{linenumber}.	uint8 [encoding UTF-8]	NoUnit
instanceSpecifier	InstanceSpecifier used to try to create the object.	uint8 [encoding UTF-8]	NoUnit
className	Name of the class that was instantiated.	uint8 [encoding UTF-8]	NoUnit

7.10.4 Production Errors

This functional cluster does not define any production errors (i.e., Diagnostic Events).

8 API specification

This chapter provides a reference of the APIs defined by this functional cluster. The API is described in the following chapters in tables. Table 8.1 explains the content that is described in such an API table.

Kind:	Defines the kind of the declaration that this API table describes. The following values are supported: <ul style="list-style-type: none"> • class (Declaration of a class) • function (Declaration of a member or non-member function) • struct (Declaration of a structure) • type alias (Declaration of a type alias) • enumeration (Declaration of an enumeration) • variable (Declaration of a variable) 	
Header File:	Defines the header file to be included according to [SWS_CORE_90001]	
Forwarding Header File:	Defines the forwarding header file to be included according to [SWS_CORE_90001]	
Scope:	Defines the scope that may be a namespace (in case of a class or non-member function) or a class declaration (in case of a member)	
Symbol:	Entity name	
Thread Safety:	Defines whether a function is thread-safe, not thread-safe, or conditional according to [SWS_CORE_13200] and [SWS_CORE_13202]	
Syntax:	Description of C++ syntax	
Template Param:	Template parameter (0..*)	Template parameter(s) used to parametrize the template
Parameters (in):	Parameter declaration (0..*)	Parameter(s) that are passed to the function
Parameters (out):	Parameter declaration (0..*)	Parameter(s) that are returned to the caller
Return Value:	Return type	Type of the value that the function returns
Exception Safety:	Defines whether a function is exception-safe, not exception safe or conditionally exception safe	
Exceptions:	List of exceptions that may be thrown from the function	
Violations:	List of violations that may occur in the function	
Errors:	Error type (0..*)	List of defined error codes that may be returned by the function with their recoverability class defined in [RS_AP_00160]. APIs can be extended with vendor-specific error codes. These are not part of the AUTOSAR SWS specifications
Description:	Brief description of the function	

Table 8.1: Explanation of an API table

8.1 Header: ara/nm/network_handle.h

8.1.1 Class: NetworkHandle

[SWS_ANM_01000] Definition of API class ara::nm::NetworkHandle

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	class
Header file:	#include "ara/nm/network_handle.h"
Forwarding header file:	#include "ara/nm/nm_fwd.h"
Scope:	namespace ara::nm
Symbol:	NetworkHandle
Syntax:	<code>class NetworkHandle final {...};</code>
Description:	Class NetworkHandle is the access to the network handle referenced by the <code>ara::core::InstanceSpecifier</code> . Provides information about network state per NetworkHandle. Intended to be only used by StateManagement

]

8.1.1.1 Public Member Types

8.1.1.1.1 Type Alias: NetworkStateChangeNotifier

[SWS_ANM_01020] Definition of API type ara::nm::NetworkHandle::NetworkStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	type alias
Header file:	#include "ara/nm/network_handle.h"
Scope:	<code>class ara::nm::NetworkHandle</code>
Symbol:	NetworkStateChangeNotifier
Syntax:	<code>using NetworkStateChangeNotifier = std::function<void(const NetworkStateType&)>;</code>
Thread Safety:	not thread-safe
Description:	A function wrapper for the handler function that gets called by the Communication Management software in case the network state has changed.

]

8.1.1.1.2 Enumeration: NetworkStateType

[SWS_ANM_01358] Definition of API enum ara::nm::NetworkHandle::NetworkStateType

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	enumeration	
Header file:	#include "ara/nm/network_handle.h"	
Forwarding header file:	#include "ara/nm/nm_fwd.h"	
Scope:	class ara::nm::NetworkHandle	
Symbol:	NetworkStateType	
Underlying type:	std::uint32_t	
Syntax:	enum class NetworkStateType : std::uint32_t {...};	
Values:	kNoCom= 0	Not all PNCs, VLANs and/or physical channels associated to this instance of the NetworkState are in kFullCom.
	kFullCom= 1	All PNCs, VLANs and/or physical channels associated to this instance of the NetworkState are in kFullCom.
Description:	Enumeration of elementary supervision status.	

]

8.1.1.2 Public Member Functions

8.1.1.2.1 Special Member Functions

8.1.1.2.1.1 Copy Constructor

[SWS_ANM_01005] Definition of API function ara::nm::NetworkHandle::NetworkHandle

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function
Header file:	#include "ara/nm/network_handle.h"
Scope:	class ara::nm::NetworkHandle
Syntax:	NetworkHandle (const NetworkHandle &)=delete;
Description:	The copy constructor for NetworkHandle shall not be used.

]

8.1.1.2.1.2 Move Constructor

[SWS_ANM_01003] Definition of API function `ara::nm::NetworkHandle::NetworkHandle`

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class <code>ara::nm::NetworkHandle</code>	
Syntax:	<code>NetworkHandle (NetworkHandle &&stbc) noexcept;</code>	
Parameters (in):	stbc	The NetworkHandle object to be moved.
Exception Safety:	exception safe	
Thread Safety:	implementation defined	
Description:	Move constructor for NetworkHandle.	

]

8.1.1.2.1.3 Copy Assignment Operator

[SWS_ANM_01006] Definition of API function `ara::nm::NetworkHandle::operator=`

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class <code>ara::nm::NetworkHandle</code>	
Syntax:	<code>NetworkHandle & operator= (const NetworkHandle &)=delete;</code>	
Description:	The copy assignment operator for NetworkHandle shall not be used.	

]

8.1.1.2.1.4 Move Assignment Operator

[SWS_ANM_01004] Definition of API function `ara::nm::NetworkHandle::operator=`

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	NetworkHandle & operator= (NetworkHandle &&stbc) & noexcept;	
Parameters (in):	stbc	The NetworkHandle object to be moved.
Return value:	NetworkHandle &	The moved NetworkHandle object.
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Description:	Move assignment operator for NetworkHandle.	

]

8.1.1.2.1.5 Destructor

[SWS_ANM_01002] Definition of API function `ara::nm::NetworkHandle::~~NetworkHandle`

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	~NetworkHandle () noexcept;	
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Description:	NetworkHandle destructor	

]

8.1.1.2.2 Constructors

8.1.1.2.2.1 NetworkHandle

[SWS_ANM_01001] Definition of API function `ara::nm::NetworkHandle::NetworkHandle`

Upstream requirements: [RS_Nm_00050](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	<code>class ara::nm::NetworkHandle</code>	
Syntax:	explicit NetworkHandle (const ara::core::InstanceSpecifier &specifier) noexcept;	
Parameters (in):	specifier	ara::core::InstanceSpecifier to a PortPrototype of a NetworkManagementPortInterface
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	NetworkHandle constructor	

]

8.1.1.2.3 Member Functions

8.1.1.2.3.1 GetNetworkRequestedState

[SWS_ANM_01008] Definition of API function `ara::nm::NetworkHandle::GetNetworkRequestedState`

Upstream requirements: [RS_Nm_00050](#), [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	<code>class ara::nm::NetworkHandle</code>	
Syntax:	ara::core::Result< NetworkStateType > GetNetworkRequestedState () const noexcept;	
Return value:	ara::core::Result< NetworkStateType >	As per [SWS_ANM_01007]
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Errors:	NmErrc::kServiceNot Available	rollback_semantics

▽

△

		The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous NetworkState.
Description:	Method to obtain the current network requested state i.e. if the PNC / VLAN / Physical Network is currently requested or released	

]

8.1.1.2.3.2 GetNetworkState

[SWS_ANM_01007] Definition of API function `ara::nm::NetworkHandle::GetNetworkState`

Upstream requirements: [RS_Nm_00050](#), [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	<code>class ara::nm::NetworkHandle</code>	
Syntax:	<code>ara::core::Result< NetworkStateType > GetNetworkState () const noexcept;</code>	
Return value:	<code>ara::core::Result< NetworkStateType ></code>	<ul style="list-style-type: none"> • If successful: an <code>ara::core::Result</code> containing a <code>ara::core::Result::value_type</code> containing a <code>ara::nm::NetworkStateType</code> indicating the network requested state of the corresponding PNC / VLAN / Physical Network • If unsuccessful: an <code>ara::core::Result</code> containing an <code>ara::core::Result::error_type</code> i.e. a corresponding <code>ara::com::NmErrc</code>
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Errors:	<code>NmErrc::kServiceNot Available</code>	rollback_semantics The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous NetworkState.
Description:	Method to obtain the current network state i.e. PNC / VLAN / Physical Network is currently active or not	

]

8.1.1.2.3.3 RegisterNetworkRequestedStateChangeNotifier

[SWS_ANM_01012] Definition of API function ara::nm::NetworkHandle::RegisterNetworkRequestedStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	ara::core::Result< void > RegisterNetworkRequestedStateChangeNotifier (NetworkStateChangeNotifier notifier) noexcept;	
Parameters (in):	notifier	The function to register
Return value:	ara::core::Result< void >	As per [SWS_ANM_01010]
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Errors:	NmErrc::kInvalidHandler	rollback_semantics
		Provided Callable handler does not exist or is null
Description:	Register a notifier function which is called if the current network requested state is changed (i.e. changed into FullCom or into NoCom). A maximum of one notifier can be registered. Every further registration overwrites the current registration.	

]

8.1.1.2.3.4 RegisterNetworkRequestedStateChangeNotifier

[SWS_ANM_01014] Definition of API function ara::nm::NetworkHandle::RegisterNetworkRequestedStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	template <typename ExecutorT> ara::core::Result< void > RegisterNetworkRequestedStateChangeNotifier (NetworkStateChangeNotifier notifier, ExecutorT &&executor) noexcept;	
Template param:	As	per ExecutorT in [SWS_ANM_01015]
Parameters (in):	notifier	As per notifier in [SWS_ANM_01012]
	executor	As per executor in [SWS_ANM_01015]
Return value:	ara::core::Result< void >	As per [SWS_ANM_01010]
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	

▽

△

Errors:	NmErrc::kInvalidHandler	rollback_semantics
		Provided Callable handler does not exist or is null
Description:	As per [SWS_ANM_01012] but the method shall execute in a provided context	

]

8.1.1.2.3.5 RegisterNetworkStateChangeNotifier

[SWS_ANM_01010] Definition of API function ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	ara::core::Result< void > RegisterNetworkStateChangeNotifier (NetworkStateChangeNotifier notifier) noexcept;	
Parameters (in):	notifier	The function to register. A maximum of one notifier can be registered. Every further registration overwrites the current registration.
Return value:	ara::core::Result< void >	<ul style="list-style-type: none"> • If successful: an ara::core::Result containing a ara::core::Result::value_type containing a void • If unsuccessful: an ara::core::Result containing an ara::core::Result::error_type i.e. a corresponding ara::com::NmErrc
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Errors:	NmErrc::kInvalidHandler	rollback_semantics
		Provided Callable handler does not exist or is null
Description:	Register a notifier function which is called if the current network state is changed (i.e. changed into FullCom or into NoCom).	

]

8.1.1.2.3.6 RegisterNetworkStateChangeNotifier

[SWS_ANM_01015] Definition of API function ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	<pre>template <typename ExecutorT> ara::core::Result< void > RegisterNetworkStateChangeNotifier (Network StateChangeNotifier notifier, ExecutorT &&executor) noexcept;</pre>	
Template param:	ExecutorT	Context object type in which the asynchronous computation spawn shall be invoked.
Parameters (in):	notifier	As per [SWS_ANM_01010]
	executor	Executioner object in which any asynchronous computation spawn by RegisterNetworkStateChangeNotifier shall be invoked.
Return value:	ara::core::Result< void >	As per [SWS_ANM_01010]
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Errors:	NmErrc::kInvalidHandler	rollback_semantics
		Provided Callable handler does not exist or is null
Description:	As per [SWS_ANM_01010] but the method shall execute in a provided context	

]

8.1.1.2.3.7 SetNetworkRequestedState

[SWS_ANM_01009] Definition of API function ara::nm::NetworkHandle::SetNetworkRequestedState

Upstream requirements: [RS_Nm_00045](#), [RS_Nm_02513](#)

[

Kind:	function	
Header file:	#include "ara/nm/network_handle.h"	
Scope:	class ara::nm::NetworkHandle	
Syntax:	<pre>ara::core::Result< void > SetNetworkRequestedState (NetworkStateType networkState) noexcept;</pre>	
Parameters (in):	networkState	The request state to be set



△

Return value:	ara::core::Result< void >	<ul style="list-style-type: none"> • If successful: an ara::core::Result containing a ara::core::Result::value_type containing a void • If unsuccessful: an ara::core::Result containing an ara::core::Result::error_type i.e. a corresponding ara::com::NmErrc
Exception Safety:	exception safe	
Thread Safety:	not thread-safe	
Errors:	NmErrc::kServiceNot Available	rollback_semantics The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous NetworkState.
Description:	A method that can be used to set a new network requested state. Setting a new network requested state will request or release the PNC / VLAN / Physical Network.	

]

8.1.1.2.3.8 UnregisterNetworkRequestedStateChangeNotifier

[SWS_ANM_01013] Definition of API function ara::nm::NetworkHandle::UnregisterNetworkRequestedStateChangeNotifier

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function
Header file:	#include "ara/nm/network_handle.h"
Scope:	<code>class ara::nm::NetworkHandle</code>
Syntax:	void UnregisterNetworkRequestedStateChangeNotifier () noexcept;
Return value:	None
Exception Safety:	exception safe
Thread Safety:	not thread-safe
Description:	Unregister a notifier function which is called if a current network requested state is changed.

]

8.1.1.2.3.9 UnregisterNetworkStateChangeNotifier

[SWS_ANM_01011] Definition of API function `ara::nm::NetworkHandle::UnregisterNetworkStateChangeNotifier`

Upstream requirements: [RS_Nm_00051](#)

[

Kind:	function
Header file:	<code>#include "ara/nm/network_handle.h"</code>
Scope:	<code>class ara::nm::NetworkHandle</code>
Syntax:	<code>void UnregisterNetworkStateChangeNotifier () noexcept;</code>
Return value:	None
Exception Safety:	exception safe
Thread Safety:	not thread-safe
Description:	Unregister a notifier function which is called if a current network state is changed.

]

8.2 Header: `ara/nm/nm_error_domain.h`

8.2.1 Non-Member Types

8.2.1.1 Enumeration: `NmErrc`

[SWS_ANM_01111] Definition of API enum `ara::nm::NmErrc`

Upstream requirements: [RS_AP_00122](#), [RS_AP_00125](#), [RS_AP_00127](#), [RS_AP_00149](#)

[

Kind:	enumeration				
Header file:	<code>#include "ara/nm/nm_error_domain.h"</code>				
Forwarding header file:	<code>#include "ara/nm/nm_fwd.h"</code>				
Scope:	namespace <code>ara::nm</code>				
Symbol:	<code>NmErrc</code>				
Underlying type:	<code>ara::core::ErrorDomain::CodeType</code>				
Syntax:	<code>enum class NmErrc : ara::core::ErrorDomain::CodeType {...};</code>				
Values:	<table border="1"> <tr> <td><code>kServiceNotAvailable= 1</code></td> <td>The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous <code>NetworkState</code>.</td> </tr> <tr> <td><code>kInvalidHandler= 2</code></td> <td>Provided Callable handler does not exist or is null</td> </tr> </table>	<code>kServiceNotAvailable= 1</code>	The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous <code>NetworkState</code> .	<code>kInvalidHandler= 2</code>	Provided Callable handler does not exist or is null
<code>kServiceNotAvailable= 1</code>	The connection to the daemon is currently lost, so the application must implement an appropriate error strategy, such as taking over the previous <code>NetworkState</code> .				
<code>kInvalidHandler= 2</code>	Provided Callable handler does not exist or is null				
Description:	Defines the error codes for the <code>ara::nm::NmErrorDomain</code>				

]

8.2.2 Non-Member Functions

8.2.2.1 Other

8.2.2.1.1 GetNmDomain

[SWS_ANM_01109] Definition of API function `ara::nm::GetNmDomain`

Upstream requirements: [RS_AP_00119](#), [RS_AP_00120](#), [RS_AP_00159](#)

[

Kind:	function	
Header file:	#include "ara/nm/nm_error_domain.h"	
Scope:	namespace ara::nm	
Syntax:	constexpr const ara::core::ErrorDomain & GetNmDomain () noexcept;	
Return value:	const ara::core::ErrorDomain &	Reference to the ara::nm::NmErrorDomain object
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	Returns a reference to the ara::nm::NmErrorDomain object	

]

8.2.2.1.2 MakeErrorCode

[SWS_ANM_01110] Definition of API function `ara::nm::MakeErrorCode`

Upstream requirements: [RS_AP_00119](#), [RS_AP_00120](#), [RS_AP_00121](#), [RS_AP_00159](#), [RS_AP_00135](#)

[

Kind:	function	
Header file:	#include "ara/nm/nm_error_domain.h"	
Scope:	namespace ara::nm	
Syntax:	constexpr ara::core::ErrorCode MakeErrorCode (NmErrc code, ara::core::ErrorDomain::SupportDataType data) noexcept;	
Parameters (in):	code	Error code number
	data	Vendor defined data associated with the error
Return value:	ara::core::ErrorCode	An ara::core::ErrorCode object.
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	Creates an instance of ara::core::ErrorCode	

]

8.2.3 Class: NmErrorDomain

[SWS_ANM_01101] Definition of API class `ara::nm::NmErrorDomain`

Upstream requirements: [RS_AP_00122](#), [RS_AP_00127](#), [RS_AP_00140](#)

[

Kind:	class
Header file:	#include "ara/nm/nm_error_domain.h"
Forwarding header file:	#include "ara/nm/nm_fwd.h"
Scope:	namespace <code>ara::nm</code>
Symbol:	<code>NmErrorDomain</code>
Base class:	<code>ara::core::ErrorDomain</code>
Syntax:	<code>class NmErrorDomain final : public ara::core::ErrorDomain {...};</code>
Unique ID:	As per ara::nm::NmErrorDomain in [SWS_CORE_90023]
Description:	A class representing a network management error domain.

]

8.2.3.1 Public Member Types

8.2.3.1.1 Type Alias: Errc

[SWS_ANM_01103] Definition of API type `ara::nm::NmErrorDomain::Errc`

Upstream requirements: [RS_AP_00122](#)

[

Kind:	type alias
Header file:	#include "ara/nm/nm_error_domain.h"
Scope:	<code>class ara::nm::NmErrorDomain</code>
Symbol:	<code>Errc</code>
Syntax:	<code>using Errc = NmErrc;</code>
Description:	Alias for the error code value enumeration

]

8.2.3.1.2 Type Alias: Exception

[SWS_ANM_01104] Definition of API type `ara::nm::NmErrorDomain::Exception`

Upstream requirements: [RS_AP_00122](#)

[

Kind:	type alias
Header file:	#include "ara/nm/nm_error_domain.h"
Scope:	<code>class ara::nm::NmErrorDomain</code>
Symbol:	Exception
Syntax:	<code>using Exception = NmException;</code>
Description:	Alias for the exception base class

]

8.2.3.2 Public Member Functions

8.2.3.2.1 Special Member Functions

8.2.3.2.1.1 Default Constructor

[SWS_ANM_01105] Definition of API function `ara::nm::NmErrorDomain::NmErrorDomain`

Upstream requirements: [RS_AP_00119](#), [RS_AP_00120](#), [RS_AP_00159](#)

[

Kind:	function
Header file:	#include "ara/nm/nm_error_domain.h"
Scope:	<code>class ara::nm::NmErrorDomain</code>
Syntax:	<code>NmErrorDomain () noexcept;</code>
Exception Safety:	exception safe
Thread Safety:	thread-safe
Description:	Constructs a new <code>ara::nm::NmErrorDomain</code> object

]

8.2.3.2.2 Member Functions

8.2.3.2.2.1 Message

[SWS_ANM_01107] Definition of API function `ara::nm::NmErrorDomain::Message`

Upstream requirements: [RS_AP_00119](#), [RS_AP_00120](#), [RS_AP_00121](#), [RS_AP_00159](#)

[

Kind:	function	
Header file:	#include "ara/nm/nm_error_domain.h"	
Scope:	<code>class ara::nm::NmErrorDomain</code>	
Syntax:	<code>const char * Message (CodeType errorCode) const noexcept override;</code>	
Parameters (in):	errorCode	The error code number.
Return value:	const char *	The message associated with the error code
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	Returns the message associated with the error code	

]

8.2.3.2.2.2 Name

[SWS_ANM_01106] Definition of API function `ara::nm::NmErrorDomain::Name`

Upstream requirements: [RS_AP_00119](#), [RS_AP_00120](#), [RS_AP_00159](#)

[

Kind:	function	
Header file:	#include "ara/nm/nm_error_domain.h"	
Scope:	<code>class ara::nm::NmErrorDomain</code>	
Syntax:	<code>const char * Name () const noexcept override;</code>	
Return value:	const char *	A string constant associated with the <code>ara::nm::NmErrorDomain</code>
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	Retrieve the name of the error domain	

]

8.2.3.2.2.3 ThrowAsException

[SWS_ANM_01108] Definition of API function `ara::nm::NmErrorDomain::ThrowAsException`

Upstream requirements: [RS_AP_00120](#), [RS_AP_00121](#)

[

Kind:	function
Header file:	<code>#include "ara/nm/nm_error_domain.h"</code>
Scope:	<code>class ara::nm::NmErrorDomain</code>
Syntax:	<code>void ThrowAsException (const ara::core::ErrorCode &errorCode) const noexcept (false) override;</code>
Parameters (in):	errorCode The error to throw.
Return value:	None
Exception Safety:	not exception safe
Thread Safety:	thread-safe
Description:	Throws the exception associated with the error code. As per [SWS_CORE_10304], this function does not participate in overload resolution when C++ exceptions are disabled in the compiler toolchain.

]

8.2.4 Class: NmException

[SWS_ANM_01100] Definition of API class `ara::nm::NmException`

Upstream requirements: [RS_AP_00122](#), [RS_AP_00127](#)

[

Kind:	class
Header file:	<code>#include "ara/nm/nm_error_domain.h"</code>
Forwarding header file:	<code>#include "ara/nm/nm_fwd.h"</code>
Scope:	<code>namespace ara::nm</code>
Symbol:	<code>NmException</code>
Base class:	<code>ara::core::Exception</code>
Syntax:	<code>class NmException : public ara::core::Exception {...};</code>
Description:	Defines a class for exceptions to be thrown by the API.

]

8.2.4.1 Public Member Functions

8.2.4.1.1 Constructors

8.2.4.1.1.1 NmException

[SWS_ANM_01102] Definition of API function `ara::nm::NmException::NmException`

Upstream requirements: [RS_AP_00120](#), [RS_AP_00121](#), [RS_AP_00159](#), [RS_AP_00135](#)

[

Kind:	function	
Header file:	#include "ara/nm/nm_error_domain.h"	
Scope:	<code>class ara::nm::NmException</code>	
Syntax:	<code>explicit NmException (ara::core::ErrorCode errorCode) noexcept;</code>	
Parameters (in):	errorCode	The error code
Exception Safety:	exception safe	
Thread Safety:	thread-safe	
Description:	Constructs a new <code>ara::nm::NmException</code> containing an <code>ara::core::ErrorCode</code>	

]

9 Service Interfaces

This functional cluster does not define any provided or required service interfaces.

10 Configuration

The configuration model of this functional cluster is defined in [8]. This chapter defines the default values for attributes and semantic constraints for elements specified in [8] that are part of the configuration model of this functional cluster.

10.1 Default Values

This functional cluster does not define any default values for attributes specified in [8].

10.2 Semantic Constraints

This section defines semantic constraints for elements specified in [8] that are part of the configuration model of this functional cluster.

[SWS_ANM_CONSTR_00001] Configurable Namespace for Network Management [[NetworkManagementPortInterface.namespace](#) shall never exist.]

A Mentioned Manifest Elements

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document but which are not contained directly in the scope of describing specific meta-model semantics.

This chapter is generated.

Class	EthernetCommunicationConnector			
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::Fibex4Ethernet::EthernetTopology			
Note	Ethernet specific attributes to the CommunicationConnector.			
Base	<i>ARObject, CommunicationConnector, Identifiable, MultilanguageReferrable, Referrable</i>			
Aggregated by	EculInstance.connector, MachineDesign.communicationConnector			
Attribute	Type	Mult.	Kind	Note
apApplicationEndpoint	ApApplicationEndpoint	*	aggr	Collection of Application Addresses that are used on the CommunicationConnector.
canXIProps	CanXIProps	*	ref	If the Ethernet frames handled by this Ethernet CommunicationConnector are tunneled through CAN XL, then this reference shall refer the CanXIProps which contains the specific configuration parameters of the CAN XL controller of the physical CAN XL connection to be used for tunneling.
maximumTransmissionUnit	PositiveInteger	0..1	attr	This attribute specifies the maximum transmission unit in bytes.
neighborCacheSize	PositiveInteger	0..1	attr	This attribute specifies the size of neighbor cache or ARP table in units of entries.
pathMtuEnabled	Boolean	0..1	attr	If enabled the IPv4/IPv6 processes incoming ICMP "Packet Too Big" messages and stores a MTU value for each destination address.
pathMtuTimeout	TimeValue	0..1	attr	If this value is >0 the IPv4/IPv6 will reset the MTU value stored for each destination after n seconds.
unicastNetworkEndpoint	NetworkEndpoint	*	ref	Network Endpoint that defines the IPAddress of the machine.

Table A.1: EthernetCommunicationConnector

Class	MachineDesign			
Package	M2::AUTOSARTemplates::AdaptivePlatform::SystemDesign			
Note	This meta-class represents the ability to define requirements on a Machine in the context of designing a system. Tags: atp.recommendedPackage=MachineDesigns			
Base	<i>ARElement, ARObject, AtpClassifier, AtpFeature, AtpStructureElement, CollectableElement, FibexElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, UploadableDesignElement, UploadablePackageElement</i>			
Aggregated by	ARPackage.element, <i>AtpClassifier.atpFeature</i>			
Attribute	Type	Mult.	Kind	Note
accessControl	AccessControlEnum	0..1	attr	This attribute defines how the access restriction to the Service Instance is defined.





Class	MachineDesign			
communicationConnector	CommunicationConnector	*	aggr	This aggregation defines the network connection of the machine. Stereotypes: atpSplitable Tags: atp.Splitkey=communicationConnector.shortName
communicationController	CommunicationController	*	aggr	CommunicationControllers of the Machine that are used for description of 10-Base-T1S topologies Stereotypes: atpSplitable Tags: atp.Splitkey=communicationController.shortName
cryptoKeySlot	CryptoKeySlotDesign	*	aggr	This aggregation represents the key slots for which a key slot design is created in the context of the enclosing machine design. Stereotypes: atpSplitable Tags: atp.Splitkey=cryptoKeySlot.shortName
ethIpProps	EthIpProps	*	ref	Machine specific IP attributes.
functionalClusterDesign	AbstractFunctionalClusterDesign	*	aggr	Configuration settings for Functional Clusters on the machine design level.
pncPrepareSleepTimer	TimeValue	0..1	attr	Time in seconds the PNC state machine shall wait in PNC_PREPARE_SLEEP.
pnResetTimer	TimeValue	0..1	attr	Specifies the runtime of the reset timer in seconds. This reset time is valid for the reset of PN requests.
serviceDiscoveryConfig	ServiceDiscoveryConfiguration	*	aggr	Set of service discovery configuration settings that are defined on the machine for individual Communication Connectors. Stereotypes: atpSplitable Tags: atp.Splitkey=serviceDiscoveryConfig
tcpIpCmpProps	EthTcpIpCmpProps	*	ref	Machine specific ICMP (Internet Control Message Protocol) attributes
tcpIpProps	EthTcpIpProps	*	ref	Machine specific TcpIp Stack attributes.

Table A.2: MachineDesign

Class	NetworkManagementPortInterface			
Package	M2::AUTOSARTemplates::AdaptivePlatform::ApplicationDesign::PortInterface			
Note	This PortInterface shall be used to submit triggers to the state management Tags: atp.recommendedPackage=NetworkManagementInterfaces			
Base	ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface , Referrable			
Aggregated by	ARPackage.element			
Attribute	Type	Mult.	Kind	Note
–	–	–	–	–

Table A.3: NetworkManagementPortInterface

Class	NmCluster (abstract)
Package	M2::AUTOSARTemplates::SystemTemplate::NetworkManagement
Note	Set of NM nodes coordinated with use of the NM algorithm.
Base	ARObject, Identifiable, MultilanguageReferrable, Referrable
Subclasses	CanNmCluster, FlexrayNmCluster, UdpNmCluster





Class	NmCluster (abstract)			
Aggregated by	NmConfig.nmCluster			
Attribute	Type	Mult.	Kind	Note
communication Cluster	CommunicationCluster	0..1	ref	Association to a CommunicationCluster in the topology description.
nmLightTimeout	TimeValue	0..1	attr	Defines the timeout (in seconds) after COMM_FULL_COMMUNICATION sub-state COMM_FULL_COM_READY_SLEEP is left.
nmNode	NmNode	*	aggr	Collection of NmNodes of the NmCluster. atpVariation: Derived, because NmNode can be variable. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=nmNode.shortName, nmNode.variation Point.shortLabel vh.latestBindingTime=postBuild
nmPnc Participation	Boolean	0..1	attr	Defines whether this NmCluster contributes to the partial network mechanism.
pncCluster VectorLength	PositiveInteger	0..1	attr	Optionally defines the length of the PNC Vector per CommunicationCluster (and VLAN in case of UdpNm). If not defined then System.pncVectorLength applies. Should only make the PNC Vector shorter (or same length as defined in System.pncVectorLength).

Table A.4: NmCluster

Class	NmNetworkHandle			
Package	M2::AUTOSARTemplates::AdaptivePlatform::PlatformModuleDeployment::AdaptiveModule Implementation			
Note	Group of partialNetworks and/or VLANs that can be controlled collectively.			
Base	<i>ARObject, Referrable</i>			
Aggregated by	NmInstantiation.networkHandle			
Attribute	Type	Mult.	Kind	Note
partialNetwork	PncMappingIdent	*	ref	Reference to a Partial Network that is included in the Nm NetworkHandle. Stereotypes: atpSplitable Tags: atp.Splitkey=partialNetwork
vlan	EthernetCommunication Connector	*	ref	Reference to a VLAN that is included in the NmNetwork Handle.

Table A.5: NmNetworkHandle

Class	NmNode (abstract)			
Package	M2::AUTOSARTemplates::SystemTemplate::NetworkManagement			
Note	The linking of NmEcus to NmClusters is realized via the NmNodes.			
Base	<i>ARObject, Identifiable, MultilanguageReferrable, Referrable</i>			
Subclasses	CanNmNode, FlexrayNmNode, UdpNmNode			
Aggregated by	NmCluster.nmNode			
Attribute	Type	Mult.	Kind	Note
machine	MachineDesign	0..1	ref	Reference to the machine that contains the NmNode.





Class	NmNode (abstract)			
nmNodeid	Integer	0..1	attr	Node identifier of local NmNode. Shall be unique in the NmCluster.
nmVariant	NmVariantEnum	0..1	attr	Defines the functionality of Network Management.

Table A.6: NmNode

Class	PncMapping			
Package	M2::AUTOSARTemplates::SystemTemplate::PncMapping			
Note	Describes a mapping between one or several Virtual Function Clusters onto Partial Network Clusters. A Virtual Function Cluster is realized by a PortGroup. A Partial Network Cluster is realized by one or more ServiceInstances.			
Base	ARObject, Describable			
Aggregated by	SystemMapping.pncMapping			
Attribute	Type	Mult.	Kind	Note
ident	PncMappingIdent	0..1	aggr	This adds the ability to become referable to PncMapping.
physical Channel	PhysicalChannel	*	ref	This reference maps the partial network to a communication channel. Stereotypes: atpSplitable Tags: atp.Splitkey=physicalChannel
pncConsumed Provided ServiceInstance Group	ConsumedProvided ServiceInstanceGroup	*	ref	ConsumedProvidedServiceInstanceGroup used in a Partial Network Cluster. This reference is optional, since this could be used for starting and stopping Consumed ProvidedServiceInstanceGroup according the requested partial network, but is not necessarily needed. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=pncConsumedProvidedServiceInstanceGroup.consumedProvidedServiceInstanceGroup, pnc ConsumedProvidedServiceInstanceGroup.variation Point.shortLabel vh.latestBindingTime=postBuild
pncIdentifier	PositiveInteger	0..1	attr	Identifier of the Partial Network Cluster. This number represents the absolute bit position of this Partial Network Cluster in the NM Pdu.
pncWakeup Enable	Boolean	0..1	attr	If this parameter is available and set to true then this PNC will be woken up as soon as a channel wakeup occurs on a channel where this PNC is assigned to. This is ensured by adding this PNC to the corresponding channel wakeup sources during upstream mapping.
serviceInstance	AdaptivePlatform ServiceInstance	*	ref	Reference to ServiceInstances that are participating in a Partial Network Cluster.
shortLabel	Identifier	0..1	attr	This attribute specifies an identifying shortName for the PncMapping. It shall be unique in the System scope.
vfc	PortGroup	*	iref	Virtual Function Cluster to be mapped onto a Partial Network Cluster. This reference is optional in case that the System Description doesn't use a complete Software Component Description (VFB View). This supports the inclusion of legacy systems. InstanceRef implemented by: PortGroupInSystem InstanceRef

Table A.7: PncMapping

Class	PncMappingIdent			
Package	M2::AUTOSARTemplates::SystemTemplate::PncMapping			
Note	This meta-class is created to add the ability to become the target of a reference to the non-Referrable PncMapping.			
Base	<i>ARObject, Referrable</i>			
Aggregated by	PncMapping.ident			
Attribute	Type	Mult.	Kind	Note
–	–	–	–	–

Table A.8: PncMappingIdent

Class	PortInterface (abstract)			
Package	M2::AUTOSARTemplates::SWComponentTemplate::PortInterface			
Note	Abstract base class for an interface that is either provided or required by a port of a software component.			
Base	<i>ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable</i>			
Subclasses	<i>AbstractRawDataStreamInterface, AbstractSynchronizedTimeBaseInterface, ClientServerInterface, CryptoInterface, DataInterface, DiagnosticPortInterface, FirewallStateSwitchInterface, IdsmAbstractPortInterface, LogAndTraceInterface, ModeSwitchInterface, NetworkManagementPortInterface, PersistencyInterface, PlatformHealthManagementInterface, ServiceInterface, StateManagementPortInterface, TriggerInterface</i>			
Aggregated by	ARPackage.element			
Attribute	Type	Mult.	Kind	Note
namespace (ordered)	SymbolProps	*	aggr	This represents the SymbolProps used for the definition of a hierarchical namespace applicable for the generation of code artifacts out of the definition of a ServiceInterface. Stereotypes: atpSplitable Tags: atp.Splitkey=namespace.shortName

Table A.9: PortInterface

Class	PortPrototype (abstract)			
Package	M2::AUTOSARTemplates::SWComponentTemplate::Components			
Note	Base class for the ports of an AUTOSAR software component. The aggregation of PortPrototypes is subject to variability with the purpose to support the conditional existence of ports.			
Base	<i>ARObject, AtpBlueprintable, AtpFeature, AtpPrototype, Identifiable, MultilanguageReferrable, Referrable</i>			
Subclasses	<i>AbstractProvidedPortPrototype, AbstractRequiredPortPrototype</i>			
Aggregated by	<i>AtpClassifier.atpFeature, SwComponentType.port</i>			
Attribute	Type	Mult.	Kind	Note
clientServer Annotation	ClientServerAnnotation	*	aggr	Annotation of this PortPrototype with respect to client/server communication.
delegatedPort Annotation	DelegatedPort Annotation	0..1	aggr	Annotations on this delegated port.
ioHwAbstraction Server Annotation	IoHwAbstractionServer Annotation	*	aggr	Annotations on this IO Hardware Abstraction port.
modePort Annotation	ModePortAnnotation	*	aggr	Annotations on this mode port.
nvDataPort Annotation	NvDataPortAnnotation	*	aggr	Annotations on this non volatile data port.





Class	PortPrototype (abstract)			
parameterPort Annotation	ParameterPort Annotation	*	aggr	Annotations on this parameter port.
portPrototype Props	PortPrototypeProps	0..1	aggr	This attribute allows for the definition of further qualification of the semantics of a PortPrototype.
senderReceiver Annotation	SenderReceiver Annotation	*	aggr	Collection of annotations of this ports sender/receiver communication.
triggerPort Annotation	TriggerPortAnnotation	*	aggr	Annotations on this trigger port.

Table A.10: PortPrototype

Class	System			
Package	M2::AUTOSARTemplates::SystemTemplate			
Note	The top level element of the System Description. Tags: atp.recommendedPackage=Systems			
Base	ARElement, ARObject, AtpClassifier, AtpFeature, AtpStructureElement, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, Referrable, UploadableDesignElement, UploadablePackageElement			
Aggregated by	ARPackage.element, AtpClassifier.atpFeature			
Attribute	Type	Mult.	Kind	Note
fibexElement	FibexElement	*	ref	Reference to ASAM FIBEX elements specifying Communication and Topology. All Fibex Elements used within a System Description shall be referenced from the System Element. atpVariation: In order to describe a product-line, all Fibex Elements can be optional. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=fibexElement.fibexElement, fibexElement.variationPoint.shortLabel vh.latestBindingTime=postBuild
interpolation Routine MappingSet	InterpolationRoutine MappingSet	*	ref	This reference identifies the InterpolationRoutineMapping Sets that are relevant in the context of the enclosing System.
mapping	SystemMapping	*	aggr	Aggregation of all mapping aspects relevant in the System Description. Stereotypes: atpSplitable; atpVariation Tags: atp.Splitkey=mapping.shortName, mapping.variationPoint.shortLabel vh.latestBindingTime=postBuild
pncVector Length	PositiveInteger	0..1	attr	Length of the partial networking request release information vector (in bytes).
pncVectorOffset	PositiveInteger	0..1	attr	Absolute offset (with respect to the NM-PDU) of the partial networking request release information vector that is defined in bytes as an index starting with 0.





Class	System			
rootSoftwareComposition	RootSwCompositionPrototype	0..1	aggr	Aggregation of the root software composition, containing all software components in the System in a hierarchical structure. This element is not required when the System description is used for a network-only use-case. atpVariation: The RootSwCompositionPrototype can vary. Stereotypes: atpSplittable; atpVariation Tags: atp.Splitkey=rootSoftwareComposition.shortName, rootSoftwareComposition.variationPoint.shortLabel vh.latestBindingTime=systemDesignTime
systemVersion	RevisionLabelString	0..1	attr	Version number of the System Description.

Table A.11: System

Class	UdpNmCluster			
Package	M2::AUTOSARTemplates::SystemTemplate::NetworkManagement			
Note	Udp specific NmCluster attributes			
Base	ARObject, Identifiable, MultilanguageReferrable, NmCluster, Referrable			
Aggregated by	NmConfig.nmCluster			
Attribute	Type	Mult.	Kind	Note
networkConfiguration	UdpNmNetworkConfiguration	0..1	aggr	Configuration of a UDP port and UDP multicast IP address of the Nm communication on a VLAN.
nmCbvPosition	Integer	0..1	attr	Defines the position of the control bit vector within the Nm Pdu (Byte position). If this attribute is not configured, the Control Bit Vector is not used.
nmImmediateNmCycleTime	TimeValue	0..1	attr	Defines the immediate NmPdu cycle time in seconds which is used for nmImmediateNmTransmissions NmPdu transmissions. This attribute is only valid if nmImmediateNmTransmissions is greater one.
nmImmediateNmTransmissions	PositiveInteger	0..1	attr	Defines the number of immediate NmPdus which shall be transmitted. If the value is zero no immediate NmPdus are transmitted. The cycle time of immediate NmPdus is defined by nmImmediateNmCycleTime.
nmMsgCycleTime	TimeValue	0..1	attr	Period of a NmPdu in seconds. It determines the periodic rate in the periodic transmission mode with bus load reduction and is the basis for transmit scheduling in the periodic transmission mode without bus load reduction.
nmNetworkTimeout	TimeValue	0..1	attr	Network Timeout for NmPdus in seconds. It denotes the time how long the UdpNm shall stay in the Network Mode before transition into Prepare Bus-Sleep Mode shall take place.
nmNidPosition	Integer	0..1	attr	Defines the byte position of the source node identifier within the NmPdu. If this attribute is not configured, the Node Identification is not used.
nmRepeatMessageTime	TimeValue	0..1	attr	Timeout for Repeat Message State in seconds. Defines the time how long the NM shall stay in the Repeat Message State.
nmUserDataLength	Integer	0..1	attr	Defines the length in bytes of the user data contained in the Nm message. User data excludes the PNC bit vector.
nmUserDataOffset	PositiveInteger	0..1	attr	Specifies the offset (in bytes) of the user data information in the NM message. User data excludes the PNC bit vector.





Class	UdpNmCluster			
nmWaitBusSleepTime	TimeValue	0..1	attr	Timeout for bus calm down phase in seconds. It denotes the time how long the CanNm shall stay in the Prepare Bus-Sleep Mode before transition into Bus-Sleep Mode shall take place.
vlan	EthernetPhysicalChannel	0..1	ref	Reference to the vlan (represented by the Ethernet PhysicalChannel) this UdpNmCluster shall apply to.

Table A.12: UdpNmCluster

Class	UdpNmNode			
Package	M2::AUTOSARTemplates::SystemTemplate::NetworkManagement			
Note	Udp specific NM Node attributes.			
Base	ARObject, Identifiable, MultilanguageReferrable, NmNode, Referrable			
Aggregated by	NmCluster.nmNode			
Attribute	Type	Mult.	Kind	Note
allNmMessagesKeepAwake	Boolean	0..1	attr	Specifies if Nm drops irrelevant NM PDUs. false: Only NM PDUs with a Partial Network Information Bit (PNI) = true and containing a Partial Network request for this ECU trigger the standard RX indication handling and thus keep the ECU awake true: Every NM PDU triggers the standard RX indication handling and keeps the ECU awake
communicationConnector	EthernetCommunicationConnector	0..1	ref	Reference to the CommunicationConnector that represents the UdpNmNode in the topology description.
nmMsgCycleOffset	TimeValue	0..1	attr	Node specific time offset in the periodic transmission node. It determines the start delay of the transmission. Specified in seconds.
nmPnHandleMultipleNetworkRequests	Boolean	0..1	attr	Specifies if NM performs an additional transition from Network Mode to Repeat Message State (true) or not (false).

Table A.13: UdpNmNode

B Demands and constraints on Base Software (normative)

This functional cluster defines no demands or constraints for the Base Software on which the AUTOSAR Adaptive Platform is running on (usually a POSIX-compatible operating system).

C Platform Extension Interfaces (normative)

This functional cluster does not specify any Platform Extension Interfaces.

D Not implemented requirements

This functional cluster implements all functional requirements specified in the corresponding requirement specifications.

E History of Constraints and Specification Items

This chapter provides an overview of the history of constraints and specification items. Please note that the lists in this chapter also include constraints and specification items that have been removed from the specification in a later version. These constraints and specification items do not appear as hyperlinks in the document.

E.1 Constraint and Specification Item Changes between AUTOSAR Release R23-11 and R24-11

E.1.1 Added Specification Items in R24-11

none

E.1.2 Changed Specification Items in R24-11

Number	Heading
[SWS_ANM_00029]	
[SWS_ANM_01001]	Definition of API function <code>ara::nm::NetworkHandle::NetworkHandle</code>
[SWS_ANM_01002]	Definition of API function <code>ara::nm::NetworkHandle::~~NetworkHandle</code>
[SWS_ANM_01003]	Definition of API function <code>ara::nm::NetworkHandle::NetworkHandle</code>
[SWS_ANM_01004]	Definition of API function <code>ara::nm::NetworkHandle::operator=</code>
[SWS_ANM_01005]	Definition of API function <code>ara::nm::NetworkHandle::NetworkHandle</code>
[SWS_ANM_01006]	Definition of API function <code>ara::nm::NetworkHandle::operator=</code>
[SWS_ANM_01007]	Definition of API function <code>ara::nm::NetworkHandle::GetNetworkState</code>
[SWS_ANM_01008]	Definition of API function <code>ara::nm::NetworkHandle::GetNetworkRequestedState</code>
[SWS_ANM_01009]	Definition of API function <code>ara::nm::NetworkHandle::SetNetworkRequestedState</code>
[SWS_ANM_01010]	Definition of API function <code>ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier</code>
[SWS_ANM_01012]	Definition of API function <code>ara::nm::NetworkHandle::RegisterNetworkRequestedStateChangeNotifier</code>
[SWS_ANM_01014]	Definition of API function <code>ara::nm::NetworkHandle::RegisterNetworkRequestedStateChangeNotifier</code>
[SWS_ANM_01015]	Definition of API function <code>ara::nm::NetworkHandle::RegisterNetworkStateChangeNotifier</code>
[SWS_ANM_01020]	Definition of API type <code>ara::nm::NetworkHandle::NetworkStateChangeNotifier</code>
[SWS_ANM_01102]	Definition of API function <code>ara::nm::NmException::NmException</code>
[SWS_ANM_01105]	Definition of API function <code>ara::nm::NmErrorDomain::NmErrorDomain</code>





Number	Heading
[SWS_ANM_01107]	Definition of API function ara::nm::NmErrorDomain::Message
[SWS_ANM_01108]	Definition of API function ara::nm::NmErrorDomain::ThrowAsException

Table E.1: Changed Specification Items in R24-11

E.1.3 Deleted Specification Items in R24-11

none

E.1.4 Added Constraints in R24-11

Number	Heading
[SWS_ANM_- CONSTR_- 00001]	Configurable Namespace for Network Management

Table E.2: Added Constraints in R24-11

E.1.5 Changed Constraints in R24-11

none

E.1.6 Deleted Constraints in R24-11

none

E.2 Constraint and Specification Item Changes between AUTOSAR Release R22-11 and R23-11

E.2.1 Added Specification Items in R23-11

Number	Heading
[SWS_ANM_00052]	
[SWS_ANM_00053]	
[SWS_ANM_00054]	
[SWS_ANM_00056]	
[SWS_ANM_00095]	
[SWS_ANM_01000]	Definition of API class ara::nm::NetworkHandle
[SWS_ANM_01001]	Definition of API function ara::nm::NetworkHandle::NetworkHandle
[SWS_ANM_01002]	Definition of API function ara::nm::NetworkHandle::~~NetworkHandle
[SWS_ANM_01003]	Definition of API function ara::nm::NetworkHandle::NetworkHandle
[SWS_ANM_01004]	Definition of API function ara::nm::NetworkHandle::operator=
[SWS_ANM_01005]	Definition of API function ara::nm::NetworkHandle::NetworkHandle
[SWS_ANM_01006]	Definition of API function ara::nm::NetworkHandle::operator=
[SWS_ANM_01007]	Definition of API function ara::nm::NetworkHandle::GetNetworkState
[SWS_ANM_01008]	Definition of API function ara::nm::NetworkHandle::GetNetworkRequested State
[SWS_ANM_01009]	Definition of API function ara::nm::NetworkHandle::SetNetworkRequested State
[SWS_ANM_01010]	Definition of API function ara::nm::NetworkHandle::RegisterNetwork State ChangeNotifier
[SWS_ANM_01011]	Definition of API function ara::nm::NetworkHandle::UnregisterNetwork State ChangeNotifier
[SWS_ANM_01012]	Definition of API function ara::nm::NetworkHandle::RegisterNetwork RequestedStateChangeNotifier
[SWS_ANM_01013]	Definition of API function ara::nm::NetworkHandle::UnregisterNetwork RequestedStateChangeNotifier
[SWS_ANM_01014]	Definition of API function ara::nm::NetworkHandle::RegisterNetwork RequestedStateChangeNotifier
[SWS_ANM_01015]	Definition of API function ara::nm::NetworkHandle::RegisterNetwork State ChangeNotifier
[SWS_ANM_01020]	Definition of API type ara::nm::NetworkHandle::NetworkStateChangeNotifier
[SWS_ANM_01100]	Definition of API class ara::nm::NmException
[SWS_ANM_01101]	Definition of API class ara::nm::NmErrorDomain
[SWS_ANM_01102]	Definition of API function ara::nm::NmException::NmException
[SWS_ANM_01103]	Definition of API type ara::nm::NmErrorDomain::Errc
[SWS_ANM_01104]	Definition of API type ara::nm::NmErrorDomain::Exception



△

Number	Heading
[SWS_ANM_01105]	Definition of API function ara::nm::NmErrorDomain::NmErrorDomain
[SWS_ANM_01106]	Definition of API function ara::nm::NmErrorDomain::Name
[SWS_ANM_01107]	Definition of API function ara::nm::NmErrorDomain::Message
[SWS_ANM_01108]	Definition of API function ara::nm::NmErrorDomain::ThrowAsException
[SWS_ANM_01109]	Definition of API function ara::nm::GetNmDomain
[SWS_ANM_01110]	Definition of API function ara::nm::MakeErrorCode
[SWS_ANM_01111]	Definition of API enum ara::nm::NmErrc
[SWS_ANM_01358]	Definition of API enum ara::nm::NetworkHandle::NetworkStateType

Table E.3: Added Specification Items in R23-11

E.2.2 Changed Specification Items in R23-11

Number	Heading
[SWS_ANM_00022]	
[SWS_ANM_00029]	
[SWS_ANM_00051]	
[SWS_ANM_00062]	
[SWS_ANM_00070]	
[SWS_ANM_00083]	
[SWS_ANM_00084]	
[SWS_ANM_00086]	
[SWS_ANM_00090]	Communication Shutdown
[SWS_ANM_00094]	Immediate Nm Transmissions

Table E.4: Changed Specification Items in R23-11

E.2.3 Deleted Specification Items in R23-11

Number	Heading
[SWS_ANM_00093]	
[SWS_ANM_91000]	
[SWS_ANM_91001]	

Table E.5: Deleted Specification Items in R23-11

E.3 Constraint and Specification Item Changes between AUTOSAR Release R21-11 and R22-11

E.3.1 Added Specification Items in R22-11

none

E.3.2 Changed Specification Items in R22-11

Number	Heading
[SWS_ANM_00055]	
[SWS_ANM_00083]	
[SWS_ANM_00093]	
[SWS_ANM_91000]	
[SWS_ANM_91001]	

Table E.6: Changed Specification Items in R22-11

E.3.3 Deleted Specification Items in R22-11

Number	Heading
[SWS_ANM_00004]	
[SWS_ANM_00028]	

Table E.7: Deleted Specification Items in R22-11

E.3.4 Added Constraints in R22-11

none

E.3.5 Changed Constraints in R22-11

none

E.3.6 Deleted Constraints in R22-11

none