

<b>Document Title</b>	Specification of FlexRay Interface
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	027
<b>Document Classification</b>	Standard

<b>Document Version</b>	3.1.0
<b>Document Status</b>	Final
<b>Part of Release</b>	3.1
<b>Revision</b>	5

<b>Document Change History</b>			
<b>Date</b>	<b>Version</b>	<b>Changed by</b>	<b>Change Description</b>
20.09.2010	3.1.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Update sequence chart 9-6</li> <li>Extension of FrIf05063 (behavior in case of return value E_NOT_OK for API TriggerTransmit())</li> </ul>
23.06.2008	3.0.2	AUTOSAR Administration	Legal disclaimer revised
22.01.2008	3.0.1	AUTOSAR Administration	Correction of Figure 5.1
18.12.2007	3.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Simplification of the FlexRay Interface State Machine due to the introduction of the new AUTOSAR SWS FlexRay State Manager</li> <li>Cluster-based APIs were removed due to the introduced AUTOSAR SWS FlexRay State Manager</li> <li>The FlexRay Interface does not initialize any other modules any more due to the introduction of the "flat initialization" for AUTOSAR release 3.0</li> <li>Document meta information extended</li> <li>Small layout adaptations made</li> </ul>
06.02.2007	2.0.1	AUTOSAR Administration	<ul style="list-style-type: none"> <li>"Advice for users" revised</li> <li>Legal disclaimer added</li> <li>"Revision Information" added</li> <li>Release Notes added</li> </ul>
30.06.2006	2.0.0	AUTOSAR Administration	Second Release
19.09.2005	1.0.0	AUTOSAR Administration	Initial Release

## Disclaimer

This specification and the material contained in it, as released by AUTOSAR is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.  
For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## Advice for users

AUTOSAR Specification Documents may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the Specification Documents for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such Specification Documents, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

## Table of Contents

1	Introduction and Functional Overview .....	7
2	Information about this Document.....	9
2.1	General Hints .....	9
2.2	Acronyms and Abbreviations.....	10
3	Related Documentation .....	11
3.1	Input Documents .....	11
3.2	Related Standards and Norms .....	12
4	Constraints and Assumptions.....	13
4.1	Limitations .....	13
4.2	Applicability to Car Domains .....	13
5	Dependencies to Other Modules .....	14
5.1	AUTOSAR Operating System .....	14
5.2	AUTOSAR BSW Scheduler.....	14
5.3	All Upper Layer AUTOSAR BSW Modules.....	14
5.4	AUTOSAR PDU-Router .....	14
5.5	AUTOSAR FlexRay Network Management.....	15
5.6	AUTOSAR FlexRay Transport Protocol .....	15
5.7	AUTOSAR FlexRay Driver .....	15
5.8	AUTOSAR FlexRay Transceiver Driver.....	15
5.9	AUTOSAR Development Error Tracer.....	15
5.10	AUTOSAR Diagnostic Event Manager .....	15
5.11	File Structure.....	16
5.11.1	Code File Structure .....	16
5.11.2	Header File Structure .....	16
6	Requirements Traceability.....	19
6.1	General Requirements on Basic Software Modules .....	19
6.2	Requirements on FlexRay.....	21
6.3	Specification Items .....	22
7	Functional Specification.....	24
7.1	FlexRay BSW Stack .....	24
7.2	Indexing Scheme.....	24
7.2.1	Principle .....	24
7.2.2	Supported Indexed Resources.....	27
7.3	FlexRay Interface State Machine .....	27
7.3.1	FlexRay Interface Main Function.....	29
7.4	Implementation Requirements .....	31
7.5	Configuration description.....	32
7.6	Data Communication via FlexRay .....	33
7.6.1	PDU Packing, PDU Update-Bits, and Frame Construction Plans .....	33
7.6.1.1	AlwaysTransmit .....	35
7.6.2	Realization of the Time-Driven FlexRay Schedule .....	35
7.6.2.1	FlexRay Job List .....	36

7.6.2.2	FlexRay Job List Execution Function.....	37
7.6.3	Communication Operations.....	39
7.6.3.1	TransmitWithDecoupledBufferAccess .....	39
7.6.3.2	ProvideTxConfirmation .....	40
7.6.3.3	ReceiveAndStore.....	40
7.6.3.4	ProvideRxIndication.....	41
7.6.3.5	ReceiveAndIndicate.....	41
7.6.3.6	PREPARE_LPDU.....	42
7.6.4	Transmission with Immediate Buffer Access.....	42
7.7	Error Classification .....	43
7.8	Error Detection .....	44
7.9	Error Notification.....	44
8	API Service Specification .....	45
8.1	Imported types.....	45
8.2	Type Definitions.....	45
8.2.1	Frlf_ConfigType .....	45
8.2.2	Frlf_StateType .....	46
8.2.3	Frlf_StateTransitionType.....	46
8.3	Function Definitions.....	46
8.3.1	Frlf_GetVersionInfo .....	47
8.3.2	Frlf_Init.....	48
8.3.3	Frlf_ControllerInit .....	49
8.3.4	Frlf_StartCommunication .....	49
8.3.5	Frlf_HaltCommunication .....	50
8.3.6	Frlf_AbortCommunication .....	51
8.3.7	Frlf_GetState.....	52
8.3.8	Frlf_SetState .....	52
8.3.9	Frlf_SetWakeupChannel.....	53
8.3.10	Frlf_SendWUP .....	54
8.3.11	Frlf_GetSyncState.....	55
8.3.12	Frlf_SetExtSync .....	56
8.3.13	Frlf_GetPOCStatus .....	57
8.3.14	Frlf_GetGlobalTime.....	57
8.3.15	Frlf_AllowColdstart.....	58
8.3.16	Frlf_GetMacroticksDuration .....	59
8.3.17	Frlf_Transmit.....	60
8.3.18	Frlf_SetTransceiverMode.....	61
8.3.19	Frlf_GetTransceiverMode .....	62
8.3.20	Frlf_GetTransceiverWUReason .....	63
8.3.21	Frlf_EnableTransceiverWakeup.....	64
8.3.22	Frlf_DisableTransceiverWakeup.....	65
8.3.23	Frlf_ClearTransceiverWakeup .....	66
8.3.24	Frlf_GetCycleLength .....	67
8.4	Optional Function Definitions .....	68
8.4.1	Frlf_SetAbsoluteTimer .....	68
8.4.2	Frlf_SetRelativeTimer .....	69
8.4.3	Frlf_CancelAbsoluteTimer.....	69
8.4.4	Frlf_CancelRelativeTimer .....	70
8.4.5	Frlf_EnableAbsoluteTimerIRQ .....	71

8.4.6	Frlf_EnableRelativeTimerIRQ .....	72
8.4.7	Frlf_GetAbsoluteTimerIRQStatus .....	73
8.4.8	Frlf_GetRelativeTimerIRQStatus .....	74
8.4.9	Frlf_AckAbsoluteTimerIRQ .....	75
8.4.10	Frlf_AckRelativeTimerIRQ .....	76
8.4.11	Frlf_DisableAbsoluteTimerIRQ .....	77
8.4.12	Frlf_DisableRelativeTimerIRQ .....	77
8.4.13	Frlf_GetNmVector .....	78
8.5	Interrupt Service Routines .....	80
8.5.1	Frlf_JobListExec_<ClstIdx> .....	80
8.6	Call-back Notifications .....	81
8.6.1	Frlf_Cbk_WakeupByTransceiver .....	81
8.7	Scheduled Functions .....	82
8.7.1	Frlf_MainFunction_<ClstIdx> .....	82
8.8	Expected Interfaces .....	83
8.8.1	Mandatory Interfaces .....	83
8.8.2	Optional Interfaces .....	84
8.8.3	Configurable Interfaces .....	84
8.8.3.1	<UL_RxIndication> .....	84
8.8.3.2	<UL_TxConfirmation> .....	85
8.8.3.3	<UL_TriggerTransmit> .....	85
9	Sequence Diagrams .....	87
9.1	Data Transmission .....	87
9.1.1	TransmitWithImmediateBufferAccess .....	87
9.1.2	TransmitWithDecoupledBufferAccess .....	88
9.1.3	ProvideTxConfirmation .....	89
9.2	Data Reception .....	90
9.2.1	ReceiveAndIndicate .....	90
9.2.2	ReceiveAndStore .....	91
9.2.3	ProvideRxIndication .....	92
10	Configuration Specification .....	93
10.1	How to Read this Chapter .....	93
10.1.1	Configuration and Configuration Parameters .....	93
10.1.2	Variants .....	93
10.1.3	Containers .....	94
10.1.4	Specification Template for Configuration Parameters .....	94
10.2	Containers and Configuration Parameters .....	95
10.2.1	Variants .....	95
10.2.2	Frlf .....	95
10.2.3	FrlfGeneral .....	96
10.2.4	FrlfCluster .....	97
10.2.5	FrlfController .....	107
10.2.6	FrlfAbsTimer .....	108
10.2.7	FrlfRelTimer .....	108
10.2.8	FrlfFrameTriggering .....	109
10.2.9	FrlfJobList .....	111
10.2.10	FrlfJob .....	112
10.2.11	FrlfCommunicationOperation .....	113
10.2.12	FrlfFrameStructure .....	114

10.2.13	FrlfPduInFrame.....	114
10.2.14	FrlfLPdu.....	115
10.2.15	FrlfPdu.....	116
10.2.16	FrlfTxPdu.....	116
10.2.17	FrlfRxPdu .....	117
10.2.18	FrlfPduDirection.....	117
10.2.19	FrlfTransceiver .....	118
10.2.20	FrlfConfig.....	118
10.3	Published Information.....	120
11	Changes during SWS Improvements by Technical Office .....	121
11.1	Deleted SWS Items .....	121
11.2	Replaced SWS Items .....	121
11.3	Changed SWS Items.....	121
11.4	Added SWS Items .....	121

## 1 Introduction and Functional Overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module "FlexRay Interface".

In the AUTOSAR Layered Software Architecture [2], the FlexRay Interface belongs to the *ECU Abstraction Layer*, or more precisely, to the *Communication Hardware Abstraction*. This indicates the main task of the FlexRay Interface:

Provide to upper layers an abstract interface to the FlexRay Communication System. At least as far as data transmission (i.e. data sending and reception) is concerned, this interface shall be uniform for all bus systems in Autosar (FlexRay, CAN, LIN). Thus, the upper layer (Communication Services like PDU Router, Transport Protocol, and Network Management and others) may access all underlying bus systems for data transmission in a uniform manner. The configuration of the FlexRay Interface however is bus-specific, since it takes into account the specific features of the communication system.

The FlexRay Interface does not directly access the FlexRay hardware (FlexRay Communication Controller and FlexRay Transceiver), but by means of one or more hardware-specific Driver modules.

In order to access the FlexRay Communication Controller(s), the FlexRay Interface uses one or multiple FlexRay Driver modules, which abstract the specific features and interfaces ([CHI](#)) of the respective FlexRay Communication Controller(s).

Frlf05095:

Likewise, in order to access the FlexRay Transceiver(s), the FlexRay Interface shall use one or multiple FlexRay Transceiver Driver module(s), which abstract the specific features and interfaces of the respective FlexRay Transceiver(s)

Frlf05096:

Therefore, the FlexRay Interface executable code (however, not the configuration used during runtime) shall be completely independent of the FlexRay Communication Controller(s) and the FlexRay Transceiver(s).

### **Note:**

The FlexRay Interface is specified in a way that allows for object code delivery of the code module, following the "one-fits-all" principle, i.e. the entire configuration of the FlexRay Interface can be carried out without modifying any source code. Thus, the configuration of the FlexRay Interface can be carried out largely without detailed knowledge of the underlying hardware.

Frlf05097:

The FlexRay Interface provides to upper layer AUTOSAR [BSW](#) modules the following groups of functions:

- initialization
- data transmission (sending and reception)
- start/halt/abort communication
- FlexRay specific functions (e.g. send wake-up pattern)
- set operation mode
- get status information
- various timer functions



## 2 Information about this Document

### 2.1 General Hints

In general, the FlexRay Interface has no knowledge of the origin of a PDU passed to it in an API service call.

Therefore, throughout this document, unless stated otherwise, the term "PDU" is being used for PDUs originating from or sent to:

- AUTOSAR Com (I-PDU) via the PDU-Router, or
- AUTOSAR FlexRay TP (N-PDU), or
- AUTOSAR FlexRay NM

Frlf05098:

In addition to the above-mentioned AUTOSAR BSW modules, the Frlf shall, with the functionality described within the specification in hand, also support other non-AUTOSAR upper layer software modules, provided that these modules interact with the Frlf in the same manner as the upper layer AUTOSAR BSW modules.

One example for such a non-AUTOSAR software module is a proprietary XCPonFlexRay module that users may add to their AUTOSAR BSW stack.

Throughout this document, several scenarios for changing configuration data are mentioned. They are being used as follows:

- "**pre compile time**" = carried out *before* compiling the code of the FlexRay Interface, since the code generation depends on this setting.
- "**at system configuration time**" = static configuration parameters stored in the FlexRay Interface; may be defined *after* compilation of the code of the FlexRay Interface ("**link time**" or "**post build time**"), but have to be defined *before* the first execution of the FlexRay Interface code.
- "**by a flashing process**" = data (not code!) manipulation carried out in a *flashing process* of a flashable memory (in general a Flash-EEPROM) e.g. in a garage, but **not** while the car is being driven. Usually used to **replace** a static configuration *already stored* in the ECU, or a part thereof. Therefore, the respective data are of configuration class "link time" or "post build time".
- "**during runtime**" = dynamically switching (in [POC: normal active](#) state of the FlexRay [CC](#), if supported) between different configuration parameter sets stored in the static configuration of the FlexRay Interface, or the FlexRay Driver, respectively.

Everything not explicitly mentioned in this document, should be considered as implementation-specific.

## 2.2 Acronyms and Abbreviations

The following acronyms and abbreviations are used throughout this document:

Acronym:	Description:
FrIf	FlexRay Interface (AUTOSAR BSW module)
CC	(FlexRay) Communication Controller
WUP	Wake-Up Pattern
WUS	Wake-Up Symbol
CAS	Collision Avoidance Symbol
MTS	Media Access Test Symbol
POC	Protocol Operation Control
CHI	Controller Host Interface of a FlexRay <a href="#">CC</a>
BSW	(AUTOSAR) Basic Software
ISR	Interrupt Service Routine
COM	Communication (AUTOSAR BSW module)
PduR	PDU Router (AUTOSAR BSW module)
FrTp	FlexRay Transport Layer (AUTOSAR BSW module)
FrNm	FlexRay Network Management (AUTOSAR BSW module)
DEM	Diagnostic Event Manager (AUTOSAR BSW module)
DET	Development Error Tracer (AUTOSAR BSW module)
ComM	Communication Manager (AUTOSAR BSW module)
System Designer	The person responsible for the configuration of all system parameters that do not influence the <b>executable code</b> itself (i.e. the sequence of instructions executed during runtime), but the <b>data</b> used to <b>configure</b> <i>which operations</i> this executable code performs on <i>which data</i> and at <i>which points in time</i> .

Abbreviation:	Description:
i.e.	[lat.] id est = [eng.] that is
e.g.	[lat.] exempli gratia = [eng.] for example
N/A	not applicable

## 3 Related Documentation

### 3.1 Input Documents

- [1] List of Basic Software Modules  
AUTOSAR\_BasicSoftwareModules.pdf
- [2] AUTOSAR Layered Software Architecture  
AUTOSAR\_LayeredSoftwareArchitecture.pdf
- [3] AUTOSAR General Requirements on Basic Software Modules  
AUTOSAR\_SRS\_General.pdf
- [4] Specification of AUTOSAR COM  
AUTOSAR\_SWS\_COM.pdf
- [5] AUTOSAR Requirements on FlexRay  
AUTOSAR\_SRS\_FlexRay.pdf
- [6] Specification of FlexRay Driver  
AUTOSAR\_SWS\_FlexRay\_Driver.pdf
- [7] FlexRay State Manager  
AUTOSAR\_SWS\_FlexRayStateManager.pdf
- [8] Specification of FlexRay Transceiver Driver  
AUTOSAR\_SWS\_FlexRayTransceiver.pdf
- [9] Specification of FlexRay Transport Layer  
AUTOSAR\_SWS\_FlexRay\_TP.pdf
- [10] Specification of FlexRay Network Management  
AUTOSAR\_SWS\_FlexRay\_NM.pdf
- [11] Specification of PDU Router  
AUTOSAR\_SWS\_PDU\_Router.pdf
- [12] Specification of BSW Scheduler  
AUTOSAR\_SWS\_Scheduler.pdf
- [13] ECU Configuration Specification  
AUTOSAR\_SWS\_ECU\_StateManager.pdf
- [14] Specification of Memory Mapping  
AUTOSAR\_SWS\_MemoryMapping.pdf
- [15] AUTOSAR Basic Software Module Description Template,  
AUTOSAR\_BSW\_Module\_Description.pdf

### 3.2 Related Standards and Norms

- [16] FlexRay Communications System Protocol Specification Version 2.1  
Revision A
- [17] FlexRay Communications System Electrical Physical Layer Specification  
Version 2.1 Revision A

## 4 Constraints and Assumptions

### 4.1 Limitations

The FlexRay [BSW](#) modules are only able to handle a single thread of execution per Cluster. The execution for a particular Cluster must not be pre-empted by itself for the same Cluster. The same applies to the execution of the FlexRay Job List Execution Function.

It is not possible to transmit signals, PDUs, and/or L-SDUs, which exceed the available buffer size of the used FlexRay [CC](#) during normal operation. Longer signals, PDUs, and/or L-SDUs have to be transmitted using the FlexRay Transport Protocol.

**Note:**

The FlexRay Interface does not make any PDU payload-dependent routing decisions.

Frlf05008:

In order for the AUTOSAR FlexRay [BSW](#) ([Frlf](#) and FlexRay Driver) modules to be able to control a FlexRay [CC](#), this [CC](#) must allow for configuring its transmit/receive buffers to support the Cycle Counter Filter Criterion / (Support of Slot/Cycle Multiplexing)

$$\text{Cycle Number} = (\mathbf{B} + \mathbf{n} * 2^{\mathbf{R}})_{\text{mod}64}$$

with **exactly one tuple** of values for **B** and  $2^{\mathbf{R}}$ , where:

- Base Cycle **B**  $\in [0 \dots 63]$
- Cycle Repetition  $2^{\mathbf{R}}$ ;  $\mathbf{R} \in [0 \dots 6]$
- Variable **n** = 0 ... 63
- $\mathbf{B} < 2^{\mathbf{R}}$

### 4.2 Applicability to Car Domains

The FlexRay BSW Stack can be used wherever high data rates and fault tolerant communication (in conjunction with AUTOSAR [COM](#)) are required. Of course, it can also be used for less-demanding use cases, i.e. for low data rates or non-fault-tolerant communication. Furthermore, it enables the synchronized operation of several ECUs within a car.

## 5 Dependencies to Other Modules

Frlf05074:

### 5.1 AUTOSAR Operating System

Frlf05099:

There is one dedicated FlexRay Job List Execution Function for each FlexRay Cluster.

Frlf05100:

The FlexRay Interface executes the Flexray Job List Execution Function.

**Note:**

It is up to the implementer whether the FlexRay Job List Execution Functions runs in a task context or in an ISR.

### 5.2 AUTOSAR BSW Scheduler

Frlf05101:

There is one dedicated FlexRay Interface Main Function for each FlexRay Cluster

Frlf05102:

Each of these FlexRay Interface Main Functions must be called cyclically from a task body provided by the [BSW](#) Scheduler. The calling period must be configurable.

### 5.3 All Upper Layer AUTOSAR BSW Modules

Frlf05050:

The calling of the FlexRay Job List Execution Function synchronously to the FlexRay Global Time shall ensure that both the indication (to an upper layer [BSW](#) module) of received data and the request (to an upper layer [BSW](#) module) for data to be sent occur synchronously to the FlexRay Global Time.

Frlf05049:

If the respective upper layer [BSW](#) module does not operate synchronously to the FlexRay Global Time, these occurrences are asynchronous to the code execution of this [BSW](#) module. Therefore, this [BSW](#) module shall allow access to its PDU buffers at all times and it also has to ensure data consistency in its buffers.

### 5.4 AUTOSAR PDU-Router

The [Frlf](#) declares and calls some callback functions of the PDU-Router in order to confirm transmission and notify reception of PDUs.

## 5.5 AUTOSAR FlexRay Network Management

The [Frlf](#) declares and calls some callback functions of the FlexRay Network Management in order to confirm transmission and notify reception of PDUs.

## 5.6 AUTOSAR FlexRay Transport Protocol

The [Frlf](#) declares and calls some callback functions of the FlexRay Transport Protocol in order to confirm transmission and notify reception of PDUs.

## 5.7 AUTOSAR FlexRay Driver

The [Frlf](#) has a tight relation to the FlexRay Driver since many of the FlexRay-related services offered by the [Frlf](#) to upper layer [BSW](#) modules are actually carried out by the FlexRay Driver [BSW](#) module. For those services, the [Frlf](#) mainly performs only an abstraction of the communication hardware specific information (e.g. the topology of the FlexRay Communication System) and then calls the respective FlexRay Driver with the appropriate parameters.

Frlf05051:

The FlexRay Driver shall be the only BSW Modules which has to run necessarily synchronous to the FlexRay Interface.

## 5.8 AUTOSAR FlexRay Transceiver Driver

The [Frlf](#) has a tight relation to the FlexRay Transceiver Driver since calls of API services of the FlexRay Transceiver Driver are also routed through the [Frlf](#) in order to abstract the communication hardware specific information (e.g. the topology of the FlexRay Communication System).

## 5.9 AUTOSAR Development Error Tracer

Frlf05065:

In order to be able to report development errors, the [Frlf](#) has to have access to the error hook of the Development Error Tracer.

## 5.10 AUTOSAR Diagnostic Event Manager

Frlf05066:

In order to be able to report production errors, the [Frlf](#) has to have access to the Diagnostic Event Manager.

## 5.11 File Structure

### 5.11.1 Code File Structure

The code file structure shall not completely be defined within this specification.

Frlf05075:

However, the code-file structure shall include the following files:

Frlf.c	general source code file of the FlexRay Interface
Frlf_Cfg.c	contains pre-compile time configurable parameters
Frlf_Lcfg.c	contains <a href="#">link time</a> configurable parameters
Frlf_PBcfg.c	contains <a href="#">post build time</a> configurable parameters


### 5.11.2 Header File Structure

Frlf05076:

The header file structure shall contain the following header files:

Frlf.h	general header file of the FlexRay Interface
Frlf_Cfg.h	contains the Frlf pre-compile-time configurable parameters (pre processor constants)
Frlf_Cbk.h	contains the declarations of the callback functions provided by the <a href="#">Frlf</a> to other <a href="#">BSW</a> modules
Fr.h	contains the declarations of the API services of the FlexRay Driver used by the FlexRay Interface
FrTrcv.h	contains the declarations of the API services of the FlexRay Transceiver Driver used by the FlexRay Interface.
Fr_Types.h	contains declarations shared by all AUTOSAR FlexRay <a href="#">BSW</a> modules
ComStack_Types.h	contains the communication module abstracted datatypes shared by AUTOSAR communication BSW.
PduR_Frlf.h	contains the declarations of API services the PDU router offers to the FlexRay Interface
FrNm_Cbk.h	contains the declarations of API services the FrNm offers to the FlexRay Interface
FrTp_Cbk.h	contains the declarations of API services the FrTp offers to the FlexRay Interface
Dem.h	contains the declarations of the API services of the Dem used by the FlexRay Interface
Det.h	contains the declarations of the API services of the Det optionally used by the FlexRay Interface
SchM_Frlf.h	Contains the declaration of the API services the SchM offers to the FlexRay Interface
MemMap.h	





**Figure 5-1: FlexRay Interface Header File Structure**

Besides the FlexRay-specific header files, the FlexRay Interface shall include the file `Dem.h`. By this inclusion, the API services used to report errors as well as the required Event-Id symbols are included. The specification in hand defines the name of the Event-Id symbols, which are provided in XML format to the [DEM](#) configuration tool. The [DEM](#) configuration tool assigns ECU-dependent values to the Event-Id symbols and publishes the symbols in `Dem_IntErrId.h`.

**FrIf05081:**

All files related to the `FrIf` module shall follow the naming convention `FrIf[_<description>].<extension>`

**FrIf05091:**

The `FrIf` module shall include the `Dem.h` file. By this inclusion the APIs to report errors as well as the required Event Id symbols are included. This specification defines the name of the Event Id symbols, which are provided by XML to the DEM configuration tool. The DEM configuration tool assigns ECU dependent values to the Event Id symbols and publishes the symbols in `Dem_IntErrId.h`.

**FrIf05140:**

The implementation of the `FrIf` module shall provide the header file `FrIf.h`, which is the main module interface file. It shall contain all types and function prototypes required by the `FrIf` module's environment.

**FrIf05141:**

The implementation of the `FrIf` module shall provide the header file `FrIf_Cfg.h` that shall contain the pre-compile-time configuration parameters.



## 6 Requirements Traceability

### 6.1 General Requirements on Basic Software Modules

<b>Requirement</b>	<b>Satisfied by</b>
BSW00344 Reference to link-time configuration	FrIf05068
BSW00404 Reference to post build time configuration	FrIf05069
BSW00405 Reference to multiple configuration sets	FrIf05003
BSW00345 Pre-compile-time configuration	FrIf05069
BSW159 Tool-based configuration	FrIf05070
BSW167 Static configuration checking	FrIf05071, FrIf05072, FrIf05073
BSW171 Configurability of optional functionality	FrIf05089
BSW170 Data for reconfiguration of AUTOSAR SW-Components	FrIf05089
BSW00380 Separate C-Files for configuration parameters	FrIf05075
BSW00419 Separate C-Files for pre-compile time configuration parameters	FrIf05075
BSW00381 Separate configuration header file for pre-compile time parameters	FrIf05075
BSW00412 Separate H-File for configuration parameters	FrIf05076
BSW00383 List dependencies of configuration files	FrIf05075
BSW00384 List dependencies to other modules	FrIf05074
BSW00387 Specify the configuration class of callback function	n/a
BSW00388 Introduce containers	FrIf05077
BSW00389 Containers shall have names	Chapter 10.2
BSW00390 Parameter content shall be unique within the module	Chapter 10.2
BSW00391 Parameter shall have unique names	Chapter 10.2
BSW00392 Parameters shall have a type	Chapter 10.2
BSW00393 Parameters shall have a range	Chapter 10.2
BSW00394 Specify the scope of the parameters	Chapter 10.2
BSW00395 List the required parameters (per parameter)	Chapter 10.2
BSW00396 Configuration classes	Chapter 10.2
BSW00397 Pre-compile-time parameters	Chapter 10.2
BSW00398 Link-time parameters	Chapter 10.2
BSW00399 Loadable Post-build time parameters	Chapter 10.2
BSW00400 Selectable Post-build time parameters	Chapter 10.2
BSW00402 Published information	FrIf05086
BSW00375 Notification of wake-up reason	
BSW101 Initialization interface	FrIf05003
BSW00416 Sequence of Initialization	n/a
BSW00406 Check module initialization	FrIf05002
BSW168 Diagnostic Interface of SW components	n/a
BSW00407 Function to read out published parameters	FrIf05002
BSW00423 Usage of SW-C template to describe BSW modules with AUTOSAR Interfaces	
BSW00424 BSW main processing function task allocation	n/a
BSW00425 Trigger conditions for schedulable objects	
BSW00426 Exclusive areas in BSW modules	n/a
BSW00427 ISR description for BSW modules	n/a
BSW00428 Execution order dependencies of main processing functions	n/a
BSW00429 Restricted BSW OS functionality access	n/a
BSW00431 The BSW Scheduler module implements task bodies	n/a
BSW00432 Modules should have separate main processing functions for read/receive and write/transmit data path	n/a
BSW00433 Calling of main processing functions	
BSW00434 The Schedule Module shall provide an API for exclusive areas	n/a

BSW00336	Shutdown interface	FrIf05006
BSW00337	Classification of errors	FrIf05139
BSW00338	Detection and Reporting of development errors	Chapter 8.3
BSW00369	Do not return development error codes via API	Chapter 8.3
BSW00339	Reporting of production relevant error status	Chapter 8.3
BSW00417	Reporting of Error Events by Non-Basic Software	n/a
BSW00323	API parameter checking	Chapter 8.3
BSW004	Version check	FrIf05090
BSW00409	Header files for production code error IDs	FrIf05091
BSW00385	List possible error notifications	Chapter 8.3
BSW00386	Configuration for detecting an error	n/a
BSW161	Microcontroller abstraction	n/a
BSW162	ECU layout abstraction	n/a
BSW005	No hard coded horizontal interfaces within MCAL	n/a
BSW00415	User dependent include files	n/a
BSW164	Implementation of interrupt service routines	n/a
BSW00325	Runtime of interrupt service routines	n/a
BSW00326	Transition from ISRs to OS tasks	n/a
BSW00342	Usage of source code and object code	FrIf05078
BSW00343	Specification and configuration of time	FrIf05141
BSW160	Human-readable configuration data	FrIf05079
BSW007	HIS MISRA C	FrIf05080
BSW00300	Module naming convention	FrIf05081
BSW00413	Accessing instances of BSW modules	n/a
BSW00347	Naming separation of different instances of BSW drivers	n/a
BSW00305	Self-defined data types naming convention	FrIf05082
BSW00307	Global variables naming convention	FrIf05083
BSW00310	API naming convention	FrIf05083
BSW00373	Main processing function naming convention	n/a
BSW00327	Error values naming convention	FrIf05142
BSW00335	Status values naming convention	n/a
BSW00350	Development error detection keyword	FrIf05084
BSW00408	Configuration parameter naming convention	
BSW00410	Compiler switches shall have defined values	n/a
BSW00411	Get version info keyword	FrIf05002
BSW00346	Basic set of module files	FrIf05075
BSW158	Separation of configuration from implementation	FrIf05075
BSW00314	Separation of interrupt frames and service routines	n/a
BSW00370	Separation of callback interface from API	n/a
BSW00348	Standard type header	FrIf05001
BSW00353	Platform specific type header	FrIf05001
BSW00361	Compiler specific language extension header	FrIf05001
BSW00301	Limit imported information	Figure 5-1
BSW00302	Limit exported information	FrIf05141
BSW00328	Avoid duplication of code	n/a
BSW00312	Shared code shall be reentrant	n/a
BSW006	Platform independency	n/a
BSW00357	Standard API return type	Chapter 8.3
BSW00377	Module specific API return types	n/a
BSW00304	AUTOSAR integer data types	FrIf05001
BSW00355	Do not redefine AUTOSAR integer data types	FrIf05001
BSW00378	AUTOSAR boolean type	FrIf05001
BSW00306	Avoid direct use of compiler and platform specific keywords	n/a
BSW00308	Definition of global data	FrIf05143
BSW00309	Global data with read-only constraint	FrIf05068
BSW00371	Do not pass function pointers via API	n/a
BSW00358	Return type of init() functions	FrIf05003
BSW00414	Parameter of init function	FrIf05003

BSW00376	Return type and parameters of main processing functions	n/a
BSW00359	Return type of callback functions	Chapter 8.7.3
BSW00360	Parameters of callback functions	Chapter 8.7.3
BSW00329	Avoidance of generic interfaces	n/a
BSW00330	Usage of macros / inline functions instead of functions	n/a
BSW00331	Separation of error and status values	n/a
BSW009	Module User Documentation	n/a
BSW00401	Documentation of multiple instances of configuration parameters	
BSW172	Compatibility and documentation of scheduling strategy	n/a
BSW010	Memory resource documentation	n/a
BSW00333	Documentation of callback function context	n/a
BSW00374	Module vendor identification	FrIf 05086
BSW00379	Module identification	FrIf 05086
BSW003	Version identification	FrIf 05086
BSW00318	Format of module version numbers	FrIf 05086
BSW00321	Enumeration of module version numbers	FrIf 05086
BSW00341	Microcontroller compatibility documentation	n/a
BSW00334	Provision of XML file	FrIf05089
BSW00435	Header File Structure for the Basic Software Scheduler	FrIf05087
BSW00436	Module Header File Structure for the Memory Mapping	FrIf05088

## 6.2 Requirements on FlexRay

<b>Requirement</b>	<b>Satisfied by</b>
BSW05000 Support of Synchronous SW Modules	FrIf05050
BSW05001 Support of Asynchronous SW Modules	FrIf05049
BSW05002 FlexRay Interface and FlexRay Driver as Only Necessarily Synchronous SW Modules	FrIf05051
BSW05003 Support of Slot/Cycle Multiplexing	FrIf05008
BSW05169 Avoid Timer Interrupts during Start-up	8.3.2
BSW05055 Avoid Timer Interrupts during Shutdown	8.3.8, 8.3.9
BSW05004 PDU-Based Data API	FrIf05055
BSW05010 Unique PDU-ID	FrIf05052
BSW05126 PDU Update/Valid Information	FrIf05056
BSW05097 Number of FlexRay Drivers per FlexRay Interface	FrIf05057
BSW05007 Number of FlexRay CCs per Interface	FrIf05053
BSW05130 Transmit Request Queuing	FrIf05058
BSW05060 Scheduling of Copy Operation into/from FlexRay CC	FrIf05059
BSW05096 Assignment of Drivers to Controllers	FrIf05060
BSW05013 Initialize Local Memory Space	FrIf05003
BSW05031 Initialization of a FlexRay CC	FrIf05004
BSW05078 Initialization of a FlexRay Cluster	N/A (moved to FrSm)
BSW05034 Configuration Modifiable by a Flashing Process	
BSW05042 Switch Configuration in Normal Active Mode	FrIf05061
BSW05015 Start-up of a FlexRay CC	FrIf05005
BSW05101 Start-up of a FlexRay Cluster	N/A (moved to FrSm)
BSW05018 Sending of a Wake-Up Pattern	FrIf05011
BSW05158 Get FlexRay Transceiver Wake-up Reason	FrIf05036
BSW05159 Enable FlexRay Transceiver Wake-up Indication	FrIf05037
BSW05163 Cluster-wide Enable FlexRay Transceiver Wake-Up Indication	N/A (moved to FrSm)
BSW05160 Disable FlexRay Transceiver Wake-up	FrIf05038
BSW05164 Cluster-wide Disable FlexRay Transceiver Wake-up Indication	N/A (moved to FrSm)
BSW05161 Clear FlexRay Transceiver Wake-up Events	FrIf05039
BSW05165 Cluster-wide Clear FlexRay Transceiver Wake-up Events	N/A (moved to FrSm)
BSW05067 Set FlexRay Cluster Offline Mode	N/A
BSW05068 Set FlexRay Cluster Online Mode	N/A (moved to FrSm)
BSW05155 Set FlexRay Cpmtrpöoer Pmööme ;pde	FrIf05005

BSW05069	Get FlexRay Cluster Mode	N/A (moved to FrSm)
BSW05153	Get FlexRay Controller Mode	N/A (moved to FrSm)
BSW05022	Get FlexRay CC POC Status	Frlf05014
BSW05023	Get FlexRay CC Sync State	Frlf05012
BSW05035	MTS Sending	N/A (no use without BG)
BSW05038	Get MTS Reception Status	N/A (no use without BG)
BSW05039	Set FlexRay Transceiver Operation Mode	Frlf05034
BSW05162	Set Cluster-wide FlexRay Transceiver Operation Mode	N/A (moved to FrSm)
BSW05157	Get FlexRay Transceiver Operation Mode	Frlf05035
BSW05174	Interrupt Handling	
BSW05170	Receive PDU	Frlf05062
BSW05027	Transmit PDU	Frlf05063
BSW05016	Abortion of a FlexRay CC Communication	Frlf05007
BSW05113	Abortion of a FlexRay Cluster Communication	N/A (moved to FrSm)
BSW05063	Halt of a FlexRay CC Communication	Frlf05006
BSW05102	Halt of a FlexRay Cluster Communication	N/A (moved to FrSm)
BSW05102	Provide Error Information	Frlf05065, Frlf05066
BSW05006	Abstraction of FlexRay-Specific Features	
BSW05009	Local Memory Space Usage	
BSW05056	Configuration of the FlexRay Interface at System Configuration Time	Frlf05067, Frlf05054

## 6.3 Specification Items

The following Items shall be seen as implementation hints only!

### Functional Specification

Usage of abstract index	Frlf05103
Passing of translated index	Frlf05104
Abstraction of FlexRay Transceivers	Frlf05105
Usage of Controller and Channel Index	Frlf05106
Usage of zero-based index	Frlf05107
Usage of FR Cluster Index	Frlf05108
Configuration Data	Frlf05109
Usage of PDU index	Frlf05110
Support one of both or both FlexRay Channels	Frlf05111
Support of at least four FlexRay Clusters	Frlf05112
Support of at least one absolute timer per FlexRay CCs	Frlf05113
Support of at least one relative timer per FlexRay CC	Frlf05114

### FlexRay Interface State Machine

One State Machine per Cluster	Frlf05115
Frlf_State offline during initialization	Frlf05116
Frlf_State offline during initialization	Frlf05117

### FlexRay Interface Main Function

One Main Function for each FlexRay Cluster	Frlf05119
Main Function tasks	Frlf05120

### Data Communication via FlexRay

Packaging of multiple PDUs in one FR Frame	Frlf05121
Frame construction plan (layout)	Frlf05122
Frame construction plan (config)	Frlf05123
Transmission rule	Frlf05124
Update Information per PDU	Frlf05125
Location of Update Information	Frlf05126
Configuration of Update Information	Frlf05127
Indication in case of no update information	Frlf05128
Transmission with Immediate Buffer Access	Frlf05129
Ensure synchronous buffer access	Frlf05130
Sortation of Communication Job	Frlf05131
Communication Job properties	Frlf05132
Communication Job execution start time	Frlf05133
Actions specified by Communication Operation	Frlf05134
Communication Operation properties	Frlf05135
Job List Execution Function nameing	Frlf05136
Job List synchronously to global time	Frlf05137
Job List Execution Function actions	Frlf05138

## 7 Functional Specification

### 7.1 FlexRay BSW Stack

As part of the AUTOSAR Layered Software Architecture according to [2], the FlexRay [BSW](#) modules also form a layered software stack.

Figure 7-1 depicts the basic structure of this FlexRay [BSW](#) stack. The [Frlf](#) accesses several [CCs](#) using the FlexRay Driver layer, which can be made up of several FlexRay Drivers modules. The FlexRay Transceivers are not shown in this figure; however, the structure that applies to the FlexRay Drivers and the FlexRay [CCs](#) analogously applies to the FlexRay Transceiver Drivers and the FlexRay Transceivers.




Figure 7-1: Basic Structure of the FlexRay BSW Stack

### 7.2 Indexing Scheme

#### 7.2.1 Principle

Most of the [Frlf](#)'s API services used for accessing the numerous (hardware and software) resources<sup>1</sup> map to corresponding API services of the underlying FlexRay Driver(s), or FlexRay Transceiver Driver(s), respectively.

<sup>1</sup> E.g. timers, configuration data sets, etc.



In order to select those resources spread over the various entities<sup>2</sup> accessed via the [Frlf](#), the FlexRay-related AUTOSAR [BSW](#) modules use an indexing scheme that exemplarily described in

Figure 7-2 and Figure 7-3.

Frlf05052:

The [Frlf](#) achieves the abstraction (of the CCs and Drivers) by providing to the upper layer [BSW](#) modules an abstract, unique, zero-based consecutive index<sup>3</sup> for each sort of resource, independent of their type, location, and access method.


Frlf05103:

In general, the [Frlf](#) API service then uses the abstract index passed to it by the upper layer [BSW](#) module to retrieve:

1. **the function pointer to a corresponding lower layer BSW module's API service** from a static configuration data table containing function pointers to all API services of all lower layer [BSW](#) modules called by the [Frlf](#)<sup>4</sup>, and
2. **the translated index used in the call to the lower layer BSW module's API service** from a static configuration data table.

Frlf05104:

The [Frlf](#) then calls the corresponding lower layer [BSW](#) module's API service via the function pointer and passes the translated index in the API call.



<sup>2</sup> FlexRay Drivers, FlexRay Communication Controllers, FlexRay Transceiver Drivers, and FlexRay Transceivers


<sup>3</sup> Like ControllerIndex, ClusterIndex, ChannelIndex, etc.

<sup>4</sup> Since this table contains function pointers to the lower layer BSW modules' API services, it obviously has to be linked against the linked and located code of the lower layer BSW modules.

**Figure 7-2: CC Indexing Scheme of the FlexRay Interface**

Frlf05060:

In order to abstract for upper layer [BSW](#) modules the various CCs, which the [Frlf](#) controls via the FlexRay Drivers, the [Frlf](#) generates an abstract, unique, zero-based consecutive index `Frlf_CtrlIdx`, which maps to a tuple of FlexRay Driver API Service function pointer and CC index `Fr_CtrlIdx`.



**Figure 7-3: Flexray Transceiver Indexing Scheme of the FlexRay Interface**

Frlf05105:

In order to abstract for upper layer [BSW](#) modules the various FlexRay Transceivers, which the [Frlf](#) accesses via the FlexRay Transceiver Drivers, the [Frlf](#) takes advantage of the fact that each FlexRay Transceiver is unambiguously assigned to a specific Channel on a specific FlexRay [CC](#).

Frlf05106:

Therefore, the [Frlf](#) abstracts the various FlexRay Transceivers by a **combination** of the two indices `Frlf_CtrlIdx` (Controller Index) and `Frlf_ChnlIdx` (Channel Index) and maps this to a tuple of FlexRay Transceiver Driver API Service function pointer and FlexRay Transceiver index `FrTrcv_TrcvIdx`. (Transceiver Index)

Frlf05107:

Besides hardware and software resources, the [Frlf](#) also numbers the logical structure elements presented by FlexRay with an abstract, unique, zero-based consecutive index.

Frlf05108:

The FlexRay Clusters are numbered with the index `Frlf_ClstIdx` in order to provide Cluster-based API services

Frlf05109:

The static configuration data of the [Frlf](#) contains a data structure that specifies which FlexRay [CC](#) and which FlexRay Transceivers are connected to which Clusters, or in other words, that maps each value of `Frlf_ClstIdx` to (one, or in general) a set of values for `Frlf_CtrlIdx` and tuples of (`Frlf_CtrlIdx`, `Frlf_ChnlIdx`).

Frlf05110:

The [Frlf](#) numbers all PDUs to be transmitted with an abstract, unique, zero-based consecutive index `Frlf_TxPdul`.

**Note:**

This index is used in the [Frlf](#) API service `Frlf_Transmit()` and allows the [Frlf](#) to quickly identify (e.g. by a table look-up) the PDU that is passed to it by an upper layer [BSW](#) module, and to process it accordingly.

## 7.2.2 Supported Indexed Resources

Frlf05057:

The [Frlf](#) can be configured to support at least four (possibly different) **FlexRay Drivers** to access the FlexRay Communication Controllers.

**Frlf05053:**

The [Frlf](#) can be configured to support at least four (possibly different) **FlexRay CCs**.

Frlf05111:

The [Frlf](#) can be configured to support one of both or both **FlexRay Channels** as specified in [16].

Frlf05112:

The [Frlf](#) can be configured to support at least four **FlexRay Clusters**.

Frlf05113:

The [Frlf](#) can be configured to support at least one **absolute timer** per FlexRay [CCs](#).

Frlf05114:


The [Frlf](#) can be configured to support at least one **relative timer** per FlexRay [CCs](#).

## 7.3 FlexRay Interface State Machine

In order to allow to control the communication operations of the FlexRay system,

Frlf05115:

the [Frlf](#) implements a simple state machine (one per FlexRay cluster), called **FlexRay Interface State Machine**



**Figure 7-4: FlexRay Interface State Machine**

Figure 7-4 shows the states and transitions that are visible to the user of the [Frlf](#). The two different states (Frlf\_State) represent the communication capabilities of the Frlf.

State	Description
FRIF_STATE_OFFLINE	No communication services are executed (see chapter 7.6 for details).
FRIF_STATE_ONLINE	All communication services (reception, transmission, transmission confirmation) are executed (see chapter 7.6 for details).

Frlf05116:

During initialization of the Frlf by executing Frlf\_Init() (transition (1)) all CCs shall be offline (CC is brought to the POC-State 'Ready')

Frlf05117:

and the Frlf\_State for each cluster is initialized with state 'FRIF\_STATE\_OFFLINE'.

The transitions are requested by an API service which takes the Cluster to process on and the Transition name to invoke.

The following table describes the transition names that can be passed to Frlf\_SetState().

Transition Name	Transitions (see Figure 7-4)	Description
FRIF_GOTO_ONLINE	(2)	Transition resulting in Frlf_State FRIF_STATE_ONLINE

<b>Transition Name</b>	<b>Transitions (see Figure 7-4)</b>	<b>Description</b>
FRIF_GOTO_OFFLINE	(3)	Transition resulting in Frlf_State FRIF_STATE_OFFLINE

### 7.3.1 FlexRay Interface Main Function

Frlf05118:

The FlexRay Interface Main Function needs to be called cyclically from a task body provided by the [BSW](#) Scheduler with a calling period depending on the FlexRay Cycle length and configurable [at system configuration time](#).

Since the Cycle length of each Cluster is independent, and therefore the desired calling period of the FlexRay Interface Main Function might differ from Cluster to Cluster,

Frlf05119:

there shall be one dedicated FlexRay Interface Main Function for each FlexRay Cluster that is controlled by the FlexRay Interface.

The API names of the FlexRay Interface Main Functions therefore are:

- Frlf\_MainFunction\_0() for Cluster # 0 (Frlf\_ClstIdx = 0)
- Frlf\_MainFunction\_1() for Cluster # 1 (Frlf\_ClstIdx = 1)
- Frlf\_MainFunction\_2() for Cluster # 2 (Frlf\_ClstIdx = 2)
- Frlf\_MainFunction\_3() for Cluster # 3 (Frlf\_ClstIdx = 3)
- ... and so on, if more than 4 FlexRay Clusters are supported.

The Main Function monitors and controls the continuous execution of the FlexRay Job List Execution Function, including the (re)synchronization if a loss of the JobList's synchronization (see [JobListAsyncFlag](#)) or a miss of execution was detected.

This is done by the following steps:

Frlf05120:

The FlexRay Interface Main Function performs the following tasks at each invocation:

- Get the global time (Frlf\_GetGlobalTime())

- add some 'safety margin'
- search the FlexRay Job List for the subsequent job, i.e. that job with an invocation time greater than the current global time + safety margin. If the end of the Job List has been reached, wrap around to the beginning of the Job List.
- set the JobListPointer to that job and program the absolute timer with this job's invocation time (now the FlexRay Job List is synchronized again)
- clear the JobListAsyncFlag
- Enable the absolute timer interrupt

## 7.4 Implementation Requirements

Frlf05068:

Link-time and post-build-time configuration data shall be implemented as read-only data structures. Link-time configuration data shall be immediately referenced by the implementation, the start-address of post-build-time configuration data shall be passed during module initialization

Frlf05069:

The Frlf module shall support pre-compile time, link-time and post-build-time configuration.

Frlf05078:

The Frlf module shall implement the API functions specified by the Fr SWS as real C code functions and shall not implement the API functions as macros.

The rationale is to allow object code module integration.

Frlf05079:

The description of the configuration and initialization data itself is not part of this specification but very implementation specific. The generated configuration data should be "human-readable".

Frlf05080:

The Frlf module's implementation shall conform to the HIS subset of the MISRA C Standard.

Frlf05085:

In case development error detection is enabled for the Frlf module: the Frlf module shall check API parameters for validity and report detected errors to the DET.

Frlf05087:

The Frlf module source code file(s) shall include *SchM\_Frlf.h* if data consistency mechanisms of the BSW scheduler are required as described in [13].

Frlf05088:

The Frlf module header file shall include *MemMap.h* and apply the memory mapping abstraction mechanisms as specified by [15].

Frlf05090:

The header file *Frlf.h* shall contain a software and specification version number.

Frlf05092:

The Frlf shall support dynamic payload length for LPdus whose associated parameter *FrlfAllowDynamicLSduLength* is set to true.

Frlf05143:

None of the Frlf module's header files shall define global variables.

## 7.5 Configuration description

Frlf05089:

The Frlf module shall provide an XML file that contains the data which is required for the SW identification (it shall contain the vendor identification, module ID and software version information), configuration and integration process. This file should describe vendor specific configuration parameters as well as it should contain recommended configuration parameter values.



## 7.6 Data Communication via FlexRay

FlexRay in general is a deterministic time-driven communication system.

Frlf05067:

Each datum that should be transmitted or received has to be scheduled [at system configuration time](#). This even holds true for data that - from the application's point of view - are considered *event-driven*.

**Note:**

When looking only at specific instances of the AUTOSAR FlexRay software modules running on a specific ECU it is not possible to "anticipate" the **exact point in time** when a certain FlexRay frame is being sent (or received, respectively) in the Dynamic Segment of the FlexRay Cycle.

Frlf05054:

However, the resources (e.g. a buffer in the FlexRay Communication Controller or FlexRay Driver) needed for this data transmission (or reception, respectively) have to be defined [at system configuration time](#) specifically for this data transmission (or reception, respectively).

**Note:**

There is no true spontaneous event-driven data communication on FlexRay. Even application data that occur at unpredictable points in time (i.e. "event-driven"), and that should be transmitted via FlexRay, have to be scheduled for transmission [at system configuration time](#).

### 7.6.1 PDU Packing, PDU Update-Bits, and Frame Construction Plans

In accordance with basic AUTOSAR rules,

Frlf05055:

the API services that the [Frlf](#) provides to upper layer [BSW](#) modules for data transmission and data reception are PDU-based.

**Note:**

Since bus-independent AUTOSAR PDUs have a maximal length of 8 bytes, and since according to [16] a FlexRay Frame can contain as many as 254 bytes of payload data,

Frlf05121:

the [Frlf](#) shall be capable of packing multiple PDUs into one FlexRay Frame.

**Note:**

It is also allowed to define PDUs which are larger than 8 bytes. Please be aware that PDUs greater than 8 bytes are not bus independent any more!

Frlf05122:

The rules defining how to pack PDUs into FlexRay Frames, the so-called **Frame Construction Plans**, are defined [at system configuration time](#)

Frlf05123:

The Frame Construction Plan shall be stored in the static configuration of the [Frlf](#) (configuration parameter [FrlfFrameStructure](#)).

Frlf05124:

In cases where multiple PDUs are packed into a single FlexRay Frame, this FlexRay Frame has to be transmitted if at least one of the contained PDUs has been updated.

**Note:**

As a result, those PDUs in this FlexRay Frame that have not been updated by the upper layer BSW module will also be transmitted.

Frlf05056:

In order for the receiving [Frlf](#) to be able to determine which of the PDUs in a received FlexRay Frame have actually been updated by the upper layer BSW module (by a call of `Frlf_Transmit()`) on the transmitter side, additional update information, so called **PDU Update-Bits** within the FlexRay Frame, shall be transmitted to the receiving [Frlf](#).

Frlf05125:

For each PDU, a dedicated PDU Update-Bit in the FlexRay Frame can be configured (see configuration parameter [FrlfPduUpdateBitOffset](#)).

Frlf05126:

This PDU Update-Bit can be located at an arbitrary bit position in the Frame Construction Plan that is not occupied by any PDU.

Frlf05127:

The configuration of Update-Bits for the PDUs and the definition of the location of the Update-Bits within the FlexRay Frame are performed [at system configuration time](#) [Configuration Parameter [FrlfPduUpdateBitOffset](#)]

Frlf05128:

If no update bit is configured for a specific PDU, this PDU is always assumed to be valid and its reception is always indicated to the upper layer BSW module on the receiver side.

Frlf05129:

If Transmission with Immediate Buffer Access is used, only one PDU is allowed per FlexRay Frame (L-SDU).

**Note:**

Therefore, PDU Update-Bits can be omitted for Transmission with Immediate Buffer Access.

### 7.6.1.1 AlwaysTransmit

**Note:**

According to [16], a FlexRay [CC](#) might **only** support the so-called “continuous transmission mode” where a message is transmitted continuously until the host explicitly invalidates the transmit buffer. If such a FlexRay [CC](#) is being used for transmission, and the receiving [Frlf](#) should still be able to determine which of the PDUs in a received FlexRay Frame have actually been updated by an upper layer [BSW](#) module on the transmitter side, a special mechanism is needed in the transmitting [Frlf](#), called **AlwaysTransmit** (configuration parameter [FrlfAlwaysTransmit](#)). If [AlwaysTransmit](#) is enabled for an L-PDU that is transmitted using the Communication Operation [4], the FlexRay Driver’s API service `Fr_TransmitTxLPdu()` is always called for this L-PDU, independent from any PDUs in this L-PDU having been updated by an upper layer [BSW](#) module. This enables resetting the PDU Update-Bits in the FlexRay [CC](#)’s transmit buffer, even if none of the PDUs in the FlexRay Frame have actually been updated by an upper layer [BSW](#) module, and thus ensures the correct interpretation of the received Frame contents by the receiving [Frlf](#).

Since:

- in general, the transmit mode of a FlexRay [CC](#) can be configured (“continuous mode” / “single shot mode”), and
- [AlwaysTransmit](#) can be configured independently per L-PDU, and
- Update-Bits can be configured independently per PDU,

the [Frlf](#) can be tailored to exhibit exactly the behavior required by a certain use case. However, it is the responsibility of the [System Designer](#) to select the correct configuration of all these parameters. An incorrect configuration will lead to undesired results.

### 7.6.2 Realization of the Time-Driven FlexRay Schedule

According to [16], a FlexRay [CC](#) is **not** required to provide mechanisms in hardware to ensure asynchronous access to its transmit and receive buffers e.g. by providing shadow buffers that may be accessed asynchronously by the AUTOSAR FlexRay software modules.

Frlf05130:

Therefore, the calling of all functions accessing these buffers (i.e. performing data transmission or reception, respectively) must be synchronous (i.e. synchronized to the FlexRay Global Time) in order to ensure buffer access taking place only at well-defined points in time<sup>5</sup> and thus avoid concurrent access to the buffers by the hardware and the software.

**Note:**

In order to provide this necessary synchronicity, the [Frlf](#) defines for each Cluster a FlexRay Job List [Configuration Parameter [FrlfJobList](#)].

---

<sup>5</sup> In FlexRay Global Time

The Cluster's FlexRay Job List is executed by its Job List Execution Function (see 8.5.1) using an absolute timer [Configuration Parameter [FrlfAbsTimerRef](#)] of a FlexRay [CC](#) connected to the respective Cluster.

### 7.6.2.1 FlexRay Job List

Frlf05131:

A FlexRay Job List is a list of Communication Jobs sorted according to their respective execution start time.

Frlf05132:

Each Communication Job [Configuration Parameter [FrlfJob](#)] contains the following properties:

- Job start time by means of
  - FlexRay Communication Cycle [Configuration Parameter [FrlfCycle](#)]
  - Macrotick Offset within the Communication Cycle [Configuration Parameter [FrlfMacrotick](#)].
- A list of Communication Operations [Configuration Parameter [FrlfCommunicationOperation](#)] sorted according to a configurable Communication operation index [Configuration Parameter [FrlfCommunicationOperationIdx](#)]. The sorting order defines the order of execution of the Communication Operations within a FlexRay Communication Job.

Frlf05133:

The execution start time assigned to each Communication Job defines when the respective Cluster's FlexRay Job List Execution Function shall be called to execute this FlexRay Communication Job.

Frlf05134:

The Communication Operations specify the actions to process within the Communication Job.

Frlf05135:

Each Communication Operation contains the following properties:

- Communication Operation Index [Configuration Parameter [FrlfCommunicationOperationIdx](#)], which determines the execution order of the Communication Operations.
- Communication Action [Configuration Parameter [FrlfCommunicationAction](#)], which specifies the actual action to perform (see 7.6.3):
  - DECOUPLED\_TRANSMISSION
  - TX\_CONFIRMATION
  - RECEIVE\_AND\_STORE
  - RX\_INDICATION
  - RECEIVE\_AND\_INDICATE
  - PREPARE\_LPDU
- A reference to a frame triggering (L-PDU) which is associated with the Communication Action to perform [Configuration parameter [FrlfLPduIdx](#)]<sup>6</sup>.

Frlf05059:

### 7.6.2.2 FlexRay Job List Execution Function

Since the Communication Schedule of each FlexRay Cluster is independent, there is one dedicated FlexRay Job List and one dedicated FlexRay Job List Execution Function for each FlexRay Cluster that is controlled by the FlexRay Interface.

Frlf05136:

The API names of the FlexRay Job List Execution Functions therefore are:

- Frlf\_JobListExec\_0() for Cluster # 0 (Frlf\_ClstIdx = 0)
- Frlf\_JobListExec\_1() for Cluster # 1 (Frlf\_ClstIdx = 1)
- Frlf\_JobListExec\_2() for Cluster # 2 (Frlf\_ClstIdx = 2)
- Frlf\_JobListExec\_3() for Cluster # 3 (Frlf\_ClstIdx = 3)
- ... and so on, if more than 4 FlexRay Clusters are supported.

---

<sup>6</sup> The LPDU is identified by a LPdu Index, which has a 1:1 association to a frame triggering for historical reasons. To obtain compatibility this configuration structure is not changed here. The L-PDU index is identified with a zero-based and dense index, which shall be used as the parameter Fr\_LPduIdx passed to the AUTOSAR FlexRay Driver when processing LPdus.

Frlf05137:

The FlexRay Job List Execution Function executes the Cluster's FlexRay Job List Jobs synchronously to the Cluster's global time (i.e. at well-defined points in time).

Frlf05138:

Upon invocation, the FlexRay Job List Execution Function performs the following steps:

1. Retrieve the FlexRay Global Time from the FlexRay [CC](#) providing the Cluster's absolute timer interrupt.
2. If the FlexRay Global Time cannot be retrieved or the global time delay compared to the jobs start time is larger than a maximum delay [Configuration Parameter [FrlfMaxIsrDelay](#)], the execution of the FlexRay Job List is considered to be asynchronous to the FlexRay Global Time and thus the following actions are performed:
  - Set a flag (JobListAsyncFlag) indicating that the execution of the FlexRay Job List of this Cluster is asynchronous
  - Call Dem\_ReportErrorStatus(FRIF\_E\_JLE\_SYNC, DEM\_EVENT\_STATUS\_FAILED)
  - Disable absolute Timer Interrupt
  - Terminate the execution of this FlexRay Job.

Otherwise, the FlexRay Job List Execution Function continues with step 3.

3. Retrieve the sorted list of Communication Operations of the current Job pointed to by the current job-list-pointer.
4. Forward the current job-list pointer to the next job-list entry. If the job-list pointer was at the end of the job-list, wrap around and set it to the first job-list entry.
5. Retrieve the execution start time of the job marked by the job-list pointer and set the absolute timer to this job's start time in order to invoke the FlexRay Job List Execution Function again.
6. Execute the retrieved Communication Operations in the correct order.

**Note:**

In order to keep the runtime of the JLEF short, it is acceptable to implement the described functionality of the JLEF into a separate, high priority task which has to be activated immediately in the JLEF.

Frlf05093:

In case the parameter 'FrlfAllowDynamicLSduLength' is set to true for the associated frame triggering, the actual used L-PDU length shall be passed to the driver (Fr\_TransmitTxLPdu()) taking into account the following for each PDU:

- the position of the PDU within the L-PDU
- the actual PDU length passed via Frlf\_Transmit()

- the position of the update-bit information (if configured)

Frlf05094:

In case the parameter 'FrlfAllowDynamicLSduLength' is set to true for the associated frame triggering for reception, PDUs in non received areas (PDU offset > actual L-PDU length) shall not be indicated to upper layer(s).

### 7.6.3 Communication Operations

This chapter describes each Communication Operation that is executed within the Job List Execution Function.

Frlf05058:

#### 7.6.3.1 TransmitWithDecoupledBufferAccess

Frlf05063:

DECOUPLED\_TRANSMISSION is executed if the related CC is in Frlf\_State FRIF\_STATE\_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation DECOUPLED\_TRANSMISSION the following steps are performed:

1. Iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering of this Communication Operation and
2. Check whether [TrigTxCounter](#) is > 0 or FrlfNoneMode == true for the PDU. If not, clear the update-bit for this PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and proceed with the next PDU.
3. Call the upper layer's function <UL>\_TriggerTransmit() with the associated PDUId (Frlf\_TxPdulId) and pass a pointer to a temporary buffer within the Frlf that assembles the L-SDU. The pointer shall consider the byte offset [Configuration Parameter [FrlfPduOffset](#)] of the PDU within the frame.
4. Decrement [TrigTxCounter](#) only if TrigTxCounter > 0.
5. Remember that a transmission for this PDU is pending if a transmission confirmation is needed for this PDU [Configuration Parameter [FrlfConfirm](#)] (increment TxConfCounter<sup>7</sup>).
6. Set the update-bit if configured for this PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] only in case the API <UL>\_TriggerTransmit() returned E\_OK for the corresponding PDU.
7. If at least one PDU was requested for transmission, or the FlexRay Driver's API service Fr\_TransmitTxLPdu() shall always be called for this L-PDU [Configuration Parameter [FrlfAlwaysTransmit](#)] or FrlfNoneMode == true, the FlexRay Driver's API service Fr\_TransmitTxLPdu() is called:
  - a. Fr\_CtrlIdx is derived according to the indexing scheme described in 7.2
  - b. Fr\_LPdulIdx is set to the configured L-PDU index [Configuration Parameter [FrlfLPdulIdx](#)] associated with the Communication Operation
  - c. Fr\_LSduPtr is set to the temporary Frlf L-SDU assembling buffer.

<sup>7</sup> Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

- d. Fr\_LSduLength is set to the L-SDU length [Configuration Parameter [FrlfLSduLength](#)]
8. In case the Driver's API Fr\_TransmitTxLPdu() returned E\_NOT\_OK (indicating that the transmission failed) **changes** on [TrigTxCounter](#) and [TxConfCounter](#) must be rolled back (see 4. and 5.) for each PDU contained in the FlexRay L-SDU.

All previously described actions are depicted in detail in the sequence chart in chapter 9.1.2.

### 7.6.3.2 ProvideTxConfirmation

Frlf05064:

TX\_CONFIRMATION is executed if the related CC is in Frlf\_State FRIF\_STATE\_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation TX\_CONFIRMATION the following steps are performed:

1. Call the FlexRay Driver's API function Fr\_CheckTxLPduStatus():
  - a. Fr\_CtrlIdx is derived according to the indexing scheme described in 7.2
  - b. Fr\_LPduldx is set to the configured L-PDU buffer index [Configuration Parameter [FrlfLPduldx](#)] associated with the Communication Operation.
2. If the transmission was performed (Output parameter \*Fr\_TxLPduStatusPtr is successfully set to FR\_TRANSMITTED) then iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering. If [TxConfCounter](#) for a PDU is 0 proceed with the next PDU, otherwise
  - a. Call the upper layer's function <UL>\_TxConfirmation() with the associated PDUId (Frlf\_TxPdulid).
  - b. Decrement [TxConfCounter](#).

### 7.6.3.3 ReceiveAndStore

RECEIVE\_AND\_STORE is executed if the related CC is in Frlf\_State FRIF\_STATE\_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RECEIVE\_AND\_STORE the following steps are performed:

1. Call the FlexRay Driver's API function Fr\_ReceiveRxLPdu():
  - a. Fr\_CtrlIdx is derived according to the indexing scheme described in 7.2
  - b. Fr\_LPduldx is set to the configured L-PDU index [Configuration Parameter [FrlfLPduldx](#)] associated with the Communication Operation.
  - c. Fr\_LSduPtr is set to a temporary buffer.



2. If a L-PDU was received (Output parameter \*Fr\_LPduStatusPtr is set to FR\_RECEIVED) iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering and:
  - a. If an update bit was configured for the PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and the update bit for the PDU is not set, continue with the next PDU. Otherwise,
  - b. Copy the PDU Payload from the temporary buffer considering the PDU offset within the L-SDU [Configuration Parameter [FrlfPduOffset](#)] into a Frlf PDU-related static buffer.
  - c. Mark the PDU-related static buffer as up-to-date.

#### 7.6.3.4 ProvideRxIndication

Frlf05062:

RX\_INDICATION is executed if the related CC is in Frlf\_State FRIF\_STATE\_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RX\_INDICATION the following steps are performed:

1. Iterate over all PDU-related static buffers of PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering
2. If the PDU-related static buffer is marked as outdated, continue with the next PDU. Otherwise if the buffer is marked up-to-date,
  - a. Call the upper layer's function <UL>\_RxIndication() with the PDU Id the receiving module expects and a pointer to the PDU-related static buffer as parameters.
  - b. Mark the PDU-related static buffer as outdated.

#### 7.6.3.5 ReceiveAndIndicate

RECEIVE\_AND\_INDICATE is executed if the related CC is in Frlf\_State FRIF\_STATE\_ONLINE. Otherwise, this Communication Operation is ignored.

For Communication Operation RECEIVE\_AND\_INDICATE the following steps are performed:

1. Call the FlexRay Driver's API function Fr\_ReceiveRxLPdu():
  - a. Fr\_CtrlIdx is derived according to the indexing scheme described in 7.2
  - b. Fr\_LPduIdx is set to the configured L-PDU index [Configuration Parameter [FrlfLPduIdx](#)] associated with the Communication Operation.
  - c. Fr\_LSduPtr is set to a temporary buffer.
2. If an L-PDU was received (Output parameter \*Fr\_LPduStatusPtr is set to FR\_RECEIVED) iterate over all PDUs contained in the [FrlfFrameStructure](#) of the associated frame triggering and:
  - a. If an update bit was configured for the PDU [Configuration Parameter [FrlfPduUpdateBitOffset](#)] and the update bit for the PDU is not set, continue with the next PDU. Otherwise,

- c. Call the upper layer's function <UL>\_RxIndication() with the PDU Id the receiving module expects and a pointer to the temporary buffer considering the PDU offset within the L-SDU [Configuration Parameter [FrlfPduOffset](#)] as parameters.

### 7.6.3.6 PREPARE\_LPDU

Frlf05061:

PREPARE\_LPDU is executed in every Frlf\_State.

For Communication Operation PREPARE\_LPDU the following steps are performed:

1. Call the FlexRay Driver's API function Fr\_PrepareLPdu():
  - a. Fr\_CtrlIdx is derived according to the indexing scheme described in 7.2
  - b. Fr\_LPduldx is set to the configured L-PDU index [Configuration Parameter [FrlfLPduldx](#)] associated with the Communication Operation.

The Communication Operation PREPARE\_LPDU enables hardware optimization purposes. Its purpose is to enable certain FlexRay CC hardware resources (e.g. a CC's message buffer) to be prepared (configured) for the transmission/reception of a certain L-PDU.

This Communication Operation enables the FlexRay Driver to optimize the usage of hardware resources if available at appropriate point of times. However, it is the responsibility of the FlexRay Driver to decide and validate resource allocation optimizations based on the PREPARE\_LPDU Communication Operations. Practically the usage of this Communication Operation will introduce some runtime-overhead even if the FlexRay Driver does not use the opportunity for reconfiguration.

### 7.6.4 Transmission with Immediate Buffer Access

The FlexRay Job List Execution Function does not initiate transmission with immediate buffer access. Instead, the actions described here are carried out in the context of the Frlf\_Transmit() API service, which in turn is called by an upper layer [BSW](#) module.

For PDUs transmitted with immediate buffer access, the following restriction regarding static configuration apply:

- The PDU must be **the only** PDU in a FlexRay Frame (L-SDU). It is **not** packed into a FlexRay Frame together with other PDUs (i.e., the mapping between this PDU and the respective L-SDU is a 1:1 association).
- The PDU must be located **at the beginning** of the L-SDU.
- There is no update-bit for immediate PDUs configured.

If an immediate PDU transmission is indicated by calling `Frlf_Transmit()` with `Frlf_TxPduId` being configured for an immediate PDU, the following steps are performed within the context of the `Frlf_Transmit()` API service:

1. Call the FlexRay Driver's API function `Fr_TransmitTxLPdu()`:
  - a. `Fr_CtrlIdx` is derived according to the indexing scheme described in 7.2
  - b. `Fr_LPduIdx` is set to the configured L-PDU index [Configuration Parameter [FrlfLPduIdx](#)] associated with the `Frlf_TxPduId`.
  - c. `Fr_LSduPtr` is set to the Pdu Payload pointer contained in the `PduInfoPtr` passed as parameter to `Frlf_Transmit`.
  - d. `Fr_LSduLength` is set to the L-SDU length [Configuration Parameter [FrlfLSduLength](#)]
2. In case the Driver's API `Fr_TransmitTxLPdu()` returned `E_OK` (indicating that the transmission request succeeded) the [TxConfCounter](#) is incremented<sup>8</sup> for the respective PDU.

## 7.7 Error Classification

Frlf05139:

Values for production code Event Ids are assigned externally by the configuration of the [DEM](#). They are published in the file `Dem_IntErrId.h` and included via `Dem.h`.

Frlf05142:

The error values and EventIds are named in capital letters according to the scheme `FRIF_E_<NAME>`, where `NAME` describes the error/EventId and may consist of several words separated by underscores.

Development error values are of type `uint8`.

<b>Type or error</b>	<b>Relevance</b>	<b>Related error code</b>	<b>Value [hex]</b>
Invalid pointer	Development	<code>FRIF_E_INV_POINTER</code>	0x01
Invalid Controller index	Development	<code>FRIF_E_INV_CTRL_IDX</code>	0x02
Invalid Cluster index	Development	<code>FRIF_E_INV_CLST_IDX</code>	0x03
Invalid Channel index	Development	<code>FRIF_E_INV_CHNL_IDX</code>	0x04
Invalid timer index	Development	<code>FRIF_E_INV_TIMER_IDX</code>	0x05
Invalid <code>Frlf_TxPdu</code> Index	Development	<code>FRIF_E_INV_TXPDUID</code>	0x06
<code>Frlf</code> not initialized	Development	<code>FRIF_E_NOT_INITIALIZED</code>	0x08
Invalid Controller State	Development	<code>FRIF_E_INV_FRIF_CC_STATE</code>	0x09
Job List Execution lost synchronization to the FlexRay Global Time	Production	<code>FRIF_E_JLE_SYNC</code>	Assigned by <a href="#">DEM</a>

**Table 7-1: Definition of Error Codes**

<sup>8</sup> Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

## 7.8 Error Detection

Frlf05084:

The detection of development errors is configurable (ON / OFF) at pre-compile time. The switch [FRIF\\_DEV\\_ERROR\\_DETECT](#) shall activate or deactivate the detection of all development errors.

If the [FRIF\\_DEV\\_ERROR\\_DETECT](#) switch is set to ON, API parameter checking is enabled. The detailed description of the detected errors can be found in chapter 7.7 and chapter 8.

If the [FRIF\\_DEV\\_ERROR\\_DETECT](#) switch is set to ON, all [Frlf](#) API services other than [Frlf\\_Init\(\)](#) and [Frlf\\_GetVersionInfo\(\)](#) shall:

- not execute their normal operation,
- report to the DET module (using [FRIF\\_E\\_NOT\\_INITIALIZED](#)),
- and return [E\\_NOT\\_OK](#),

unless the [Frlf](#) has been initialized with a preceding call of [Frlf\\_Init\(\)](#).

## 7.9 Error Notification

Detected development errors shall be reported to the [Det\\_ReportError\(\)](#) API service of the [DET](#) if the pre-processor switch [FRIF\\_DEV\\_ERROR\\_DETECT](#) is set to ON.

Production errors shall be reported to the [DEM](#).

## 8 API Service Specification

Frlf05083:

All AP functions or global variables, whether they are specified or not shall follow the naming scheme `FrIf_<name>`, where the first letter of each word in `<name>` is written uppercase and the remainder of the word lowercase.

### 8.1 Imported types

In this chapter all types included from the following files are listed:

**Frlf05001:**

<b>Header file</b>	<b>Imported Type</b>
Dem_Types.h	Dem_EventIdType
PrimitiveTypes.h	PduInfoType
FrTrcv_Types.h	FrTrcv_TrvcModeType
	FrTrcv_TrvcWUReasonType
Fr_Types.h	Fr_POCTestStatusType
	Fr_ChannelType
	Fr_RateCorrectionType
	Fr_OffsetCorrectionType
	Fr_SyncStateType
ComStack_Types.h	PduIdType
	BusTrcvErrorType
Std_Types.h	Std_ReturnType
	Std_VersionInfoType

### 8.2 Type Definitions

This chapter lists the data types that the FlexRay Interface defines.

Frlf05082:

All types whether they are specified or implementation dependant shall follow the naming scheme `FrIf_<name>Type`, where the first letter of each word in `<name>` is written uppercase and the remainder of the word is written lowercase.

#### 8.2.1 Frlf\_ConfigType

<b>Name:</b>	FrIf_ConfigType
<b>Type:</b>	Structure
<b>Range:</b>	Implementation specific
<b>Description:</b>	This type contains the implementation-specific post build time configuration structure. Only pointers of this type are allowed.

### 8.2.2 FrIf\_StateType

<b>Name:</b>	FrIf_StateType	
<b>Type:</b>	Enumeration	
<b>Range:</b>	FRIF_STATE_OFFLINE	The FlexRay CC is not ready for communication, the FlexRay cluster is not synchronized.
	FRIF_STATE_ONLINE	The FlexRay CC is ready for communication, the FlexRay cluster is synchronized.
<b>Description:</b>	Variables of this type are used to represent the FrIf_State of a FlexRay CC.	

### 8.2.3 FrIf\_StateTransitionType

<b>Name:</b>	FrIf_StateTransitionType	
<b>Type:</b>	Enumeration	
<b>Range:</b>	FRIF_GOTO_OFFLINE	Literal for requesting transition into FRIF_STATE_OFFLINE
	FRIF_GOTO_ONLINE	Literal for requesting transition into FRIF_STATE_ONLINE state.
<b>Description:</b>	Variables of this type are used to represent the FrIf_State of a FlexRay CC.	

## 8.3 Function Definitions

This is a list of API services (functions) the [FrIf](#) provides to upper layer [BSW](#) modules.

### 8.3.1 Frlf\_GetVersionInfo

Frlf05002:

<b>Service name:</b>	Frlf_GetVersionInfo
<b>Syntax:</b>	void FrIf_GetVersionInfo( Std_VersionInfoType* FrIf_VersionInfoPtr )
<b>Service ID[hex]:</b>	0x01
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non Reentrant
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	Frlf_VersionInfoPtr Pointer to a memory location where the FlexRay Interface version information shall be stored.
<b>Return value:</b>	None
<b>Description:</b>	Returns the version information of this module.

Parameter Frlf\_VersionInfoPtr: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_POINTER) if Frlf\_VersionInfoPtr equals NULL\_PTR.

This API service of the FlexRay Interface returns the version information of the FlexRay Interface. The version number consists of three parts:

- Two bytes for the vendor ID
- One byte for the module ID
- Three bytes version number.  
The numbering shall be vendor specific; it shall consist of:
  - the major version number of the module,
  - the minor version number of the module,
  - and the patch version number of the module
- The AUTOSAR specification version number shall not be included.

This API service shall be pre compile time configurable ON/OFF by the configuration parameter FRIF\_VERSION\_INFO\_API (derived from configuration parameter [FrlfVersionInfoApi](#)).

#### Hint:

If source code for caller and callee of this API service is available, this function should be realized as a macro. The macro should be defined in the file Frlf\_Cfg.h.

#### Configuration:

If pre-compile-time configuration parameter 'FRIF\_VERSION\_INFO\_API' is 'ON' this API function is included in the compilation process.

If pre-compile-time configuration parameter 'FRIF\_VERSION\_INFO\_API' is 'OFF' this API function is excluded from the compilation process.

### 8.3.2 FrIf\_Init

FrIf05003:

<b>Service name:</b>	FrIf_Init
<b>Syntax:</b>	void FrIf_Init( const FrIf_ConfigType* FrIf_ConfigPtr )
<b>Service ID[hex]:</b>	0x02
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non Reentrant
<b>Parameters (in):</b>	FrIf_ConfigPtr Base pointer to the configuration structure of the FlexRay Interface.
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	Initializes the FlexRay Interface.

Parameter FrIf\_ConfigPtr: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_POINTER) if FrIf\_ConfigPtr equals NULL\_PTR.

This API service of the FlexRay Interface is used to initialize the FlexRay Interface

This initialization is carried out by the following actions:

- Configure the FlexRay Interface: initialize the local memory space used to store the PDU data and the PDU properties and state variables and the FlexRay Interface State Machine.

The AUTOSAR ECU StateManager calls this FlexRay Interface API service with the address of the static configuration structure of the [FrIf](#) in parameter FrIf\_ConfigPtr.

Caveats: Since during the execution of this API service, several hardware devices are accessed, the initialization order of [BSW](#) modules needs to ensure that those hardware devices can physically be accessed (e.g. the DIO Driver needs to be available, if applicable).



### 8.3.3 FrIf\_ControllerInit

FrIf05004:

<b>Service name:</b>	FrIf_ControllerInit	
<b>Syntax:</b>	Std_ReturnType FrIf_ControllerInit( uint8 FrIf_CtrlIdx )	
<b>Service ID[hex]:</b>	0x03	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Initialized a FlexRay CC.	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_ControllerInit() by:

Translating (based on static [FrIf](#) configuration) the FlexRay [CC](#) index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific [CC](#) index Fr\_CtrlIdx).

Setting parameters Fr\_LowLevelConfSetIdx and Fr\_BufConfSetIdx to 0.

Calling Fr\_ControllerInit() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.4 FrIf\_StartCommunication

FrIf05005:

<b>Service name:</b>	FrIf_StartCommunication	
<b>Syntax:</b>	Std_ReturnType FrIf_StartCommunication( uint8 FrIf_CtrlIdx )	
<b>Service ID[hex]:</b>	0x07	
<b>Sync/Async:</b>	Asynchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.

<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_StartCommunication().

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_StartCommunication() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

Calling Fr\_StartCommunication() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [FrIf05389](#).

### 8.3.5 FrIf\_HaltCommunication

FrIf05006:

<b>Service name:</b>	FrIf_HaltCommunication
<b>Syntax:</b>	Std_ReturnType FrIf_HaltCommunication( uint8 FrIf_CtrlIdx )
<b>Service ID[hex]:</b>	0x09
<b>Sync/Async:</b>	Asynchronous
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx
<b>Parameters (in):</b>	FrIf_CtrlIdx      Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	Std_ReturnType E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_HaltCommunication().

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_HaltCommunication()` by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

Calling `Fr_HaltCommunication()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.6 Frlf\_AbortCommunication

Frlf05007:

<b>Service name:</b>	Frlf_AbortCommunication	
<b>Syntax:</b>	Std_ReturnType Frlf_AbortCommunication( uint8 Frlf_CtrlIdx )	
<b>Service ID[hex]:</b>	0x0b	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of <code>Frlf_CtrlIdx</code> , reentrant for different values of <code>Frlf_CtrlIdx</code>	
<b>Parameters (in):</b>	<code>Frlf_CtrlIdx</code>	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_AbortCommunication()</code> .	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_AbortCommunication()` by:

1. Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

Calling `Fr_AbortCommunication()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.7 FrIf\_GetState

<b>Service name:</b>	FrIf_GetState	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetState (     uint8          FrIf_ClstIdx,     FrIf_StateType *FrIf_StatePtr )</pre>	
<b>Service ID[hex]:</b>	0x35	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	FrIf_ClstIdx	Index of the cluster addressed.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	FrIf_StatePtr	Pointer to a memory location where the retrieved FrIf_State will be stored.
<b>Return value:</b>	Std_ReturnType	E_OK: Function was successfully executed. State transition request was accepted. E_NOT_OK: Function execution failed due to detected errors. State transition request was not accepted.
<b>Description:</b>	Get current FrIf state.	

Parameter FrIf\_ClstIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CLST\_IDX) if FrIf\_CtrlIdx has an invalid value.

Parameter FrIf\_StatePtr: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_POINTER) if FrIf\_StatePtr equals NULL\_PTR.

This API service of the FlexRay Interface retrieves the FrIf\_State of the FlexRay Cluster with index FrIf\_ClstIdx.

2. Return the current state of the FrIf State Machine:
  - a. FRIF\_STATE\_ONLINE
  - b. FRIF\_STATE\_OFFLINE

The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.8 FrIf\_SetState

<b>Service name:</b>	FrIf_SetState	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_SetState(     FrIf_StateTransitionType FrIf_StateTransition,     uint8 FrIf_ClstIdx )</pre>	
<b>Service ID[hex]:</b>	0x35	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Non Reentrant	

<b>Parameters (in):</b>	FrIf_StateTransition	Requested FrIf state transition.
	FrIf_ClstIdx	Index of the cluster addressed.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: Function was successfully executed. State transition request was accepted. E_NOT_OK: Function execution failed due to detected errors. State transition request was not accepted.
<b>Description:</b>	Requests FrIf state machine transition.	

Parameter FrIf\_StateTransition: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_FRIF\_CC\_STATE) if FrIf\_StateTransition has an invalid value.

Parameter FrIf\_ClstIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface requests for FlexRay Cluster with index FrIf\_ClstIdx the FrIf\_State reached by the state transition according to FrIf\_StateTransition.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.9 FrIf\_SetWakeupChannel

FrIf05010:

<b>Service name:</b>	FrIf_SetWakeupChannel	
<b>Syntax:</b>	Std_ReturnType FrIf_SetWakeupChannel( uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx )	
<b>Service ID[hex]:</b>	0x11	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_SetWakeupChannel().	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_SetWakeupChannel()` by:

Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

### 3. Setting parameters

- `Fr_ChnIdx` to `FrIf_ChnIdx`

### 4. Calling `Fr_SetWakeupChannel()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

## 8.3.10 `FrIf_SendWUP`

FrIf05011:

<b>Service name:</b>	<code>FrIf_SendWUP</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_SendWUP(     uint8 FrIf_CtrlIdx )</pre>	
<b>Service ID[hex]:</b>	0x12	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of <code>FrIf_CtrlIdx</code> , reentrant for different values of <code>FrIf_CtrlIdx</code>	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	<p><code>E_OK</code>: The call of the FlexRay Driver's API service has returned <code>E_OK</code>.</p> <p><code>E_NOT_OK</code>: The call of the FlexRay Driver's API service has returned <code>E_NOT_OK</code>, or an error has been detected in development mode.</p>
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_SendWUP()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_SendWUP()` by:

Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

### 5. Calling `Fr_SendWUP()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.11 Frlf\_GetSyncState

Frlf05012:

<b>Service name:</b>	Frlf_GetSyncState	
<b>Syntax:</b>	<pre>Std_ReturnType Frlf_GetSyncState(     uint8 Frlf_CtrlIdx,     Fr_SyncStateType* Frlf_SyncStatePtr )</pre>	
<b>Service ID[hex]:</b>	0x16	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of <code>Frlf_CtrlIdx</code> , reentrant for different values of <code>Frlf_CtrlIdx</code>	
<b>Parameters (in):</b>	<code>Frlf_CtrlIdx</code>	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	<code>Frlf_SyncStatePtr</code>	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_GetSyncState()</code>	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

Parameter `Frlf_SyncStatePtr`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_POINTER`) if `Frlf_SyncStatePtr` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_GetSyncState()` by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

#### 6. Setting parameters

- `Fr_SyncStatePtr` to `Frlf_SyncStatePtr`

#### 7. Calling `Fr_GetSyncState()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.12 FrIf\_SetExtSync

FrIf05013:

<b>Service name:</b>	FrIf_SetExtSync	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_SetExtSync(     uint8 FrIf_CtrlIdx,     Fr_OffsetCorrectionType FrIf_Offset,     Fr_RateCorrectionType FrIf_Rate )</pre>	
<b>Service ID[hex]:</b>	0x17	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_Offset	Offset correction that shall be applied
	FrIf_Rate	Rate correction that shall be applied
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_SetExtSync().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_SetExtSync() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

#### 8. Setting parameters

- Fr\_Rate to FrIf\_Rate
- Fr\_Offset to FrIf\_Offset
- Calling Fr\_SetExtSync() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).



### 8.3.13 FrIf\_GetPOCStatus

FrIf05014:

<b>Service name:</b>	FrIf_GetPOCStatus	
<b>Syntax:</b>	Std_ReturnType FrIf_GetPOCStatus( uint8 FrIf_CtrlIdx, Fr_POCStatusType* FrIf_POCStatusPtr )	
<b>Service ID[hex]:</b>	0x19	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	FrIf_POCStatusPtr	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_GetPOCStatus().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

Parameter FrIf\_POCStatusPtr: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_POINTER) if FrIf\_POCStatusPtr has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_GetPOCStatus() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

#### 9. Setting parameters

- Fr\_POCStatusPtr to FrIf\_POCStatusPtr

10. Calling Fr\_GetPOCStatus() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [[FrIf05389](#)].

### 8.3.14 FrIf\_GetGlobalTime

FrIf05015:

<b>Service name:</b>	FrIf_GetGlobalTime
----------------------	--------------------

<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetGlobalTime(     uint8 FrIf_CtrlIdx,     uint8* FrIf_CyclePtr,     uint16* FrIf_MacroTickPtr )</pre>	
<b>Service ID[hex]:</b>	0x1a	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	FrIf_CyclePtr	Pointer to a memory location where output value will be stored.
	FrIf_MacroTickPtr	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_GetGlobalTime().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_GetGlobalTime() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

#### 11. Setting parameters

- Fr\_CylcePtr to FrIf\_CyclePtr
- Fr\_MacroTickPtr to FrIf\_MacroTickPtr

**12. Calling Fr\_GetGlobalTime()** of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.15 FrIf\_AllowColdstart

FrIf05017:

<b>Service name:</b>	FrIf_AllowColdstart	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_AllowColdstart(     uint8 FrIf_CtrlIdx )</pre>	
<b>Service ID[hex]:</b>	0x35	
<b>Sync/Async:</b>	Asynchronous	

<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_AllowColdstart().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_AllowColdstart() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

13. Calling Fr\_\_AllowColdstart() of the determined FlexRay Driver

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.16 FrIf\_GetMacroticksDuration

FrIf0501x:

<b>Service name:</b>	FrIf_GetMacroticksDuration	
<b>Syntax:</b>	uint16 FrIf_GetMacroticksDuration( uint8 FrIf_CtrlIdx )	
<b>Service ID[hex]:</b>	0x1b	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	uint16	Number of nanoseconds of one Macrotick
<b>Description:</b>	Retrieves the duration of one Macrotick in nanoseconds	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface retrieves the number of Macroticks per FlexRay Cycle of the FlexRay Cluster with index FrIf\_CtrlIdx out of the static configuration.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [[FrIf05389](#)].

### 8.3.17 FrIf\_Transmit

#### FrIf05033:

<b>Service name:</b>	FrIf_Transmit	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_Transmit(     PduIdType FrIf_TxPduId,     const PduInfoType * FrIf_PduInfoPtr )</pre>	
<b>Service ID[hex]:</b>	0x06	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of <code>FrIf_TxPduId</code> , reentrant for different values of <code>FrIf_TxPduId</code>	
<b>Parameters (in):</b>	<code>FrIf_TxPduId</code>	ID of FlexRay PDU to be transmitted.
	<code>FrIf_PduInfoPtr</code>	Pointer to a structure with FlexRay PDU related data.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	<p><code>E_OK</code>: No error has occurred during the execution of this API service.</p> <p><code>E_NOT_OK</code>: An error occurred during execution of this API service:</p> <ul style="list-style-type: none"> <li>• FlexRay Driver reported an error in case of immediate transmission</li> <li>• An error has been detected in development mode</li> </ul>
<b>Description:</b>	Requests the sending of a PDU.	

Parameter `FrIf_TxPduId`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_TXPDUID`) if `FrIf_TxPduId` has an invalid value.

Parameter `FrIf_PduInfoPtr`:

`FRIF_E_INV_POINTER` shall be reported to DET in case `FrIf_PduInfoPtr` equals `NULL_PTR`

If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_POINTER`) if `SduDataPtr` in `FrIf_PduInfoPtr` equals `NULL_PTR`.

This API service of the FlexRay Interface allows upper layer [BSW](#) modules to request the sending of a PDU via the FlexRay Communication System.

In case of decoupled transmission the PDU with index `FrIf_TxPduld` is **not yet** passed to the underlying FlexRay Driver for transmission. `FrIf` only remembers the PDU's transmission request (increment `TrigTxCounter`<sup>9</sup>). This decoupling mechanism between the call of `FrIf_Transmit()` and the execution of the [FrlfCommunicationAction](#) has some implications:

- The upper layer BSW module may operate asynchronously to the FlexRay Communication System and thus may call `FrIf_Transmit()` at any point in time.
- The upper layer [BSW](#) module must permanently buffer the PDU's payload data and must be able to handle a call of its `<UL_TriggerTransmit>()` API service at (from the [BSW](#)'s point of view) any arbitrary point in time.

In case of immediate transmission the PDU (single PDU, no Update bit) is passed to the underlying FlexRay Driver immediately for transmission.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.18 Frlf\_SetTransceiverMode

Frlf05034:

<b>Service name:</b>	Frlf_SetTransceiverMode	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_SetTransceiverMode(     uint8 FrIf_CtrlIdx,     Fr_ChannelType FrIf_ChnlIdx,     FrTrcv_TrcevModeType FrIf_TrcevMode )</pre>	
<b>Service ID[hex]:</b>	0x28	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>FrIf_CtrlIdx</code> .
	<code>FrIf_TrcevMode</code>	Transceiver mode to be set.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_NO_ERROR</code> . E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_ERROR</code> .
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_SetTransceiverMode()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

<sup>9</sup> Limited by static configuration [Configuration Parameter [FrlfCounterLimit](#)]

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_SetTransceiverMode()` by:

1. Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).
2. Setting parameters
  - `FrTrcv_TrcvMode` to `FrIf_TrcvMode`
3. Calling `FrTrcv_SetTransceiverMode()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.19 `FrIf_GetTransceiverMode`

FrIf05035:

<b>Service name:</b>	<code>FrIf_GetTransceiverMode</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetTransceiverMode(     uint8 FrIf_CtrlIdx,     Fr_ChannelType FrIf_ChnlIdx,     FrTrcv_TrcvModeType* FrIf_TrcvModePtr )</pre>	
<b>Service ID[hex]:</b>	0x2a	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>FrIf_CtrlIdx</code> .
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	<code>FrIf_TrcvModePtr</code>	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	<code>Std_ReturnType</code>	<code>E_OK</code> : The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_NO_ERROR</code> .
		<code>E_NOT_OK</code> : The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_ERROR</code> .
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_GetTransceiverMode()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API

function FrTrcv\_GetTransceiverMode() by:

1. Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index FrIf\_CtrlIdx | FlexRay Channel index FrIf\_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv\_TrcvIdx).
2. Setting parameters
  - FrTrcv\_TrcvModePtr to FrIf\_TrcvModePtr
3. Calling FrTrcv\_GetTransceiverMode() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.20 FrIf\_GetTransceiverWUReason

FrIf05036:

<b>Service name:</b>	FrIf_GetTransceiverWUReason	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetTransceiverWUReason(     uint8 FrIf_CtrlIdx,     Fr_ChannelType FrIf_ChnlIdx,     FrTrcv_TrcvWUReasonType* FrIf_TrcvWUReasonPtr )</pre>	
<b>Service ID[hex]:</b>	0x2b	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	FrIf_TrcvWUReasonPtr	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function FrTrcv_GetTransceiverWUReason()	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

Parameter FrIf\_ChnlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CHNL\_IDX) if FrIf\_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_GetTransceiverWUReason()` by:

1. Translating (based on static [Frlf](#) configuration) the tuple (FlexRay [CC](#) index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).
2. Setting parameters
  - `FrTrcv_TrcvWUReasonPtr` to `FrIf_WUReasonPtr`
3. Calling `FrTrcv_GetTransceiverWUReason()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

### 8.3.21 `FrIf_EnableTransceiverWakeup`

Frlf05037:

<b>Service name:</b>	<code>FrIf_EnableTransceiverWakeup</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_EnableTransceiverWakeup(     uint8 FrIf_CtrlIdx,     Fr_ChannelType FrIf_ChnlIdx )</pre>	
<b>Service ID[hex]:</b>	0x2c	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_ChnlIdx</code>	Index of the FlexRay Channel to address in scope of the FlexRay controller <code>FrIf_CtrlIdx</code> .
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_NO_ERROR</code> . E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned <code>BUSTRCV_E_ERROR</code> .
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_EnableTransceiverWakeup()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_EnableTransceiverWakeup()` by:

Translating (based on static [Frlf](#) configuration) the tuple (FlexRay [CC](#) index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).

Calling `FrTrcv_EnableTransceiverWakeup()` of the determined FlexRay Driver with



the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.22 FrIf\_DisableTransceiverWakeup

FrIf05038:

<b>Service name:</b>	FrIf_DisableTransceiverWakeup	
<b>Syntax:</b>	Std_ReturnType FrIf_DisableTransceiverWakeup( uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx )	
<b>Service ID[hex]:</b>	0x2e	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function FrTrcv_DisableTransceiverWakeup().	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_DisableTransceiverWakeup()` by:

Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).

Calling `FrTrcv_DisableTransceiverWakeup()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.23 FrIf\_ClearTransceiverWakeup

FrIf05039:

<b>Service name:</b>	FrIf_ClearTransceiverWakeup	
<b>Syntax:</b>	Std_ReturnType FrIf_ClearTransceiverWakeup( uint8 FrIf_CtrlIdx, Fr_ChannelType FrIf_ChnlIdx )	
<b>Service ID[hex]:</b>	0x30	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Reentrant	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_NO_ERROR. E_NOT_OK: The call of the FlexRay Transceiver Driver's API service has returned BUSTRCV_E_ERROR.
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function FrTrcv_EnableTransceiverWakeup().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

Parameter FrIf\_ChnlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CHNL\_IDX) if FrIf\_ChnlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function FrTrcv\_EnableTransceiverWakeup() by:

Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index FrIf\_CtrlIdx | FlexRay Channel index FrIf\_ChnlIdx) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index FrTrcv\_TrcvIdx).

Calling FrTrcv\_EnableTransceiverWakeup() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.3.24 FrIf\_GetCycleLength

<b>Service name:</b>	FrIf_GetCycleLength	
<b>Syntax:</b>	uint32 FrIf_GetCycleLength( uint8 FrIf_CtrlIdx )	
<b>Service ID[hex]:</b>	0x3a	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	Non Reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	uint32	Time in unit of nanoseconds
<b>Description:</b>	This API returns the configured time of the configuration parameter "GdCycle" in nanoseconds for the FlexRay controller with index FrIf_CtrlIdx.	

**FrIf05237:** If parameter FrIf\_CtrlIdx of FrIf\_GetCycleLength has an invalid value and if development error detection is enabled (i.e. FRIF\_DEV\_ERROR\_DETECT equals ON), the function FrIf\_GetCycleLength shall report development error code FRIF\_E\_INV\_CTRL\_IDX to the Det\_ReportError service of the DET module.

**FrIf05238:** Caveats of FrIf\_GetCycleLength: The FlexRay Interface module has to be initialized with a call of FrIf\_Init() before this API service may be called, see FrIf05002.

## 8.4 Optional Function Definitions

### 8.4.1 Frlf\_SetAbsoluteTimer

Frlf05021:

<b>Service name:</b>	Frlf_SetAbsoluteTimer	
<b>Syntax:</b>	<pre>Std_ReturnType Frlf_SetAbsoluteTimer(     uint8 Frlf_CtrlIdx,     uint8 Frlf_AbsTimerIdx,     uint8 Frlf_Cycle,     uint16 Frlf_Offset )</pre>	
<b>Service ID[hex]:</b>	0x1e	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_AbsTimerIdx	Index of the absolute timer to address.
	Frlf_Cycle	FlexRay Cycle number to be set.
	Frlf_Offset	Number of Macroticks to be set.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_SetAbsoluteTimer().	

Parameter Frlf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if Frlf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_SetAbsoluteTimer() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

#### 2. Setting parameters

- Fr\_AbsTimerIdx to Frlf\_AbsTimerIdx
- Fr\_Cycle to Frlf\_Cycle
- Fr\_Offset to Frlf\_Offset

#### 3. Calling Fr\_SetAbsoluteTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf\_Init() before this API service may be called, see [[Frlf05389](#)].

## 8.4.2 Frlf\_SetRelativeTimer

Frlf05022:

<b>Service name:</b>	Frlf_SetRelativeTimer	
<b>Syntax:</b>	<pre>Std_ReturnType Frlf_SetRelativeTimer(     uint8 Frlf_CtrlIdx,     uint8 Frlf_RelTimerIdx,     uint16 Frlf_Offset )</pre>	
<b>Service ID[hex]:</b>	0x1f	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	Frlf_CtrlIdx	Index of the FlexRay CC to address.
	Frlf_RelTimerIdx	Index of the relative timer to address.
	Frlf_Offset	Number of Macroticks the relative timer shall be set to.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_SetRelativeTimer().	

Parameter Frlf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if Frlf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_SetRelativeTimer() by:

Translating (based on static Frlf configuration) the FlexRay CC index Frlf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

Setting parameters

- Fr\_RelTimerIdx to Frlf\_RelTimerIdx
- Fr\_Offset to Frlf\_Offset
- Calling Fr\_SetRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of Frlf\_Init() before this API service may be called, see [\[Frlf05389\]](#).

## 8.4.3 Frlf\_CancelAbsoluteTimer

Frlf05023:

<b>Service name:</b>	Frlf_CancelAbsoluteTimer	
<b>Syntax:</b>	<pre>Std_ReturnType Frlf_CancelAbsoluteTimer(     uint8 Frlf_CtrlIdx,     uint8 Frlf_AbsTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x20	
<b>Sync/Async:</b>	Synchronous	

<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_AbsTimerIdx	Index of the absolute timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_CancelAbsoluteTimer() .	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_CancelAbsoluteTimer() by:

Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).

- Setting parameters
- Fr\_AbsTimerIdx to FrIf\_AbsTimerIdx
- Calling Fr\_AbsoluteRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Calling Fr\_AbsoluteRelativeTimer() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

#### 8.4.4 FrIf\_CancelRelativeTimer

FrIf05024:

<b>Service name:</b>	FrIf_CancelRelativeTimer	
<b>Syntax:</b>	Std_ReturnType FrIf_CancelRelativeTimer( uint8 FrIf_CtrlIdx, uint8 FrIf_RelTimerIdx )	
<b>Service ID[hex]:</b>	0x21	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_RelTimerIdx	Index of the relative timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has

		returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_CancelAbsoluteTimer().	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value. `Frlf_EnableAbsoluteTimerIRQ`

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_CancelRelativeTimer()` by:

1. Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_RelTimerIdx` to `Frlf_RelTimerIdx`
3. Calling `Fr_CancelRelativeTimer()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

#### 8.4.5 `Frlf_EnableAbsoluteTimerIRQ`

`Frlf05025`:

<b>Service name:</b>	<code>Frlf_EnableAbsoluteTimerIRQ</code>	
<b>Syntax:</b>	<pre>Std_ReturnType Frlf_EnableAbsoluteTimerIRQ(     uint8 Frlf_CtrlIdx,     uint8 Frlf_AbsTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x22	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>Frlf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>Frlf_AbsTimerIdx</code>	Index of the absolute timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	<code>E_OK</code> : The call of the FlexRay Driver's API service has returned <code>E_OK</code> . <code>E_NOT_OK</code> : The call of the FlexRay Driver's API service has returned <code>E_NOT_OK</code> , or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_EnableAbsoluteTimerIRQ()</code> .	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_EnableAbsoluteTimerIRQ()` by:

1. Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `Frlf_AbsTimerIdx`
3. Calling `Fr_EnableAbsoluteTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

#### 8.4.6 `Frlf_EnableRelativeTimerIRQ`

Frlf05026:

<b>Service name:</b>	<code>Frlf_EnableRelativeTimerIRQ</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_EnableRelativeTimerIRQ(     uint8 FrIf_CtrlIdx,     uint8 FrIf_RelTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x23	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>Frlf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>Frlf_RelTimerIdx</code>	Index of the relative timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_EnableRelativeTimerIRQ()</code> .	



Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_EnableRelativeTimerIRQ()` by:

1. Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `FrIf_AbsTimerIdx`
3. Calling `Fr_EnableRelativeTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.4.7 `FrIf_GetAbsoluteTimerIRQStatus`

#### **FrIf05027:**

<b>Service name:</b>	<code>FrIf_GetAbsoluteTimerIRQStatus</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetAbsoluteTimerIRQStatus(     uint8 FrIf_CtrlIdx,     uint8 FrIf_AbsTimerIdx,     boolean* FrIf_IRQStatusPtr )</pre>	
<b>Service ID[hex]:</b>	0x39	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_AbsTimerIdx</code>	Index of the absolute timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	<code>FrIf_IRQStatusPtr</code>	Pointer to a memory location where output value will be stored.
	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Return value:</b>		
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_GetAbsoluteTimerIRQStatus()</code>	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_GetAbsoluteTimerIRQStatus()` by:

1. Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `Frlf_AbsTimerIdx`
  - `Fr_IRQStatusPtr` to `Frlf_IRQStatusPtr`
3. Calling `Fr_GetAbsoluteTimerIRQStatus()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [[Frlf05389](#)].

### 8.4.8 `Frlf_GetRelativeTimerIRQStatus`

#### **Frlf05028:**

<b>Service name:</b>	<code>Frlf_GetRelativeTimerIRQStatus</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_GetRelativeTimerIRQStatus(     uint8 FrIf_CtrlIdx,     uint8 FrIf_RelTimerIdx,     boolean* FrIf_IRQStatusPtr )</pre>	
<b>Service ID[hex]:</b>	0x3a	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>Frlf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>Frlf_RelTimerIdx</code>	Index of the relative timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	<code>Frlf_IRQStatusPtr</code>	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_GetRelativeTimerIRQStatus()</code> .	

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_GetRelativeTimerIRQStatus()` by:

1. Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_RelTimerIdx` to `FrIf_RelTimerIdx`
  - `Fr_IRQStatusPtr` to `FrIf_IRQStatusPtr`
3. Calling `Fr_GetRelativeTimerIRQStatus()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [[FrIf05389](#)].

#### 8.4.9 FrIf\_AckAbsoluteTimerIRQ

##### FrIf05029:

<b>Service name:</b>	FrIf_AckAbsoluteTimerIRQ	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_AckAbsoluteTimerIRQ(     uint8 FrIf_CtrlIdx,     uint8 FrIf_AbsTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x24	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_AbsTimerIdx</code>	Index of the absolute timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_AckAbsoluteTimerIRQ()</code>	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_AckAbsoluteTimerIRQ()` by:

1. Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `FrIf_AbsTimerIdx`
3. Calling `Fr_AckAbsoluteTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

#### 8.4.10 `FrIf_AckRelativeTimerIRQ`

##### **FrIf05030:**

<b>Service name:</b>	<code>FrIf_AckRelativeTimerIRQ</code>	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_AckRelativeTimerIRQ(     uint8 FrIf_CtrlIdx,     uint8 FrIf_RelTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x25	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	<code>FrIf_CtrlIdx</code>	Index of the FlexRay CC to address.
	<code>FrIf_RelTimerIdx</code>	Index of the relative timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	<code>Std_ReturnType</code>	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_AckRelativeTimerIRQ()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_AckRelativeTimerIRQ()` by:

1. Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `FrIf_AbsTimerIdx`
3. Calling `Fr_AckRelativeTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.4.11 FrIf\_DisableAbsoluteTimerIRQ

#### FrIf05031:

<b>Service name:</b>	FrIf_DisableAbsoluteTimerIRQ	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_DisableAbsoluteTimerIRQ(     uint8 FrIf_CtrlIdx,     uint8 FrIf_AbsTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x26	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_AbsTimerIdx	Index of the absolute timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function <code>Fr_DisableAbsoluteTimerIRQ()</code> .	

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function `Fr_DisableAbsoluteTimerIRQ()` by:

1. Translating (based on static `FrIf` configuration) the FlexRay CC index `FrIf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).
2. Setting parameters
  - `Fr_AbsTimerIdx` to `FrIf_AbsTimerIdx`
3. Calling `Fr_DisableAbsoluteTimerIRQ()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

### 8.4.12 FrIf\_DisableRelativeTimerIRQ

#### FrIf05032:

<b>Service name:</b>	FrIf_DisableRelativeTimerIRQ	
<b>Syntax:</b>	<pre>Std_ReturnType FrIf_DisableRelativeTimerIRQ(     uint8 FrIf_CtrlIdx,     uint8 FrIf_RelTimerIdx )</pre>	
<b>Service ID[hex]:</b>	0x27	

<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for the same FlexRay CC, reentrant for different FlexRay CCs	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
	FrIf_RelTimerIdx	Index of the relative timer to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	None	
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.
<b>Description:</b>	Wraps the FlexRay Driver API function Fr_DisableRelativeTimerIRQ().	

Parameter FrIf\_CtrlIdx: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using FRIF\_E\_INV\_CTRL\_IDX) if FrIf\_CtrlIdx has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Driver API function Fr\_DisableRelativeTimerIRQ() by:

1. Translating (based on static FrIf configuration) the FlexRay CC index FrIf\_CtrlIdx into a tuple (FlexRay Driver | Driver-specific CC index Fr\_CtrlIdx).
2. Setting parameters
  - Fr\_RelTimerIdx to FrIf\_RelTimerIdx
3. Calling Fr\_DisableRelativeTimerIRQ() of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

### 8.4.13 FrIf\_GetNmVector

FrIf05016:

<b>Service name:</b>	FrIf_GetNmVector	
<b>Syntax:</b>	Std_ReturnType FrIf_GetNmVector( uint8 FrIf_CtrlIdx, uint8* FrIf_CyclePtr, uint8* FrIf_NmVectorPtr )	
<b>Service ID[hex]:</b>	0x34	
<b>Sync/Async:</b>	Synchronous	
<b>Reentrancy:</b>	non reentrant for identical values of FrIf_CtrlIdx, reentrant for different values of FrIf_CtrlIdx	
<b>Parameters (in):</b>	FrIf_CtrlIdx	Index of the FlexRay CC to address.
<b>Parameters (inout):</b>	None	
<b>Parameters (out):</b>	FrIf_CyclePtr	Pointer to a memory location where output value will be stored.
	FrIf_NmVectorPtr	Pointer to a memory location where output value will be stored.
<b>Return value:</b>	Std_ReturnType	E_OK: The call of the FlexRay Driver's API service has returned E_OK. E_NOT_OK: The call of the FlexRay Driver's API service has returned E_NOT_OK, or an error has been detected in development mode.

<b>Description:</b>	Derives the FlexRay NM Vector.
---------------------	--------------------------------

Parameter `Frlf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `Frlf_CtrlIdx` has an invalid value.

This API service of the FlexRay Interface derives the FlexRay NM Vector by:

Translating (based on static `Frlf` configuration) the FlexRay CC index `Frlf_CtrlIdx` into a tuple (FlexRay Driver | Driver-specific CC index `Fr_CtrlIdx`).

14. Setting parameters

- `Fr_CylcePtr` to `Frlf_CyclePtr`
- `Fr_NmVectorPtr` to `Frlf_NmVectorPtr`

Calling `Fr_GetNmVector()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `Frlf_Init()` before this API service may be called, see [\[Frlf05389\]](#).

## 8.5 Interrupt Service Routines

### 8.5.1 FrIf\_JobListExec\_<ClstIdx>

FrIf05040:

<b>Service name:</b>	FrIf_JobListExec_<ClstIdx>
<b>Syntax:</b>	void FrIf_JobListExec_<ClstIdx>(
	)
<b>Service ID[hex]:</b>	0x32
<b>Sync/Async:</b>	Synchronous
<b>Reentrancy:</b>	Non Reentrant
<b>Parameters (in):</b>	None
<b>Parameters (inout):</b>	None
<b>Parameters (out):</b>	None
<b>Return value:</b>	None
<b>Description:</b>	Processes the FlexRay Job List of the FlexRay Cluster with index ClstIdx.

This API service of the FlexRay Interface processes the FlexRay Job List of the FlexRay Cluster with index ClstIdx.

For a detailed description of this API service, please refer to chapter 7.6.2.2.

**Caveats:** This API service of the FlexRay Interface exists once per FlexRay Cluster. The API name contains the index of the respective FlexRay Cluster (ClstIdx).

For each FlexRay Cluster (identified by index ClstIdx), the respective API service FrIf\_JobListExec\_<ClstIdx> must be registered in the AUTOSAR OS as the [ISR](#) of an absolute timer of a FlexRay [CC](#) connected to the FlexRay Cluster with index ClstIdx, if the CC does **not guarantee asynchronous buffer access**.

The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

**Note:**

If the CC guarantees asynchronous buffer access, the execution of FrIf\_JobListExec<ClstIdx> can run in a regular OS task.



## 8.6 Call-back Notifications

This is a list of functions provided for other modules. The function prototypes of the callback functions shall be provided in the file `FrIf_Cbk.h`

### 8.6.1 FrIf\_Cbk\_WakeupByTransceiver

FrIf05041:

<b>Service name:</b>	FrIf_Cbk_WakeupByTransceiver				
<b>Syntax:</b>	<pre>void FrIf_Cbk_WakeupByTransceiver(     uint8 FrIf_CtrlIdx,     Fr_ChannelType FrIf_ChnlIdx )</pre>				
<b>Service ID[hex]:</b>	0x3b				
<b>Sync/Async:</b>	Synchronous				
<b>Reentrancy:</b>	Reentrant				
<b>Parameters (in):</b>	<table border="0"> <tr> <td>FrIf_CtrlIdx</td> <td>Index of the FlexRay CC to address.</td> </tr> <tr> <td>FrIf_ChnlIdx</td> <td>Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.</td> </tr> </table>	FrIf_CtrlIdx	Index of the FlexRay CC to address.	FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.
FrIf_CtrlIdx	Index of the FlexRay CC to address.				
FrIf_ChnlIdx	Index of the FlexRay Channel to address in scope of the FlexRay controller FrIf_CtrlIdx.				
<b>Parameters (inout):</b>	None				
<b>Parameters (out):</b>	None				
<b>Return value:</b>	None				
<b>Description:</b>	Wraps the FlexRay Transceiver Driver API function <code>FrTrcv_Cbk_WakeupByTransceiver()</code> .				

Parameter `FrIf_CtrlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CTRL_IDX`) if `FrIf_CtrlIdx` has an invalid value.

Parameter `FrIf_ChnlIdx`: If development error detection is enabled (i.e. [FRIF\\_DEV\\_ERROR\\_DETECT](#) equals ON), it shall be reported to the DET module (using `FRIF_E_INV_CHNL_IDX`) if `FrIf_ChnlIdx` has an invalid value.

This API service of the FlexRay Interface wraps the FlexRay Transceiver Driver API function `FrTrcv_Cbk_WakeupByTransceiver()` by:

Translating (based on static [FrIf](#) configuration) the tuple (FlexRay [CC](#) index `FrIf_CtrlIdx` | FlexRay Channel index `FrIf_ChnlIdx`) into a tuple (FlexRay Transceiver Driver | Driver-specific Transceiver index `FrTrcv_TrcvIdx`).

Calling `FrTrcv_CbkWakeupByTransceiver()` of the determined FlexRay Driver with the parameters determined as described above.

Caveats: The FlexRay Interface has to be initialized with a call of `FrIf_Init()` before this API service may be called, see [\[FrIf05389\]](#).

## 8.7 Scheduled Functions

### 8.7.1 FrIf\_MainFunction\_<ClstIdx>

FrIf05042:

<b>Service name:</b>	FrIf_MainFunction_<ClstIdx>
<b>Syntax:</b>	void FrIf_MainFunction_<ClstIdx>(
	)
<b>Service ID[hex]:</b>	0x33
<b>Timing:</b>	VARIABLE_CYCLIC
<b>Description:</b>	This function will be called cyclically by a task body provided by the BSW Scheduler.

This cyclically executed API service of the FlexRay Interface serves the following purposes:

- Initially program the absolute timer interrupt in order to start the execution of FrIf\_JobListExec\_<ClstIdx>() if the CC does not support asynchronous buffer access.
- Monitoring the proper (in time) execution of the FrIf\_JobListExec\_<ClstIdx>() and resynchronize the Joblist if necessary.

Please refer to chapter 7.3 for a detailed description.

Pre condition: This API service of the FlexRay Interface is cyclically called from a task body provided by the [BSW](#) Scheduler.

Since the duration of a FlexRay Cycle may be different for two Clusters of an ECU, the calling period of this API service shall be configurable independently for each Cluster [at system configuration time](#).

Caveats: This API service of the FlexRay Interface exists once per FlexRay Cluster. The API name contains the index of the respective FlexRay Cluster (ClstIdx).

The FlexRay Interface has to be initialized with a call of FrIf\_Init() before this API service may be called, see [\[FrIf05389\]](#).

## 8.8 Expected Interfaces

This chapter lists all API services required from other [BSW](#) modules.

### 8.8.1 Mandatory Interfaces

This chapter defines all API services which are required from other [BSW](#) modules to fulfill the core functionality of the FlexRay Interface.

FrIf05043:

<b>API function</b>	<b>Description</b>
Fr_PrepareLPdu	Prepares a LPdu.
Fr_DisableRelativeTimerIRQ	Disables the interrupt line of a timer.
Fr_SetWakeupChannel	Sets a wakeup channel.
Fr_GetNmVector	Gets the network management vector of the last communication cycle.
Fr_GetRelativeTimerIRQStatus	Gets IRQ status of a relative timer.
Fr_SetExtSync	Adjusts the global time of a FlexRay CC to an external clock source.
Fr_GetGlobalTime	Gets the current global FlexRay time.
Fr_SendWUP	Invokes the CC CHI command 'WAKEUP'.
Fr_GetAbsoluteTimerIRQStatus	Gets IRQ status of an absolute timer.
Fr_SetAbsoluteTimer	Sets the absolute FlexRay timer.
Fr_SendMTS	Triggers a MTS.
Fr_AllowColdstart	Invokes the CC CHI command 'ALLOW_COLDSTART'.
Fr_StopMTS	Stops the periodic transmission of MTS symbols.
Fr_StartCommunication	Starts communication.
Fr_DisableAbsoluteTimerIRQ	Disables the interrupt line of an absolute timer.
Fr_GetVersionInfo	Returns the version information of this module.
Fr_AckRelativeTimerIRQ	Resets the interrupt condition of a relative timer.
Fr_CancelAbsoluteTimer	Stops an absolute timer.
Fr_AckAbsoluteTimerIRQ	Resets the interrupt condition of an absolute timer.
Fr_ControllerInit	Initializes a FlexRay CC.
Fr_Init	Initializes the Fr.
Fr_EnableRelativeTimerIRQ	Enables the interrupt line of a relative timer.
Fr_GetPOCStatus	Gets the POC status.
Fr_SetRelativeTimer	Sets the FlexRay timer.
Fr_CancelRelativeTimer	Stops a relative timer.
Fr_HaltCommunication	Invokes the CC CHI command 'HALT'.
Fr_GetSyncState	Gets the sync state.
Fr_CheckMTS	Checks the MTS.
Fr_CheckTxLPduStatus	Checks the transmit status of the LSdu.
Fr_TransmitTxLPdu	Transmits data on the FlexRay network.
Fr_ReceiveRxLPdu	Receives data from the FlexRay network.
Fr_AbortCommunication	Invokes the CC CHI command 'FREEZE'.
Fr_EnableAbsoluteTimerIRQ	Enables the interrupt line of an absolute timer.
FrTrcv_MainFunction	--
FrTrcv_SetTransceiverMode	This service returns the transceiver mode.
FrTrcv_ClearTransceiverWakeup	This function clears a pending wake up event.
FrTrcv_DisableTransceiverWakeup	This function disables the notification for wake up events on the addressed bus.
FrTrcv_EnableTransceiverWakeup	This function enables the notification for wake up events on the addressed bus.
FrTrcv_GetTransceiverWUReason	This function returns the wakeup reason.
FrTrcv_GetVersionInfo	This service returns the version information of this module.
FrTrcv_TrvcvInit	This service initializes the FrTrcv.

FrTrcv_GetTransceiverMode	This function returns the actual state of the transceiver.
Dem_ReportErrorStatus	Reports errors to the DEM.

## 8.8.2 Optional Interfaces

This chapter defines all API services which are required from other [BSW](#) modules to fulfill an optional functionality of the FlexRay Interface

Frlf05044:

API function	Description
Det_ReportError	Service to report development errors.

## 8.8.3 Configurable Interfaces

This chapter lists all interfaces where the target API service of any upper layer, which require one or more of these mentioned interfaces to be called has to be set up by static configuration of the FlexRay Interface.

These call-out services are specified and implemented in the upper layer BSW modules, which use the FlexRay Interface according to [2]. The specific call-out notification is specified in the corresponding AUTOSAR SWS document (see chapter 3).

In addition to upper layer AUTOSAR BSW modules, the Frlf shall, with the functionality described within the specification in hand, also support other non-AUTOSAR upper layer software modules, provided that these modules interact with the Frlf in the same manner as the upper layer AUTOSAR BSW modules. In particular, those non-AUTOSAR modules need to provide APIs as described in this chapter. One example for such a non-AUTOSAR software module is a proprietary XCPonFlexRay module that users may add to their AUTOSAR BSW stack.

### 8.8.3.1 <UL\_RxIndication>

Frlf05045:

Service name:	<UL_RxIndication>	
Syntax:	void <UL_RxIndication>( PduIdType FrIf_RxPduId, const PduInfoType* PduInfoPtr )	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_RxPduId, Non reentrant for the same FrIf_RxPduId	
Parameters (in):	FrIf_RxPduId	PDU-ID of FlexRay PDU that has been received

	PduInfoPtr	Contains the length (SduLength) of the received I-PDU and a pointer to a buffer (SduDataPtr) containing the I-PDU.
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	Indication of a received I-PDU from a lower layer communication module.	

Caveats: This API service is called during the execution of the FlexRay Job List Execution Function.

### 8.8.3.2 <UL\_TxConfirmation>

Frlf05046:

Service name:	<UL_TxConfirmation>	
Syntax:	void <UL_TxConfirmation>( PduIdType FrIf_TxPduId )	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_TxPduId, Non reentrant for the same FrIf_TxPduId	
Parameters (in):	FrIf_TxPduId	PDU-ID of FlexRay PDU whose transmission is being confirmed
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	This API service of an upper layer BSW module <UL> (e.g. PduR, FrTp, FrNm) is called by the FlexRay Interface to confirm to this upper layer BSW module that the PDU with index FrIf_TxPduId has been transmitted via the FlexRay Communication System.	

Caveats: This API service is called during the execution of the FlexRay Job List Execution Function.

### 8.8.3.3 <UL\_TriggerTransmit>

Frlf05047:

Service name:	<UL_TriggerTransmit>
---------------	----------------------

Syntax:	Std_ReturnType <UL_TriggerTransmit>( PduIdType FrIf_TxPduId, PduInfoType* PduInfoPtr )	
Service ID[hex]:	0x00	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant for different FrIf_TxPduId, Non reentrant for the same FrIf_TxPduId	
Parameters (in):	FrIf_TxPduId	PDU-ID of FlexRay PDU that shall be copied to the FrIf
Parameters (inout):	PduInfoPtr	Contains a pointer to a buffer (SduDataPtr) to where the SDU shall be copied to. On return, the service will indicate the length of the copied SDU data in SduLength.
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK: SDU has been copied and SduLength indicates the number of copied bytes. E_NOT_OK: No SDU has been copied. PduInfoPtr must not be used since it may contain a NULL pointer or point to invalid data.
Description:	The lower layer communication module requests the buffer of the SDU for transmission from the upper layer module.	

**Caveats:** This API service is called during the execution of the FlexRay Job List Execution Function.

## 9 Sequence Diagrams

The sequence diagrams in this chapter show the basic operations carried out in a FlexRay Cluster's FlexRay Job List Execution Function when executing the various Communication Operations. They also show the interaction of the [Frlf](#) with the upper layer [BSW](#) module and with the underlying FlexRay Driver.

Please note that the sequence diagrams are an extension for illustrational purposes to ease understanding of the specification.

### 9.1 Data Transmission

#### 9.1.1 TransmitWithImmediateBufferAccess





Figure 9-1: TransmitWithImmediateBufferAccess


**9.1.2 TransmitWithDecoupledBufferAccess**



**Figure 9-2: TransmitWithDecoupledBufferAccess**



**9.1.3 ProvideTxConfirmation**



**Figure 9-3: ProvideTxConfirmation**

## 9.2 Data Reception

### 9.2.1 ReceiveAndIndicate






Figure 9-4: ReceiveAndIndicate

**9.2.2 ReceiveAndStore**



**Figure 9-5: ReceiveAndStore**

**9.2.3 ProvideRxIndication**



**Figure 9-6: ProvideRxIndication**

## 10 Configuration Specification

This chapter defines configuration parameters and their clustering into containers. Chapter 10.1 gives information to help understanding the subsequent chapters. Chapter 10.2 specifies the structure (containers) and the parameters of the FlexRay Interface. Chapter 10.3 specifies published information of the FlexRay Interface.

### 10.1 How to Read this Chapter

In addition to this section, it is highly recommended to read the documents:

- AUTOSAR Layered Software Architecture [2]
- AUTOSAR ECU Configuration Specification [13]  
This document describes the AUTOSAR configuration methodology and the AUTOSAR configuration metamodel in detail.

The following is only a short survey of the topic and it will not replace the ECU Configuration Specification document.

#### 10.1.1 Configuration and Configuration Parameters

Configuration parameters define the variability of the generic part(s) of an implementation of a module. This means that only generic or configurable module implementation can be adapted to the environment (software/hardware) in use during system and/or ECU configuration.

The configuration of parameters can be achieved at different times during the software process: [pre compile time](#), before [link time](#) or [post build time](#). In the following, the term "configuration class" (of a parameter) shall be used in order to refer to a specific configuration point in time.

Frlf05144:

All configuration data of the [Frlf](#) that is definable [at system configuration time](#) shall be re-loadable into the ECU [by a flashing process](#).

#### 10.1.2 Variants

Variants describe sets of configuration parameters. E.g., variant 1: only pre-compile time configuration parameters; variant 2: mix of [pre compile-](#) and [post build time-](#)configuration parameters. In one variant, a parameter can only be of one configuration class.

### 10.1.3 Containers

Frlf05077:

Containers structure the set of configuration parameters. This means:

- *all* configuration parameters are kept in containers.
- (sub-) containers can reference (sub-) containers. It is possible to assign a multiplicity to these references. The multiplicity then defines the possible number of instances of the contained parameters.

### 10.1.4 Specification Template for Configuration Parameters

The following tables consist of three sections:

- the general section
- the configuration parameter section
- the section of included/referenced containers

Pre compile time - specifies whether the configuration parameter shall be of configuration class Pre-compile time or not

<b>Label</b>	<b>Description</b>
X	The configuration parameter shall be of configuration class <i>Pre-compile time</i> .
--	The configuration parameter shall never be of configuration class <i>Pre-compile time</i> .

Link time - specifies whether the configuration parameter shall be of configuration class link time or not

<b>Label</b>	<b>Description</b>
x	The configuration parameter shall be of configuration class <u>link time</u> .
--	The configuration parameter shall never be of configuration class <u>link time</u> .

Post build time - specifies whether the configuration parameter shall be of configuration class post build time or not

<b>Label</b>	<b>Description</b>
x	The configuration parameter shall be of configuration class <u>post build time</u> and no specific implementation is required.
L	<i>Loadable</i> - the configuration parameter shall be of configuration class <u>post build time</u> and only one configuration parameter set resides in the ECU.
M	<i>Multiple</i> - the configuration parameter shall be of configuration class <u>post build time</u> and is selected out of a set of multiple parameters by passing a dedicated pointer to the init function of the module.
--	The configuration parameter shall never be of configuration class <u>post build time</u> .

## 10.2 Containers and Configuration Parameters

Frlf05070:

The following chapters summarize all configuration parameters. The detailed meanings of the parameters are described in chapter 7 and chapter 8.

The listed configuration items can be derived from a network description database, which is based on the EcuConfigurationTemplate. The configuration tool shall extract all information to configure the [Frlf](#).

Frlf05071:

The configuration tool must check the consistency of the configuration at configuration time.

Frlf05072:

Configuration rules and constraints for plausibility checks shall be performed during configuration time, wherever possible.

Frlf05073:

These dependencies between FlexRay Interface and FlexRay Driver configuration must be provided at configuration time by the configuration tools.

### 10.2.1 Variants

**VARIANT-POST-BUILD:** All configuration parameters in container 'FrlfGeneral' shall be configurable at pre-compile time. All other configuration parameters shall be configurable at post-build-time.

Use case: Object code delivery, selectable configuration

**VARIANT-PRE-COMPILE:** All configuration parameters shall be configurable at pre-compile time.

Use case: Execution time optimizations

### 10.2.2 Frlf

<b>Module Name</b>	<i>Frlf</i>
<b>Module Description</b>	Configuration of the Frlf (FlexRay Interface) module.

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfConfig	1	Configuration of the FlexRay Interface. This container is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.
FrlfGeneral	1	This container contains the general configuration parameters of the FlexRay Interface.

### 10.2.3 FrlfGeneral

<b>SWS Item</b>	<b>Frlf05360 :</b>
<b>Container Name</b>	FrlfGeneral{FRIF_GENERAL_CONFIGURATION}
<b>Description</b>	This container contains the general configuration parameters of the FlexRay Interface.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06080 :</b>		
<b>Name</b>	FrlfDevErrorDetect {FRIF_DEV_ERROR_DETECT}		
<b>Description</b>	Switches the Development Error Detection and Notification on or off true: Development Error Detection and Notification on false: Development Error Detection and Notification off		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06114 :</b>		
<b>Name</b>	FrlfGetNmVectorSupport {FRIF_GET_NM_VECTOR_SUPPORT}		
<b>Description</b>	Configuration parameter to enable/disable Frlf support to request the FlexRay hardware NMVector.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06081 :</b>		
<b>Name</b>	FrlfNumClstSupported {FRIF_CLST_IDX_MAX_SUPPORTED}		
<b>Description</b>	Maximum number of FlexRay Clusters that the FlexRay Interface supports.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06082 :</b>		
<b>Name</b>	FrlfNumCtrlSupported {FRIF_CTRL_IDX_MAX_SUPPORTED}		
<b>Description</b>	Maximum number of FlexRay CCs that the FlexRay Interface supports		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06083 :</b>
<b>Name</b>	FrlfVersionInfoApi {FRIF_VERSION_INFO_API}



<b>Description</b>	Enables/disables the existence of the Frlf_GetVersionInfo() API service true: Frlf_GetVersionInfo() API service exists false: Frlf_GetVersionInfo() API service does not exist		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	All Variants
	<b>Link time</b>	--	
	<b>Post-build time</b>	--	
<b>Scope / Dependency</b>	scope: Module		

No Included Containers

### 10.2.4 FrlfCluster

<b>SWS Item</b>	<b>Frlf05366 :</b>		
<b>Container Name</b>	FrlfCluster{FRIF_CLUSTER}		
<b>Description</b>	This container specifies a Frlf Cluster and all related data which is required to enable communication of the Cluster. A Cluster may consist of more than one Controller.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06002 :</b>		
<b>Name</b>	FrlfClstIdx {FRIF_CLST_IDX}		
<b>Description</b>	This parameter provides a zero-based consecutive index of the FlexRay Clusters. Upper layer BSW modules and the Frlf itself use this index to identify a FlexRay Cluster.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06003 :</b>		
<b>Name</b>	FrlfMainFunctionPeriod {FRIF_MAINFUNCTION_PERIOD}		
<b>Description</b>	The execution cycle of the Frlf_MainFunction_<cluster>() in seconds. The Frlf does not require this information but the BSW scheduler, which invokes the cluster main functions, needs it in order to plan its tasks.		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06004 :</b>		
<b>Name</b>	FrlfMaxIsrDelay {FRIF_MAX_ISR_DELAY}		
<b>Description</b>	The maximum delay in macroticks the Frlf_JoblistExec_<cluster>() function is processed after the absolute timer interrupt was triggered.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Default value</b>	--		

<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06005 :</b>		
<b>Name</b>	GAssumedPrecision {G_ASSUMED_PRECISION}		
<b>Description</b>	Assumed precision of the application network		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 65535		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06006 :</b>		
<b>Name</b>	GChannels {G_CHANNELS}		
<b>Description</b>	The channels that are used by the cluster. Implementation Type: Fr_ChannelType		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	FR_CHANNEL_A	Cluster uses channel A	
	FR_CHANNEL_AB	Cluster uses channel A and B Implementation Type: Fr_ChannelType	
	FR_CHANNEL_B	Cluster uses channel B	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06007 :</b>		
<b>Name</b>	GClusterDriftDamping {G_CLUSTER_DRIFT_DAMPING}		
<b>Description</b>	The cluster drift damping factor, based on the longest microtick gdMaxMicrotick used in the cluster. Used to compute the local cluster drift damping factor pClusterDriftDamping [Microticks].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 5		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06008 :</b>		
<b>Name</b>	GColdStartAttempts {G_COLD_START_ATTEMPTS}		
<b>Description</b>	Maximum number of times a node in the cluster is permitted to attempt to start the cluster by initiating schedule synchronization		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 31		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	

	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06009 :</b>		
<b>Name</b>	GListenNoise {G_LISTEN_NOISE}		
<b>Description</b>	Upper limit for the start up listen timeout and wake up listen timeout in the presence of noise. It is used as a multiplier of the cluster parameter pdListenTimeout.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 16		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06010 :</b>		
<b>Name</b>	GMacroPerCycle {G_MACRO_PER_CYCLE}		
<b>Description</b>	Number of macroticks in a communication cycle.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	10 .. 16000		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module/Fr		

<b>SWS Item</b>	<b>Frlf06011 :</b>		
<b>Name</b>	GMaxWithoutClockCorrectFatal {G_MAX_WITHOUT_CLOCK_CORRECTION_FATAL}		
<b>Description</b>	Threshold used for testing the vClockCorrectionFailed counter. Defines the number of consecutive even/odd Cycle pairs with missing clock correction terms that will cause the protocol to transition from the POC:normal active or POC:normal passive state into the POC:halt state. [Even/odd cycle pairs].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 15		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06012 :</b>		
<b>Name</b>	GMaxWithoutClockCorrectPassive {G_MAX_WITHOUT_CLOCK_CORRECTION_PASSIVE}		
<b>Description</b>	Threshold used for testing the vClockCorrectionFailed counter. Defines the number of consecutive even/odd Cycle pairs with missing clock correction terms that will cause the protocol to transition from the POC:normal active state to the POC:normal passive state. [Even/Odd cycle pairs]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 15		

<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06013 :</b>		
<b>Name</b>	GNetworkManagementVectLength {G_NETWORK_MANAGEMENT_VECTOR_LENGTH}		
<b>Description</b>	Length of the Network Management vector in a cluster [bytes]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 12		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06014 :</b>		
<b>Name</b>	GNumberOfMinislots {G_NUMBER_OF_MINISLOTS}		
<b>Description</b>	Number of minislots in the dynamic segment		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 7986		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06015 :</b>		
<b>Name</b>	GNumberOfStaticSlots {G_NUMBER_OF_STATIC_SLOTS}		
<b>Description</b>	Number of static slots in the static segment		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 1023		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06016 :</b>		
<b>Name</b>	GOffsetCorrectionMax {G_OFFSET_CORRECTION_MAX}		
<b>Description</b>	describes the maximum value which the offset correction should assume in seconds.		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Range</b>	5.0E-7 .. 3.811E-4		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06017 :</b>		
<b>Name</b>	GOffsetCorrectionStart {G_OFFSET_CORRECTION_START}		
<b>Description</b>	Start of the offset correction phase within the NIT, expressed as the number of macroticks from the start of cycle.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	9 .. 15999		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06018 :</b>		
<b>Name</b>	GPayloadLengthStatic {G_PAYLOAD_LENGTH_STATIC}		
<b>Description</b>	Payload length of a static frame [16 bit words]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 127		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06019 :</b>		
<b>Name</b>	GSyncNodeMax {G_SYNC_NODE_MAX}		
<b>Description</b>	Maximum number of nodes that may send frames with the sync frame indicator bit set to one.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 15		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06020 :</b>		
<b>Name</b>	GdActionPointOffset {GD_ACTION_POINT_OFFSET}		
<b>Description</b>	Number of Macroticks the action point is offset from the beginning of a Static Slots or symbol window.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 63		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module/Fr		

<b>SWS Item</b>	<b>Frlf06021 :</b>		
<b>Name</b>	GdBit {GD_BIT}		
<b>Description</b>	Nominal bit time in seconds		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		

<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06022 :</b>		
<b>Name</b>	GdBitMax {GD_BIT_MAX}		
<b>Description</b>	Maximum bit time taking into account the allowable clock deviation of each node (in seconds).		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06023 :</b>		
<b>Name</b>	GdBitMin {GD_BIT_MIN}		
<b>Description</b>	Minimum bit time taking into account the allowable clock deviation of each node (in seconds).		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06024 :</b>		
<b>Name</b>	GdCasRxLowMax {GD_CAS_RX_LOW_MAX}		
<b>Description</b>	Upper limit of the CAS acceptance window [gdBit]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	67 .. 99		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module/Fr		

<b>SWS Item</b>	<b>Frlf06025 :</b>		
<b>Name</b>	GdCycle {GD_CYCLE}		
<b>Description</b>	Length of the cycle, expressed in s		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Range</b>	1.0E-5 .. 0.016		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06026 :</b>		
<b>Name</b>	GdDynamicSlotIdlePhase {GD_DYNAMIC_SLOT_IDLE_PHASE}		

<b>Description</b>	Duration of the idle phase within a dynamic slot [Minislots].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 2		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06027 :</b>		
<b>Name</b>	GdMacrotick {GD_MACROTICK}		
<b>Description</b>	Duration of the cluster wide nominal macrotick, expressed in s		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Range</b>	1.0E-6 .. 6.0E-6		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06028 :</b>		
<b>Name</b>	GdMaxInitializationError {GD_MAX_INITIALIZATION_ERROR}		
<b>Description</b>	Maximum error that a node may have following integration in seconds.		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Range</b>	0.0 .. 65535.0		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06029 :</b>		
<b>Name</b>	GdMaxMicrotick {GD_MAX_MICROTICK}		
<b>Description</b>	Maximum Microtick length of all Microticks configured within a Cluster.		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	T100NS		
	T12_5NS		
	T200NS		
	T25NS		
	T50NS		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06030 :</b>		
<b>Name</b>	GdMaxPropagationDelay {GD_MAX_PROPAGATION_DELAY}		
<b>Description</b>	Maximum propagation delay of a Cluster (in seconds).		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		

<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06031 :</b>		
<b>Name</b>	GdMinPropagationDelay {GD_MIN_PROPAGATION_DELAY}		
<b>Description</b>	Minimum propagation delay of a Cluster (in seconds).		
<b>Multiplicity</b>	1		
<b>Type</b>	FloatParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06032 :</b>		
<b>Name</b>	GdMiniSlotActionPointOffset {GD_MINI_SLOT_ACTION_POINT_OFFSET}		
<b>Description</b>	Number of Macroticks the Minislot action point is offset from the beginning of a Minislot [Macroticks].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 31		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06033 :</b>		
<b>Name</b>	GdMinislot {GD_MINISLOT}		
<b>Description</b>	Duration of a minislot [Macroticks]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 63		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module/Fr		

<b>SWS Item</b>	<b>Frlf06034 :</b>		
<b>Name</b>	GdNit {GD_NIT}		
<b>Description</b>	Duration of the Network Idle Time [Macroticks]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	2 .. 767		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06035 :</b>		
-----------------	--------------------	--	--



<b>Name</b>	GdSampleClockPeriod {GD_SAMPLE_CLOCK_PERIOD}		
<b>Description</b>	Sample clock period		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	T12_5NS		
	T25NS		
	T50NS		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06036 :</b>		
<b>Name</b>	GdStaticSlot {GD_STATIC_SLOT}		
<b>Description</b>	Duration of a Static Slot [Macroticks].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	4 .. 659		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06037 :</b>		
<b>Name</b>	GdSymbolWindow {GD_SYMBOL_WINDOW}		
<b>Description</b>	Duration of the symbol window [Macroticks].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 139		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06038 :</b>		
<b>Name</b>	GdTssTransmitter {GD_TSS_TRANSMITTER}		
<b>Description</b>	Number of bits in the Transmission Start Sequence [gdBits].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	3 .. 15		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06039 :</b>		
<b>Name</b>	GdWakeupSymbolRxIdle {GD_WAKEUP_SYMBOL_RX_IDLE}		
<b>Description</b>	Number of bits used by the node to test the duration of the 'idle' portion of a received wakeup symbol. Duration is equal to (gdWakeupSymbolTxIdle - gdWakeupSymbolTxLow)/2 minus a safe part. (Collisions, clock differences, and other effects can deform the Tx-wakeup pattern.) [gdBit].		
<b>Multiplicity</b>	1		

<b>Type</b>	IntegerParamDef		
<b>Range</b>	14 .. 59		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06040 :</b>		
<b>Name</b>	GdWakeupSymbolRxLow {GD_WAKEUP_SYMBOL_RX_LOW}		
<b>Description</b>	Number of bits used by the node to test the LOW portion of a received wakeup symbol. This lower limit of zero bits has to be received to detect the LOW portion by the receiver. The duration is equal to gdWakeupSymbolTxLow minus a safe part. (Active stars, clock differences, and other effects can deform the Tx-wakeup pattern.) [gdBits].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	10 .. 55		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06041 :</b>		
<b>Name</b>	GdWakeupSymbolRxWindow {GD_WAKEUP_SYMBOL_RX_WINDOW}		
<b>Description</b>	The size of the window used to detect wakeups. Detection of a wakeup requires a low and idle period (from one WUS) and a low period (from another WUS) to be detected entirely within a window of this size. The duration is equal to gdWakeupSymbolTxIdle + 2 * gdWakeupSymbolTxLow plus a safe part. (Clock differences and other effects can deform the Tx-wakeup pattern.) [gdBit].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	76 .. 301		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06042 :</b>		
<b>Name</b>	GdWakeupSymbolTxIdle {GD_WAKEUP_SYMBOL_TX_IDLE}		
<b>Description</b>	Number of bits used by the node to transmit the 'idle' part of a wakeup symbol. The duration is equal to cdWakeupSymbolTxIdle [gdBit].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	45 .. 180		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06043 :</b>		
<b>Name</b>	GdWakeupSymbolTxLow {GD_WAKEUP_SYMBOL_TX_LOW}		

<b>Description</b>	Number of bits used by the node to transmit the LOW part of a wakeup symbol. The duration is equal to cdWakeupSymbolTxLow [gdBit].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	15 .. 60		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfController	1..*	This container contains the configuration of FlexRay CC.
FrlfJobList	1	This container specifies a list of all FlexRay Jobs of the Cluster to be performed by Frlf_JobListExec_<ClstIdx>().

### 10.2.5 FrlfController

<b>SWS Item</b>	<b>Frlf05363 :</b>
<b>Container Name</b>	FrlfController
<b>Description</b>	This container contains the configuration of FlexRay CC.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06045 :</b>		
<b>Name</b>	FrlfCtrlIdx {FRIF_CTRL_IDX}		
<b>Description</b>	This parameter provides a zero-based consecutive index of the FlexRay Communication Controllers. Upper layer BSW modules and the Frlf itself use this index to identify a FlexRay CC.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

<b>SWS Item</b>	<b>Frlf06044 :</b>		
<b>Name</b>	FrlfFrCtrlRef {FRIF_FR_CTRL}		
<b>Description</b>	Reference to a Controller, which is handled by a specific Driver. This reference is unique for the ECU.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrController		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfAbsTimer	1..*	This container contains the configuration of an absolute timer of a FlexRay CC.
FrlfFrameTriggering	1..*	A Frame triggering contains the communication parameters of the FlexRay Frame as well as a reference to the Frame Construction Plan.

FrlfLPdu	1..*	LPdu is an abstraction of all FlexRay Frames (L-PDUs) belonging to the same Frame Triggering FrlfFrameTriggering.
FrlfRelTimer	0..*	This container contains the configuration of a relative timer of a FlexRay CC.
FrlfTransceiver	0..2	Up to two FlexRay Transceivers may connect a Controller to a Cluster. This container realizes a Controller-Transceiver assignment.

### 10.2.6 FrlfAbsTimer

<b>SWS Item</b>	<b>frlf05361 :</b>		
<b>Container Name</b>	FrlfAbsTimer{FRIF_ABS_TIMER}		
<b>Description</b>	This container contains the configuration of an absolute timer of a FlexRay CC.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06047 :</b>		
<b>Name</b>	FrlfAbsTimerIdx {FRIF_ABS_TIMER_IDX}		
<b>Description</b>	This parameter provides a zero-based consecutive index of the absolute timers. Upper layer BSW modules use this index to identify an absolute timer.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

<b>SWS Item</b>	<b>Frlf06046 :</b>		
<b>Name</b>	FrlfFrAbsTimerRef {FRIF_FR_ABS_TIMER}		
<b>Description</b>	Reference to an absolute timer, which is handled by a specific FlexRay Driver. This reference is unique for the ECU, therefore, an explicit reference to the FlexRay Driver is not necessary.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrAbsoluteTimer		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

#### No Included Containers

### 10.2.7 FrlfRelTimer

<b>SWS Item</b>	<b>frlf05362 :</b>		
<b>Container Name</b>	FrlfRelTimer{FRIF_REL_TIMER_IDX}		
<b>Description</b>	This container contains the configuration of a relative timer of a FlexRay CC.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06060 :</b>		
<b>Name</b>	FrlfRelTimerIdx {FRIF_REL_TIMER_IDX}		
<b>Description</b>	This parameter provides a zero-based consecutive index of the relative		

	timers. Upper layer BSW modules use this index to identify a relative timer.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

<b>SWS Item</b>	<b>Frlf06059 :</b>		
<b>Name</b>	FrlfFrRelTimerRef {FRIF_FR_REL_TIMER}		
<b>Description</b>	Reference to a relative timer, which is handled by a specific FlexRay Driver. This reference is unique for the ECU, therefore, an explicit reference to the FlexRay Driver is not necessary.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrRelativeTimer		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

**No Included Containers**

### 10.2.8 FrlfFrameTriggering

<b>SWS Item</b>	<b>FRIF_FRAME_TRIGGERING :</b>		
<b>Container Name</b>	FrlfFrameTriggering		
<b>Description</b>	A Frame triggering contains the communication parameters of the FlexRay Frame as well as a reference to the Frame Construction Plan.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06049 :</b>		
<b>Name</b>	FrlfAllowDynamicLSduLength {FRIF_ALLOW_DYNAMIC_LSDU_LENGTH}		
<b>Description</b>	Allows L-PDU length reduction ('FrlfLSduLength' defines max. length) and indicates that the related CC buffer has to be reconfigured for the actual length and Header-CRC before transmission of the L-PDU.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06050 :</b>		
<b>Name</b>	FrlfAlwaysTransmit {FRIF_ALWAYS_TRANSMIT}		
<b>Description</b>	Defines whether the driver's API function Fr_TransmitTxLPdu() shall always be called for this L-PDU.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD

<b>Scope / Dependency</b>	scope: Module
---------------------------	---------------

<b>SWS Item</b>	<b>Frlf06051 :</b>		
<b>Name</b>	FrlfBaseCycle {FRIF_BASE_CYCLE}		
<b>Description</b>	This parameter contains the FlexRay Base Cycle used to transmit this FlexRay Frame.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 63		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06052 :</b>		
<b>Name</b>	FrlfChannel {FRIF_CHANNEL_ID}		
<b>Description</b>	This parameter contains the FlexRay Channel used to transmit this FlexRay Frame.		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	FRIF_CHANNEL_A	Channel A	
	FRIF_CHANNEL_AB	Channel A and B	
	FRIF_CHANNEL_B	Channel B	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06053 :</b>		
<b>Name</b>	FrlfCycleRepetition {FRIF_CYCLE_REPETITION}		
<b>Description</b>	This parameter contains the FlexRay Cycle Repetition used to transmit this FlexRay Frame.. possible Values: 1,2,4,8,16,32,64		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 64		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06054 :</b>		
<b>Name</b>	FrlfLSduLength {FRIF_LSDU_LENGTH}		
<b>Description</b>	The payload length of the Frame is given here. This parameter is required for validation if configured PDUs and update information fits into the Frame at configuration time [bytes].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 254		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

	dependency: The parameter depends on the low level parameters of the FlexRay CC.
--	--

<b>SWS Item</b>	<b>Frlf06050 :</b>		
<b>Name</b>	FrlfNoneMode {FRIF_NONE_MODE}		
<b>Description</b>	Using the "None-Mode" which means that there is no API Frlf_Transmit call of the upper layer for this PDU.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06055 :</b>		
<b>Name</b>	FrlfPayloadPreamble {FRIF_PAYLOADPREAMBLE_ID}		
<b>Description</b>	Switching the Payload Preamble bit.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06056 :</b>		
<b>Name</b>	FrlfSlotId {FRIF_SLOT_ID}		
<b>Description</b>	This parameter contains the FlexRay Slot ID used to transmit this FlexRay Frame.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	1 .. 2047		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06048 :</b>		
<b>Name</b>	FrlfFrameStructureRef {FRIF_FRAME_STRUCTURE}		
<b>Description</b>	Reference to the Construction Plan of the FlexRay Frame.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrlfFrameStructure		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

**No Included Containers**

### 10.2.9 FrlfJobList

<b>SWS Item</b>	<b>Frlf05367 :</b>		
<b>Container Name</b>	FrlfJobList{FRIF_JOBLIST}		

<b>Description</b>	This container specifies a list of all FlexRay Jobs of the Cluster to be performed by Frlf_JobListExec_<ClstIdx>().
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06063 :</b>		
<b>Name</b>	FrlfAbsTimerRef {FRIF_ABS_TIMER}		
<b>Description</b>	Reference to the absolute timer to be used to trigger the interrupt whose ISR contains the Frlf_JobListExec_<ClstIdx>() function.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrlfAbsTimer		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfJob	1..*	A job may contain more than one operation that are executed at a specific point in time.

### 10.2.10 FrlfJob

<b>SWS Item</b>	<b>Frlf05368 :</b>		
<b>Container Name</b>	FrlfJob{FRIF_JOB}		
<b>Description</b>	A job may contain more than one operation that are executed at a specific point in time.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06064 :</b>		
<b>Name</b>	FrlfCycle {FRIF_CYCLE}		
<b>Description</b>	The FlexRay Cycle in which the communication operation will execute this job		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 63		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06065 :</b>		
<b>Name</b>	FrlfMacrotick {FRIF_MACROTICK}		
<b>Description</b>	Macrotick offset in the Cycle [Macrotick]		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfCommunicationOperation	1..*	A separate operation which is part of a FlexRay Job and



	defines what type of action is executed.
--	--

### 10.2.11 FrlfCommunicationOperation

<b>SWS Item</b>	<b>Frlf05369 :</b>
<b>Container Name</b>	FrlfCommunicationOperation{FRIF_COMMUNICATION_OPERATION}
<b>Description</b>	A separate operation which is part of a FlexRay Job and defines what type of action is executed.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06067 :</b>	
<b>Name</b>	FrlfCommunicationAction {FRIF_COMMUNICATION_ACTION}	
<b>Description</b>	The action to be performed in the FlexRay Operation	
<b>Multiplicity</b>	1	
<b>Type</b>	EnumerationParamDef	
<b>Range</b>	DECOUPLED_TRANSMISSION	Decoupled transmission
	PREPARE_LPDU	Prepare message buffer of CC
	RECEIVE_AND_INDICATE	Immediate reception
	RECEIVE_AND_STORE	Decoupled reception
	RX_INDICATION	Reception indication
	TX_CONFIRMATION	Transmission confirmation
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X VARIANT-PRE-COMPILE
	<b>Link time</b>	--
	<b>Post-build time</b>	X VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module	

<b>SWS Item</b>	<b>Frlf06068 :</b>	
<b>Name</b>	FrlfCommunicationOperationIdx {FRIF_COMMUNICATION_OPERATION_IDX}	
<b>Description</b>	For each FlexRay Communication Job, this index spans a range of zero-based consecutive values and thus defines the order of the FlexRay Communication Operation in the respective FlexRay Communication Job.	
<b>Multiplicity</b>	1	
<b>Type</b>	IntegerParamDef	
<b>Default value</b>	--	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X VARIANT-PRE-COMPILE
	<b>Link time</b>	--
	<b>Post-build time</b>	X VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module	

<b>SWS Item</b>	<b>Frlf06066 :</b>	
<b>Name</b>	FrlfLPduldxRef	
<b>Description</b>	Reference to a L-PDU index	
<b>Multiplicity</b>	1	
<b>Type</b>	Reference to FrlfLPdu	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X VARIANT-PRE-COMPILE
	<b>Link time</b>	--
	<b>Post-build time</b>	X VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module	

**No Included Containers**

### 10.2.12 FrlfFrameStructure

<b>SWS Item</b>	<b>Frlf05370 :</b>
<b>Container Name</b>	FrlfFrameStructure{FRIF_FRAME_STRUCTURE}
<b>Description</b>	The Frame structure specifies a Construction Plan how a Frame is assembled with PDUs and their respective Update-Bits.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06113 :</b>		
<b>Name</b>	FrlfByteOrder {FRIF_BYTE_ORDER}		
<b>Description</b>	<p>This parameter defines the ByteOrder of all Pdus that are mapped into the Frame.</p> <p>The absolute position of a Pdu in the Frame is determined by the definition of the ByteOrder parameter: If BIG_ENDIAN is specified, the FrlfPduOffset indicates the position of the most significant bit in the Frame. If LITTLE_ENDIAN is specified, the FrlfPduOffset indicates the position of the least significant bit in the Frame.</p>		
<b>Multiplicity</b>	1		
<b>Type</b>	EnumerationParamDef		
<b>Range</b>	BIG_ENDIAN		
	LITTLE_ENDIAN		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfPduInFrame	1..*	This container holds all the information about a PDU in a FlexRay Frame.

### 10.2.13 FrlfPduInFrame

<b>SWS Item</b>	<b>Frlf05371 :</b>
<b>Container Name</b>	FrlfPduInFrame{FRIF_PDUS_IN_FRAME}
<b>Description</b>	This container holds all the information about a PDU in a FlexRay Frame.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06070 :</b>		
<b>Name</b>	FrlfPduOffset {FRIF_PDU_OFFSET}		
<b>Description</b>	The value specifies the offset of the PDU within the Frame [bytes].		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 253		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: This parameter depends on the number of PDUs contained in the Frame, PDU length, and Update-Bits of other PDUs in the Frame. In addition, if the Frame will be sent in static segment, this parameter depends on GPayloadLengthStatic.		

<b>SWS Item</b>	<b>Frlf06071 :</b>
<b>Name</b>	FrlfPduUpdateBitOffset {FRIF_PDU_UPDATE_BIT_OFFSET}
<b>Description</b>	This value specifies where the PDU's Update-Bit is stored in the Frame (bit

	location of PDU's Update-Bit in the FlexRay Frame).		
<b>Multiplicity</b>	0..1		
<b>Type</b>	IntegerParamDef		
<b>Range</b>	0 .. 2031		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module dependency: This parameter depends on the number of PDUs contained in the Frame, PDU length, and Update-Bits of other PDUs in the Frame. In addition, if the Frame will be sent in static segment, this parameter depends on GPayloadLengthStatic.		

<b>SWS Item</b>	<b>Frlf06069 :</b>		
<b>Name</b>	FrFrlfPduRef {FRIF_PDU}		
<b>Description</b>	This is the reference to the local definition of a PDU.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrlfPdu		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

**No Included Containers**

### 10.2.14 FrlfLPdu

<b>SWS Item</b>	<b>Frlf05364 :</b>		
<b>Container Name</b>	FrlfLPdu		
<b>Description</b>	LPdu is an abstraction of all FlexRay Frames (L-PDUs) belonging to the same Frame Triggering FrlfFrameTriggering.		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06058 :</b>		
<b>Name</b>	FrlfLPduldx {FRIF_LPDU_IDX}		
<b>Description</b>	This parameter identifies the L-PDU in the interaction between FlexRay Interface and FlexRay Driver.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06057 :</b>		
<b>Name</b>	FrlfVBTriggeringRef {FRIF_FRAME_TRIGGERING}		
<b>Description</b>	Reference to the assigned Frame triggering.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to FrlfFrameTriggering		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

**No Included Containers**

**10.2.15 FrlfPdu**

<b>SWS Item</b>	<b>Frlf05372 :</b>
<b>Container Name</b>	FrlfPdu{FRIF_PDU}
<b>Description</b>	Contains PDU information. A PDU may be either a transmission PDU or a reception PDU.
<b>Configuration Parameters</b>	

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfPduDirection	1	A PDU is either transmit or receive

**10.2.16 FrlfTxPdu**

<b>SWS Item</b>	<b>Frlf05374 :</b>
<b>Container Name</b>	FrlfTxPdu{FRIF_TX_PDU}
<b>Description</b>	This container specifies transmission PDUs.
<b>Configuration Parameters</b>	

<b>SWS Item</b>	<b>Frlf06075 :</b>		
<b>Name</b>	FrlfConfirm {FRIF_CONFIRM}		
<b>Description</b>	Defines whether the transmission of a PDU should be checked and confirmed to the PDU owning BSW module.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06076 :</b>		
<b>Name</b>	FrlfCounterLimit {FRIF_COUNTER_LIMIT}		
<b>Description</b>	This value states the maximum number of indication of ready PDU data to the Frlf (i.e. maximum number of invocations of Frlf_Transmit) without an intermediate transmission of the PDU.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06077 :</b>		
<b>Name</b>	FrlfImmediate		
<b>Description</b>	Defines whether the the PDU is transmitted immediate or decoupled.		
<b>Multiplicity</b>	1		
<b>Type</b>	BooleanParamDef		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Module		

<b>SWS Item</b>	<b>Frlf06078 :</b>		
<b>Name</b>	FrlfTxPduId {FRIF_TX_PDU_ID}		
<b>Description</b>	The global PDU identifier, which has to be used by the upper layer BSW module. The identifier has to be zero based and consecutive.		
<b>Multiplicity</b>	1		
<b>Type</b>	IntegerParamDef (Symbolic Name generated for this parameter)		
<b>Default value</b>	--		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: Frlf and PduR/FrNm/FrTp		

<b>SWS Item</b>	<b>Frlf06074 :</b>		
<b>Name</b>	FrlfPduRef {FRIF_PDU_REF}		
<b>Description</b>	Reference to the external PDU definition.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to Pdu		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

No Included Containers

### 10.2.17 FrlfRxPdu

<b>SWS Item</b>	<b>Frlf05373 :</b>		
<b>Container Name</b>	FrlfRxPdu{FRIF_RX_PDU}		
<b>Description</b>	Receive PDU		
<b>Configuration Parameters</b>			

<b>SWS Item</b>	<b>Frlf06073 :</b>		
<b>Name</b>	FrlfPduRef {FRIF_PDU_REF}		
<b>Description</b>	Reference to the external PDU definition.		
<b>Multiplicity</b>	1		
<b>Type</b>	Reference to Pdu		
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X	VARIANT-PRE-COMPILE
	<b>Link time</b>	--	
	<b>Post-build time</b>	X	VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU		

No Included Containers

### 10.2.18 FrlfPduDirection

<b>SWS Item</b>	<b>Frlf06072 :</b>		
<b>Choice Container Name</b>	FrlfPduDirection		
<b>Description</b>	A PDU is either transmit or receive		

<b>Container Choices</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfRxPdu	0..1	Receive PDU

FrlfTxPdu	0..1	This container specifies transmission PDUs.
-----------	------	---

### 10.2.19 FrlfTransceiver

<b>SWS Item</b>	<b>Frlf05391 :</b>	
<b>Container Name</b>	FrlfTransceiver{FRIF_TRANSCEIVER}	
<b>Description</b>	Up to two FlexRay Transceivers may connect a Controller to a Cluster. This container realizes a Controller-Transceiver assignment.	
<b>Configuration Parameters</b>		

<b>SWS Item</b>	<b>Frlf06062 :</b>	
<b>Name</b>	FrlfClusterChannel {FRIF_TRCV_CLUSTER_CHANNEL}	
<b>Description</b>	This parameter identifies to which one of the two Channels "A" or "B" of the Cluster the Transceiver is connected.	
<b>Multiplicity</b>	1	
<b>Type</b>	EnumerationParamDef	
<b>Range</b>	FRIF_CHANNEL_A	Channel A
	FRIF_CHANNEL_B	Channel B
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X VARIANT-PRE-COMPILE
	<b>Link time</b>	--
	<b>Post-build time</b>	X VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU	

<b>SWS Item</b>	<b>Frlf06061 :</b>	
<b>Name</b>	FrlfFrTrcvChannelRef {FRIF_TRCV_CHANNEL}	
<b>Description</b>	Reference to a Transceiver Driver Channel. This reference is unique for the ECU.	
<b>Multiplicity</b>	1	
<b>Type</b>	Reference to FrTrcvNode	
<b>ConfigurationClass</b>	<b>Pre-compile time</b>	X VARIANT-PRE-COMPILE
	<b>Link time</b>	--
	<b>Post-build time</b>	X VARIANT-POST-BUILD
<b>Scope / Dependency</b>	scope: ECU	

**No Included Containers**

### 10.2.20 FrlfConfig

<b>SWS Item</b>	<b>Frlf06001 :</b>	
<b>Container Name</b>	FrlfConfig [Multi Config Container]	
<b>Description</b>	Configuration of the FlexRay Interface. This container is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.	
<b>Configuration Parameters</b>		

<b>Included Containers</b>		
<b>Container Name</b>	<b>Multiplicity</b>	<b>Scope / Dependency</b>
FrlfCluster	1..*	This container specifies a Frlf Cluster and all related data which is required to enable communication of the Cluster. A Cluster may consist of more than one Controller.
FrlfFrameStructure	0..*	The Frame structure specifies a Construction Plan how a Frame is assembled with PDUs and their respective Update-Bits.
FrlfPdu	1..*	Contains PDU information. A PDU may be either a

	transmission PDU or a reception PDU.
--	--------------------------------------

### 10.3 Published Information

Published information contains data defined by the implementer of the SW module that does not change when the module is adapted (i.e. configured) to the actual HW/SW environment. It thus contains version and manufacturer information. In addition, the published information contains some [link time](#) configuration data that is needed by the configuration tools.

The standard common published information like

```
vendorId (<Module>_VENDOR_ID),  
moduleId (<Module>_MODULE_ID),  
arMajorVersion (<Module>_AR_MAJOR_VERSION),  
arMinorVersion (<Module>_AR_MINOR_VERSION),  
arPatchVersion (<Module>_AR_PATCH_VERSION),  
swMajorVersion (<Module>_SW_MAJOR_VERSION),  
swMinorVersion (<Module>_SW_MINOR_VERSION),  
swPatchVersion (<Module>_SW_PATCH_VERSION),  
vendorApiInfix (<Module>_VENDOR_API_INFIX)
```

is provided in the BSW Module Description Template (see [15] Figure 4.1 and Figure 7.1).

Additional published parameters are listed below if applicable for this module.



## 11 Changes during SWS Improvements by Technical Office

### 11.1 Deleted SWS Items

None

### 11.2 Replaced SWS Items

None

### 11.3 Changed SWS Items

None

### 11.4 Added SWS Items

<b>SWS Item</b>	<b>Rationale</b>
<a href="#">Frlf05001</a>	UML model linking of imported types
<a href="#">Frlf05002</a>	UML model linking of Frlf_GetVersionInfo
<a href="#">Frlf05003</a>	UML model linking of Frlf_Init
<a href="#">Frlf05004</a>	UML model linking of Frlf_ControllerInit
<a href="#">Frlf05005</a>	UML model linking of Frlf_StartCommunication
<a href="#">Frlf05006</a>	UML model linking of Frlf_HaltCommunication
<a href="#">Frlf05007</a>	UML model linking of Frlf_AbortCommunication
<a href="#">Frlf05008</a>	UML model linking of Frlf_RequestControllerStateTransition
<a href="#">Frlf05009</a>	UML model linking of Frlf_GetControllerState
<a href="#">Frlf05010</a>	UML model linking of Frlf_SetWakeupChannel
<a href="#">Frlf05011</a>	UML model linking of Frlf_SendWUP
<a href="#">Frlf05012</a>	UML model linking of Frlf_GetSyncState
<a href="#">Frlf05013</a>	UML model linking of Frlf_SetExtSync
<a href="#">Frlf05014</a>	UML model linking of Frlf_GetPOCStatus
<a href="#">Frlf05015</a>	UML model linking of Frlf_GetGlobalTime
<a href="#">Frlf05016</a>	UML model linking of Frlf_GetNmVector
<a href="#">Frlf05017</a>	UML model linking of Frlf_AllowColdstart
<a href="#">Frlf05018</a>	UML model linking of Frlf_GetMacroticksPerCycle
<a href="#">Frlf05019</a>	UML model linking of Frlf_ConvertNanosecToMacroticks
<a href="#">Frlf05020</a>	UML model linking of Frlf_ConvertMacroticksToNanosec
<a href="#">Frlf05021</a>	UML model linking of Frlf_SetAbsoluteTimer
<a href="#">Frlf05022</a>	UML model linking of Frlf_SetRelativeTimer
<a href="#">Frlf05023</a>	UML model linking of Frlf_CancelRelativeTimer
<a href="#">Frlf05024</a>	UML model linking of Frlf_CancelRelativeTimer
<a href="#">Frlf05025</a>	UML model linking of Frlf_EnableAbsoluteTimerIRQ
<a href="#">Frlf05026</a>	UML model linking of Frlf_EnableRelativeTimerIRQ
<a href="#">Frlf05027</a>	UML model linking of Frlf_GetAbsoluteTimerIRQStatus
<a href="#">Frlf05028</a>	UML model linking of Frlf_GetRelativeTimerIRQStatus
<a href="#">Frlf05029</a>	UML model linking of Frlf_AckAbsoluteTimerIRQ
<a href="#">Frlf05030</a>	UML model linking of Frlf_AckRelativeTimerIRQ
<a href="#">Frlf05031</a>	UML model linking of Frlf_DisableAbsoluteTimerIRQ
<a href="#">Frlf05032</a>	UML model linking of Frlf_DisableRelativeTimerIRQ
<a href="#">Frlf05033</a>	UML model linking of Frlf_Transmit
<a href="#">Frlf05034</a>	UML model linking of Frlf_SetTransceiverMode
<a href="#">Frlf05035</a>	UML model linking of Frlf_GetTransceiverMode

<a href="#">Frlf05036</a>	UML model linking of Frlf_GetTransceiverWUReason
<a href="#">Frlf05037</a>	UML model linking of Frlf_EnableTransceiverWakeup
<a href="#">Frlf05038</a>	UML model linking of Frlf_DisableTransceiverWakeup
<a href="#">Frlf05039</a>	UML model linking of Frlf_ClearTransceiverWakeup
<a href="#">Frlf05040</a>	UML model linking of Frlf_JobListExec <ClstIdx>
<a href="#">Frlf05041</a>	UML model linking of Frlf_Cbk_WakeupByTransceiver
<a href="#">Frlf05042</a>	UML model linking of Frlf_MainFunction_<ClstIdx>
<a href="#">Frlf05043</a>	UML model linking of mandatory interfaces
<a href="#">Frlf05044</a>	UML model linking of optional interfaces
<a href="#">Frlf05045</a>	UML model linking of <UL_RxIndication>
<a href="#">Frlf05046</a>	UML model linking of <UL_TxConfirmation>
<a href="#">Frlf05047</a>	UML model linking of <UL_TriggerTransmit>