

<b>Document Title</b>	Requirements on Network Management
<b>Document Owner</b>	AUTOSAR
<b>Document Responsibility</b>	AUTOSAR
<b>Document Identification No</b>	003
<b>Document Classification</b>	Auxiliary

<b>Document Version</b>	3.0.0
<b>Document Status</b>	Final
<b>Part of Release</b>	4.0
<b>Revision</b>	3

<b>Document Change History</b>			
<b>Date</b>	<b>Version</b>	<b>Changed by</b>	<b>Change Description</b>
04.10.2011	3.0.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Added support for Partial Networking</li> <li>Added support for NM Co-ordination on Nested Sub-buses</li> </ul>
30.11.2009	2.1.0	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Added the following New requirements                             <ol style="list-style-type: none"> <li>Compliance with non AUTOSAR-NMs</li> <li>Control of NM</li> <li>Bus Synchronization on Demand</li> </ol> </li> <li>Removed the following requirements                             <ol style="list-style-type: none"> <li>Compliance with OSEK NM on a gateway</li> <li>Compliance with OSEK NM on one cluster</li> </ol> </li> <li>Legal disclaimer revised</li> </ul>
23.06.2008	2.0.3	AUTOSAR Administration	Legal disclaimer revised
12.11.2007	2.0.2	AUTOSAR Administration	<ul style="list-style-type: none"> <li>Document meta information extended</li> <li>Small layout adaptations made</li> </ul>
24.01.2007	2.0.1	AUTOSAR Administration	<ul style="list-style-type: none"> <li>“Advice for users” revised</li> <li>“Revision Information” added</li> </ul>

<b>Document Change History</b>			
<b>Date</b>	<b>Version</b>	<b>Changed by</b>	<b>Change Description</b>
01.12.2006	2.0.0	AUTOSAR Administration	New requirements regarding: <ul style="list-style-type: none"><li>• Immediate Transmission Confirmation</li><li>• Configurable Role In Cluster Shutdown (Passive Node)</li><li>• ISO 14229 CommunicationControl (28 hex) service support</li></ul> Removed requirements regarding: <ul style="list-style-type: none"><li>• Bus independency</li><li>• Number of FlexRay hardware send/receive buffers</li><li>• Reading the local NM Identifier</li></ul> Legal disclaimer revised
30.06.2005	1.0.0	AUTOSAR Administration	Initial Release

## **Disclaimer**

This specification and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.  
For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

## **Advice for users**

AUTOSAR specifications may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the specifications for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such specifications, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

## Table of Contents

1	Scope of Document.....	6
2	Conventions to be used.....	7
3	Functional Overview .....	8
4	Requirement Specification.....	9
4.1	Functional Requirements .....	9
4.1.1	[BSW02517] Partial Networking .....	9
4.1.2	Configuration.....	9
4.1.2.1	[BSW150] Configuration of functionality.....	9
4.1.3	Initialization .....	10
4.1.3.1	[BSW151] Integration into running NM cluster .....	10
4.1.3.2	[BSW043] Bus Traffic without NM Initialization .....	10
4.1.4	Normal Operation.....	11
4.1.4.1	[BSW044] Applicability to different types of communication systems .....	11
4.1.4.2	[BSW02515] Compliance with non AUTOSAR-NMs.....	11
4.1.4.3	[BSW045] NM-cluster Independent Shutdown Coordination.....	11
4.1.4.4	[[BSW02513] Control of NM.....	12
4.1.4.5	[BSW046] Trigger of startup of all Nodes at any Point in Time ...	12
4.1.4.6	[BSW047] Bus Keep Awake Services.....	13
4.1.4.7	[BSW048] Bus Sleep Mode.....	13
4.1.4.8	[BSW050] NM State Information .....	13
4.1.4.9	[BSW051] NM State Change Indication .....	14
4.1.4.10	[BSW052] Notification that all other ECUs are ready to sleep.....	14
4.1.4.11	[BSW02509] Notification that at least one other node is not ready to sleep anymore .....	14
4.1.4.12	[BSW02503] Sending user data.....	15
4.1.4.13	[BSW02504] Receiving user data .....	15
4.1.4.14	[BSW153] Detection of present nodes .....	15
4.1.4.15	[BSW02508] Unambiguous node identification per bus .....	16
4.1.4.16	[BSW02505] Sending node identifier .....	16
4.1.4.17	[BSW02506] Receiving node identifier.....	16
4.1.4.18	[BSW02511] Configurable Role in Cluster Shutdown .....	17
4.1.5	Fault Operation .....	17
4.1.5.1	[BSW053] Deterministic Behavior in Case of Bus Unavailability..	17
4.1.5.2	[BSW137] Communication system error handling.....	18
4.1.6	Gateway Operation .....	18
4.1.6.1	[BSW02514] Coordination of coupled networks.....	18
4.1.6.2	[BSW02516] Bus Synchronization on demand .....	19
4.1.6.3	[BSW02535] NM coordination on Nested Sub-Buses .....	19
4.1.7	Partial Networking.....	20
4.1.7.1	[BSW02518] Distinguish between NM Message.....	20
4.1.7.2	[BSW02519] Cluster Request Information Bit .....	20
4.1.7.3	[BSW02520] Evaluate CRI bit .....	20
4.1.7.4	[BSW02521] Request for Partial Networking functionality.....	21

4.1.7.5	[BSW02522] Calculate the combined partial network request status EIRA .21	
4.1.7.6	[BSW02523] Calculate the status of the external partial network requests ERA.....	21
4.1.7.7	[BSW02524] Communicate EIRA and ERA requests to the upper layers	22
4.1.7.8	[BSW02525] Configuration for ERA .....	22
4.1.7.9	[BSW02526] Configuration for EIRA .....	22
4.2	Non-Functional Requirements (Qualities) .....	23
4.2.1	Timing Requirements .....	23
4.2.1.1	[BSW054] Deterministic Time for Bus Sleep.....	23
4.2.2	Resource Usage .....	23
4.2.2.1	[BSW142] Limitation of NM bus load .....	23
4.2.2.2	[BSW143] Predictable NM bus load.....	23
4.2.2.3	[BSW144] ECU cluster size .....	24
4.2.2.4	[BSW145] Robustness against NM message losses .....	24
4.2.2.5	[BSW146] Robustness against NM message jitter.....	24
4.2.2.6	[BSW147] Processor independent algorithm .....	25
4.2.2.7	[BSW149] Configurable Timing.....	25
4.2.3	Hardware independency .....	25
4.2.3.1	[BSW154] Bus independency of API.....	25
4.3	CAN Specific Requirements.....	26
4.3.1	Resource Usage .....	26
4.3.1.1	[BSW148] Separation of Communication system dependent parts .....	26
4.3.2	Transmission Confirmation .....	26
4.3.2.1	[BSW02510] Immediate Transmission Confirmation.....	27
4.3.3	Diagnostic Service .....	27
4.3.3.1	[BSW02512] CommunicationControl (28 hex) service support ....	27
4.3.4	Partial Networking.....	27
4.3.4.1	[BSW02527] Filter Algorithm.....	27
4.3.4.2	[BSW02528] Service for spontaneous sending of NM messages	28
4.3.4.3	[BSW02529] ECU sends Wakeup Frame as first message .....	28
4.3.4.4	[BSW02530] Optional channel-specific TX filter.....	28
4.3.4.5	[BSW02531] CanIf initiates clear and check wake-up flags in the transceiver	29
4.3.4.6	[BSW02532] Enable Pass Mode on the CanIf TX filter .....	29
4.3.4.7	[BSW02533] CanSm initiates clear and check wake-up flags in the transceiver	29
4.3.4.8	[BSW02534] PN Shutdown Sequence.....	30
4.4	FlexRay Specific Requirements .....	30
5	References .....	31
5.1	Deliverables of AUTOSAR .....	31
5.2	Related standards and norms .....	31
5.2.1	OSEK.....	31
5.2.2	HIS.....	31

## 1 Scope of Document

The goal of this document is to define the functional and non-functional requirements on the AUTOSAR Network Management.

### Requirements Guidelines

Existing specifications shall be referenced (in form of a single requirement). Differences to these specifications are specified as additional requirements.

All Requirements shall have the following properties:

- **Redundancy**  
Requirements shall not be repeated within one requirement or in other requirements
- **Clearness**  
All requirements shall allow one possibility of interpretation only. Only technical terms of the glossary may be used.
- **Atomicity**  
Each Requirement shall only contain one requirement. A Requirement is atomic if it cannot be split up in further requirements.
- **Testability**  
Requirements shall be testable by analysis, review or test.
- **Traceability**  
The source and status of a requirement shall be visible at all times.

### Constraints

First scope for specification of requirements on basic software modules are systems which are not safety relevant. For this reason safety requirements are assigned to medium priority.

## 2 Conventions to be used

Each requirement has its unique identifier starting with the prefix “BSW” (for “Basic Software”). For any review annotations, remarks or questions, please refer to this unique ID rather than chapter or page numbers!

Each module specific chapter contains a short functional description of the Basic Software Module. Requirements of the same kind within each chapter are grouped under the following headlines (where applicable):

Functional Requirements:

- Configuration (which elements of the module need to be configurable)
- Initialization
- Normal Operation
- Shutdown Operation
- Fault Operation
- ...

Non-Functional Requirements:

- Timing Requirements
- Resource Usage
- Usability
- Output for other WPs (e.g. Description Templates, Tooling,...)
- ...

### 3 Functional Overview

The following SRS covers requirements on following functional entities:

- Network Management coordinating a particular NM-cluster.
- Network Management bus specifics for a particular bus.
- Gateway and Interoperability of Network Management between NM-clusters.

The communication system where NM is applicable has to support a “bus sleep” mode. That means that the transceiver of the communication system can switch to a low power mode and can be switched again to full power mode by (specific) bus traffic and/or application



## 4 Requirement Specification

### 4.1 Functional Requirements

#### 4.1.1 [BSW02517] Partial Networking

<b>ID:</b>	BSW02517
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	Partial Networking
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<Bus>Nm shall support Partial Networking on CAN, FlexRay and Ethernet.
<b>Rationale:</b>	It is necessary to implement complete partial network support on the bus protocol <Bus>, to reduce the power consumption of <Bus> communication domains.
<b>Use Case:</b>	The power consumption can be reduced by e.g. <ul style="list-style-type: none"> <li>• Shutting down of seat control functions</li> <li>• Shutting down of park assistant functions</li> <li>• Hazard flashers</li> <li>• Shutting down of Electric Park Brake (EPB)</li> </ul>
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.2 Configuration

##### 4.1.2.1 [BSW150] Configuration of functionality

<b>ID:</b>	BSW150
<b>Initiator:</b>	FMC
<b>Date:</b>	20.08.2008
<b>Short Description:</b>	Configuration of functionality
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The following functions of the Network Management shall be statically configurable at pre-compile time: <ul style="list-style-type: none"> <li>– Detection of present nodes (on/off) – <a href="#">BSW153</a></li> <li>– Notification that all other ECUs are (no more) ready to sleep (i.e. Remote Sleep Indication (Cancellation)) (on/off) – <a href="#">BSW052</a>, <a href="#">BSW02509</a></li> <li>– NM Coordination support (on/off) – <a href="#">BSW02514</a></li> <li>– User data support (on/off) – <a href="#">BSW02503</a>, <a href="#">BSW02504</a></li> <li>– Bus load reduction (on/off) – <a href="#">BSW142</a></li> <li>– Sending node identifier (on/off) – <a href="#">BSW02505</a></li> <li>– Receiving node identifier (on/off) – <a href="#">BSW02506</a></li> <li>– Immediate Transmission Confirmation (on/off) - <a href="#">BSW02510</a></li> <li>– Configurable Role In Cluster Shutdown (on/off) - <a href="#">BSW02511</a></li> <li>– Bus Keep Awake Services (on/off) – <a href="#">BSW047</a></li> <li>– Partial Networking extensions (on/off) – <a href="#">BSW02517</a></li> <li>– EIRA (External and Internal Requests Aggregated) reset timer timeout – <a href="#">BSW02525</a> and <a href="#">BSW02526</a></li> </ul>
<b>Rationale:</b>	Scalability
<b>Use Case:</b>	Configuration of ECU SW
<b>Dependencies:</b>	--

<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.1.3 Initialization

#### 4.1.3.1 [BSW151] Integration into running NM cluster

<b>ID:</b>	BSW151
<b>Initiator:</b>	BMW
<b>Date:</b>	11.02.2004
<b>Short Description:</b>	Integration into running NM cluster
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The Network Management algorithm shall allow any node to integrate into an already running NM cluster.
<b>Rationale:</b>	Integration of <ul style="list-style-type: none"> <li>a) late nodes</li> <li>b) nodes that have recovered from fault state</li> <li>c) nodes that have been connected to a running vehicle network (e.g. by service)</li> </ul>
<b>Use Case:</b>	See rationale
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.3.2 [BSW043] Bus Traffic without NM Initialization

<b>ID:</b>	BSW043
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	NM shall not prohibit bus traffic with NM not being initialized
<b>Type:</b>	Changed after review in VCC (06.05.2004)
<b>Importance:</b>	High
<b>Description:</b>	It shall be possible that software modules are enabled to access the communication system, independent of the presence of NM (NM initialized or not).
<b>Rationale:</b>	Initialization delays or errors of NM shall not prohibit the communication of application software.
<b>Use Case:</b>	ECU without NM or NM starts later (see rationale)
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4 Normal Operation

##### 4.1.4.1 [BSW044] Applicability to different types of communication systems

<b>ID:</b>	BSW044
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	The NM shall be applicable to different types of communication systems which are in the scope of Autosar and support a bus sleep mode.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<p>Network management mechanisms for each supported protocol shall be realized using a limited number of predefined NM states and NM transitions. The events triggering the transitions between states and the actions taken on these transitions may be protocol specific. A bus sleep mode shall be supported for each protocol.</p> <p>NM shall be executable on asynchronous communication systems (e.g. CAN) as well as on synchronous communication systems (e.g. FlexRay), and also on any other types of communication systems which are in the scope of Autosar.</p>
<b>Rationale:</b>	In today's cars, multiple different communication systems are implemented. For energy consumption, all ECUs have to be able to switch into a low power mode. Therefore, network management is necessary for all communication systems. To facilitate understanding, NM shall be constructed from a common set of state definitions.
<b>Use Case:</b>	ECU with CAN and FlexRay
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

##### 4.1.4.2 [BSW02515] Compliance with non AUTOSAR-NMs

##### 4.1.4.3 [BSW045] NM-cluster Independent Shutdown Coordination

<b>ID:</b>	BSW02515
<b>Initiator:</b>	Release 4.0 Concept 065 by FMC
<b>Date:</b>	25.07.2008
<b>Short Description:</b>	NM shall offer a generic possibility to run other NMs than the AUTOSAR-NMs
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<p>Support for managing a non AUTOSAR-NM based network shall be done either by extending/modifying an existing bus-specific NM or by introducing a Complex Device Driver (CDD) which uses the generic interfaces of the NM.</p> <p>Support for running both one of the AUTOSAR-NM and a non AUTOSAR-NM on a single network shall be done the same way.</p> <p>The actual extensions or bus-specific NMs or CDDs is not specified by AUTOSAR.</p> <p>Can be used to support the old Use Cases of BSW139 and BSW140 which has been removed.</p>
<b>Rationale:</b>	--
<b>Use Case:</b>	Running OSEK-NM or another Legacy-NM on one of the networks.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	Introduced because of Feature BRF00256.
<b>Contributes to:</b>	--

<b>ID:</b>	BSW045
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	NM has to provide services to coordinate shutdown of NM-clusters independently of each other.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM has to provide services to coordinate shutdown of NM-clusters independently of each other.  Implementation hint: Instantiate NM multiple times and provide a coordinating module (e.g. ECU state manager).
<b>Rationale:</b>	In today's cars, multiple different communication systems are implemented. Therefore, ECUs might be connected to multiple communication channels (e.g. 2 CAN clusters, 1 FlexRay cluster, etc.). Not in all cases all channels have to be in full power mode. Because of that, each channel has to be able to be started up or shut down separately.
<b>Use Case:</b>	Gateways with more than one bus
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.4 [[BSW02513] Control of NM

<b>ID:</b>	[BSW02513
<b>Initiator:</b>	FMC
<b>Date:</b>	08.07.2008
<b>Short Description:</b>	NM shall provide functionality which enables upper layers to control the sleep mode.
<b>Type:</b>	Derived from BSW136
<b>Importance:</b>	High
<b>Description:</b>	NM shall provide an interface which enable upper layers to coordinate the different NM modes (especially sleep and wake-up/keep awake).
<b>Rationale:</b>	Enable control of NM from the upper layers. Enable the NM Coordinator to control multiple bus-specific NMs.
<b>Use Case:</b>	Control of NM NM Coordinator
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	Related requirement <a href="#">BSW02512</a> .
<b>Contributes to:</b>	--

#### 4.1.4.5 [BSW046] Trigger of startup of all Nodes at any Point in Time

<b>ID:</b>	BSW046
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	NM has to provide services to trigger a NM-startup of all nodes connected to a NM-cluster at any point in time.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	At a specific point in time all nodes connected to NM-cluster have to be started-up (e.g. if the car is started). Because of that NM has to provide services to start up NM of all nodes connected to a NM-cluster at any point in time. The point in time can not be calculated offline, therefore this service has to be accessible at any time.  Note regarding FlexRay networks: Under certain circumstances, a shutdown may be required before a startup can occur. In this situation substantial delays may occur.

<b>Rationale:</b>	All nodes means all nodes connected to clamp 30 (nodes permanently connected to power supply). ECUs connected to clamp 15 (nodes power supplied through some power relay) have to be treated separately, due to the fact that they cannot be started-up at any point in time. Note: "Passive Nodes" are not able to initiate a start-up of a NM-cluster, but they are able to be woken up if any other node initiates a start-up. Please refer <a href="#">BSW02511</a> .
<b>Use Case:</b>	Driver enters the car and wants to start the engine.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.6 [BSW047] Bus Keep Awake Services

<b>ID:</b>	BSW047
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	NM shall provide a service to request to keep the bus awake and a service to cancel this request.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The application implemented on one ECU must be enabled to signal at any point in time after the NM has been initialized, that it requests to keep the bus awake and at any other point in time want to cancel this request. These bus keep awake services shall not be available for nodes configured to not contribute to the cluster shutdown decision, refer <a href="#">BSW02511</a>
<b>Rationale:</b>	Basic NM functionality
<b>Use Case:</b>	See Rationale
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.7 [BSW048] Bus Sleep Mode

<b>ID:</b>	BSW048
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	Bus Sleep Mode
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	If no Application/ECU connected to a NM-cluster requires bus communication, NM shall indicate to put the communication controller into sleep mode.
<b>Rationale:</b>	Basic functionality
<b>Use Case:</b>	See Rationale
<b>Dependencies:</b>	<a href="#">[BSW047]</a>
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.8 [BSW050] NM State Information

<b>ID:</b>	BSW050
<b>Initiator:</b>	DC
<b>Date:</b>	12.01.2004
<b>Short Description:</b>	NM State Information
<b>Type:</b>	New
<b>Importance:</b>	High

<b>Description:</b>	The NM shall provide an interface to retrieve information about the current state of NM.
<b>Rationale:</b>	The application shall be able to get NM state information by accessing specific interfaces of NM. Basic functionality. The NM state reflects the state of the bus.
<b>Use Case:</b>	See Rationale
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.9 [BSW051] NM State Change Indication

<b>ID:</b>	BSW051
<b>Initiator:</b>	DC
<b>Date:</b>	12.01.2004
<b>Short Description:</b>	NM shall inform application when NM state changes occur.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM shall provide an interface, which can be used by applications to get informed when specific NM state changes occur.
<b>Rationale:</b>	Applications shall be enabled to react on state changes.
<b>Use Case:</b>	Especially the transition to sleep state to switch off transceiver is interesting.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.10 [BSW052] Notification that all other ECUs are ready to sleep.

<b>ID:</b>	BSW052
<b>Initiator:</b>	DC
<b>Date:</b>	12.01.2004
<b>Short Description:</b>	The NM interface shall signal to the application that all other ECUs are ready to sleep.
<b>Type:</b>	New
<b>Importance:</b>	Medium
<b>Description:</b>	NM shall provide an interface, which signals to an application that all other applications/ECUs are ready for sleep.
<b>Rationale:</b>	Prohibition of unintentional keep awake.
<b>Use Case:</b>	Internal check in the application if ECU unintentionally keeps the bus awake. External network management coordination.
<b>Dependencies:</b>	<a href="#">[BSW02509]</a>
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	Updated as a result of Feature BRF00256.
<b>Contributes to:</b>	--

#### 4.1.4.11 [BSW02509] Notification that at least one other node is not ready to sleep anymore

<b>ID:</b>	BSW02509
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	The NM interface shall signal to the application that at least one other ECUs is not ready to sleep anymore.
<b>Type:</b>	New
<b>Importance:</b>	Medium
<b>Description:</b>	NM shall provide an interface, which signals to an application that at least one other applications/ECUs is not ready for sleep anymore.
<b>Rationale:</b>	Notification that a bus is kept awake if necessary.

<b>Use Case:</b>	Identification of the last node that keeps the bus awake. External network management gateway coordination.
<b>Dependencies:</b>	<a href="#">[BSW052]</a>
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.12 **[BSW02503] Sending user data**

<b>ID:</b>	BSW02503
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	Sending user data
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM API shall optionally give the possibility to set the user data that may be attached to every NM message sent on the bus. NM shall guarantee data consistency for the write operation.
<b>Rationale:</b>	Exchange of system relevant information within the network.
<b>Use Case:</b>	Distribution of wakeup-reason in the network.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.13 **[BSW02504] Receiving user data**

<b>ID:</b>	BSW02504
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	Receiving user data
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM API shall optionally give the possibility to get the user data that may be attached to every NM message received from the bus. NM shall guarantee data consistency for the read operation.
<b>Rationale:</b>	Exchange of system relevant information within the network.
<b>Use Case:</b>	Distribution of wakeup-reason in the network.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.14 **[BSW153] Detection of present nodes**

<b>ID:</b>	BSW153
<b>Initiator:</b>	BMW
<b>Date:</b>	11.02.2004
<b>Short Description:</b>	Detection of present nodes
<b>Type:</b>	New
<b>Importance:</b>	Medium
<b>Description:</b>	The Network Management shall optionally provide a possibility to detect nodes that are currently present on the bus. It shall be possible that nodes, on request, send their NM-related data.  This feature is statically configurable (available or not) (see <a href="#">BSW150</a> ).  Comment: This function is only needed in master ECUs (e.g. head unit, central body controller, ...)
<b>Rationale:</b>	For diagnostics purposes and configuration checks.

<b>Use Case:</b>	The Vehicle State Management can use this information to check the completeness of the network.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.15 [BSW02508] Unambiguous node identification per bus

<b>ID:</b>	BSW02508
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	Unique node identification per NM-cluster.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	Every node shall have associated with it a node identifier that is unique in the NM-cluster.
<b>Rationale:</b>	Avoidance of node misidentification.
<b>Use Case:</b>	Identification of the last node that keeps the bus awake. Detection of present nodes.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.16 [BSW02505] Sending node identifier

<b>ID:</b>	BSW02505
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	Sending node identifier
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM shall optionally set the local node identifier to the NM-message..
<b>Rationale:</b>	Exchange of system relevant information within the network.
<b>Use Case:</b>	Identification of the last node that keeps the bus awake. Detection of present nodes.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.17 [BSW02506] Receiving node identifier

<b>ID:</b>	BSW02506
<b>Initiator:</b>	WP NM
<b>Date:</b>	15.11.2004
<b>Short Description:</b>	Receiving node identifier
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM API shall give the possibility to read the source node identifier of the sender from the most recently received NM message. NM shall guarantee data consistency for the read operation. Note: This NM API is optional, since it is optional to send the source node identifier.
<b>Rationale:</b>	Exchange of system relevant information within the network.
<b>Use Case:</b>	Identification of the last node that keeps the bus awake. Detection of present nodes.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--



<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.4.18 [BSW02511] Configurable Role in Cluster Shutdown

<b>ID:</b>	BSW02511
<b>Initiator:</b>	GM
<b>Date:</b>	03.05.2006
<b>Short Description:</b>	Configurable Role In Cluster Shutdown
<b>Type:</b>	New
<b>Importance:</b>	Medium
<b>Description:</b>	<p>It shall be possible to configure the Network Management of a node so that it cannot contribute to the cluster shutdown decision.</p> <p>Specifically, it shall be possible to configure some nodes of a cluster so that they are not able to broadcast the information used by other nodes to trigger shutdown, i.e., they have no NM-related communication defined for the node.</p> <p>Such nodes shall not be capable of keeping the bus awake, but they are required to shut down in a manner consistent with the others.</p>
<b>Rationale:</b>	<p>Eliminating unnecessary communication reduces bus and buffer overhead. Allowing shutdown to be controlled by a subset of the cluster's nodes enables the possibility that only fault tolerant nodes control shutdown. However, these nodes shall be otherwise capable of normal communication.</p>
<b>Use Case:</b>	<p>In a dual channel FlexRay cluster with some single channel nodes, the cluster can be configured so that only dual channel nodes influence the shutdown. This ensures that all shutdown votes are replicated on across channels even though some nodes are only connected to one channel, thus making the decision process robust against the loss of a channel.</p>
<b>Dependencies:</b>	<p>In order to avoid inconsistencies between and NM and the COM Manager, the COM Manager is not allowed to request keeping the bus awake.</p>
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.1.5 Fault Operation

#### 4.1.5.1 [BSW053] Deterministic Behavior in Case of Bus Unavailability

<b>ID:</b>	BSW053
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	Deterministic Behavior in Case of Bus Unavailability
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<p>NM on a node which is or become bus unavailable shall react such that:</p> <ul style="list-style-type: none"> <li>• If a bus becomes unavailable and the node is not ready to sleep, the NM shall not enter bus sleep mode by itself.</li> <li>• If a bus becomes unavailable and the node is ready to sleep, the NM shall enter bus sleep mode by itself.</li> <li>• If a bus is unavailable and the node changes its state to ready to sleep, the NM shall enter bus sleep mode by itself.</li> <li>• If a bus is unavailable and the node changes its state to not ready to sleep, the NM shall not enter bus sleep mode by itself.</li> </ul>
<b>Rationale:</b>	<p>Faults (transient and/or permanent) shall not cause non deterministic behavior.</p>
<b>Use Case:</b>	Bus unavailability (Bus Off), Loss of NM messages
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

**Note:**

The four rules in the description of [BSW053](#) will make sure that the NM of a node that is currently not in *bus sleep mode* will never enter *bus sleep mode* while the node itself is not ready to sleep. If the node itself is ready to sleep, the NM shall enter *bus sleep mode* on its own.

[BSW053](#) does not apply for a node that is already in *bus sleep mode*. In addition, bus unavailability may be hard to check at that time since the bus is not used to communicate in bus sleep mode.

**4.1.5.2 [BSW137] Communication system error handling**

<b>ID:</b>	BSW137
<b>Initiator:</b>	DC
<b>Date:</b>	20.01.2004
<b>Short Description:</b>	NM shall perform communication system error handling for errors that have impact on the NM behavior.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<p>If bus errors of a specific bus on which NM is running have impact on the NM behavior, the error handling must be performed by NM.</p> <p>Focus: bus errors, not protocol errors. Example: loss of NM message is handled.</p>
<b>Rationale:</b>	Error handling
<b>Use Case:</b>	Communication loss
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

**4.1.6 Gateway Operation**
**4.1.6.1 [BSW02514] Coordination of coupled networks**

<b>ID:</b>	BSW02514
<b>Initiator:</b>	FMC
<b>Date:</b>	08.07.2008
<b>Short Description:</b>	Coordination of NM on multiple networks in clusters
<b>Type:</b>	Derived from BSW 136
<b>Importance:</b>	High
<b>Description:</b>	<p>It shall be possible to group networks into <i>NM Coordination Clusters</i>. Each bus specific NM shall, by configuration, be part of 0 or 1 <i>NM Coordination Cluster</i>.</p> <p>NM shall provide functionality (<i>NM Coordination</i>) to coordinate the different NM modes (especially sleep and keep awake) on all networks in an <i>NM Coordination Cluster</i>, by performing a synchronized shutdown on all included networks.</p> <p>The level of synchronization is determined by the configuration of the shutdown synchronization algorithm.</p> <p>Specifically, it shall be possible to perform <i>NM Coordination</i> for each <i>NM Coordination Cluster</i> separately and independently.</p>
<b>Rationale:</b>	It shall be possible to perform coordinated and/or synchronized shutdown of multiple NM clusters independently.
<b>Use Case:</b>	NM Coordinator
<b>Dependencies:</b>	--

<b>Conflicts:</b>	--
<b>Supporting Material:</b>	Introduced because of Feature BRF00256.
<b>Contributes to:</b>	--

Note:

The definitions of *NM Coordination Cluster*, *NM Coordinator*, *Synchronize* and *Coordinate* are available in the AUTOSAR Glossary [4].

#### 4.1.6.2 [BSW02516] Bus Synchronization on demand

<b>ID:</b>	BSW02516
<b>Initiator:</b>	BMW
<b>Date:</b>	06.11.2008
<b>Short Description:</b>	Supporting coordination functionality with bus synchronization on demand
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	All AUTOSAR NM instances shall support the NM Coordinator functionality of the Generic NM Interface including Bus synchronization on demand. Bus Synchronization on demand allows for synchronization of an NM-cluster at an arbitrary point in time, meaning the NM-Timeout Timers in all nodes of the NM-cluster are restarted simultaneously.
<b>Rationale:</b>	Bus synchronization on demand allows synchronization of a NM-cluster for an arbitrary point of time; in result, NM-Timeout Timers in all nodes of the NM-cluster are restarted.
<b>Use Case:</b>	NM Coordinator
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	
<b>Contributes to:</b>	

#### 4.1.6.3 [BSW02535] NM coordination on Nested Sub-Buses

<b>ID:</b>	BSW02535
<b>Initiator:</b>	DC
<b>Date:</b>	02.09.2011
<b>Short Description:</b>	Supported of NM coordination on nested sub-busses
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	Extent the existing algorithm in a way that it allows to coordinate a second level of bus hierarchy, when shutting down coordinated busses. There is no limitation of hierarchy levels with this concept.
<b>Rationale:</b>	The network management stack allows to have a coordinated shutdown of more than one bus if an ECU exists which is connected to the busses which are to be coordinated. The functionality is included in the NmIf module. However, there are currently two limitations 1. If a sub-bus exists on a coordinated bus, which is connected by a gateway, this sub-bus can currently not be added to the list of coordinated busses, because the algorithm only handles one level. As a result, a coordinated bus may shut down, but connected sub busses may still be active. 2. The functionality is not reliable, because, if the coordinating ECU fails, the busses will no longer be coordinated and act on their own; that is, they will – if no node is active – shut down independently. This concept intent to fix these shortcomings.
<b>Use Case:</b>	Nested Gateways
<b>Dependencies:</b>	--

<b>Conflicts:</b>	--
<b>Supporting Material:</b>	
<b>Contributes to:</b>	

#### 4.1.7 Partial Networking

##### 4.1.7.1 [BSW02518] Distinguish between NM Message

<b>ID:</b>	BSW02518
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall be able to distinguish between an NM message without PN request information (CRI = Cluster Request Information) and an NM message with PN CRI contained in the NM user data.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	If Partial Networking is supported, NM shall distinguish between NM message without PN request information and NM message with PN CRI.
<b>Rationale:</b>	This is required to assure the compatibility between carry over parts from current vehicle platforms and new ECUs with Partial Networking. Current ECUs may not send NM messages with PN request information
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

##### 4.1.7.2 [BSW02519] Cluster Request Information Bit

<b>ID:</b>	BSW02519
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	The NM Control Bit Vector shall contain a CRI (Cluster Request Information) bit.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM Control Bit Vector shall contain a CRI (Cluster Request Information) bit with the following meaning: 0: NM message does not contain PN request information 1: NM message contains PN request information (CRI)
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

##### 4.1.7.3 [BSW02520] Evaluate CRI bit

<b>ID:</b>	BSW02520
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall evaluate the CRI bit in the NM message
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM shall evaluate the CRI bit in the NM message; If CRI bit is Set, the partial networking information shall be evaluated from the message.
<b>Rationale:</b>	--

<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.4 [BSW02521] Request for Partial Networking functionality

<b>ID:</b>	BSW02521
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall set the CRI bit for requesting Partial Network functionality
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	While sending NM message, NM will set the CRI bit to request partial networking functionality.
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.5 [BSW02522] Calculate the combined partial network request status EIRA

<b>ID:</b>	BSW02522
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall calculate the combined partial network request status EIRA
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM shall calculate the combined partial network request status EIRA (External and Internal Requests Aggregated) for each partial network relevant to the ECU. The calculation shall use a configurable time constant for resetting EIRA requests.
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.6 [BSW02523] Calculate the status of the external partial network requests ERA

<b>ID:</b>	BSW02523
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall calculate the status of the external partial network requests ERA
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<Bus>Nm shall calculate the status of the external partial network requests ERA (External Requests Aggregated) for each partial network relevant to the ECU. The calculation shall use a configurable time constant for resetting ERA requests.
<b>Rationale:</b>	--

<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.7 [BSW02524] Communicate EIRA and ERA requests to the upper layers

<b>ID:</b>	BSW02524
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall communicate EIRA and ERA requests to the upper layers using virtual PDUs
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM shall communicate EIRA and ERA requests to the upper layers using virtual PDUs (not contained in the System Description but generated during Ecu configuration)
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.8 [BSW02525] Configuration for ERA

<b>ID:</b>	BSW02525
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall support channel-specific configuration for ERA
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<Bus>Nm shall support channel-specific configuration for ERA
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.1.7.9 [BSW02526] Configuration for EIRA

<b>ID:</b>	BSW02526
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	<Bus>Nm shall support a global configuration for EIRA over all channels
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	<Bus>Nm shall support a global configuration for EIRA over all channels
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--

<b>Contributes to:</b>	--
------------------------	----

## 4.2 Non-Functional Requirements (Qualities)

### 4.2.1 Timing Requirements

#### 4.2.1.1 [BSW054] Deterministic Time for Bus Sleep

<b>ID:</b>	BSW054
<b>Initiator:</b>	DC
<b>Date:</b>	09.01.2004
<b>Short Description:</b>	There shall be a deterministic time from the point where all nodes agree to go to bus sleep to the point where bus is switched off.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The time required from the point in time when the NM of each ECU agree on shutting down a communication system and the point in time when the communication system is really shutting down, has to be deterministic (guarantee of min time and max time). This time must be statically configurable cluster.
<b>Rationale:</b>	Determinism of network behavior, guarantee of synchronized sleep-mode
<b>Use Case:</b>	See Rationale
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.2.2 Resource Usage

#### 4.2.2.1 [BSW142] Limitation of NM bus load

<b>ID:</b>	BSW142
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	NM shall guarantee an upper limit for the bus load generated by NM itself.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	NM shall not exceed a specified upper limit of bus load. This bus load has to be specified.  Example: 3% in normal operation, 6% Bus load peak.
<b>Rationale:</b>	Determinism
<b>Use Case:</b>	Avoid solution like in OSEK NM 2.5.3: alive messages after bus wakeup
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.2 [BSW143] Predictable NM bus load

<b>ID:</b>	BSW143
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	The bus load caused by NM shall be predictable.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The bus load caused by NM shall be predictable. The bus load for normal

	operation (no error occurred) has to be specified or calculable (dependent on the timing).
<b>Rationale:</b>	Predictability
<b>Use Case:</b>	Prediction of bus load for NM on the specific bus
<b>Dependencies:</b>	<a href="#">BSW149</a>
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.3 [BSW144] ECU cluster size

<b>ID:</b>	BSW144
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	ECU cluster size
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	Communication clusters of up to 64 ECUs / controllers shall be supported by NM.
<b>Rationale:</b>	Flexibility
<b>Use Case:</b>	See Rationale
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.4 [BSW145] Robustness against NM message losses

<b>ID:</b>	BSW145
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	Robustness against NM message losses.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	On a properly configured node, NM shall tolerate a loss of a predefined number of NM messages. The limitations of the number of message losses have to be described in the specification.
<b>Rationale:</b>	Robustness: There shall be no need for NM to receive every NM message. A loss of one message (in case of bursts) shall have no impact on the NM behaviour.
<b>Use Case:</b>	Loss of NM-message(s) must be tolerated
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.5 [BSW146] Robustness against NM message jitter

<b>ID:</b>	BSW146
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	Robustness against NM message jitter.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM shall tolerate a time jitter of NM messages in one or more ECUs. The limitations of the jitter have to be described in the specification.
<b>Rationale:</b>	Robustness
<b>Use Case:</b>	Jitter of NM-message(s) must be tolerated
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--



<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.6 [BSW147] Processor independent algorithm

<b>ID:</b>	BSW147
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	The NM algorithm shall be processor independent.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The algorithm of NM shall not rely on processor specific mechanisms. It shall be realizable on every processor architecture.
<b>Rationale:</b>	Re-use
<b>Use Case:</b>	Usage of NM on different processor architectures
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.2.2.7 [BSW149] Configurable Timing

<b>ID:</b>	BSW149
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	The timing of NM shall be configurable.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	All timing parameters of the NM (e.g., the cycle timing of message sent on the communication media) shall be configurable. NM Implementation shall support at least one of the following strategies: - pre-compile or - post-compile or - post build. SWS shall define which of parameters are cluster specific and which are node specific.
<b>Rationale:</b>	Flexibility
<b>Use Case:</b>	1. Time until network is shut down after all nodes have indicated that they are ready to sleep. 2. Time interval between two consecutive status indications of a node, whether it is ready to sleep or not. 3. Determination of timing depending on the configurable number of nodes.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.2.3 Hardware independency

#### 4.2.3.1 [BSW154] Bus independency of API

<b>ID:</b>	BSW154
<b>Initiator:</b>	BMW
<b>Date:</b>	11.02.2004
<b>Short Description:</b>	Bus independency of API.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The Network Management API shall be independent from the communication bus i.e. equal for CAN and FlexRay.
<b>Rationale:</b>	Common, standardized interface to application and ECU state manager.

<b>Use Case:</b>	Usage of NM on different types of bus; only one interface independent of the underlying bus architecture.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

## 4.3 CAN Specific Requirements

### 4.3.1 Resource Usage

#### 4.3.1.1 [BSW148] Separation of Communication system dependent parts

<b>ID:</b>	BSW148
<b>Initiator:</b>	DC
<b>Date:</b>	05.02.2004
<b>Short Description:</b>	Separation of Communication system dependent parts.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The specification and implementation shall be split-up into a communication system independent and communication system dependent parts (the communication system dependent parts shall be based on the communication system abstraction).
<b>Rationale:</b>	Re-use
<b>Use Case:</b>	CAN NM Software Architecture (AUTOSAR SC decision from Apr 25th, 2006).
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.3.2 Transmission Confirmation

#### 4.3.2.1 [BSW02510] Immediate Transmission Confirmation

<b>ID:</b>	BSW02510
<b>Initiator:</b>	FMC (WP NM)
<b>Date:</b>	16.03.2006
<b>Short Description:</b>	Immediate Transmission Confirmation
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	For CAN NM it shall be optionally possible that the NM message transmission confirmation is generated at the transmission request to the CAN Interface layer.
<b>Rationale:</b>	If the bus access is completely regulated through an offline system design tool, the actual transmit confirmation to inform the Nm about a successful transmission can be regarded as redundant. Since the maximum arbitration time is known it is acceptable to immediately raise the confirmation at the transmission request time. Moreover, implementation of superfluous actual transmission confirmation in such a system only for one NM message would mean a significant performance loss regarding the execution time of the overall CAN Interface/Driver layer making the calculated time schedule inefficient.
<b>Use Case:</b>	Usage of CAN NM in a deterministic bus system.
<b>Dependencies:</b>	--
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.3.3 Diagnostic Service

#### 4.3.3.1 [BSW02512] CommunicationControl (28 hex) service support

<b>ID:</b>	BSW02512
<b>Initiator:</b>	WP NM
<b>Date:</b>	04.09.2006
<b>Short Description:</b>	CommunicationControl (28 hex) service support
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	The NM shall give the possibility to enable or disable the network management related communication configured for an active NM node. By default network management related communication shall be enabled.
<b>Rationale:</b>	Conformance to ISO 14229 CommunicationControl (28 hex) service
<b>Use Case:</b>	Diagnostics
<b>Dependencies:</b>	BSW02511
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

### 4.3.4 Partial Networking

#### 4.3.4.1 [BSW02527] Filter Algorithm

<b>ID:</b>	BSW02527
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanNm shall implement a filter algorithm dropping all NM messages that are not relevant for the ECU
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanNm shall implement a filter algorithm dropping all NM messages that are

	not relevant for the ECU. The algorithm uses the Partial Network request information included with CAN NM.
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.2 [BSW02528] Service for spontaneous sending of NM messages

<b>ID:</b>	BSW02528
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanNm shall provide a service which allows for spontaneous sending of NM messages.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanNm shall provide a service which allows for spontaneous sending of NM messages.
<b>Rationale:</b>	A PN request originating from the ECU needs to be sent out as fast as possible to avoid long latency
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.3 [BSW02529] ECU sends Wakeup Frame as first message

<b>ID:</b>	BSW02529
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	If partial networking is used, the ECU shall secure that the first message on the bus is the wakeup frame.
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	If partial networking is used, the ECU shall secure that the first message on the bus is the wakeup frame. This requirement will be implemented in CanIf.
<b>Rationale:</b>	If all ECUs on the bus use partial networking, they use the CAN transceiver with the partial networking extensions. These transceivers only wake up after receiving the Wakeup Frame.
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.4 [BSW02530] Optional channel-specific TX filter

<b>ID:</b>	BSW02530
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanIf shall provide an optional channel-specific TX filter
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanIf shall provide an optional channel-specific TX filter. In blocking mode, the filter shall only pass transmission of wakeup frames. In pass mode the

	filter shall pass every PDU transmitted by an upper layer.
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.5 [BSW02531] CanIf initiates clear and check wake-up flags in the transceiver

<b>ID:</b>	BSW02531
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanIf shall provide the possibility to initiate clear and check wake-up flags in the transceiver
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanIf shall provide the possibility to initiate clear and check wake-up flags in the transceiver
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.6 [BSW02532] Enable Pass Mode on the CanIf TX filter

<b>ID:</b>	BSW02532
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	When full communication is requested, CanSm shall enable pass mode on the CanIf TX filter
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	When full communication is requested, CanSm shall enable pass mode on the CanIf TX filter
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.7 [BSW02533] CanSm initiates clear and check wake-up flags in the transceiver

<b>ID:</b>	BSW02533
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanSm shall provide the possibility to initiate clear and check wake-up flags in the transceiver
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanSm shall provide the possibility to initiate clear and check wake-up flags in the transceiver

<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

#### 4.3.4.8 [BSW02534] PN Shutdown Sequence

<b>ID:</b>	BSW02534
<b>Initiator:</b>	All
<b>Date:</b>	15.03.2011
<b>Short Description:</b>	CanSm shall support a new PN shutdown sequence
<b>Type:</b>	New
<b>Importance:</b>	High
<b>Description:</b>	CanSm shall support a new PN shutdown sequence (CAN CC STOP -> CAN TRCV STANBY -> CAN CC SLEEP)
<b>Rationale:</b>	--
<b>Use Case:</b>	--
<b>Dependencies:</b>	BSW02517
<b>Conflicts:</b>	--
<b>Supporting Material:</b>	--
<b>Contributes to:</b>	--

## 4.4 FlexRay Specific Requirements

None.

## 5 References

### 5.1 Deliverables of AUTOSAR

[1] Layered Software Architecture  
AUTOSAR\_EXP\_LayeredSoftwareArchitecture.pdf

[2] General Requirements on Basic Software Modules  
AUTOSAR\_SRS\_BSWGeneral.pdf

[3] Specification of the Virtual Functional Bus  
AUTOSAR\_EXP\_VFB.pdf

[4] AUTOSAR Glossary  
AUTOSAR\_TR\_Glossary.pdf

Layered Software Architecture  
AUTOSAR\_EXP\_LayeredSoftwareArchitecture.pdf

Requirements on Basic Software Modules  
AUTOSAR\_SRS\_BSWGeneral.pdf

[DOC\_VFB] Specification of the Virtual Functional Bus  
AUTOSAR\_EXP\_VFB.pdf

Feature Specification of the BSW Architecture and the RTE  
AUTOSAR\_TR\_BSWAndRTEFeatures

### 5.2 Related standards and norms

#### 5.2.1 OSEK

[5] [\[STD\\_OSEK\\_NM\]](#)  
OSEK/VDX NM Specification (ISO 17356-5), Version 2.5.3

[STD\_OSEK\_NM] OSEK/VDX NM Specification (ISO 17356-5), V2.5.3  
<http://www.osek-vdx.org/>

#### 5.2.2 HIS

[5] [\[HIS\\_NM\\_RQMT\]](#)  
HIS NM Requirements

[HIS\_NM\_RQMT] HIS NM Requirements  
<http://www.automotive-his.de/>