

Document Title	Specification of LIN State Manager
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	255
Document Classification	Standard

Document Version	1.3.0
Document Status	Final
Part of Release	4.0
Revision	3

Document Change History			
Date	Version	Changed by	Change Description
02.11.2011	1.3.0	AUTOSAR Administration	<ul style="list-style-type: none"> • Added post-build configuration support • Added completion of Production error concept in Com Stack • Removed local network index
13.10.2010	1.2.0	AUTOSAR Administration	<ul style="list-style-type: none"> • Post-build configuration variant added • Module version check changed according SRS_General BSW004 • TrcvModeType definition moved from LinIf to LinTrcv
10.12.2009	1.1.0	AUTOSAR Administration	<ul style="list-style-type: none"> • Controlling of I-PDU groups has been moved to the BSW Mode Manager module • Interface to the LIN Transceiver module has been introduced since LIN Transceiver driver is a new module in release 4.0 • Legal disclaimer revised
23.06.2008	1.0.1	AUTOSAR Administration	Legal disclaimer revised
03.12.2007	1.0.0	AUTOSAR Administration	Initial Release

Disclaimer

This specification and the material contained in it, as released by AUTOSAR is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the specification.

The material contained in this specification is protected by copyright and other types of Intellectual Property Rights. The commercial exploitation of the material contained in this specification requires a license to such Intellectual Property Rights.

This specification may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only.
For any other purpose, no part of the specification may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The AUTOSAR specifications have been developed for automotive applications only. They have neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.

Advice for users

AUTOSAR Specification Documents may contain exemplary items (exemplary reference models, "use cases", and/or references to exemplary technical solutions, devices, processes or software).

Any such exemplary items are contained in the Specification Documents for illustration purposes only, and they themselves are not part of the AUTOSAR Standard. Neither their presence in such Specification Documents, nor any later documentation of AUTOSAR conformance of products actually implementing such exemplary items, imply that intellectual property rights covering such exemplary items are licensed under the same rules as applicable to the AUTOSAR Standard.

Table of Contents

1	Introduction and functional overview	6
1.1	Architectural overview	6
1.2	Functional overview.....	7
2	Acronyms and abbreviations	8
3	Related documentation.....	9
3.1	Input documents.....	9
3.2	Related standards and norms	9
4	Constraints and assumptions	10
4.1	Limitations	10
4.2	Applicability to car domains.....	10
5	Dependencies to other modules.....	11
5.1	Relation to Upper layers.....	12
5.1.1	Operating System	12
5.1.2	Module DET (Development Error Tracer)	13
5.1.3	Module DEM (Diagnostic Event Manager)	13
5.1.4	ComM	13
5.1.5	BSW Mode Manager.....	13
5.2	Relation to Lower layers.....	13
5.2.1	LinIf	13
5.3	File structure	14
5.3.1	Code file structure	14
5.3.2	Header File structure.....	14
5.3.2.1	LinSM header files.....	14
5.3.2.2	Included header files	15
6	Requirements traceability	17
7	Functional specification	21
7.1	States and transitions of the LinSM state machine.....	21
7.1.1	LINSM_UNINIT	22
7.1.2	LINSM_INIT	22
7.1.3	LINSM_NO_COM	23
7.1.4	LINSM_FULL_COM	24
7.1.5	Goto sleep.....	25
7.1.6	Changing schedule table.....	26
7.1.7	Wake up process	26
7.1.8	Timeout of requests	27
7.2	Handling multiple networks and drivers.....	28
7.2.1	Multiple networks	28
7.3	Error classification	29
7.4	Error detection.....	30
7.5	Error notification	30
7.6	Debugging.....	30
8	API specification.....	32

8.1	Imported types.....	32
8.1.1	Standard types	32
8.2	Type definitions	32
8.2.1	LinSM_ModeType	32
8.2.2	LinSM_ConfigType.....	32
8.3	LinSM API	33
8.3.1	LinSM_Init	33
8.3.2	LinSM_ScheduleRequest.....	33
8.3.3	LinSM_GetVersionInfo	34
8.3.4	LinSM_GetCurrentComMode.....	35
8.3.5	LinSM_RequestComMode	36
8.4	Scheduled Functions.....	37
8.4.1	LinSM_MainFunction	38
8.5	LinSM callbacks	38
8.5.1	LinSM_ScheduleRequestConfirmation	38
8.5.2	LinSM_GotoSleepConfirmation.....	39
8.5.3	LinSM_WakeupConfirmation.....	40
8.6	Mandatory Interfaces.....	40
8.7	Optional Interfaces	41
8.8	Configurable Interfaces	41
9	Sequence diagrams	42
9.1	Goto-sleep process	43
9.2	Internal wake up.....	44
9.3	Schedule switch	45
10	Configuration specification	47
10.1	How to read this chapter	47
10.1.1	Configuration and configuration parameters	47
10.1.2	Containers.....	47
10.1.3	Specification template for configuration parameters	47
10.2	Containers and configuration parameters	48
10.2.1	Configuration Tool.....	48
10.2.2	Variants.....	48
10.2.2.1	VARIANT-PRE-COMPILE	49
10.2.2.2	VARIANT-LINK-TIME	49
10.2.2.3	VARIANT-POST_BUILD.....	49
10.3	LinSM_Configuration.....	49
10.3.1	LinSM.....	49
10.3.2	LinSMConfigSet	49
10.3.3	LinSMChannel.....	50
10.3.4	LinSMGeneral	51
10.3.5	LinSMSchedule	52
10.4	Published Information.....	53
11	Changes between Release 3.0/3.1 and 4.0	54
11.1	Deleted SWS Items	54
11.2	Changed SWS Items.....	54
11.3	Added SWS Items	54
12	Not applicable requirements.....	56

1 Introduction and functional overview

This specification specifies the functionality, API and the configuration of the AUTOSAR Basic Software module LIN State Manager (LinSM). The LinSM together with the LIN Interface, LIN driver, LIN Transceiver driver forms the complete LIN protocol.

The LIN State Manager is designed to be hardware independent.

The LinSM is dependent on upper module Communication Manager [11] (ComM) and lower module LIN Interface [7] (LinIf).

It is assumed that the reader is familiar with the LIN 2.1 specification [13]. This document will not describe functionality already described in the LIN 2.1 specification [13].

Note that figures in this document are not regarded as requirements. All requirements are described in text prefixed with a requirement tag (e.g. LINSM042). Text not prefixed with a requirement shall be seen as informative text.

1.1 Architectural overview

The Layered Software Architecture [1] positions the LinSM within the BSW architecture as shown below.




Figure 1 – AUTOSAR BSW software architecture - LIN stack scope

1.2 Functional overview

The LinSM is responsible for the control flow of the LIN Bus.

This means:

- Switching schedule tables when requested by the upper layer(s).
- Go to sleep and wake up handling, when requested by the upper layer(s)
- Notification to upper layers when new state is entered.

2 Acronyms and abbreviations

Acronyms and abbreviations used in this document. Additional abbreviations can be found in the LIN 2.1 specification [13].

Abbreviation / Acronym:	Description:
API	Application Program Interface
AUTOSAR	Automotive Open System Architecture
BSW	Basic Software
BswM	BSW Mode Manager
ComM	Communication Manager
DCM	Diagnostic Communication Manager
DEM	Diagnostic Event Manager
DET	Development Error Tracer
ECU	Electric Control Unit
ID	Identifier
ISR	Interrupt Service Routine
Jitter	Difference between longest delay and shortest delay (e.g. Worst case execution time – Best case execution time)
LIN	Local Interconnect Network
LinIf	LIN Interface
LinSM	LIN State Manager (the subject of this document)
MCAL	Microcontroller Abstraction Layer
PDU	Protocol Data Unit
RAM	Random Access memory
RTE	Run Time Environment
RX	Receive
SPAL	Standard Peripheral Abstraction Layer
SRS	Software Requirement Specification
SW	Software
SWS	Software Design Specification
TP	Transport Protocol
TX	Transmit
UART	Universal Asynchronous Receiver Transmitter
UML	Universal Modelling Language
URL	Uniform Resource Locator
WP11	Work Package in AUTOSAR phase 2
XML	Extensible Markup Language

3 Related documentation

3.1 Input documents

- [1] List of Basic Software Modules
AUTOSAR_TR_BSWModuleList.pdf
- [2] Layered Software Architecture,
AUTOSAR_EXP_LayeredSoftwareArchitecture.pdf
- [3] General Requirements on Basic Software Modules
AUTOSAR_SRS_BSWGeneral.pdf
- [4] Specification of Standard Types
AUTOSAR_SWS_StandardTypes.pdf
- [5] Specification of Development Error Tracer
AUTOSAR_SWS_DevelopmentErrorTracer.pdf
- [6] Requirements on LIN
AUTOSAR_SRS_LIN.pdf
- [7] Specification of LIN Interface
AUTOSAR_SWS_LINInterface.pdf
- [8] Specification of Diagnostic Event Manager
AUTOSAR_SWS_DiagnosticEventManager.pdf
- [9] Specification of ECU Configuration
AUTOSAR_TPS_ECUConfiguration.pdf
- [10] Specification of LIN Driver
AUTOSAR_SWS_LINDriver.pdf
- [11] Specification of Communication Manager
AUTOSAR_SWS_COMManager.pdf
- [12] Specification of Basic Software Mode Manager
AUTOSAR_SWS_BSWModeManager.pdf

3.2 Related standards and norms

- [13] LIN Specification Package Revision 2.1, September 23, 2003
<http://www.lin-subbus.org/>

4 Constraints and assumptions

4.1 Limitations

The LinSM module can only be used as a LIN master in a LIN cluster. There is at most one instance of the LinSM in each ECU. If the underlying LIN Driver [10] supports multiple networks, the LinSM may be master on more than one cluster.

4.2 Applicability to car domains

This specification is applicable to all car domains, where LIN is used.

5 Dependencies to other modules

This section describes the relations to other modules within the basic software. It describes the services that are used from these modules. Figure 2 shows the modules that are required or optional for the realization of the LinSM module. The figure is complete but is not regarded as requirement.

To be able for the LinSM module to operate the following modules will be interfaced:

[LINSM001] [LIN Interface – LinIf] (BSW00384)

[LINSM085] [Diagnostic Event Manager – DEM] (BSW00384)

[LINSM086] [Development Error Tracer (if enabled) – DET] (BSW00384)

[LINSM105] [Communication Manager – ComM] (BSW00384)

[LINSM196] [BSW Mode Manager - BswM] (BSW00384)

Note that modules that are using the interface (except callbacks) from this module are not listed.




Figure 2 Dependencies to other modules

5.1 Relation to Upper layers

In principle, there is no requirement that specific modules shall call the interfaces of the LinSM module. Below, the normal users of LinSM module are listed.

5.1.1 Operating System

The LinSM module does not contain access of shared data with above or below modules (using the API). The data that is shared will not need a help of the OS to protect the data for consistency (there are no array accesses, only simple type accesses). However, there may be reentrant functions that access the same data in the LinSM module. It is up to the implementer to solve these accesses.

5.1.2 Module DET (Development Error Tracer)

In development mode the Det_ReportError – function of module DET [5] will be called.

5.1.3 Module DEM (Diagnostic Event Manager)

Production errors will be reported to the Diagnostic Event Manager [8] module.

5.1.4 ComM

The Com manager module requests the communication via the LIN stack and queries the state of the LinSM module.

5.1.5 BSW Mode Manager

The LinSM module will notify the BSW Mode Manager module [12] when a state is changed. The BSW Mode Manager module will interface the LinSM module when requesting a new schedule table.

5.2 Relation to Lower layers

Below are the BSW modules that will be interfaced by LinSM module.

5.2.1 LinIf

The LinSM module assumes the following primitives to be provided by the LinIf [7] module:

- Transmission of the goto-sleep command (LinIf_GoToSleep)
- The wakeup of the Lin bus (LinIf_Wakeup)
- Request to change schedule tables (LinIf_ScheduleRequest)

It is assumed that the LinIf module will call the following callbacks:

- Confirming the Wake Up signals has been transmitted (LinSM_WakeupConfirmation)
- Confirming that the goto-sleep command has been transmitted (LinSM_GotoSleepConfirmation)
- Confirming a schedule change (LinSM_ScheduleRequestConfirmation)

[LINSM002] [The LinSM module shall not use or access the LIN driver or assume information about it any way other than what the LinIf module provides through the function calls to the LinIf module listed above.] ()

5.3 File structure

5.3.1 Code file structure

This chapter describes the c-files that implement the LinSM module Configuration. The code file structure is not defined completely within this specification. It is up to each implementer to design the missing structure details.

The pre compile and link time configuration parameters has to be kept in separate files:

[LINSM003] [A c-file LinSM_Lcfg.c shall exist and contain all link time configurable parameters] (BSW00344, BSW00380, BSW00412)

[LINSM078] [A c-file LinSM_Cfg.c shall exist and contain all pre compile parameters that are “const”.] (BSW00380, BSW00412, BSW00419)

5.3.2 Header File structure

This chapter describes the header files that will be included by the LinSM module and possible other modules.

5.3.2.1 LinSM header files

Following header files will exist in a LinSM implementation:

[LINSM005] [A LinSM implementation shall provide a header file LinSM.h that contains all data exported from the LinSM – API declarations (except callbacks), extern types, and global data.] ()

[LINSM006] [A LinSM implementation shall provide a header file LinSM_Cbk.h that contains function declarations for the callback functions in the LinSM.] (BSW00370)

[LINSM007] [A header file LinSM_Cfg.h shall exist that contains the pre compile time parameters.] (BSW00345, BSW00381)

[LINSM195] [The LinSM implementation shall include the header file SchM_LinSM.h] (BSW00435)

5.3.2.2 Included header files

Figure 3 shows the header file structure of the LinSM realization.




Figure 3 Header file structure

The LinSM implementation object in Figure 3 represent one or more .c files. It is not required to provide the complete implementation in one file.

Following external header files shall be included:

[LINSM011] [The LinSM module shall include the Dem.h file.] ()

[LINSM012] [The LinSM module shall include the LinIf.h file.] ()

[LINSM013] [The LinSM module shall include the ComM.h file] ()

[LINSM014] [The LinSM module shall include the MemMap.h file.] ()

[LINSM015] [The LinSM module shall include the Det.h file in case LinSMDevErrorDetect is enabled] ()

[LINSM016] [The LinSM module shall include the ComStack_Types.h] ()

[LINSM201] [The LinSM module shall include the BswM.h] ()

[LINSM208] [The LinSM module shall perform a consistency check between code files and header files based on pre-process-checking the version numbers of related code files and header files.] (BSW004)

[LINSM209] [The LinSM module shall perform inter module checks to avoid integration of incompatible files. The imported header files shall be checked by preprocessing directives. The following version numbers shall be verified:

- <MODULENAME>_AR_RELEASE_MAJOR_VERSION

- <MODULENAME>_AR_RELEASE_MINOR_VERSION

where <MODULENAME> is the module short name of the other (external) modules which provide header files included by the LinSM module. If the values are not identical to the expected values, an error shall be reported.] (BSW004)

6 Requirements traceability

This chapter contains a matrix that shows the link between the SWS requirements defined for the LinSM and the input requirement documents (SRS).

Requirement	Description	Satisfied by
BSW00321	These requirements are not applicable to this specification.	LINSM211
BSW00323	If the LinSMDevErrorDetect switch is enabled, API parameter checking is enabled.	LINSM055
BSW00327		LINSM053
BSW00331	These requirements are not applicable to this specification.	LINSM211
BSW00333	These requirements are not applicable to this specification.	LINSM211
BSW00334	These requirements are not applicable to this specification.	LINSM211
BSW00337		LINSM053
BSW00338	The detection of development errors is configurable (ON / OFF) at pre-compile time.	LINSM054
BSW00339	Production errors shall be reported to Diagnostic Event Manager (DEM) [8] module.	LINSM058
BSW00341	These requirements are not applicable to this specification.	LINSM211
BSW00343	These requirements are not applicable to this specification.	LINSM211
BSW00344	A c-file LinSM_Lcfg.	LINSM003
BSW00345	A header file LinSM_Cfg.	LINSM007
BSW00350		LINSM053
BSW00358		LINSM155
BSW00359	These requirements are not applicable to this specification.	LINSM211
BSW00360	These requirements are not applicable to this specification.	LINSM211
BSW00369		LINSM113, LINSM126, LINSM122,
BSW00370	A LinSM implementation shall provide a header file LinSM_Cbk.	LINSM006
BSW00373		LINSM156
BSW00375	These requirements are not applicable to this specification.	LINSM211
BSW00376		LINSM156
BSW00380	A c-file LinSM_Lcfg.	LINSM003, LINSM078
BSW00381	A header file LinSM_Cfg.	LINSM007

BSW00384	LIN Interface - LinIf	LINSM001, LINSM086, LINSM196	LINSM085, LINSM105,
BSW00385		LINSM053	
BSW00387	The LinSM_GotoSleepConfirmation shall be configurable.	LINSM199, LINSM198	
BSW00399	These requirements are not applicable to this specification.	LINSM211	
BSW004	The LinSM module shall perform a consistency check between code files and header files based on p...	LINSM208, LINSM209	
BSW00400	These requirements are not applicable to this specification.	LINSM211	
BSW00404	These requirements are not applicable to this specification.	LINSM211	
BSW00405	These requirements are not applicable to this specification.	LINSM211	
BSW00406	If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active then the error-code LINSM_...	LINSM116, LINSM128, LINSM131, LINSM134	LINSM125, LINSM179, LINSM137,
BSW00407		LINSM117	
BSW00409	Values for production code Event Ids are assigned externally by the configuration of the Dem [8],...	LINSM051	
BSW00411	This function shall be pre compile time configurable On/Off by the configuration parameter: LinSM...	LINSM121	
BSW00412	A c-file LinSM_Lcfg.	LINSM003, LINSM078	
BSW00414		LINSM155	
BSW00415	These requirements are not applicable to this specification.	LINSM211	
BSW00416	These requirements are not applicable to this specification.	LINSM211	
BSW00417	These requirements are not applicable to this specification.	LINSM211	
BSW00419	A c-file LinSM_Cfg.	LINSM078	
BSW00422	These requirements are not applicable to this specification.	LINSM211	
BSW00425	These requirements are not applicable to this specification.	LINSM211	
BSW00432	These requirements are not applicable to this specification.	LINSM211	
BSW00433	These requirements are not applicable to this specification.	LINSM211	
BSW00435	The LinSM implementation shall include the header file SchM_LinSM.	LINSM195	
BSW00436	These requirements are not applicable to this specification.	LINSM211	

BSW00437	These requirements are not applicable to this specification.	LINSM211
BSW00438	These requirements are not applicable to this specification.	LINSM211
BSW00439	These requirements are not applicable to this specification.	LINSM211
BSW00440	The LinSM_GotoSleepConfirmation shall be configurable.	LINSM199, LINSM198
BSW00442	Each variable that shall be accessible by AUTOSAR Debugging, shall be defined as global variable.	LINSM184, LINSM185, LINSM186, LINSM187, LINSM188, LINSM189
BSW00443	These requirements are not applicable to this specification.	LINSM211
BSW00444	These requirements are not applicable to this specification.	LINSM211
BSW00445	These requirements are not applicable to this specification.	LINSM211
BSW00446	These requirements are not applicable to this specification.	LINSM211
BSW005	These requirements are not applicable to this specification.	LINSM211
BSW010	These requirements are not applicable to this specification.	LINSM211
BSW01560	These requirements are not applicable to this specification.	LINSM211
BSW01577	These requirements are not applicable to this specification.	LINSM211
BSW01590	These requirements are not applicable to this specification.	LINSM211
BSW101		LINSM155
BSW161	These requirements are not applicable to this specification.	LINSM211
BSW162	These requirements are not applicable to this specification.	LINSM211
BSW167	Detected development errors will be reported to the Det_ReportError API of the Development Error ...	LINSM057
BSW168	These requirements are not applicable to this specification.	LINSM211
BSW170	These requirements are not applicable to this specification.	LINSM211
BSW171	The detection of development errors is configurable (ON / OFF) at pre-compile time.	LINSM054

7 Functional specification

This chapter specifies the requirements on the module LinSM module. See the Basic Software Modules document [2] for an overview of the responsibilities of the LinSM.

The main responsibilities for the LinSM are:

- Control the communication status (no communication or full communication) of all LIN networks
- Handle schedule change requests
- Handle communication mode requests
- Notify of state changes to upper layers

The LinSM module will not directly implement functionality in the LIN specification. The LinSM module will support the behavior of the master in the LIN 2.1 specification. The master behavior provided by the LinSM module will allow the reuse of existing slaves conforming to the LIN 1.2, 1.3, 2.0 and 2.1 specifications.

[LINSM019] [The LinSM module shall be able to handle one or more LIN networks.] ()

Number of LIN networks are restricted by the LinIf specification. All networks are handled via the NetworkHandle_Type specified by the ComM module.

The identification of the LIN networks is made using reference in the configuration to the ComM network handles.

7.1 States and transitions of the LinSM state machine

The LinSM module will operate in a state-machine. Each network connected will operate in an independent sub-state-machine. The State Machine is depicted in Figure 4 shows a simplified version of the requirements below, the intention of the figure is not to be complete, rather give an overview.

[LINSM020] [The LinSM module shall have one state-machine containing the states LINSM_UNINIT and LINSM_INIT.] ()

[LINSM173] [In the LINSM_INIT there shall be a sub-state-machine for each network with the states LINSM_NO_COM and LINSM_FULL_COM.] ()

[LINSM021] [In LINSM_INIT each network may be in the sub-states LINSM_NO_COM or LINSM_FULL_COM independently.] ()




Figure 4: LinSM State Machine

7.1.1 LINSM_UNINIT

The uninit state is the first state that is active in the LinSM module.

[LINSM022] [There shall be a state called LINSM_UNINIT] ()

[LINSM161] [The state LINSM_UNINIT shall be active at start-up, before any API is called.] ()

7.1.2 LINSM_INIT

After the initialization is made the LinSM module will activate the init state. There are two sub-states in this state. One is the no communication state where no communication is made on the LIN bus, the other is full communication where

schedule tables are active and all communication is made. Each network may be in no communication or full communication independent of each other.

[LINSM024] [There shall be a state called LINSM_INIT] ()

[LINSM025] [The LinSM state-machine shall transit from any state or sub-state to the state LINSM_INIT when LinSM_Init is called.] ()

[LINSM152] [The LinSM state-machine shall transit from any state or sub-state to sub-state LINSM_NO_COM for all networks when LinSM_Init is called.] ()

[LINSM043] [When entering LINSM_INIT the LinSM shall be put in an init state. Init state means that global variables, etc, shall be set to default value (reset value).] ()

[LINSM160] [The sub-state LINSM_NO_COM shall be active when entering the LINSM_INIT state, for all networks when LinSM_Init is called.] ()

[LINSM0216] [The LinSM_Init function shall set the schedule type NULL_SCHEDULE for each configured channel.] ()

To make the LinSM independent from the LinIf module the LinSM module should not call the LinIf module in when the LinSM module is in the init function. The LinSM_Init has therefore additional requirement, see 8.3.1.

7.1.3 LINSM_NO_COM

The no communication state is active after initialization and when the ComM module requests no communication.

[LINSM026] [There shall be a sub-state called LINSM_NO_COM in the state LINSM_INIT.] ()

[LINSM027] [When entering LINSM_NO_COM the LinSM module shall notify (with the exception **[LINSM166)** ComM of the state change by calling the ComM_BusSM_ModelIndication with the parameter COMM_NO_COMMUNICATION for the specific network.] ()

[LINSM193] [When entering LINSM_NO_COM the LinSM module shall notify (with the exception **[LINSM166)** BswM of the state change by calling the BswM_LinSM_CurrentState with the parameter LINSM_NO_COM for the specific network.] ()

There is one exception to the above two requirements. The rationale is that the ComM may not be initialized when executing the LinSM_Init function.

[LINSM166] [The LinSM module shall not notify the state change to LINSM_NO_COM when the LinSM is executing the LinSM_Init function, i.e. the LinSM_Init function shall neither call ComM_BusSM_ModelIndication nor BswM_LinSM_CurrentState.] ()

[LINSM028] [When LINSM_NO_COM is active, the LinSM module shall not command the LinIf module to communicate for the selected network, i.e. bus shall be silent.

Note: Upon entering or exiting the LINSM_NO_COM state the LinSM module will not set the hardware interface or μ -controller into a new power mode. This is not in the scope of the LinSM] ()

[LINSM203] [When entering LINSM_NO_COM the transceiver shall be set to STANDBY if LinSMTransceiverPassiveMode is true and SLEEP otherwise by using the LinIf_SetTrcvMode. This requirement is applicable only when LinSMTransceiverPassiveMode is configured for the channel.] ()

[LINSM204] [The LinIf_SetTrcvMode shall not be called from the function LinSM_Init.

Note: There is no need to set the mode in the LinSM init function since the Transceiver will set the mode in its init function. The mode is selected in the Transceiver configuration.] ()

7.1.4 LINSM_FULL_COM

The LINSM_FULL_COM is the only state where communication on the LIN bus is allowed. Each network can be in LINSM_FULL_COM independent of each other. All of the following requirements are applicable for each network.

[LINSM032] [There shall be a sub-state called LINSM_FULL_COM for each network in the state LINSM_INIT.] ()

[LINSM033] [When entering LINSM_FULL_COM the ComM shall be notified of the state change by calling the ComM_BusSM_ModelIndication with the parameter COMM_FULL_COMMUNICATION for the specified network.] ()

[LINSM192] [When entering LINSM_FULL_COM the BswM shall be notified of the state change by calling the BswM_LinSM_CurrentState with the parameter LINSM_FULL_COM for the specified network.] ()

[LINSM205] [When entering LINSM_FULL_COM the transceiver shall be set to active by using the LinIf_SetTrcvMode. This requirement is applicable only when LinSMTransceiverPassiveMode is configured for the channel.] ()

7.1.5 Goto sleep

The goto sleep the LinSM will request the goto-sleep command to be sent on the LIN bus, and after that set no communication mode and notify the BswM and ComM of the new state. The callback will always be made, even if there was a problem.

[LINSM035] [The LinSM module may only call LinIf_GotoSleep API in LinIf when the state LINSM_FULL_COM is active, E_NOT_OK is returned otherwise.] ()

[LINSM0208] [If the state is LINSM_FULL_COM, the LinSMSleepSupport is true and the ComM requests COMM_NO_COMMUNICATION; the LinSM shall call LinIf_GotoSleep to transmit a goto sleep command on the requested network.] ()

[LINSM0209] [In all other cases from **[LINSM0208]** the LinIf_GotoSleep shall not be called.] ()

[LINSM036] [If the ComM module calls LinSM_RequestComMode requesting COMM_NO_COMMUNICATION the LinSM module shall directly call (and not wait for next main function call) the LinIf module function LinIf_GotoSleep on the specified network.] ()

[LINSM177] [If the LinIf_GotoSleep returns E_NOT_OK the LinSM_RequestComMode shall return E_NOT_OK.

If the LinSM module returns LinSM_RequestComMode with E_NOT_OK, the same state shall be set (so that a ComM_BusSM_ModeIndication and BswM_LinSM_CurrentState are called).] ()

[LINSM044] [After the ComM module requests COMM_NO_COMMUNICATION, the LinSM module shall return E_NOT_OK for any requests for the same network until the LinIf notifies or request timer has elapsed.] ()

[LINSM045] [After the LinIf module notifies that the goto-sleep command was sent successfully (success = true) on the bus, the sub-state LINSM_NO_COM shall be set.] ()

[LINSM046] [The sub-state LINSM_FULL_COM for the specific network shall be set, after the LinIf module notifies that the goto-sleep command was NOT sent successfully (success = false) on the bus.] ()

This may happen since the goto-sleep command may fail on the bus.

7.1.6 Changing schedule table

[LINSM079] [If the function `LinSM_ScheduleRequest` is called, the `LinSM` module shall forward (and not wait for the next main function call) the request to the `LinIf` module using the function call `LinIf_ScheduleRequest`.] ()

[LINSM167] [If `LinIf_ScheduleRequest` returns with `E_OK` the `LinSM_ScheduleRequest` shall return with `E_OK`.] ()

[LINSM168] [If `LinIf_ScheduleRequest` returns with `E_NOT_OK` the `LinSM_ScheduleRequest` shall return with `E_NOT_OK`.

The caller of `LinSM_ScheduleRequest` will assume that `LinSM` module calls the callback:] ()

[LINSM0213] [If `LinIf_ScheduleRequest` returns with `E_NOT_OK` the `LinSM` module shall call `BswM_LinSM_CurrentSchedule` with the old schedule table in the next main function call.] ()

[LINSM206] [When the `LinSM` module gets the confirmation of setting a schedule table from the `LinIf` module the `BswM_LinSM_CurrentSchedule` shall be called, if not timer has elapsed.] ()

[LINSM0214] [If timer has elapsed, the `LinSM` module shall call `BswM_LinSM_CurrentSchedule` with unchanged schedule table.

Be aware of that the `LinIf` will switch to a `NULL` schedule when entering sleep, then it may make a schedule switch callback.] ()

[LINSM207] [If the `LinIf` confirms a schedule switch without a preceding call to request new schedule table the `BswM_LinSM_CurrentSchedule` shall be called] ()

7.1.7 Wake up process

A LIN network will be woken up if `ComM` module requests a wake up through the `LinSM_RequestComMode` call or if a LIN slave node transmits the wakeup signal on the network. The wakeup by cluster is not handled by the `LinSM` module, it is handled by the `EcuM` module and will lead to that the `ComM` requests the network. In both cases the `ComM` will request full communication to the `LinSM` module for the specific network.

In case the LinIf is already awake (because of a slave node waking up the bus) the LinIf will just ignore the wakeup call.

[LINSM047] [If the state is LINSM_NO_COM, the LinSMSleepSupport is true and the ComM requests COMM_FULL_COMMUNICATION; the LinSM shall call LinIf_Wakeup directly (and not wait for next main function call) to transmit a wake up signal on the requested network.] ()

[LINSM178] [In all other cases from **[LINSM047]** the LinSM module shall not call LinIf_Wakeup.] ()

[LINSM049] [When the LinIf notifies that the WakeUp is successfully sent (success = true), the state shall be set to LINSM_FULL_COM.] ()

[LINSM0202] [In all other cases from **[LINSM049]** the state shall be set same state as previous to the request (so that a mode indication callback is made to BswM and ComM).] ()

[LINSM176] [If the LinIf_Wakeup returns E_NOT_OK the LinSM_RequestComMode shall return E_NOT_OK directly with no further action] ()

7.1.8 Timeout of requests

After calling LinIf_GotoSleep, LinIf_Wakeup or LinIf_ScheduleRequest the LinSM module is waiting for the LinIf module to confirm the transmission of the goto sleep command, the wake up on the bus or schedule is changed. There is a possibility that the confirmation is not received, and therefore the LinSM module will wait forever. The only cause for this situation is problem in the software, i.e. no bus event or similar can cause this situation.

[LINSM175] [There shall be request timers for each network. One network shall be independent of another network.] ()

[LINSM162] [The handling (countdown and expiration) of the all request timers used by the LinSM module shall be made done in the LinSM_MainFunction.] ()

[LINSM159] [All request timers shall have a time that is a divisible by the LinSM_MainFunction (i.e. LinSM_MainFunction period * m; m integer >0)] ()

[LINSM100] [Before the LinSM calls the LinIf_GotoSleep, LinIf_Wakeup or LinIf_ScheduleRequest is called, the LinSM module shall start a timer.] ()

[LINSM101] [When a timer expires, i.e. greater than the configuration parameter LinSMConfirmationTimeout, a timeout occurs.] ()

[LINSM154] [If the LinIf module calls the confirmation callback before the timeout occurs, the active timer shall stop, so that the timeout will not occur.] ()

[LINSM102] [if LinSMDevErrorDetect is enabled: When a timeout occurs, the error code LINSM_E_CONFIRMATION_TIMEOUT shall be reported to the DET module.] ()

[LINSM170] [If request timer elapses (i.e. module LinIf is not notifying within the timeout), the LinSM module shall notify ComM module with same state.] ()

[LINSM0215] [If request timer elapses (i.e. module LinIf is not notifying within the timeout), the LinSM module shall notify BswM module with same state.] ()

Making the timeout optional enhances implementation size, if the timeout is not required:

[LINSM103] [If the configuration parameter LinSMConfirmationTimeout is set to zero the timer is not used, and hence a timeout cannot occur. This means that requirements **[LINSM102]**, **[LINSM170]** and **[LINSM0215]** will not happen.] ()

[LINSM172] [If LinIf module calls the confirmation callback after the timer has elapsed, no further notification shall be made to the ComM modules, i.e. the confirmation is ignored.] ()

7.2 Handling multiple networks and drivers

Usually only one LIN driver module (supporting multiple networks) is needed in an ECU to handle all LIN networks. However, rarely, some hardware configurations the ECU contain different LIN hardware (e.g. an advanced LIN controller and a UART). In such case, more than one different LIN drivers are required. This will not affect the LinSM module since the LIN driver only interfaces the LinIf module and not the LIN driver module directly.

The LinSM will only handle networks, and is not concerned to which driver the network maps to, this will be handled by the LinIf.

7.2.1 Multiple networks

Each network has a unique network index (LinSMComMNetworkHandleRef) in the LinSM configuration.

The configuration parameter `LinSMComMNetworkHandleRef` is referencing the ComM module configuration directly. This means that no mapping between networks has to be made in the LinSM module when interfacing to the LinIf module. The network index may be used directly to the LinIf module APIs.

[LINSM164] [The LinSM module shall use the same `NetworkHandle` value, received through an API, when interfacing to the LinIf module (when LIN network is required as a parameter).] ()

7.3 Error classification

This chapter lists and classifies errors that can be detected within this software module. Each error is classified according to relevance (development / production) and related error code. For development errors, a value is defined.

[LINSM051] [Values for production code Event Ids are assigned externally by the configuration of the Dem [8], they are published in the file `Dem_InitErrId.h` and included via `Dem.h`.] (BSW00409)

The `Dem.h` includes the APIs to report errors as well as the required Event Id symbols. The table below defines the name of the Event Id symbols that are provided by XML to the DEM configuration tool. The DEM configuration tool assigns ECU dependent values to the Event Id symbols and publishes the symbols in `Dem_IntErrId.h`.

[LINSM052] [Development error values are of type `uint8`.] ()

The Table 1 shows the available error codes (to DET and DEM) for the LinSM. The list of production errors is complete. The development errors consist of a minimum number of errors detected. It is possible for the implementer to extend the development errors.

[LINSM053] [

Type or error	Relevance	Related error code	Value [hex]
API called without initialization of LinSM	Development	LINSM_E_UNINIT	0x00
Referenced network does not exist (identification is out of range)	Development	LINSM_E_NONEXISTENT_NETWORK	0x20
API service called with wrong parameter	Development	LINSM_E_PARAMETER	0x30
API service called with invalid pointer	Development	LINSM_E_PARAMETER_POINTER	0x40
Timeout of the callbacks from LinIf	Development	LINSM_E_CONFIRMATION_TIMEOUT	0x50

Table 1 - Error codes for DET and DEM

] (BSW00337, BSW00385, BSW00327, BSW00350)

[LINSM200] [Additional errors that are detected because of specific implementation and/or specific hardware properties shall be added in the module's implementation documentation. The classification and enumeration shall be compatible to the errors listed above] ()

7.4 Error detection

[LINSM054] [The detection of development errors is configurable (*ON / OFF*) at pre-compile time. The switch *LinSMDevErrorDetect* (see chapter 10) shall activate or deactivate the detection of all development errors.] (BSW171, BSW00338)

[LINSM055] [If the *LinSMDevErrorDetect* switch is enabled, API parameter checking is enabled. The detailed description of the detected errors can be found in chapter 7.3 and chapter 8.] (BSW00323)

[LINSM056] [It shall not be possible to switch off detection and reporting of production code errors.] ()

7.5 Error notification

[LINSM057] [Detected development errors will be reported to the *Det_ReportError* API of the Development Error Tracer (DET) [5] module if the pre-processor switch *LinSMDevErrorDetect* is set (see paragraph 10).] (BSW167)

[LINSM058] [Production errors shall be reported to Diagnostic Event Manager (DEM) [8] module.] (BSW00339)

7.6 Debugging

To allow standardized debugging of the LinSM module, following requirements applies:

[LINSM184] [Each variable that shall be accessible by AUTOSAR Debugging, shall be defined as global variable.] (BSW00442)

[LINSM185] [All type definitions of variables which shall be debugged, shall be accessible by the header file *LinSM.h*.] (BSW00442)

[LINSM186] [The declaration of variables in the header file shall be such, that it is

possible to calculate the size of the variables by C-"sizeof".] (BSW00442)

[LINSM187] [Variables available for debugging shall be described in the respective Basic Software Module Description] (BSW00442)

[LINSM188] [The state of the state-machine (LINSM_UNINIT and LINSM_INIT) shall be accessible for debugging.] (BSW00442)

[LINSM189] [The state of the sub-state-machine (LINSM_NO_COM and LINSM_FULL_COM) shall be accessible for debugging.] (BSW00442)

8 API specification

8.1 Imported types

8.1.1 Standard types

In this chapter all types included from the following files are listed. The standard AUTOSAR types are defined in the AUTOSAR Specification of Standard Types document [4].

Following types are used by the LinSM module:

[LINSM0219] [

<i>Module</i>	<i>Imported Type</i>
ComM	ComM_ModeType
ComStack_Types	NetworkHandleType
LinIf	LinIf_SchHandleType
LinTrcv	LinTrcv_TrvcModeType
Std_Types	Std_ReturnType
	Std_VersionInfoType

] ()

8.2 Type definitions

Following types are defined by the LinSM module:

8.2.1 LinSM_ModeType

[LINSM0220] [

Name:	LinSM_ModeType		
Type:	uint8		
Range:	LINSM_FULL_COM	1	Full communication
	LINSM_NO_COM	2	No communication
Description:	Type used to report the current mode to the BswM		

] ()

8.2.2 LinSM_ConfigType

[LINSM0221] [

Name:	LinSM_ConfigType		
Type:	Structure		
Range:	implementation specific	--	

Service ID[hex]:	0x10	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant	
Parameters (in):	network	Identification of the LIN channel
	schedule	Pointer to the new Schedule table
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK - Schedule table request has been accepted. E_NOT_OK - Schedule table switch request has not been accepted due to one of the following reasons: * LinSM has not been initialized referenced channel does not exist (identification is out of range) * Referenced schedule table does not exist (identification is out of range) * Sub-state is not LINSM_FULL_COM
Description:	The upper layer requests a schedule table to be changed on one LIN network.	

] (BSW00369)

[LINSM114] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM115] [If LinSMDevErrorDetect is enabled: If the schedule parameter has an invalid value, then the error-code LINSM_E_PARAMETER shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM116] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active then the error-code LINSM_E_UNINIT shall be reported to the DET module and E_NOT_OK shall be returned.] (BSW00406)

[LINSM163] [If the function LinSM_ScheduleRequest is called and another request is in process on the same network, the LinSM_ScheduleRequest shall return directly with E_NOT_OK.] ()

[LINSM0211] [If the function LinSM_ScheduleRequest is called and the state is not LINSM_FULL_COM, the LinSM_ScheduleRequest shall return directly with E_NOT_OK.] ()

8.3.3 LinSM_GetVersionInfo

[LINSM117] [

Service name:	LinSM_GetVersionInfo	
Syntax:	void	LinSM_GetVersionInfo(Std_VersionInfoType* versioninfo)
Service ID[hex]:	0x02	
Sync/Async:	Synchronous	

Return value:	Std_ReturnType	E_OK - OK E_NOT_OK - Not possible to perform the request, e.g. not initialized.
Description:	Function to query the current communication mode.	

] (BSW00369)

[LINSM123] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value, then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM124] [If LinSMDevErrorDetect is enabled: If the mode pointer parameter is invalid (e.g. NULL), then the error-code LINSM_E_PARAMETER_POINTER shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM125] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active, then the error-code LINSM_E_UNINIT shall be reported to the DET module and E_NOT_OK shall be returned] (BSW00406)

[LINSM180] [If active state is LINSM_NO_COM the state COMM_NO_COMMUNICATION shall be returned.] ()

[LINSM181] [If active state is LINSM_FULL_COM the state COMM_FULL_COMMUNICATION shall be returned.] ()

[LINSM182] [If active state is LINSM_UNINIT the state COMM_NO_COMMUNICATION shall be returned. This is also captured above when the DET is enabled. This is to be defensive.] ()

Note that COMM_SILENT_COMMUNICATION is not used by the LinSM module.

8.3.5 LinSM_RequestComMode

[LINSM126] [

Service name:	LinSM_RequestComMode	
Syntax:	Std_ReturnType	LinSM_RequestComMode(NetworkHandleType network, ComM_ModeType mode)
Service ID[hex]:	0x12	
Sync/Async:	Asynchronous	
Reentrancy:	Reentrant	
Parameters (in):	network	Identification of the LIN channel
	mode	Request mode
Parameters (inout):	None	
Parameters (out):	None	
Return value:	Std_ReturnType	E_OK - Request accepted

		E_NOT_OK - Not possible to perform the request, e.g. not initialized.
Description:	Requesting of a communication mode.	
	The mode switch will not be made instant. The LinSM will notify the caller when mode transition is made.	

] (BSW00369)

[LINSM127] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value, then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM191] [If LinSMDevErrorDetect is enabled: If the mode parameter has an invalid value, then the error-code LINSM_E_PARAMETER shall be reported to the DET module and E_NOT_OK shall be returned.] ()

[LINSM128] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active, then the error-code LINSM_E_UNINIT shall be reported to the DET module and E_NOT_OK shall be returned.] (BSW00406)

[LINSM174] [If the function LinSM_RequestComMode is called and another request is in process on the same network, the LinSM_RequestComMode shall return directly with E_NOT_OK.] ()

[LINSM183] [If COMM_SILENT_COMMUNICATION is requested the function shall return E_NOT_OK directly without action] ()

[LINSM0210] [If the requested mode is the same as the current active mode, the function shall return E_NOT_OK directly without action.] ()

[LINSM0223] [LinSM_RequestComMode shall store the requested mode, if the return value is E_OK.

The next activation of the LinSM_MainFunction will then process this request when processing the state machine.

Note, that the state machine definition in section 7.1 refers to this stored request as reqComMode.] ()

8.4 Scheduled Functions

This chapter lists the functions that are called with a fixed period.

8.4.1 LinSM_MainFunction

This function is directly called by the Basic Software Scheduler module. The following function has no return value, no parameter and is non-reentrant.

There is no dependency to other main functions. This main function may be executed without considering other main functions. But scheduling the different main functions intelligent will minimize execution time and jitter.

[LINSM156] [

Service name:	LinSM_MainFunction
Syntax:	void LinSM_MainFunction(void)
Service ID[hex]:	0x30
Timing:	FIXED_CYCLIC
Description:	Periodic function that runs the timers of different request timeouts

Design hint: The function LinSM_MainFunction may be interrupted by other functions. It should be assured that the timers operated by this function are protected so that they behave correctly (e.g. by using critical sections if necessary).] (BSW00373, BSW00376)

[LINSM157] [The LinSM_MainFunction shall handle the timers that are attached to the functions LinIf_GotoSleep, LinIf_Wakeup or LinIf_ScheduleRequest (see paragraph 7.1.8)] ()

[LINSM179] [If LinSMDevErrorDetect is enabled: The function LinSM_MainFunction shall raise the error LINSM_E_UNINIT when the state LINSM_UNINIT is active.] (BSW00406)

8.5 LinSM callbacks

The function prototypes of the callback functions will be provided in the file LinSM_Cbk.h

8.5.1 LinSM_ScheduleRequestConfirmation

[LINSM129] [

Service name:	LinSM_ScheduleRequestConfirmation
Syntax:	void LinSM_ScheduleRequestConfirmation(NetworkHandleType network, LinIf_SchHandleType schedule)
Service ID[hex]:	0x20

Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	network	Identification of the LIN channel
	schedule	Pointer to the new active Schedule table
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	The LinIf module will call this callback when the new requested schedule table is active.	

] ()

[LINSM130] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value, then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module.] ()

[LINSM131] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active, then the error-code LINSM_E_UNINIT shall be reported to DET module and E_NOT_OK shall be returned.] (BSW00406)

8.5.2 LinSM_GotoSleepConfirmation

[LINSM135] [

Service name:	LinSM_GotoSleepConfirmation	
Syntax:	<pre>void LinSM_GotoSleepConfirmation(NetworkHandleType network, boolean success)</pre>	
Service ID[hex]:	0x22	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	network	Identification of the LIN channel
	success	True if goto sleep was successfully sent, false otherwise
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	The LinIf will call this callback when the go to sleep command is sent successfully or not sent successfully on the network.	

] ()

[LINSM136] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value, then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module.] ()

[LINSM137] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active, then the error-code LINSM_E_UNINIT shall be reported to the DET module.] (BSW00406)

[LINSM199] [The LinSM_GotoSleepConfirmation shall be configurable.]
(BSW00387, BSW00440)

8.5.3 LinSM_WakeupConfirmation

[LINSM132] [

Service name:	LinSM_WakeupConfirmation	
Syntax:	<pre>void LinSM_WakeupConfirmation(NetworkHandleType network, boolean success)</pre>	
Service ID[hex]:	0x21	
Sync/Async:	Synchronous	
Reentrancy:	Reentrant	
Parameters (in):	network	Identification of the LIN channel
	success	True if wakeup was successfully sent, false otherwise
Parameters (inout):	None	
Parameters (out):	None	
Return value:	None	
Description:	The LinIf will call this callback when the wake up signal command is sent not successfully/successfully on the network.	

] ()

[LINSM133] [If LinSMDevErrorDetect is enabled: If the network parameter has an invalid value, then the error-code LINSM_E_NONEXISTENT_NETWORK shall be reported to the DET module.] ()

[LINSM134] [If LinSMDevErrorDetect is enabled: If the state LINSM_UNINIT is active, then the error-code LINSM_E_UNINIT shall be reported to the DET module.]
(BSW00406)

[LINSM198] [The LinSM_WakeupConfirmation shall be configurable.] (BSW00387, BSW00440)

8.6 Mandatory Interfaces

This chapter defines all interfaces that are required to fulfill the core functionality.

API function	Description
BswM_LinSM_CurrentSchedule	Function called by LinSM to indicate the currently active schedule table for a specific LIN channel.
BswM_LinSM_CurrentState	Function called by LinSM to indicate its current state.
ComM_BusSM_ModeIndication	Indication of the actual bus mode by the corresponding Bus State Manager. ComM shall propagate the indicated state to the users with means of the RTE and BswM.
LinIf_ScheduleRequest	Requests a schedule table to be executed.

8.7 Optional Interfaces

This chapter defines all interfaces, which are required to fulfill an optional functionality of the module.

[LINSM138] [

<i>API function</i>	<i>Description</i>
Det_ReportError	Service to report development errors.
LinIf_GotoSleep	Initiates a transition into the Sleep Mode on the selected channel.
LinIf_SetTrcvMode	Set the given LIN transceiver to the given mode.
LinIf_Wakeup	Initiates the wake up process.

] ()

8.8 Configurable Interfaces

No configurable interfaces.

9 Sequence diagrams

This chapter will show use-cases for LIN communication and API usage. As the communication is in real-time it is not easy to show the real-time behavior in the UML dynamic diagrams. It is advisable to read the corresponding descriptive text to each UML diagram.

To show the behavior of the modules in the different use-cases, there are local function calls made to show what is done and when to get information. It is not mandatory to use these local functions; they are here just to make the use-cases more understandable.

Note that all parameters and return types are left out to make the diagrams easier to read and understand. If needed for clarification the parameter value or return value are shown.

9.1 Goto-sleep process

This use-case in shows the transition into the LINSM_GOTOSLEEP state when the goto-sleep command has been sent successfully on the bus.




Figure 5 - Goto-sleep-command process

9.2 Internal wake up

The Figure 6 shows the internal wakeup. A wakeup is requested from module above the LinSM.




Figure 6 - Internal wake up

9.3 Schedule switch




Figure 7 shows the use-cases of switching the schedule table when the LinSM accepts the request.




Figure 7: Schedule Table switch

10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers.

The chapter 10.3 specifies the structure (containers) and the parameters of the LinSM module.

10.1 How to read this chapter

In addition to this section, it is highly recommended to read the documents:
AUTOSAR Layered Software Architecture [2]
AUTOSAR ECU Configuration Specification [9] - This document describes the AUTOSAR configuration methodology and the AUTOSAR configuration meta-model in detail.

The following is only a short survey of the topic and it will not replace the ECU Configuration Specification document.

10.1.1 Configuration and configuration parameters

Configuration parameters define the variability of the generic part(s) of an implementation of a module. This means that only generic or configurable module implementation can be adapted to the environment (software/hardware) in use during system and/or ECU configuration.

The configuration of parameters can be achieved at different times during the software process: pre compile time, before link time or after build time. In the following, the term “configuration class” (of a parameter) shall be used in order to refer to a specific configuration point in time.

10.1.2 Containers

Containers structure the set of configuration parameters. This means:
All configuration parameters are kept in containers.
(sub-) containers can reference (sub-) containers. It is possible to assign a multiplicity to these references. The multiplicity then defines the possible number of instances of the contained parameters.

10.1.3 Specification template for configuration parameters

The following tables consist of three sections:

- the general section
- the configuration parameter section
- the section of included/referenced containers

- Pre-compile time - specifies whether the configuration parameter shall be of configuration class *Pre-compile time* or not

Label	Description
x	The configuration parameter shall be of configuration class <i>Pre-compile time</i> .
--	The configuration parameter shall never be of configuration class <i>Pre-compile time</i> .

Link time - specifies whether the configuration parameter shall be of configuration class *Link time* or not

Label	Description
x	The configuration parameter shall be of configuration class <i>Link time</i> .
--	The configuration parameter shall never be of configuration class <i>Link time</i> .

Post Build - specifies whether the configuration parameter shall be of configuration class *Post Build* or not

Label	Description
x	The configuration parameter shall be of configuration class <i>Post Build</i> and no specific implementation is required.
L	<i>Loadable</i> - the configuration parameter shall be of configuration class <i>Post Build</i> and only one configuration parameter set resides in the ECU.
M	<i>Multiple</i> - the configuration parameter shall be of configuration class <i>Post Build</i> and is selected out of a set of multiple parameters by passing a dedicated pointer to the init function of the module.
--	The configuration parameter shall never be of configuration class <i>Post Build</i> .

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe Chapters 7 and Chapter 8.

Example: The LinSM_Configuration is placed in a specific Flash sector. This flash sector may be reflashed after the ECU is placed in the vehicle.

10.2.1 Configuration Tool

A configuration tool will create a configuration structure that is understood by the LinSM.

[LINSM073] [The LinSM module shall not make any consistency check of the configuration in run-time in production software. It may, however, be done if the Development Error Detection is enabled.] (BSW167)

10.2.2 Variants

Following configuration variants are defined for the LinSM module.

10.2.2.1 VARIANT-PRE-COMPILE

In the the variant VARIANT-PRE-COMPILE all parameters below that are marked as Pre-compile configurable shall be configurable in a pre-compile manner, for example as #defines.

The module is most likely delivered as source code.

10.2.2.2 VARIANT-LINK-TIME

The variant VARIANT-LINK-TIME shall include all configuration options of the variant VARIANT-PRE-COMPILE. Additionally, all parameters that are marked as link-time configurable shall be configurable at link time. For example by linking a special configured parameter object file.

The module is most likely delivered as object code.

10.2.2.3 VARIANT-POST_BUILD

The variant VARIANT-POST-BUILD shall include all configuration options of the variant VARIANT-LINK-TIME. Additionally, all parameters that are marked as post-build configurable shall be configurable post build for example by flashing configuration data.

The module is most likely delivered as object code.

10.3 LinSM_Configuration

The paragraph defines the LinSM configuration.

10.3.1 LinSM

Module Name	<i>LinSM</i>
Module Description	Configuration of the Lin State Manager module.

Included Containers		
Container Name	Multiplicity	Scope / Dependency
LinSMConfigSet	1	This container describes one of multiple configuration sets of LinSm. This is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.
LinSMGeneral	1	This container contains general parameters of LIN State Manager module.

10.3.2 LinSMConfigSet

SWS Item	LINSM207_Conf :
Container Name	LinSMConfigSet{LinSM_ConfigSet} [Multi Config Container]

Description	This container describes one of multiple configuration sets of LinSm. This is a MultipleConfigurationContainer, i.e. this container and its sub-containers exist once per configuration set.
Configuration Parameters	

Included Containers		
Container Name	Multiplicity	Scope / Dependency
LinSMChannel	1..*	Describes each LIN channel the LinSM is connected to.

10.3.3 LinSMChannel

SWS Item	LINSM142_Conf :		
Container Name	LinSMChannel{LinSM_ChannelReference}		
Description	Describes each LIN channel the LinSM is connected to.		
Configuration Parameters			

SWS Item	LINSM144_Conf :		
Name	LinSMConfirmationTimeout {LINSM_CONFIRMATION_TIMEOUT}		
Description	Timeout in seconds for the goto sleep and wakeup calls to Linlf. The timeout must be longer than a goto-sleep command on the bus (i.e. it is bit rate dependent).		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	LINSM143_Conf :		
Name	LinSMSleepSupport {LINSM_SLEEP_SUPPORT}		
Description	Some LIN clusters does not need sleep, they will just shut off. This parameter will affect the behavior to achieve the no communication state.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	LINSM202_Conf :		
Name	LinSMTransceiverPassiveMode {LINSM_TRANSCEIVER_PASSIVE_MODE}		
Description	Selects STANDBY (true) or SLEEP (false) transceiver mode when entering LINSM_NO_COM.		
Multiplicity	0..1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-

			BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	LINSM145_Conf :		
Name	LinSMComMNetworkHandleRef		
Description	Unique handle to identify one certain LIN network. Reference to one of the network handles configured in the ComM.		
Multiplicity	1		
Type	Reference to [ComMChannel]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME, VARIANT-POST-BUILD
	Post-build time	--	
Scope / Dependency	scope: Module		

Included Containers		
Container Name	Multiplicity	Scope / Dependency
LinSMSchedule	1..*	The schedule references to a schedule that is located in the LinIf configuration. Moreover, the PDU groups are located in the COM configuration. Note that there are two references to PDU groups. The simple reason is that a PDU group is only allowed to contain one direction (TX or RX).

10.3.4 LinSMGeneral

SWS Item	LINSM139_Conf :		
Container Name	LinSMGeneral		
Description	This container contains general parameters of LIN State Manager module.		
Configuration Parameters			

SWS Item	LINSM206_Conf :		
Name	LinSMDevErrorDetect {LINSM_DEV_ERROR_DETECT}		
Description	Switches the Development Error Detection and Notification ON or OFF.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	LINSM141_Conf :		
Name	LinSMMainProcessingPeriod		
Description	Fixed period that the MainFunction shall be called.		
Multiplicity	1		
Type	EcucFloatParamDef		
Range	0 .. INF		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

SWS Item	LINSM140_Conf :		
Name	LinSMVersionInfoApi {LINSM_VERSION_INFO_API}		
Description	Switches the LinSM_GetVersionInfo function ON or OFF.		
Multiplicity	1		
Type	EcucBooleanParamDef		
Default value	--		
ConfigurationClass	Pre-compile time	X	All Variants
	Link time	--	
	Post-build time	--	
Scope / Dependency	scope: Module		

No Included Containers

10.3.5 LinSMSchedule

SWS Item	LINSM146_Conf :		
Container Name	LinSMSchedule{LinSM_Schedule}		
Description	The schedule references to a schedule that is located in the LinIf configuration. Moreover, the PDU groups are located in the COM configuration. Note that there are two references to PDU groups. The simple reason is that a PDU group is only allowed to contain one direction (TX or RX).		
Configuration Parameters			

SWS Item	LINSM001_Conf :		
Name	LinSMScheduleIndex		
Description	This index parameter can be used by the BswM as a SymbolicNameReference target. The LinSM just forwards the request from the BswM to LinIf. Note that the value of the LinSMScheduleIndex shall be the same as the value from the LinIf.		
Multiplicity	1		
Type	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 .. 255		
Default value	--		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

SWS Item	LINSM149_Conf :		
Name	LinSMScheduleIndexRef {LINSM_SCHEDULE_INDEX_REF}		
Description	Reference to a schedule table in the LinIf configuration		
Multiplicity	1		
Type	Reference to [LinIfScheduleTable]		
ConfigurationClass	Pre-compile time	X	VARIANT-PRE-COMPILE
	Link time	X	VARIANT-LINK-TIME
	Post-build time	X	VARIANT-POST-BUILD
Scope / Dependency	scope: Module		

No Included Containers

10.4 Published Information

[LINSM210] [The standardized common published parameters as required by BSW00402 in the General Requirements on Basic Software Modules [3] shall be published within the header file of this module and need to be provided in the BSW Module Description. The according module abbreviation can be found in the List of Basic Software Modules [1].] (BSW00402, BSW00374, BSW00379, BSW00318)

Additional module-specific published parameters are listed below if applicable.

11 Changes between Release 3.0/3.1 and 4.0

11.1 Deleted SWS Items

SWS Item	Rationale
LINSM089	PDU group switching is now made in BswM
LINSM080	PDU group switching is now made in BswM
LINSM081	PDU group switching is now made in BswM
LINSM017	Requirement changed to information
LINSM018	Requirement changed to information
LINSM083	The parameter checking have requirement already for each API
LINSM088	LinSM is no longer using COM
LINSM010	internal version check removed
LINSM194	internal version check removed
LINSM009	internal version check removed
LINSM042	Post-build configuration support

11.2 Changed SWS Items

SWS Item	Rationale
LINSM078	Post-build parameters removed
LINSM010	Updated to latest SRS general requirement BSW004
LINSM018	Included all relevant LIN spec versions
LINSM020	New state machine
LINSM043	Requirement moved
LINSM036	New state machine
LINSM044	New state machine
LINSM045	New state machine
LINSM046	New state machine
LINSM039	New state machine
LINSM040	New state machine
LINSM041	New state machine
LINSM042	New state machine
LINSM151	Requirement moved
LNSM155	Post-build configuration support

11.3 Added SWS Items

SWS Item	Rationale
LINSM161	-
LINSM160	-
LINSM163	-
LINSM159	-
LINSM162	-
LINSM164	-
LINSM165	-
LINSM156	-
LINSM157	-
LINSM158	-
LINSM190	-
LINSM191	-
LINSM192	-
LINSM193	-
LINSM194	-

LINSM195	-
LINSM196	-
LINSM197	-
LINSM198	-
LINSM199	-
LINSM200	-
LINSM201	-
LINSM202	New configuration item
LINSM203	-
LINSM204	-
LINSM205	-
LINSM210	Rework of Published Information
LINSM208	version check of included header files added
LINSM209	version check of included header files added
LINSM216	set NULL_SCHEDULE type in LinSM_Init
LINSM217, LINSM218, LINSM219, LINSM220, LINSM221	Post-build configuration support

12 Not applicable requirements

[LINSM211] [These requirements are not applicable to this specification.]
(BSW00404, BSW00405, BSW170, BSW00399, BSW00400, BSW00375,
BSW00416, BSW00437, BSW168, BSW00425, BSW00432, BSW00433,
BSW00422, BSW00417, BSW161, BSW162, BSW005, BSW00415, BSW00343,
BSW00436, BSW00439, BSW00359, BSW00360, BSW00331, BSW00443,
BSW00444, BSW00445, BSW00446, BSW010, BSW00333, BSW00321,
BSW00341, BSW00334, BSW01590, BSW01560, BSW01577, BSW00438)